

	Specification
• Working hour	Up to 12hour (continually working is 40min).
• Complete charging hour	2hour.
• Material	Outer: polar fleece 100%, Inner: ABS
• Duration of after service	After one-year from the date of purchase.

점핑볼(커버인형 + 본품), USB 충전케이블, 사용 설명서
 Jumping ball (doll of cover + main product), USB cable,
 User manual
 ジャンピングボール(カバーぬいぐるみ+本品)、USB充電ケーブル、
 取扱説明書



점핑볼(커버인형 + 본품)	USB충전케이블	사용 설명서
Jumping ball (doll of cover + main product)	USB cable	User manual
ジャンピングボール(カバーぬいぐるみ+本品)	USB充電ケーブル	取扱説明書

- Open the set of Bluetooth and turn on the application.
- Please press the power button until you hear "Normal Mode Power on"
- If you press the power button for 3 times continually and see "Waiting for connection" please press → **NORMAL BALL** → "connected"
- It works with → stop with
- Selected mode → **Game** → Press power button 3 times → Normal Mode (Bluetooth disconnected)
- The jumping ball will now operate in the set mode upon impact.
- After the playing, if you press the power button and hold on, you can hear "Power off" then the power will be off.
- ※If you turn off and on the power, the setting will be reset
- ※It could cause disconnection due to the Bluetooth connection error
- ※If you cannot search or connect with the device, please reset the setting

- There is sound "Normal Mode Power on" if you open the Velloro and press the power button for 3 seconds
- If you touch the main product, it will work for 5 minutes and the waiting mode will repeat for 90 minutes.
- If you touch the main product during the waiting mode, it will restart for 5 minutes.
- After playing, if you press the power button for 3 seconds then you can hear the sound "Power off" and it will be power off.

- There is a charging port inside of the stadium feature, next to the power button.
- If you can't find it, it is easy to find using pen or something by rolling.
- It will be easier to use USB charging cable to charge the battery.
- You can see the red LED light (processing charging → no LED light (completed charging))
- It takes approximately 2 hours to recharge.

- Due to the sounds of the toy and the automatic movement, your pets might need times to get used to get familiar.
- To get familiar, please turn off the power and put treats or catnip for cats in the pocket. Your pet can be familiar easier with nose activity.
- If your pets are used to use this toy, please turn the power on to interact with your pet.
- Please keep the charging cable away from your pet while charging the battery, the charge cable.
- If you separate the cover and the main product on the floor, it can be out of order.
- Cover can be washable however the main product is not waterproof
- If you place the power button near the velcro part, the hardness of the Velcro could turn the power off automatically. Please place the power button inside of the cover.

	Address	19, Yeonan-ro 58beonga-gil, Dongnae-gu, Busan, Republic of Korea.
	Customer service	070-5121-2780
	E-mail	cs@hamilpet.co.kr
	Web-site	www.hamilpet.co.kr

- ※**電源のON**を設定して⑦を実行して下さい。
- ※電源ボタンを長く押すと「Normal Mode Power On」音声が出たら電源が切れた状態です。
- ※電源ボタンを短続押し(Waiting For Connection)→アプリまで→**Normal Mode**→connected→アクセスが完了された状態です。
- ⑦ 押す→動作① 押すと止まります。
- ⑧ モード選択 → **Save** → 電源ボタンを短続押しで押す → 「Normal Mode」(Bluetooth™接続解除)
- ジャンピングボールに衝撃を与えると設定したモードで動作します。
- ※**切替が終わった後**、電源ボタンを長く押すと「Power off」音声が聞こえ電源が切り切れます。
- ※電源が切れてからしばらくは、Bluetooth™で設定したモードでONは初期化されます。
- ※Bluetooth™アクセス履歴エラーでアクセスできない現象が発生することがあります。
- ※機器故障でできないか、アクセスできない場合、設定を初期化した後、改めてみて下さい。

- ・ファスナーを開け、電源ボタンを「3秒」程度長く押すと、「Normal Mode Power On」の音声案内が出ます。
- ・手のひらで衝撃を与えると「5分動作後、90分間待機モード」が繰り返されます。
- ・待機モードで衝撃を加えると、再び5分間動作します。
- ・遊びが終わった後は電源ボタンを「3秒」程度押し、「Power Off」音声案内が出たら電源を切ることができます。

- 電源ボタンの横にある蓋(角が丸い四角形)の内側に充電端子があります。
- 見つけにくい場合、ペン等を利用して少しずつ回すと簡単に見つかります。
- USB充電ケーブルをつなげ、簡単に充電できます。
- 充電表示は赤いLED(充電中)→消灯(充電完了)で確認できます。
- 充電時間はおよそ2時間かかります。

- ・ノイズが発生した時、自動で鳴くため、ペットの性格や周りの環境により使用される時に制約が必要な場合があります。
- ・電源を切った状態で、ペットにおよやうとマハカをしならせず、使用を切ったとき突然使用したとあやうな探索行為をしながら使ってください。
- ・充電した電源をつけたままにしておくと、電池の寿命が短くなります。
- ・充電時、ケーブルがくっついていないようにペットの届かない場所に安全に充電してください。
- ・カバーを外し、本体を床において使用する場合、故障の原因となります。
- ・カバーが半で充電できず、本体には水がたまるようになっています。
- ・高湿度な場所やフラスナー付近に置き、使用する場合は、フラスナー部が湿らないよう、作業時に電源ボタンを押して使用する場合は発生する可能性がありますので、カバーの内側において使用してください。

HA:
HAMILPET
MIL

住所 19, Yeonan-ro 58beonga-gil, Dongnae-gu,
Busan, Republic of Korea.
お客様センター 070-5121-2780
E-mail cs@hamilpet.co.kr
ホームページ www.hamilpet.co.kr

- ▶ **헤드론 설정** → **②** 옵션 실행해주세요
- ▶ 저전력모드 설정하기 "Normal Mode Power On" 음성이나오면 전원키 커진상태로
- ▶ 전원이들고 3초 연속 눌러 "Waiting For Connection" → 여기서 **▶ Normal Mode** → **connected** → 연결완료된 상태입니다.
- ▶ 누르면 작동 → **▶** 누르면 멈춥니다.
- ▶ "Normal Mode" (블루투스 **▶ on**) → 전원을 켜고 연속 누르면 **▶** "Normal Mode" (블루투스 **▶ on**) → 점등모드 설정을 하면 설정한 모드로 작동합니다.
- ▶ 놀이가 끝나면 전원을 끈게 누르면 "Power off" 설정 안까지 나오며 연결이 꺼집니다.
- ▶ 전원을 켜기만 블루투스에서 설정해둔 모드는 켜집니다.
- ▶ 블루투스 연결이 안되면 연결이 안되는 현상이 발생하실 수 있습니다.
- ▶ 기기 강제리셋 안하셔요. 연결이 안되는 경우 설정을 초기화 후 재연결해 보시길 바랍니다.

- 벨크로(찍찍이)를 열어 전원버튼을 '3초' 정도 길게누르면 "Normal Mode Power On" 음성 안내가 나옵니다.
- 손바닥으로 충격을 주면 '5분' 작동 후 '90분' 대기[모드]가 반복됩니다.
- 대기[모드]에서 충격을 가하면 다시 '5분'간 작동합니다.
- 놀이나 끝난 후에는 전원버튼을 '3초' 정도 눌러 "Power Off" 음성 안내가 나오면 꺼집니다.

- 전원버튼 옆 스타디움 모양 (모서리에 둥근 사각형) 안쪽에 충전 단자가 있습니다.
- 찾기 어려울 경우 렌즈를 이용하여 살짝씩 돌리면 쉽게 찾게 될 수 있습니다.
- USB 충전 케이블을 연결하여 간편하게 충전할 수 있습니다.
- 충전 표시는 빨간 LED (충전 중) → 초승달 (충전 완료)로 확인할 수 있습니다.
- 충전 시간은 대략 2시간 소요됩니다.

[illegible]

Part 15 statements

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.