

型号: DP-2613 说明书
成品尺寸：70*105MM
材质: 157克纸
要求: 双面印刷.中间折叠.风琴折
颜色:彩色

PORTABLE SPEAKER
DP-2613

User Manual

Thank you for purchasing DIPAOER product. Hope you will have fun using it! Please read this User Manual thoroughly before using, and keep it properly.

PORTABLE SPEAKER
DP-2613

01 ENGLISH

SPECIFICATIONS

Product Specs

6.5"x2

PM,PO

8000W

Product Features

BT/USB/TF/AUX/Microphone Input

Product Accessories

AC Power Cordx1/ Wireless Mixx2/ Remote Controlx1/User Manualx1

Voltage Specifications

AC110-240V

Color

Black

Product Dimensions

290X290X570MM

Package Dimensions

330X330x635MM

QTY

1PC

G.W.

6.9kg

N.W.

5.6kg

02 ENGLISH

PORTABLE SPEAKER
DP-2613

CONTROL PANEL

1. MIC.VOL: Microphone volume

2.BASS: Bass volume knob

3. TRE: Treble volume knob

4. MUSIC.VOL: Volume adjustment

5. LED SW: Light mode switching

6. EQ: EQ Indoor and Outdoor Scene Mode

7. TWS: Bluetooth connectivity

8. REC: Recording function/Long press to play recording

9. ⏮: Previous song

10. ⏪: Play song/ pause playback

11. ⏭: Next song

12.MODE: Mode Selection

13.LED electronic display

14.POWER: power switch

15.DC 9V: DC 9V power input

16.CHARGE: Power indicator light

17.AUX: Audio input

18.USB: USB slot

19.MIC1/2: Microphone 1/2 input port

20. TF: TF card playback

21.AC INPUT: 110V-240V 50/60Hz

03 ENGLISH

PORTABLE SPEAKER
DP-2613

REMOTE CONTROL

1.MUTE:Press to mute audio output, and press again to resume

2.↔:Press this button to toggle between the various inputs(AUX,USB,TF,FM,BT).

3.REC:Press this button to start recording.

4.VOL+:Press this button to increase the master volume for the unit.

5.▶|:Press to start playing/pause, in FM mode, press to tune with jumps of 0.1 MHz

6.◀:Press this button to select the previous song/ channel.

7.VOL-:Press this button to reduce the master volume for the unit.

8.⏮:Press this button to repeat one/ repeat all.

9.REC PLAY:Press this button to play the recording or exit recording function

10.⏭:Press this button to select the next song/ channel.

11.EQ:Press this button to the EQ mode of Flat, Jazz, Rock, Pop, Classical.

12.Numeric keys:0-9. Key number for sele cting certain songs in the USB/TF Card.MODE

04 ENGLISH

PORTABLE SPEAKER
DP-2613

SAFETY INFORMATION

1. Store the loudspeaker away from humid areas, high temperature, oil and other liquids.

2. Do not expose the product to direct sunlight and rain.

3. Set a suitable volume to avoid hearing impairment.

4. If you do not use the product for a long time, charge it at least once per three months in order to avoid damage to lithium battery.

5. It is forbidden to disassemble, repair or open the product.

6. Keep out of the reach of children to avoid electric shock or suffocation.

NOTE

1. After the first connect successfully, two devices will matched connected automatically when the karaoke speaker Bluetooth function is turned on.

2. If the speaker cannot play sounds after connecting with the phone successfully first, please check the volume of the machine or the volume on the source is off. Second, please restart the phone and the speaker.

3.The TF card and the USB device only can be inserted in accordance with the card slot, do not force, or it could be damaged.

4. The speaker only supports to play with files which are AT/FAT 32, insert the TF card max is 32GB.

5. If the music formats cannot be changed to a compatible format would not able to play via the speaker. The default is MP3 format.

6. Turn off the speaker before removing the TF card, or it could be damaged

7. The USB working mode will not be available if you don't have inserted an TF or USB to the speaker. The USB mode only supports one device at a time. If you want to work with a USB, please remove the TF card first.

8. Suggest charger the speaker once every 3 months if you don't use the Speaker for a long time, to avoid the internal rechargeable battery failure.

05 ENGLISH

PORTABLE SPEAKER
DP-2613

CHARGE THE BATTERY

1. Connect the AC power cord to the AC jack of the speaker firmly, and plug it into a wall outlet.

2. When the battery is fully charged, first disconnect the AC power cord from the speaker, then from wall outlet.

3. Do not use speaker when charging.

AUDIO INPUT JACK

1. Connect an audio cable(not included) to the AUDIO INPUT jack of the speaker and to the audio output socket on the external audio devices such as MP3 player, disman etc, then select line by pressing the mode button on the front panel

2. Play from an external audio device

WIRELESS CONNECTION

Please press MODE button on control panel to select Wireless BT connection mode.Simultaneously open the Wireless BT connection setting on your phone, tablet or any other Wireless BT connection enabled audio device and select (no need to match code), the unit and device will then connected via Wireless BT connection. Press the NEXT song and PREV song button on the control panel to select the song, or press PLAY/PAUSE button to control the playing status

06 ENGLISH

英文版面

ALTAVOZ PORTÁTIL
DP-2613

MANUAL DE USUARIO

Gracias por adquirir el producto DIPAOER. Esperamos que disfrute usándolo. Lea detenidamente este Manual de Usuario antes de usarlo y guárdelo correctamente.

ALTAVOZ PORTÁTIL
DP-2613

01 ESPAÑA

ESPECIFICACIONES

Especificaciones del Producto

6.5"x2

PM,PO

8000W

Características del Producto

Entrada de BT/USB/TF/AUX/Micrófono

Accesorios del Producto

Cable de Alimentación ACx1/ Micrófono Inalámbricox2/ Mando a Distanciax1

Especificaciones de Voltaje

AC110-240V

Color

Black

Dimensiones del Producto

290X290X570MM

Dimensiones del Paquete

330X330x635MM

CANTIDAD (QTY)

1PC

Peso Bruto (G.W.)

6.9kg

Peso Neto (N.W.)

5.6kg

02 ESPAÑA

ALTAVOZ PORTÁTIL
DP-2613

PANEL DE CONTROL

1. MIC.VOL: Volumen del micrófono

2.BASS: botón de volumen de bajo

3. TRE:botón de volumen agudo

4. MUSIC.VOL: Ajuste de volumen

5. LED SW: Conmutación del modo de luz

6. EQ: EQ Modo de escena interior y exterior

7. TWS: Conectividad Bluetooth

8. REC: Función de grabación / presión larga para reproducir la grabación

9. ⏮: Canción anterior

10. ⏪: Reproducir canción/ pausar la reproducción

11. ⏭: Siguiete canción

12.MODE: Selección del modo

13.Pantalla electrónica led

14.POWER: interruptor de alimentación

15.DC 9V: Entrada de potencia DC 9V

16.CHARGE: Luz indicadora de potencia

17.AUX: Entrada de audio

18.USB: Ranura USB

19.MIC1/2: Micrófono 1/2 puerto de entrada

20. TF: Reproducción de tarjetas TF

21.AC INPUT: 110V-240V 50/60Hz

03 ESPAÑA

ALTAVOZ PORTÁTIL
DP-2613

REMOTE CONTROL

1.MUTE:Pulse para silenciar la salida de audio y pulse nuevamente para reanudarla

2.↔:Pulse este botón para alternar entre las diversas entradas (AUX, USB, TF, FM, BT)

3.REC:Pulse este botón para iniciar la grabación

4.VOL+:Pulse este botón para aumentar el volumen principal del dispositivo

5.▶|:Pulse para iniciar la reproducción/ pausa. En modo FM, pulse para sintonizar con saltos de 0,1 MHz

6.◀:Pulse este botón para seleccionar la canción/emisora anterior

7.VOL-:Pulse este botón para reducir el volumen principal del dispositivo

8.⏮:Pulse este botón para activar la repetición de una canción/todas las canciones

9.REC PLAY:Pulse este botón para reproducir la grabación o salir de la función de grabación

10.⏭:Pulse este botón para seleccionar la canción/emisora siguiente

11.EQ:Pulse este botón para cambiar el modo EQ entre Normal, Jazz, Rock, Pop y Clásico

12.Teclas numéricas:0-9, teclas para seleccionar canciones específicas en USB/tarjeta TF

04 ESPAÑA

ALTAVOZ PORTÁTIL
DP-2613

INFORMACIÓN DE SEGURIDAD

1. Guarde el altavoz lejos de zonas húmedas, altas temperaturas, aceite y otros líquidos.

2. No exponga el producto a la luz solar directa y la lluvia.

3. Establezca un volumen adecuado para evitar deterioro auditivo.

4. Si no usa el producto por mucho tiempo, cárguelo al menos una vez cada tres meses para evitar daños en la batería de litio.

5. Está prohibido desmontar, reparar o abrir el producto.

6. Manténgalo fuera del alcance de los niños para evitar descargas eléctricas o asfixia.

NOTE

1. Después de la primera conexión exitosa, dos dispositivos se conectarán automáticamente cuando se active la función Bluetooth del altavoz de karaoke.

2. Si el altavoz no puede reproducir sonidos después de conectarse exitosamente con el teléfono. Primero, verifique si el volumen de la máquina o el volumen de la fuente está apagado. En segundo lugar, reinicie el teléfono y el altavoz.

3. La tarjeta TF y el dispositivo USB solo se pueden insertar de acuerdo con la ranura de la tarjeta, no fuerce, ya que podría dañarse.

4. El altavoz solo admite la reproducción de archivos que sean AT/FAT 32, la tarjeta TF insertada tiene un máximo de 32GB.

5. Si los formatos de música no se pueden cambiar a un formato compatible, no podrán reproducirse a través del altavoz. El formato predeterminado es Mp3.

6. Apague el altavoz antes de extraer la tarjeta TF, ya que podría dañarse.

7. El modo de funcionamiento USB no estará disponible si no ha insertado una tarjeta TF o un dispositivo USB en el altavoz. El modo USB solo admite un dispositivo a la vez, si desea trabajar con un USB, retire primero la tarjeta TF.

8. Se sugiere cargar el altavoz una vez cada 3 meses si no usa el altavoz por mucho tiempo, para evitar el fallo de la batería recargable interna.

05 ESPAÑA

ALTAVOZ PORTÁTIL
DP-2613

CARGAR LA BATERÍA

1. Conecte el cable de alimentación AC firmemente al jack AC del altavoz y enchúle a una toma de corriente de la pared.

2. Cuando la batería esté completamente cargada, primero desconecte el cable de alimentación AC del altavoz, luego de la toma de corriente de la pared.

3. No use el altavoz mientras está cargando.

JACK DE ENTRADA DE AUDIO

1. Conecte un cable de audio (no incluido) al jack de ENTRADA DE AUDIO del altavoz y al socket de salida de audio de dispositivos de audio externos como reproductores MP3, etc., luego seleccione la línea presionando el botón de modo en el panel frontal.

2. Reproduzca desde un dispositivo de audio externo.

CONEXIÓN INALÁMBRICA

Presione el botón MODE en el panel de control para seleccionar el modo de conexión BT Inalámbrica. Al mismo tiempo, abra la configuración de conexión BT Inalámbrica en su teléfono, tableta u otro dispositivo de audio con conexión BT Inalámbrica habilitada y seleccione (no es necesario coincidir el código); la unidad y el dispositivo se conectarán luego a través de la conexión BT Inalámbrica. Presione los botones de CANCIÓN SIGUIENTE y CANCIÓN ANTERIOR en el panel de control para seleccionar la canción, o presione el botón REPRODUCCIÓN/PAUSA para controlar el estado de reproducción.

06 ESPAÑA

西班牙文版面

FCC Warning:

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.