P60

用户手册

PHOT

重要声明和安全指引

欢迎您选购本公司产品，为了让您更放心，为更好使用此台无人机，请您详细阅读本说明书之后再操作，同时建议重新保存此说明书，作为以后需要时的资料参考。

重要声明

- 客户端不具有此类，则直接将其删，电子，空气力学，高频技术智等非金融证据也为一块加强型设备，需要您根据当时的已产品型号来选择。出产品所有人必须要保证您的已完全操作的，操作不当，可能引起产品的人身伤害或财产损失。
- 本产品不适合儿童使用，请勿将本产品放置在儿童可接触的人群。
- 请遵守法、规则，避免影响他人，请勿当做违法和扰乱其他人员使用，视觉和体验将对其使用构成障碍不得用于结构的非现场和对相关以及人体的危害不负任何责任。
- 产品设有小零件，请将其置于幼子或残疾人的地方，以免发生误食或发生危险。

安全注意事项

温馨提醒您无人机是最高危险性物品，飞行时务必谨慎人群，人为或是不当或初级错误，电子控制不当，以及操作不熟悉，都有可能导致无人机发生损坏甚至人身伤害等不可抗拒的意外，请操作飞行前务必仔细“飞行安全”，必须了解所有的注意点各种内容等。

- 近离场特性无人机
  - 当您无人机飞行时请务必保证您飞行的安全和对您，作出您的自我负责。飞行时必须选择人群、高层建筑、高压电场等，同时避免风雨，雷电等恶劣天气下飞行，调试安装无人机必须严格按照操作说明书上指南，注意无人机飞行环节需要确实按无人指挥——未来的实现。避免无人机飞行，同等时期内人员永恶，如您和身体等，引起损害。
- 飞行前检查
  - 无人机内部连接件非常精密和电子元件和机械零件组成，对此，必须防止无人机里面进水气压机体，以免机械，电子元件短路等引起意外，维护保养时请将飞行器处于静止状态和关闭电源状态。
- 使用须知
  - 当您无人机调试飞行参与无线电是一定的体验，要开展避免操作操作飞行，禁有给他和人员造成伤害。
- 安全使用产品
  - 请使用者必须要按照进行完整或者维修，以保障飞行的安全，请在产品加装支持的范围内进行维修和检查，且并保障下安全注意安全的使用安全和设备。
- 安全操作
  - 无人机飞行的操作或在关飞行过程，操作温度无人机，避免，维修不得或操作不当，将会增加使用的危险。
  - 飞行重量过高或者低时 保持可能导致飞行状态。
- 注意高温部件的
  - 当无人机或其他连接部件，请飞行后，周围人员和物体或高温接触部件，以免造成危险发生。
- 维修
  - 维修完成
  - 请您无人机是连接属，拆除，摆线，电子元件等材料组成，请此要尽量或高热源，防止日晒，避免高温引起变形，甚至损坏。
- 特殊要求
  - 根据您不同产品，可能会对环境造成危害物，请按当地法律法规要求妥善回收处理。

P60系列飞行教程视频

扫码观看教学视频

⚠ 新手注意事项

- 新手飞行前请查上无人机保护盖。
- 若飞前将无人机摄像头被损（更显易损识方向）。
- 为了避免发生初次无人机，防手飞行前需调控指在5米以内。
- 请在空旷且无高建筑环境下飞行。
- 复杂或低层对象应尽量避免或者无人机。
- 有无人机其建筑物附近的天干扰的电子导航有关，比如：金属物之无人机屋顶或水气层入机体，以免机电，电子元件短路等引起意外，维护保养时请将飞行器处于静止状态和关闭电源状态。
- 使用须知
  - 当您无人机调试飞行参与无线电是一定的体验，要开展避免操作操作飞行，禁有给他和人员造成伤害。
- 安全使用产品
  - 请使用者必须要按照进行完整或者维修，以保障飞行的安全，请在产品加装支持的范围内进行维修和检查，且并保障下安全注意安全的使用安全和设备。
- 安全操作
  - 无人机飞行的操作或在关飞行过程，操作温度无人机，避免，维修不得或操作不当，将会增加使用的危险。
  - 飞行重量过高或者低时 保持可能导致飞行状态。
- 注意高温部件的
  - 当无人机或其他连接部件，请飞行后，周围人员和物体或高温接触部件，以免造成危险发生。
- 维修
  - 维修完成
  - 请您无人机是连接属，拆除，摆线，电子元件等材料组成，请此要尽量或高热源，防止日晒，避免高温引起变形，甚至损坏。
- 特殊要求
  - 根据您不同产品，可能会对环境造成危害物，请按当地法律法规要求妥善回收处理。

⚠ 禁止说明

为保证您安全用电台（站）电磁环境的要求，禁止在以低地面道中心向两侧各10公里，建建周围场合公室范围内以及远离地区，机场，铁路沿线等设施设备，无人机。在国家机关部门发布无线电管制命令的期间，区域内，应按要求停止使用微型遥控器、无人机。

飞行器部件名称

遥控器按键功能介绍（P40 Plus系列 /P40 Pro系列）



充飞行器电池充电

从无人机取下电池，将电池连接充电线，充电线连接USB充电口(不可使用快充)，即可充电。充电线上的LED指示灯，在充电时变成红色长亮，充满电后熄灭。

为遥控器安装电池

适用电池：1.5V AA电池 X3 （另购）

注意事项

- 新型充电池型电机，不要把电池长期使用，必须在无人机不飞行，充电时必须连接充电，充电时请护人请不要离开现场按照说明使用。
- 禁不要短路，防压包含，以免发生爆炸。
- 电源要电池不应头和充中电池，请电池不应短路，交流和电池短路，分解或投入火中；切勿将电池放在高温，受热的地方(如火中或电热器附近)
- 模型只能使用推荐的充电器，正确检查充电器的电瓶，错头外壳和其他部件是否损坏，发现损坏后应停止使用，直至修复完好；
- 充电器不能长离，充电器只能在室内使用；
- 飞行后的电池发生充电保护后，如不使用，请关闭飞行开关以防止电池发电一次，以及电池正常充电与无人机的损坏电池

对声音录音

1.将要录制的无人机远离对应机网上相对的位置更换，同时A型安装在A的位置上，同时B型安装在B的位置上，安便使用时增强相关连接把。
2.飞行时其护从器的时方向前选，找护到设置时方向前选。

避障功能介绍(部分需买避障模块后可开启)

无人机飞行过程中，智能监测上识别障碍并发现障碍时将自动刹车悬停，并自动无人机灯光提示，当无人机飞行方向遇到障碍物时，无人机自动启动前后左右避障，并实现3维灯光，同时监测前后左右避障是否开启，此时无人机无法继续往该方向飞行。（同光时避免障碍物）

连接遥控器

1.将电池装正确方向装入飞行器电池舱，将飞行器就至水平地面，长按开关约3秒，飞行器灯光闪烁表示开机成功。
2.打开遥控器开关，遥控器发出蜂鸣声后，无人机灯光头部通闪烁变为常亮，连接成功。

⚠ ● 连接前请先飞行器开机状态，避免操作同一时间，连接后请检查飞行器是否连接成功，再开始飞行。

视觉位置调

无人机飞行器视觉系统后，视觉一键校准模版，无人机底部自行快速调整，如遇位置自动调整，或自行自动调整为常规状态，请及时调整。

⚠ ● 请在调整前检查附，确认附近环境良好下进行，否则会影响飞行。

基础飞行

飞行前检查：
1.请检查，飞行器电池是否电量充足。
2.请问是否正确安装。
3.开机解锁后电机是否正常转动。

基础飞行步骤：
1.连接遥控飞行器对机。
2.请检查飞行器是否已经解锁。
3.请开机确认状态。

起飞方式 ①（推荐使用）：

如①一键起飞按键，无人机自动起飞到约1.5米。

起飞方式②：

将油门摇杆推至左下角45°，同时在程序指定左下角45°，解锁飞行器，解锁后，将左摇杆向上推，即可起飞，（如下图1，图2所示）

图1 图2

飞行控制方法

摄像头运检调节

360°翻转：

无人机可翻以正常的高度，按下油门摇杆按钮，将右摇杆往任意方向推动，无人机即可完成空中特技翻滚。

速度调节：

无人机初始认是低速，按下油摇杆按钮一次，切换为中速（遥控器将响两声），再次按下油摇杆按钮一次，切换为高速（遥控器将响两三声），再次按下，切换为低速（遥控器响一声）。

注意：首次使用时请将无人机放置在三位飞行位置

常见故障解决

序号	问题	解决方法
01	飞行器起飞后，不能悬停，自动飘移到别处	附飞行器处于开阔或水平地面上，重新进行校准校准。
02	飞行器看起来很笨重	风叶变形，需更换风叶
03	飞行器无法起飞	遥控器电飞行器电池电压太低，请将电池充满电。
04	火风平飞行器飞行不稳	排无风或是风风飞行
05	无人机云有特点	确保无人机无异动并机遇应
06	无人机只能单机遇应	无人机之前遇到新增加； 无人机=遇应单机遇应
07	开启摄像模式后，遥遇遇慢	遇增模式下无人机是自动调低遇度 因为遇增模式=低性能飞行控制



P60

instruction manual

PHOT

Important Notices and Safety Guidelines

You are welcome to buy our products, in order to make it easier and more convenient for you to use this drone, please read this manual in detail Do it later, and please keep this manual properly as an important reference for future acquirements and maintenance.

DISCLAIMER

- This product is not a toy, but a precision flight integrates professional knowledge such as machinery, electronics, aerodynamics, and high-frequency remote It should be assembled and debugged correctly to avoid accidents, damage to the product and even personal injury caused by remote control. Improper operation may cause serious personal injury or property damage.
- This product is suitable for people who have experience in operating model drones and are at least 14 years old.
- Please do not use this product near children or in areas where children are active. Children under the supervision of an adult are not responsible for any loss and damage caused by improper use or operation, as well as personal injury.
- Product contains small parts. Keep out of the reach of children to avoid eating or suffocation.

SAFETY PRECAUTIONS

Safe and pre-control usage is the most dangerous product, we want to fly/do away from the crowd, Because the drone is a high-risk product, improper operation or low-level mistakes may cause serious personal accidents such as damage to the drone or personal injury Please pay attention to flight safety, and you must understand the responsibility for accidents caused by your own negligence.

- AWAY FROM OBSTACLES AND CROWDS
  - Our remote control has flying speed and flight status uncertain, there is a potential danger. Stay away from crowds, high-rise buildings, power lines, etc. when flying, while avoiding flying in the wind and rain, which may affect the control system of the aircraft, causing the aircraft to lose control or crash, thus causing injury and property damage. Avoid flying near airports, power lines, and other places to avoid unnecessary losses due to interference with normal flights.
- AWAY FROM HEAT SOURCES AND EQUIPMENT
  - The internal of Lithi is composed of many electronic components and precision mechanical parts, it is necessary to prevent moisture or water vapor into the Lithi in order to avoid mechanical problems, electronic components, and even short circuits. Please wipe the vehicle clean with a clean cloth during maintenance.
- NO BRAKE/CLUTCH
  - The experimental Lithi are learning some drivers difficulty. Try to operate the flight by yourself, you need longer time and more practice guidance.
- PROHIBITED TO MODIFY
  - Do not disassemble or modify the product for modification or maintenance by anyone Build safety. Follow the instructions and rules of the product within the range permitted by function and not be used for illegal purposes other than the scope of the device.
- KEEP AWAY FROM PROPELLERS
  - 1. Please operate the remote control drone according to your own status and flying skills, fatigue, poor spirits or improper operation will increase the probability of accident risk.
  - 2. Do not use it When Under The Influence Of Drugs Or Alcohol.
- KEEP AWAY FROM SMALL AND LOOSE OBJECTS
  - Before each flight, check the propeller, motor, and fuselage, please keep the pilot, surrounding people and objects away from the rotating parts to avoid danger and damage.
- KEEP AWAY FROM HEAT
  - Please do not expose the components of metal, fiber, plastic, electronic components and other materials, Therefore, it is necessary to keep away from heat sources, prevent fire, sun, and avoid deformation or even damage due to high temperature.
- ENVIRONMENTAL PROTECTION
  - When getting the product will may cause environmental impact, please recycle it properly in accordance with local laws and regulations.

P60 FLIGHT TUTORIAL VIDEO

Scan the code to watch the instructional video

⚠ Notes for novices

- Please install the drone protective cover before flying.
- Please take off the drone in a relatively open environment with no wind or breeze.
- Please thoroughly inspect the drone after crashing or violent impact.
- Store the drone and remote control in a cool and dry place, away from direct sunlight.
- Avoid direct contact with water or other liquids. If there is any contact, wipe it dry immediately with an absorbent cloth.

⚠ PROHIBIT DESCRIPTION

To ensure aviation safe (station) electromagnetic environmental requirements, it is prohibited to use all kinds of model remote controls and drones within 10 km on each side of the center line of the airport runway and 20 km on each end of the runway, as well as civil aviation routes and air routes . During the national authorities issued radio control commands in the region, it should be requested to stop using the remote control model, drones.

AIRCRAFT PART NAME



REMOTE CONTROL FUNCTION



CHARGE AIRCRAFT BATTERY

Remove the battery from the drone, connect the battery to the charging cable, and connect the charging cable to the USB charging port (fast charging is not allowed), and it can be charged. The LED indicator on the charging cable will turn red when charging and will go out when fully charged.

INSTALL THE BATTERY

APPLICABLE BATTERY:
1.5V AA battery X3
(available separately)

⚠ PRECAUTIONS

Obstacle avoidance （Available after purchasing modules）

During the flight of take, once it sees the obstacle avoidance switch on the remote control, to turn on the obstacle avoidance function, after turning on, the UAV light flashes slowly. When the UAV encounters an obstacle in the flight direction, the UAV will brake and hover, and the UAV lights will flash quickly to remind the obstacle in the direction. At this time, the UAV cannot continue to fly in this direction. The remote control will give a beep warning sound. At this time, the UAV cannot continue to fly in this direction.
(Please use it in an environment with GPS signal)(Be careful during strong winds)

Connect the remote control

1. Put the battery into the aircraft battery slot in the correct direction, place the aircraft on the horizontal ground, press and hold the switch for about 3 seconds, and the aircraft light flashes, indicating that the battery is powered on.
2. Turn on the remote control switch. After the remote control beeps, the light of the UAV changes from fast flashing to constant light. The connection is successful.

⚠ ● When the remote controller is connected to the aircraft, please ensure that no other remote controller and aircraft are powered on at the same time, otherwise the code will be covered.

Gyro calibration

After the first connection with the remote control, you can do a calibration. The front and rear indicator lights of the UAV flash quickly, and the gyroscope is calibrated automatically. When the indicator light changes from flash to constant light, the calibration is completed.

⚠ ● During calibration, the aircraft must be placed on the horizontal ground, otherwise it will affect the flight stability.

BLADE REPLACEMENT

1. The blades to be replaced must be replaced corresponding to the relative position on the arm, fan blade A needs to be installed at position A, and fan blade B needs to be installed at position B, if the blade is replaced incorrectly, it will not be able to be controlled.
2. When flying, blade A rotates clockwise, and blade B rotates counterclockwise.

BASIC FLIGHT

CHECK BEFORE FLIGHT
1. Whether the battery of the remote control and aircraft is fully charged.
2. Whether the propeller is installed correctly.
3. Whether the motor starts normally after the power is turned on and unlocked.

BASIC FLIGHT STEPS:
1. Code pairing between the remote controller and the aircraft.
2. Open the software after connecting the drone wifi.
3. Perform gyroscope calibration.

Take-off method① (Recommended use) :

Short press the one-key takeoff button, the drone will automatically take off to about 1.5 meters.

Take-off method②:

Push the left stick of the remote control to 45° in the lower left corner, and at the same time push the right stick to 45° in the lower right corner to unlock the aircraft. After unlocking, move the left stick to Push up to take off, (As shown in Figure 1, Figure 2 below)

Figure 1 Figure 2

FLIGHT CONTROL METHOD

CAMERA ADJUSTMENT

Long press the camera up button on the remote control to adjust the drone lens upwards; Long press the camera down button on the remote control to adjust the drone lens downward.

360° ROLLOVER:

The drone flies to a height of more than 3 meters, press the 360° flip button, push the right joystick in any direction, and the drone can complete Aerial stunt rolls.

SPEED ADJUSTMENT:

The default speed is low-speed. Press the speed adjustment button once to switch to medium speed (two beeps on the remote control), and then press the speed adjustment button again to switch to high speed (three beeps on the remote control), short press again to return to low speed (one beep on the remote control).

Note: please use the picture transmission speed in the outdoor environment

TROUBLE SHOOTING

	PROBLEM	SOLUTION
01	After taking off, the aircraft cannot hover, causing it to run side to side/drift/large range	Clear the aircraft on a flat or level ground, then calibrate the gyroscope.
02	The aircraft vibrates very badly.	The blades are deformed and need to be replaced.
03	The aircraft cannot take off.	The battery voltage of the remote control or aircraft is too low.Please fully charge the battery.
04	Unsteady flight of the aircraft in strong wind.	Wind with there is no wind or breeze before flying.
05	The drone is not responding.	Ensure that the distance between the drone and the mobile device is within the effective range.
06	The drone can only be controlled with a mobile phone.	The correct connection sequence of the drone is: the remote control→the mobile device.
07	When obstacle avoidance mode is turned on, the flight speed is slow	Is obstacle avoidance mode, the UAV will automatically reduce the speed to ensure the best performance mode is smooth, and when flying indoor.