正面

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,
which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction

This device complies with part 15 of the FCC Rules. Operation is subject to
the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received,
including interference that may cause undesired operation.
The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction

English (英语) Operating instructions

After receiving the product, remove the earphones from the charging slot (some earphones require full charging or the earphone charging slot needs to be removed)
Remove the earphones from the charging case and start pairing, which takes approximately 4-5 seconds. After successful pairing, open your hands
Wireless connection function on the machine, search for wireless name, select connection, headphones are usually touch buttons, one click touch Touch to switch songs to adjust sound or turn on Siri. If you find that the headphones have not been successfully paired, only one ear can work,
At this point, it is usually due to insufficient battery and power of the headphones. If the two earphones are not connected, we need to choose fully charged before connecting them
Next, all of our products that leave the factory are powered by over 80% electricity.
Common faults: Usually, when receiving headphones, they will be charged and activated first, or removed from the charging case and then put back into the charging case to activate, causing the headphones to be affected
After activating and turning on the phone, wait for 4-5 seconds for the two earphones to start pairing. Pairing successful, connect the phone and pair the two earphones
The machine synchronizes sound, sometimes only connecting one earphone, which is caused by unsuccessful pairing or a depleted earphone battery
We need to charge it. If there is electricity, we can disconnect the previous headphones from the phone, turn off the wireless connection, and then turn off the ears
Put the device into the charging case and remove it, wait for pairing to succeed, then turn on the wireless connection headphones, and the sound of the two headphones will be synchronized
We must wait for the two earphones to successfully pair before we can turn on the wireless function of our phone to connect

The common functions of wireless earphones are as follows:
Click: Play/Pause
Double click: Switch songs
Triple Strike: Increase/Decrease Sound
Long press for three seconds: Open Siri

The common functions of wireless earphones are as follows:
Click: Play/Pause
Double click: add/subtract sound
Triple Click: Activate Siri
Long press for two seconds: switch songs

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio
or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that
to which the receiver is connected.
Consult the dealer or an experienced radio/TV technician for help.
Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority
to operate the equipment.

2.5 - 10 W

The power provided by the charger must be between
Minimum 2.5 watts and maximum 10 watts required
Achieve speed through wireless devices
Maximum load.

Español (西班牙语) Instrucciones de operación

Después de recibir el producto, retire los auriculares de la ranura de carga (algunos auriculares necesitan cargarse completamente o necesitan quitar la ranura de carga de auriculares)
Se tarda unos 4 - 5 segundos en sacar los auriculares de la Caja de carga y comenzar a emparejarse. Después de que el emparejamiento sea exitoso, abra la mano
Función de conexión inalámbrica en la máquina, buscar nombre inalámbrico, seleccionar conexión, auriculares suelen ser botones táctiles, toque con un solo clic
Toque para cambiar la canción para ajustar el sonido o encender siri. si descubre que los auriculares no están emparejados con éxito, solo una oreja puede funcionar,
En este momento, generalmente se debe a la falta de batería y electricidad de los auriculares. Si los dos auriculares no están conectados, necesitamos elegir cargar completamente antes de conectarnos.
A continuación, todos nuestros productos de fábrica son alimentados por más del 80% de la electricidad.
Fallas comunes: por lo general, al recibir los auriculares, se cargan y activan primero, o se retiran de la Caja de carga y luego se vuelven a poner en la Caja de carga para activarlos, lo que hace que los auriculares se vean afectados
Después de activar y encender el teléfono, espere 4 - 5 segundos para que los dos auriculares comiencen a emparejarse. el emparejamiento es exitoso, el teléfono abre la conexión y los dos auriculares se emparejan
La máquina sincroniza el sonido y a veces solo se conecta un auricular, lo que se debe a un emparejamiento fallido o al agotamiento de la batería de un auricular.
Necesitamos cargarlo. si hay electricidad, podemos desconectar los auriculares anteriores del teléfono, apagar la conexión inalámbrica y luego cerrar las orejas.
Coloque el dispositivo en la Caja de carga y retire, espere a que el emparejamiento sea exitoso, y luego abra los auriculares de conexión inalámbrica, y el sonido de los dos auriculares se sincronizará.
Tenemos que esperar a que los dos auriculares se emparejen con éxito antes de poder encender la función inalámbrica del teléfono para conectarnos.

Las funciones comunes de los auriculares inalámbricos son las siguientes:
Clic: reproducción / pausa
Doble clic: cambiar canciones
Tres golpes: sumar y restar sonido
Tres segundos de presión larga: abre Siri

Las funciones comunes de los auriculares inalámbricos son las siguientes:
Clic: reproducción / pausa
Doble clic: sumar y restar sonido
Tres golpes: abrir Siri

2.5 - 10 W

La fuente de alimentación proporcionada por el cargador debe estar entre 2,5 vatios mínimo y 10 vatios máximo necesarios
Alcanzar la velocidad a

Deutsch (德语) Bedienungsanleitung

Français (法语) Instructions de fonctionnement

Italiano (意大利语) Manuale d'uso

日本語 (日语) 取扱説明書

한국어 (韩语) 작업 명세서

Dansk sprog (丹麦语) Betjeningsvejledning

反面

Jezyk polski (波兰语) Instrukcja obsługi

(阿拉伯语)

Nederlands (荷兰语) Gebruiksaanwijzing

Čeština (捷克语) Návod k obsluze

Português (葡萄牙语) Manual de operação

Svenska (瑞典语) Bruksanvisning

Ελληνική γλώσσα (希腊语) Οδηγίες λειτουργίας

Magyar nyelv (匈牙利语) Kezelési kézikönyv