

D8+说明书 单页尺寸60*90mm

BSP D8+ 拉伸游戏手柄说明书

功能按键示意图:

适用说明:

1. 本产品采用人体工学设计, 手感舒适。
2. 具有拉伸收纳功能, 可以拉伸收纳不同长度为 123-242mm 的手机。
3. 采用蓝牙 5.2 EDR/BLE 连接, 手柄通过蓝牙与手机等各主机连接。
4. 支持 ShootingPlus APP, APP 可以通过各手机应用市场下载。
5. 支持安卓与鸿蒙 HID 标准模式, 可玩支持 HID 标准模式的各类游戏。
6. 支持安卓 6.0 以上系统 (即 ShootingPlus 安卓模式)。
7. 支持 iOS 13.0 以上系统 MFI 游戏, MFI 游戏可以玩 ShanWan MFI app 下载。
8. 支持 PS3 /SWITCH 游戏主机蓝牙连接玩游戏, 并具有陀螺仪功能。
9. 支持 Windows 10 系统笔记本电脑蓝牙连接, 玩 X-input 游戏。
10. 支持 USB 有线, 可以玩 PC/PS3/SWITCH 的游戏。
11. 手柄可通过在手机上下载安装GamepadSpace APP进行固件升级与更多附加功能修改和设置

-- P01 --

★ 因手机系统问题, 个别手机可能不支持此设备

★ 因官方游戏平台软件升级或源代码变更等不可抗拒的因素造成部分游戏无法与本产品连接操作, 我公司不承担任何责任, 对此我公司保留最终解释权。

产品特性参数:

1. 工作电压: DC3.7V
2. 工作电流: 约 10mA
3. 持续使用时间: >20H
4. 休眠电流: <5uA
5. 充电电压/电流: DC5V/500mA
6. 蓝牙传输距离: <=8M
7. 电池容量: 400mAh
8. 待机时间: 满电放置 60 天

产品使用说明:

X-input模式:

手柄模式拨动至X-input, 长按HOME键3秒, 指示灯【青色】快闪, 使用设备找到添加蓝牙设备, 点击搜索, 找到“Xbox Wireless Controller”设备名称时, 选择连接。连接成功后, 手柄指示灯常亮【青色】。

已成功连接过, 可以直接按【HOME】, 指示灯慢闪, 自动回连。

• 此模式适合安卓/iOS/鸿蒙/Xbox主机系列和PC主机的串流以及手机原生生态的游戏

Switch模式:

在 SWITCH 主机, 选择 手柄 Controllers->更改握把/顺序 ChangeGrip/order, 进入到 SWITCH 主机配对模式界面 Press L+R on the controller, 接着手柄模式拨动至Switch, 进入Switch模式配对, 长按HOME键3秒, 指示灯【绿色】快闪, 连接成功后, 手柄指示灯常亮【绿色】。

已成功连接过, 可以直接按【HOME】, 指示灯慢闪, 自动回连。

• 此模式适用于Switch主机。

-- P02 --

MFI模式:

手柄模式拨动至MFI, 长按HOME键3秒, 指示灯【紫色】快闪, 当设备搜索到“DUALSHOCK 4 Wireless Controller”设备名时, 选择连接。连接成功后, 手柄指示灯常亮【紫色】。

已成功连接过, 可以直接按【HOME】, 指示灯慢闪, 自动回连。

• 此模式适合玩苹果/安卓/鸿蒙原生游戏, 以及PS4/PS5串流游戏

V3模式:

手柄模式拨动至V3, 长按HOME键3秒, 指示灯【红色】快闪, 打开手机蓝牙, 找到蓝牙名称“D8+”, 选择连接, 连接成功后, 手柄指示灯常亮【红色】。

已成功连接过, 可以直接按【HOME】, 指示灯慢闪, 自动回连。

• 此模式仅支持安卓, 鸿蒙系统对王者荣耀、吃鸡等需要映射的游戏!

• 当手柄拨到在V3位置时先按X不放再按HOME开机, 为HID模式。并且每次都要按此方式连接。

安卓/鸿蒙 按键映射功能:

关注公众号“ShootingPlus”, 查看公众号内的默认操作说明, 如需设置映射键位, 请下载安装“ShootingPlusV3”APP, 在APP内进行按键映射以及调整按键位。

ShootingPlusV3 App, 安卓与鸿蒙系统可以到各手机应用市场下载。

ShootingPlus

有线模式:

1. 支持安卓HID, Switch, MFI, Xinput有线连接
2. 使用方法为按到所需使用的模式, 再用有传输数据功能的线连接上设备与手柄即可!

-- P03 --

马达震动力度调节:

按住手柄的M可以增强减弱马达震动力度

TURBO设置:

按下“A”再按“T”, 则为“A”键Turbo连发

第二次按下“A”再按“T”, 则为“A”键自动连发

第三次按下“A”再按“T”, 则为“A”键关闭连发(恢复原状)

当“A”键在AUTO自动连发的情况下, 按下“TURBO”左摇杆下“上”设置自动连发的速度, 分别为一秒15下, 一秒25下, 一秒8下。(注: 其他功能键设置方法同上)

轴校准功能:

手柄平放至桌面, 同时按住“START+HOME”键, 等待“状态指示灯”常亮后松手, 校准完成后“状态指示灯”灭。

-- P04 --

体感强开:

1. 按住“T”键八秒不放, 马达震动, 则切换成右摇杆。
2. 在六轴已切换成右摇杆的时候, 轻按一下T, 则进入陀螺仪半开状态, 主要使用场景为辅助FPS游戏时按下L2开锁时的射击瞄准。
3. 再次按住“T”键八秒不放, 马达震动, 则切换成左摇杆。
4. 再次按住“T”键八秒不放, 马达震动, 则取消。

宏编程:

【背部宏扩展设置】

①按住手柄的“编程键”不放, 再按“M1”, 此时“HOME”键会快闪, 这个是设置模式【M2设置方法同上】

②设置模式开启后“HOME”键会快闪, 这个时候就能设置按键, 手柄按什么键就会录入到M1按键上。如: 按一下A键, 这样A就会录入到M1上【此按键为列举, 其他键位也均可录入】

③如需设置多个按键按一下A再按B再按X再按Y, 这样按M1出招顺序就是A B X Y【此按键设置为列举, 其他出招顺序均可设置12个ABXY/上下左右A/L/ZL/R/RZ】

④按键按完后, 再按下M1即为完成编程, 此时“HOME”键常亮

【背部宏清除按键】

同时按住手柄的“编程键”+“M1”键进入编程模式, 此时“HOME”键快闪, 在此时不要键入任何键值, 再次按下“M1”键, 即可消除M1键之前设置的键值。

-- P05 --

手柄充电/休眠/唤醒功能:

1. 手柄充电功能:
 - 低电时, 指示灯快闪提示; 充电时, 指示灯慢闪提示; 充满时, 手柄关机;
2. 手柄休眠/唤醒/关机功能:
 - A. 手柄在5分钟内没有任何按键操作时自动关机休眠;
 - B. 当需要重新使用时需按HOME键唤醒即可回连;
 - C. 在开机状态下, 长按HOME键 8 秒, 产品关机, 所有 LED 指示灯熄灭。

注意事项:

1. 请不要把本产品放在潮湿或高温地方存储;
2. 不要敲击、拍打、棒打、刺穿、或试图去分解本产品, 以免对产品造成不必要的损害;
3. 产品内置电池, 请勿和垃圾一起丢弃;
4. 不要在靠近火或其他热源的地方对手柄进行充电;
5. 非专业人士请勿拆卸本产品, 否则不在售后维修服务范围内。

FCC 警告:

此设备符合FCC规则的第15部分。操作受以下两个条件限制: (1) 此设备不得造成有害干扰; (2) 此设备必须接受接收到的任何干扰, 包括可能造成不希望的操作的干扰。任何未经负责合规的明确批准的更改或修改都可能使用户操作设备的权利无效。注: 本设备已经过测试, 符合FCC规则第15部分规定的B类数字设备的限制。这些限制旨在为住宅安装提供合理保护, 防止有害干扰。本设备生产、使用并可能辐射射频能量, 如果不按说明书安装或使用, 可能会对无线电通信造成有害干扰。然而, 不能保证在特定安装中不会发生干扰。

如果该设备确实对无线电或电缆接收造成有害干扰, 可以通过关闭和重新启动设备来确定, 鼓励用户尝试通过以下一种或多种措施来纠正干扰:

- 重新定向或重新定位接收天线。
- 增加设备和接收器之间的距离。
- 将设备连接到不同电路的插座上

从接收器所连接的对象。

- 咨询经验丰富或经验丰富的无线电/电视技术人员寻求帮助。

该设备经过评估, 符合一般射频标准要求。该设备可以在便携式暴露条件下不受限制地使用。

-- P06 --

17

BSP D8+ Stretching game controller manual

Schematic diagram of function buttons:

Application instructions:

1. This product adopts ergonomic design, providing a comfortable hand feel.
2. It features a stretching and retracting function, allowing for the storage of mobile phones with varying lengths ranging from 123mm to 242mm.
3. Utilizing Bluetooth 5.2 EDR/BLE connectivity, the controller connects to various hosts such as mobile phones via Bluetooth.
4. Supports the ShootingPlus APP, which can be downloaded from various mobile app markets.
5. Supports Android and HarmonyOS HID standard mode, allowing access to various arcade games that support HID standard mode.
6. Supports Android systems above 6.0 (i.e., ShootingPlus Android mode).
7. Supports MFI games on iOS 13.0 and above systems. MFI games can be downloaded from the ShanWan MFI app.
8. Supports Bluetooth connection for playing games on PS3/SWITCH game consoles, and features gyroscope functionality.
9. Supports Bluetooth connection on Windows 10 laptops for playing X-Input games.
10. Supports USB cable, allowing you to play PC/PS3/SWITCH games.
11. The firmware of the gamepad can be upgraded, and additional functions can be modified and set through downloading and installing the GamepadSpace APP on a mobile phone

-- P07 --

★ Due to system issues with the mobile phone, some phones may not support this device

★ Due to uncontrollable factors such as official game platform software upgrades or source code changes, some games may not be able to connect and operate with this product. Our company is not responsible for any consequences. Our company reserves the right of final interpretation regarding this matter.

Product characteristic parameters:

1. Working voltage: DC3.7V
2. Working current: approximately 10mA
3. Continuous usage time:>20H
4. Sleep current:<5uA
5. Charging voltage/current: DC5V/500mA
6. Bluetooth transmission distance:<=8M
7. Battery capacity: 400mAh
8. Standby time: 60 days of fully charged storage

Product Instructions:

X-input mode:

Pull the controller mode to X-input, long press the HOME button for 3 seconds, and the indicator light (cyan) will flash. Use the device to find and add a Bluetooth device, click search, and when you find the device name "Xbox Wireless Controller", select connect. After successful connection, the indicator light on the handle remains on (cyan).

Successfully connected, you can directly press 【HOME】, the indicator light will flash slowly, and it will automatically reconnect.

• This mode is suitable for streaming on Android/iOS/HarmonyOS/Xbox console series and PC consoles, as well as playing original games on mobile phones

Switch mode:

On the SWITCH host, select Controller -->Change Grip/Order to enter the SWITCH host pairing mode interface Press L+R on the controller. Next, turn the controller mode to Switch and enter Switch mode pairing. Press and hold the HOME button for 3 seconds, and the indicator light [green] will flash. After successful connection, the controller indicator light will remain on [green].

Successfully connected, you can directly press 【HOME】, the indicator light will flash slowly, and it will automatically reconnect.

• This mode is suitable for Switch consoles.

-- P08 --

MFI mode:

Pull the controller mode to MFI, press and hold the HOME button for 3 seconds, and the indicator light (purple) will flash. When the device searches for the device name "DUALSHOCK 4 Wireless Controller", select Connect. After successful connection, the indicator light on the handle remains on (purple).

Successfully connected, you can directly press 【HOME】, the indicator light will flash slowly, and it will automatically reconnect.

• This mode is suitable for playing native Apple/Android/HarmonyOS games, as well as streaming games on PS4/PS5

V3 mode:

Pull the joystick mode to V3, press and hold the HOME button for 3 seconds, the indicator light (red) will flash, turn on the phone's Bluetooth, find the Bluetooth name "D8+", select the connection, and after successful connection, the joystick indicator light will remain on (red).

Successfully connected, you can directly press 【HOME】, the indicator light will flash slowly, and it will automatically reconnect.

• This mode only supports games that require mapping on Android and HarmonyOS systems, such as King of Glory and PUBG!

When the handle is pulled to the V3 position, hold down X first, and then press HOME to turn on the device, which is in HID mode. And it must be connected in this way every time.

Android/HarmonyOS key mapping function:

Follow the official account "ShootingPlus" and check the default operating instructions in the official account. If you need to set the mapping keys, please download and install the "ShootingPlusV3" APP, map the keys and adjust the key positions in the APP. The Shooting Plus V3 App can be downloaded from various mobile app markets for Android and HarmonyOS systems.

ShootingPlus

Wired mode:

1. Supports wired connections for Android HID, Switch, MFI, and Xinput
2. The usage method is to plug up to the desired mode, and then connect the device and handle with a cable with data transmission function!

-- P09 --

Motor vibration intensity adjustment:

Pressing and holding the M on the handle can enhance and reduce the vibration of the motor

TURBO settings:

Press "A" and then "T" to press the "A" key Turbo for continuous firing

Press "A" for the second time and then press "T", the "A" key will automatically send consecutive messages

Press "A" for the third time and then press "T" to turn off the continuous transmission (restore the original state) with the "A" key

When the "A" key is in AUTO automatic continuous firing mode, hold down the "TURBO+left joystick up and down" button to set the speed of automatic continuous firing, which is 15 strokes per second, 25 strokes per second, and 8 strokes per second. (Note: The method for setting other function keys is the same as above)

Axis calibration function:

Place the controller flat on the desktop, while holding down the "START+HOME" button, wait for the "status indicator light" to stay on, then release it. After calibration is complete, the "status indicator light" will turn off.

-- P10 --

Strong physical sensation:

1. Press and hold the "T" key for eight seconds, and if the motor vibrates, switch to simulating the right joystick.
2. When the six axis has been switched to the right joystick, lightly press T to enter the half on state of the gyroscope. The main usage scenario is to assist shooting and aiming when pressing L2 to turn on the mirror during FPS games.
3. Press and hold the "T" key again for eight seconds without releasing it. If the motor vibrates, switch to simulating the left joystick.
4. Press and hold the "T" key again for eight seconds without releasing it. If the motor vibrates, cancel.

Macro programming:

【Back macro extension settings】

① Press and hold the "Program" button on the controller, then press "M1". At this point, the "HOME" button will flash, which is the setting mode 【M2 setting method as above】

② After the setting mode is turned on, the "HOME" button will flash, and at this time, the button can be set. The key pressed on the controller will be recorded on the M1 button. For example, press the A key once, and A will be entered into M1. [This key is for listing; other keys can also be entered]

③ To set multiple buttons: press A once, then press B, then press X, and then press Y, so that the order of M1's moves is A, B, X, and Y. [This button is set to list: 12 ABXY/ up, down, left, right/L/ZL/R/ZR can be set for other move orders]

④ After pressing the button, press M1 again to complete the programming, and the "HOME" button will remain on

【Back macro clear button】

Simultaneously press and hold the "Program" and "M1" keys on the controller to enter programming mode. At this time, the "HOME" key will flash, do not enter any key values at this time. Press the "M1" key again to eliminate the key values set before the M1 key.

-- P11 --

Controller charging/sleep/wake-up function:

1. Controller charging function:
 - When the power is low, the indicator light flashes to prompt;
 - When charging, the indicator light flashes slowly to prompt;
 - When fully charged, the controller shuts down.
2. Controller sleep/wake-up/automatic function:
 - A. The controller automatically shuts down and enters sleep mode within 5 minutes without any button operation;
 - B. When it needs to be reused, press the HOME key to wake up and reconnect;
 - C. In the power on state, long press on the HOME button for 8 seconds to turn off the product and all LED indicator lights will turn off.

matters needing attention:

1. Please do not store this product in damp or high-temperature places;
2. Do not strike, drop, stick, puncture, or attempt to disassemble this product to avoid unnecessary damage to the product;
3. The product has a built-in battery, please do not dispose of it together with garbage;
4. Do not charge the handle near fire or other heat sources;
5. Non professionals are not allowed to disassemble this product, otherwise it is not covered by the after-sales warranty service.

FCC Caution :

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

-- P12 --

17

BSP D8+ストレッチゲームハンドル説明書

機能ボタンの概観図:

適用説明:

1. 本製品は人体工学設計を採用し、手触りが快適である。
2. 延縮収納機能があり、異なる長さの123-242 mmの携帯電話を延縮収納することができる。
3. Bluetooth 5.2 EDR/BLE接続を採用し、ハンドルはBluetoothを通じて携帯電話などの各ホストと接続する。
4. ShootingPlusアプリをサポートし、アプリは各携帯アプリ市場を通じてダウンロードできる。
5. アンドロイドと地獄HID標準モードをサポートし、HID標準モードをサポートする各種ゲームセンターゲームをプレイすることができます。
6. Android 6.0以上のシステム (ShootingPlus Androidモード) をサポートする。
7. iOS 13.0以上のシステムMFIゲームをサポートし、MFIゲームはShanWan MFI appでダウンロードできる。
8. PS 3/SWITCHゲーム本体のBluetooth接続ゲームをサポートし、ジャイロスコープ機能があります。
9. Windows 10システムノートパソコンのBluetooth接続をサポートし、X-inputゲームをプレイする。
10. USBケーブルに対応し、PC/PS 3/SWITCHのゲームをプレイすることができます。
11. ハンドルは携帯電話にGamepadSpace APPをダウンロードしてインストールすることによってファームウェアのアップグレードと追加機能の修正と設定を行うことができます

-- P13 --

★ 携帯電話システムの問題で、個別の携帯電話はこの機能に対応していない可能性があります

★ 公式ゲームプラットフォームのソフトウェアアップグレードやソースコード変更などの不可抗力要因により、一部のゲームが本製品と接続操作できなくなり、当社はいかなる責任も負いません。これに対して当社は最終的な解釈権を留保している。

製品特性パラメータ:

1. 動作電圧: DC 3.7 V
2. 動作電流: 約10 mA
3. 持続使用时间: >20 H
4. 休眠電流: <5 uA
5. 充電電圧/電流: DC 5 V/500 mA
6. ブルートゥース伝送距離: <=8 M
7. 電池容量: 400 mAh
8. 待機時間: 満電60日間放置

製品使用説明:

X-inputモード:

ハンドルモードをX-inputに引き抜いて、ホームボタンを3秒間押し、LED【シアン】フラッシュ、デバイスをBluetoothデバイスを通じて検索、検索をクリックして、「Xbox Wireless Controller」デバイス名を見つけたら、接続を選択します。接続が成功すると、ハンドルのLEDは常に【シアン】に点灯します

正常に接続されてお、直接【HOME】を押すことができ、ランプがゆっくり点滅し、自動的に接続を戻すことができます。

• このモードは、アンドロイド/iOS/鸿蒙/XboxホストシリーズとPCホストのストリーミング、携帯電話の原形ゲームに適しています

Switchモード:

SWITCHホストでは、ハンドルControllers->グリップ/シーケンス変更ChangeGrip/orderを選択し、SWITCHホストペアリングモード/インタフェースPress L+R on the controllerに進みます。次にハンドルモードをスイッチに抜き、スイッチモードのペアリングに入り、ホームボタンを3秒間長押しすると、ランプは【グリーン】に点滅し、接続が成功すると、ハンドルのランプは常に【グリーン】に点灯します。

正常に接続されており、直接【HOME】を押すことができ、ランプがゆっくり点滅し、自動的に接続を戻すことができます。

• このモードはSwitch本体に適用されます。

-- P14 --

MFIモード:

ハンドルモードをMFIに引き抜き、ホームキーを3秒間押し、LED【パープル】が点滅し、デバイスが"DUALSHOCK 4 Wireless Controller"デバイス名を検索した場合、接続を選択します。接続が成功すると、ハンドルのLEDは常に点灯します【パープル】。

正常に接続されており、直接【HOME】を押すことができ、ランプがゆっくり点滅し、自動的に接続を戻すことができます。

• このモードは、アップル/アンドロイド/鸿蒙原生ゲーム、PS 4/PS 5ストリーミングゲームに適しています

V3モード:

ハンドルモードをV3に引き抜いて、ホームボタンを3秒間押し、LED【あか】が点滅して、携帯電話のBluetoothを開けて、Bluetooth名称「D8+」を見つけて、接続を選択して、接続が成功した、ハンドルのランプは常に【あか】に点灯します

ハンドルモードをV3に引き抜くときはホームを押して電源を入れ、HIDモードにします。そして毎回のように接続しなければなりません。

• このモードはアンドロイド、鸿蒙システム对王者荣耀、吃鸡を食べるなどマッピングが必要なゲームのみをサポートしています

• ハンドルをV3位置に引き抜くときはホームを押して電源を入れ、HIDモードにします。そして毎回のように接続しなければなりません。(注: その他のファンクションキーの設定方法は同上)

TURBO設定:

「A」キーがAUTOで自動的に接続する場合、「TURBO+左ジョイスティック上」を押しながら自動連発の速度を設定します。それぞれ1秒15、1秒25、1秒8です。(注: その他のファンクションキーの設定方法は同上)

軸較正機能:

ハンドルをデスクトップに平らに置き、同時に「START+HOME」ボタンを押しながら、「ステータスLED」が常にか点灯するのを待ってから手放し、キャリブレーションが完了すると「ステータスLED」が消えます。

-- P15 --

モータ振動力調節:

ハンドルのMを押すと、モータの振動力を弱めます

TURBO設定:

「A」を押して「T」を押すと「A」キーTurbo連発2回目に「A」を押して「T」を押すと、「A」キーが自動的に連続します

3回目に「A」を押して「T」を押すと、「A」キーで接続を閉じる(元に戻す)

体感開:

1. 「T」ボタンを8秒間押し放さず、モーターが振動すると、アナログ右スイングレバーが切り替わります。
2. 六軸が右スイングレバーに切り替わった時に、軽くTを押すとジャイロ半開状態になり、主な使用シーンは補助FPSゲーム時にL2ミラーを押した時の射撃照準である。
3. 再び「T」ボタンを押して放さず、モーターが振動すると、アナログ左スイングレバーが切り替わります。
4. 再び「T」ボタンを8秒間押し放さず、モーターが振動したらキャンセルします。

マクロプログラミング:

【バックグラウンドマクロ拡張設定】

①ハンドルの「プログラミングキー」を押したまま「M1」を押すと、「HOME」キーがフラッシュします。これは設定モードです【M2設定方法は同上】

②設定モードがオンになると「HOME」キーが点滅し、このときにキーを設定でき、ハンドルのどのキーを押すかでM1キーに入力されます。例: Aキーを押すと、AはM1に入力されます【このキーは列挙: 他のキーも入力できます】

③数値のボタンを設定する必要がある場合: Aを押してからBを押してXを押してからYを押して、M1を押して投げる順番はA B X Yである【このボタンの設定は列挙: その他の投げる順番はすべて12個のABXY/上下左右L/ZL/R/ZRを設定することができます】

④キーを押し終わった後、M1を押すとプログラミングが完了し、「HOME」キーは常に点灯します

もしこの装置が無線やケーブルの受信に有害な干渉を与えていないならば、デバイスをシャットダウンして再起動することによって決定することができます。ユーザは次の7つ以上の方法で干渉を修正しようと試みることができます。これは推奨される一時的な解決策であり、位置を変更する必要があります。

--デバイスと受信機間の距離を増やします

--受信回路のソケットにデバイスを接続する

--変換アダプタに接続されたオブジェクト。

--デバイスと接続装置間の物理的/技術的な相対してヘルプを求めます。

この装置は評価され、一般的な暴露条件下でこの要件に適合しています。この装置は、携帯型暴露条件下で制限なく使用することができます

-- P16 --

ハンドルの充電/スリープ/ウェイクアップ機能:

1. ハンドル充電機能:
 - 低電力時は、LEDが点滅します。
 - 充電中、LEDがゆっくり点滅することを示すメッセージ。
 - 満タムになると、ハンドルがオフになります。
2. ハンドルのスリープ/起動/シャットダウン機能:
 - A. ハンドル55分以内にボタン操作がないと自動的に電源を切ってスリープします。
 - B. 再度使用が必要な場合はホームキーを押して電源を起動します。
 - C. 電源を入れた状態で、ホームボタンを8秒間押し、製品は電源を切って、すべてのLEDランプは消灯します。

注意事項:

1. 本製品は湿気や高温の場所に保管しないでください。
2. 製品に不必要な損傷を与えないように、たたく、転んだり、棒でたたいたり、刺したり、分解しようとしたりしないでください。
3. 製品には電池が内蔵されているので、ゴミと一緒に捨ててはいけません。
4. 火や他の熱源に近い場所でハンドルを充電しないでください。
5. 専門家は本製品を分解しないでください。そうしないと、アフターサービスはありません。

FCC警告:

このデバイスはFCC規則のセクション15に準拠しています。操作は以下の2つの条件によって制限される: (1) この装置は有害な妨害をもたらしてはならない。(2) このデバイスは、望ましくない動作を引き起こす可能性がある干渉を含む発信した干渉を受け入れなければならない。

コンプライアンスを担当していない当事者が明示的に承認した変更や変更は、ユーザがデバイスを使用する権限を無効にする可能性があります。

注: 本装置はすでにテスト済みで、FCC規則第15部に規定された8種類デジタル機器の制限に適合しています。これらの制限は、住宅の設置に適切な保護を提供し、有害な干渉を防止することを目的としています。本装置は無線周波数エネルギーを発生、使用し、放射する可能性があります。説明書に従って設置、使用しないと、無線通信に有害な干渉を発生させる可能性があります。しかし、特定のインストールで干渉が発生しない保証はありません。

もしこの装置が無線やケーブルの受信に有害な干渉を与えていないならば、デバイスをシャットダウンして再起動することによって決定することができます。ユーザは次の7つ以上の方法で干渉を修正しようと試みることができます。これは推奨される一時的な解決策であり、位置を変更する必要があります。

--デバイスと受信機間の距離を増やします

--受信回路のソケットにデバイスを接続する

--変換アダプタに接続されたオブジェクト。

--デバイスと接続装置間の物理的/技術的な相対してヘルプを求めます。

この装置は評価され、一般的な暴露条件下でこの要件に適合しています。この装置は、携帯型暴露条件下で制限なく使用することができます

-- P17 --

バックグラウンドマクロ拡張設定:

①ハンドルの「プログラミングキー」を押したまま「M1」を押すと、「HOME」キーがフラッシュします。これは設定モードです【M2設定方法は同上】

②設定モードがオンになると「HOME」キーが点滅し、このときにキーを設定でき、ハンドルのどのキーを押すかでM1キーに入力されます。例: Aキーを押すと、AはM1に入力されます【このキーは列挙: 他のキーも入力できます】

③数値のボタンを設定する必要がある場合: Aを押してからBを押してXを押してからYを押して、M1を押して投げる順番はA B X Yである【このボタンの設定は列挙: その他の投げる順番はすべて12個のABXY/上下左右L/ZL/R/ZRを設定することができます】

④キーを押し終わった後、M1を押すとプログラミングが完了し、「HOME」キーは常に点灯します

もしこの装置が無線やケーブルの受信に有害な干渉を与えていないならば、デバイスをシャットダウンして再起動することによって決定することができます。ユーザは次の7つ以上の方法で干渉を修正しようと試みることができます。これは推奨される一時的な解決策であり、位置を変更する必要があります。

--デバイスと受信機間の距離を増やします

--受信回路のソケットにデバイスを接続する

--変換アダプタに接続されたオブジェクト。

--デバイスと接続装置間の物理的/技術的な相対してヘルプを求めます。

この装置は評価され、一般的な暴露条件下でこの要件に適合しています。この装置は、携帯型暴露条件下で制限なく使用することができます

-- P18 --