

Y04说明书 单页尺寸60*90mm

Y04无线游戏手柄

功能按键示意图:

SELECT

HOME

START

摇杆

功能键

方向键

TURBO 模式切换键

R

L

M1

M2

模式切换键:

H S X P

HID模式 | Switch模式 | X-input模式 | PS模式

适用说明:

1. 采用经典六键布局, 更适合格斗类游戏

2. 采用霍尔摇杆, 键帽高度可调, 满足不同玩家需求

3. 采用机械轻触肩键, 轻触发, 回弹快, 反应灵敏迅速

4. 八向方向圆盘, 轻松输出大招

5. 适配Switch、PC、手机、平板、PS3、PS4平台

6. 内置非对称马达, 震动力度可调节

7. 支持TURBO功能

8. 支持宏按键设置功能

★因手机系统问题, 个别手机可能不支持此设备

★因官方游戏平台软件升级或源代码变更等不可抗力因素造成部分游戏无法与本产品连接操作, 我公司不负任何责任, 对此我公司保留最终解释权。

产品特性参数:

1. 工作电压: DC3.7V

2. 工作电流: 约 10mA

3. 持续使用时间: >20H

4. 休眠电流: <5uA

5. 充电电压/电流: DC5V/500mA

6. 蓝牙传输距离: <=8M

7. 电池容量: 800mAh

8. 待机时间: 满电放置 60 天

产品使用说明:

HID模式:

1. 模式键拨动至“H”档位, 长按“HOME键”开机, 指示灯【橙色】快闪。

2. 打开手机/平板蓝牙, 找到蓝牙名称“Y04”, 选择连接, 连接成功后, 指示灯常亮【橙色】。

3. 再次连接时, 短按“HOME键”开机, 即可自动连接。

• 此模式适用于安卓, 鸿蒙系统对原生游戏以及模拟器使用!

Switch模式:

H S X P

1. 模式键拨动至“S”档位, 长按“HOME键”开机, 指示灯【绿色】快闪。

2. 在 SWITCH 主机, 选择 手柄 Controllers->更改握把/顺序 ChangeGrip/order, 进入到 SWITCH 主机配对模式界面 Press L+R on the controller. 进入Switch模式配对, 连接成功后, 指示灯常亮【绿色】。

3. 再次连接时, 短按“HOME键”开机, 即可自动连接。

• 此模式适用于Switch主机。

X-input模式:

H S X P

1. 模式键拨动至“X”档位, 长按“HOME键”开机, 指示灯【青色】快闪。

2. 使用设备找到添加蓝牙设备, 点击搜索, 找到“Xbox Wireless Controller”设备名时, 选择连接, 连接成功后, 指示灯常亮【青色】。

3. 再次连接时, 短按“HOME键”开机, 即可自动连接。

• 此模式适合安卓/iOS/鸿蒙/Xbox主机系列和PC主机的串流以及手机原生态的游戏

PS模式(P4主机):

H S X P

1. 模式键拨动至“P”档位, 将USB数据线插上PS4的USB接口, 另外一端的Type-C接口插上Y04有线连接接口

2. 按HOME键开机, 指示灯【蓝色】快闪;

3. 连接成功后, 指示灯常亮【蓝色】。常亮后把数据线接上即可无线操作。

4. 再次连接PS4时, 按“HOME键”开机, 即可自动连接。

MFI模式:

1. 模式键拨动至“P”档位, 长按“HOME键”开机, 指示灯【紫色】快闪。

2. 当设备搜索到“DUALSHOCK4Wireless Controller”设备名时, 选择连接。

3. 连接成功后, 指示灯常亮【紫色】。

4. 再次连接时, 短按“HOME键”开机, 即可自动连接。

• 此模式适合玩苹果/安卓/鸿蒙原生游戏, 以及PS4串流游戏

有线模式:

1. 支持安卓HID、Switch、MFI、Xinput有线模式。

2. 使用方法为拨到所需使用的模式, 再用有传输数据功能的线连接上设备与手柄即可。

马达震动力度调节:

按住TURBO+摇杆上下可以增强
减弱马达震动力度

TURBO设置:

按下“A”再按“T”, 则为“A”键Turbo连发

第二次按下“A”再按“T”, 则为“A”键自动连发

第三次按下“A”再按“T”, 则为“A”键关闭连发(恢复原状)

当“A”键在AUTO自动连发的情况下, 按住“TURBO+方向键上/下”设置自动连发的速度, 分别为一秒15下, 一秒25下, 一秒8下。(注: 其他功能键设置方法同上)

宏编程:

【背部宏扩展设置】

①按住的“SELECT”不放, 再按“M1”, 1秒后指示灯会快闪, 这个是设置模式【M2设置方法同上】

②设置模式开启后指示灯会快闪, 这个时候就能设置按键, 手柄按什么键就会录入到M1按键上。如 按一下A键, 这样A就会录入到M1上【此按键为列举 其他键位也可录入】

③如需设置多个按键: 按一下A再按B再按X再按Y, 这样按M1出招顺序就是A B X Y【此按键设置为列举】, 其他出招顺序均可设置12个按键: 上/下/左/右 / A/B/C/X/Y/Z / L/B】

④按键按完后, 再按下M1即为完成编程, 此时指示灯常亮。

【背部宏清除按键】

同时按住的“SELECT”+“M1”键进入编程模式, 此时指示灯快闪, 在此时不要键入任何键值, 再次按下“M1”键, 即可清除M1键之前设置的键值。

手柄充电/休眠/唤醒功能:

1、手柄充电功能:

低电时, 指示灯快闪提示;

充电时, 指示灯慢闪提示;

充满时, 手柄关机。

2、手柄休眠/唤醒/关机功能:

A、手柄在5分钟内没有任何按键操作时自动关机休眠;

B、当需要重新使用时需按HOME键唤醒即可回连;

C、在开机状态下, 长按HOME键 8 秒, 产品关机, 所有 LED 指示灯熄灭。

Y04 Wireless gaming Controller

Schematic diagram of functional buttons:

SELECT

HOME

START

Joystick

Function keys

Directional keys

TURBO Mode switch key

R

L

M1

M2

Mode switch key:

H S X P

HID mode | Switch mode | X-input mode | PS mode

Applicable instructions:

1. Adopting the classic six key layout, it is more suitable for fighting games

2. Adopting Hall joystick and adjustable keycap height to meet the needs of different players

3. Using a mechanical touch shoulder key, it triggers lightly, rebounds quickly, and responds sensitively and quickly

4. Eight directional disc, easy to create ultimate moves

5. Compatible with Switch, PC, mobile phone, tablet, PS3, PS4 platforms

6. Built in asymmetric motor, adjustable vibration intensity

7. Support TURBO function

8. Support macro back key setting function

★ Due to system issues with the mobile phone, some phones may not support this device

★ Due to uncontrollable factors such as official game platform software upgrades or source code changes, some games may not be able to connect and operate with this product. Our company is not responsible for any consequences. Our company reserves the right of final interpretation regarding this matter.

Product characteristic parameters:

1. Working voltage: DC3.7V

2. Working current: approximately 10mA

3. Continuous usage time:>20H

4. Sleep current:<5uA

5. Charging voltage/current: DC5V/500mA

6. Bluetooth transmission distance:<=8M

7. Battery capacity: 800mAh

8. Standby time: 60 days of fully charged storage

Product Instructions:

HID mode:

1. Pull the mode button to the “H” position, press and hold the “HOME” button to turn on the device, and the indicator light (orange) will flash rapidly.

2. Turn on the Bluetooth on your phone/tablet, find the Bluetooth name “Y04”, select the connection, and after successful connection, the indicator light will remain on (orange).

3. When reconnecting, press the “HOME” button briefly to turn on the device and it will automatically connect.

• This mode is suitable for using native games and emulators on Android and HarmonyOS systems!

Switch mode:

H S X P

1. Pull the mode button to the “S” position, press and hold the “HOME” button to turn on the device, and the indicator light (green) will flash rapidly.

2. On the SWITCH host, select Controller ->Change Grip/Order to enter the SWITCH host pairing mode interface Press L+R on the controller. After entering Switch mode pairing and successfully connecting, the indicator light remains on (green).

3. When reconnecting, press the “HOME” button briefly to turn on the device and it will automatically connect.

• This mode is suitable for Switch consoles.

X-input mode:

H S X P

1. Pull the mode button to the “X” position, press and hold the “HOME” button to turn on the device, and the indicator light (cyan) will flash rapidly;

2. Use the device to find and add a Bluetooth device, click search, find the “Xbox Wireless Controller” device name, and select connect. After successful connection, the indicator light remains on (cyan).

3. When reconnecting, press the “HOME” button briefly to turn on the device and it will automatically connect.

• This mode is suitable for streaming on Android/iOS/HarmonyOS/Xbox console series and PC consoles, as well as playing original games on mobile phones

PS mode (P4 host):

H S X P

1. Pull the mode key to the “P” position, plug the USB data cable into the USB port of the PS4, and plug the Type-C port on the other end into the Y04 wired connection port

2. Press the HOME button to turn on the device, and the blue indicator light will flash rapidly;

3. After successful connection, the indicator light remains on (blue). After the light stays on, unplug the data cable to operate wirelessly.

4. When reconnecting, press the “HOME” button briefly to turn on the device and it will automatically connect.

MFi mode:

1. Pull the mode button to the “P” position, press and hold the “HOME” button to turn on the device, and the indicator light (purple) will flash rapidly.

2. When the device searches for the device name “DUALSHOCK4Wireless Controller”, select Connect.

3. After successful connection, the indicator light remains on (purple).

4. When reconnecting, press the “HOME” button briefly to turn on the device and it will automatically connect.

• This mode is suitable for playing native Apple/Android/HarmonyOS games, as well as PS4 streaming games

Wired mode:

1. Supports Android HID、Switch、MFI、Xinput wired modes.

2. The usage method is to dial to the desired mode, and then connect the device and handle with a cable with data transmission function.

Motor vibration intensity adjustment:

Pressing and holding the
TURBO-joystick up and down can
enhance and reduce the vibration of
the motor

TURBO settings:

Press “A” and then “T” to press the “A” key Turbo for continuous firing

Press “A” for the second time and then press “T”, the “A” key will automatically send consecutive messages

Press “A” for the third time and then press “T” to turn off the continuous transmission (restore the original state) with the “A” key

When the “A” key is in AUTO automatic continuous firing mode, press and hold the “TURBO-directional keys up/down” to set the speed of automatic continuous firing, which is 15 strokes per second, 25 strokes per second, and 8 strokes per second, respectively. (Note: The method for setting other function keys is the same as above)

Macro programming:

【Back macro extension settings】

① Press and hold the “SELECT” button, then press “M1”. After 1 second, the indicator light will flash. This is the setting mode 【M2 setting method as above】

② After the setting mode is turned on, the indicator light will flash rapidly. At this time, the buttons can be set, and the key pressed on the controller will be recorded on the M1 button. For example, press the A key once, and A will be entered into M1. [This key is for listing: other keys can also be entered]

③ If multiple buttons need to be set: press A once, then press B, then press X, and then press Y, so that the order of M1's moves is A B X Y (this button is set to list). Other order of moves can be set with 12 buttons: up/down/left/right/A/B/C/X/Y/Z/L/B

④ After pressing the button, press M1 again to complete the programming, and the indicator light will remain on.

【Back macro clear button】

Press and hold the “SELECT” and “M1” keys simultaneously to enter programming mode, and the indicator light will flash. Do not enter any key values at this time. Press the “M1” key again to eliminate the key values set before the M1 key.

Controller charging/sleep/wake-up function:

1. Controller charging function:

A. When the power is low, the indicator light flashes to prompt;

When charging, the indicator light flashes slowly to prompt;

When fully charged, the controller shuts down;

2. Controller sleep/wake-up/shutdown function:

A. The controller automatically shuts down and enters sleep mode within 5 minutes without any button operation;

B. When it needs to be reused, press the HOME key to wake up and reconnect;

C. In the power on state, long press the HOME button for 8 seconds to turn off the product and all LED indicator lights will turn off.

Y04ワイヤレスゲームハンドル

機能ボタンの概略図:

SELECT

HOME

START

ロックバー

ファンクションキー

方向キー

TURBO モード切替キー

R

L

M1

M2

モード切替キー:

H S X P

HIDモード | Switchモード | X-inputモード | PSモード

適用説明:

1. 古典的な6キーレイアウトを採用し、格闘型ゲームに適している

2. ホールロッキングレバーを採用し、キーキャップの高さを調整でき、異なるプレイヤーのニーズを満たす

3. 機械で肩ボタンに軽く触れ、軽く触発し、リターンが速く、反応が鋭敏で迅速である

4. 8方向円盤、簡単に大きな手を出す

5. 適合スイッチ、PC、携帯電話、タブレット、PS 3、PS 4プラットフォーム

6. 非対称モータを内蔵し、振動力を調節できる

7. TURBO機能をサポートする

8. マクロバックキー設定機能をサポートする

★ 携帯電話システムの問題で、個別の携帯電話はこの機器に対応していない可能性があります

★ 公式ゲームプラットフォームのソフトウェアアップグレードやソースコード変更などの不可抗力要因により、一部のゲームが本製品と接続操作できなくなり、当社はいかなる責任も負いません。これに対して当社は最終的な解释权を留保している。

製品特性パラメータ:

1. 動作電圧: DC 3.7 V

2. 動作電流: 約10 mA

3. 持続使用時間: >20 H

4. 休眠電流: <5 uA

5. 充電電圧/電流: DC 5 V/500 mA

6. ブルートゥース伝送距離: <=8 M

7. 電池容量: 800 mAh

8. 待機時間: 満電60日間放置

製品使用说明:

HIDモード:

1. モードキーを「H」シフトに引き抜き、「HOMEキー」を長押しして電源を入れ、LED【オレンジ】が点滅した。

2. デバイスを使用してBluetoothデバイスを追加し、検索をクリックして「Xbox Wireless Controller」デバイス名を見つけ、接続を選択します。接続に成功すると、LEDは常に【オレンジ】に点灯します。

3. 再接続する場合は、ホームキーを押して電源を入れれば、自動的に接続できます。

• このモードは、アンドロイド、鸿蒙システムのネイティブゲームやシミュレータに使用できます!

Switchモード:

H S X P

1. モードキーを「S」シフトに引き抜き、「HOMEキー」を長押しして電源を入れ、LED【グリーン】が点滅した。

2. SWITCHホストでは、ハンドルControllers->グリップ/シーケンス変更 ChangeGrip/orderを選択し、SWITCHホストペアリングモードインタフェース Press L+R on the controllerに達します。Switchモードのペアリングに入り、接続に成功すると、LEDは常に【グリーン】に点灯します。

3. 再接続する場合は、ホームキーを押して電源を入れれば、自動的に接続できます。

• このモードはSwitch本体に適用されます。

X-inputモード:

H S X P

1. モードキーを「X」シフトに引き抜き、「HOMEキー」を長押しして電源を入れ、LED【シアシアン】フラッシュ。

2. デバイスを使用してBluetoothデバイスを追加し、検索をクリックして「Xbox Wireless Controller」デバイス名を見つけ、接続を選択します。接続に成功すると、LEDは常に【シアシアン】に点灯します。

3. 再接続する場合は、ホームキーを押して電源を入れれば、自動的に接続できます。

• このモードは、アンドロイド/iOS/鸿蒙/XboxホストシリーズとPCホストのストリーミング、携帯電話の原形ゲームに適しています

PSモード (P 4ホスト):

H S X P

1. モードキーを「P」レンジに引き抜き、USBデータケーブルをPS 4のUSBインタフェースに、他端のType-CインタフェースをY 04有線接続インタフェースに差し込む

2. ホームボタンを押すと電源が入り、LEDが【ブルー】に点滅します。

3. 接続が成功すると、LEDは常に【ブルー】に点灯します。点灯したらデータ線を抜くと無線で操作できます。

4. PS 4に再接続する場合は、「ホームキー」を押して電源を入れれば、自動的に接続できます。

MFIモード:

1. モードキーを「P」レンジまで引き抜いて、「HOMEキー」を長く押し続けて起動して、ランプ【パープル】がフラッシュする。

2. デバイスが「DUALSHOCK 4 Wireless Controller」デバイス名を検索した場合、接続を選択します。

3. 接続が成功した後、LEDは常に点灯している【パープル】。

4. 再接続する時、「ホームキー」を押して電源を入れ、自動的に接続できます。

• このモードは、アップル/アンドロイド/鸿蒙原生ゲーム、PS 4ストリーミングゲームに適しています

有線モード:

1. アンドロイドHID、Switch、MFI、Xinput有線モードをサポートする。

2. 使用方法は必要な使用モードにダイヤルし、データ転送機能のある線とデバイスとハンドルを接続すればよい。

モータ振動力調節:

TURBO+ロッキングレバーを上
下に押すことで、モータの振動
力を弱めます

TURBO設定:

「A」を押して「T」を押すと、「A」キーTurbo連発

2回目に「A」を押して「T」を押すと、「A」キーが自動的に連続します

3回目に「A」を押して「T」を押すと、「A」キーで連続を閉じる（元に戻す）

「A」キーがAUTOで自動的に連続する場合、「TURBO+方向キー上/下」を押しながら自動連続の速度を設定します。それぞれ1秒15、1秒25、1秒8です。（注：その他のファンクションキーの設定方法は同上）

マクロプログラミング:

【バックグラウンドマクロ拡張設定】

①「SELECT」を押したまま放置せず、「M1」キーを押すと、1秒後にランプが点滅します。これは設定モードです【M2設定方法は同上】

②設定モードになるとランプが点滅し、その時にボタンを設定でき、ハンドルなどのボタンを押すとM1ボタンに入力されます。例：Aキーを押すと、AはM1に入力されます【このキーは列挙：他のキーも入力できます】

③複数のボタンを設定する必要がある場合：Aを押してからBを押してからYを押して、M1を押して順番にA B X Yを出す（このボタンを列挙に設定する）、その他の順番に12個のボタンを設定することができます。
上下/左右/A/B/C/X/Y/Z/L/B

④キーを押し終わったら、M1を押すとプログラミングが完了し、LEDが常に点灯します。

【バックマクロクリアボタン】

同時に押し続けた「SELECT」+「M1」キーはプログラミングモードに入り、この時ランプはフラッシュし、この時はいかなる入力値も入力せず、再び「M1」キーを押すと、M1キーの前に設定された入力値を削除することができます。

ハンドルの充電/スリープ/ウェイクアップ機能:

1、ハンドルの充電機能:

低電力時には、LEDが点滅します。

充電中、LEDがゆっくり点滅することを示すメッセージ、満タンになると、ハンドルがオフになります。

2、ハンドルのスリープ/ウェイクアップ/シャットダウン機能:

A、ハンドルは5分以内にボタン操作がないと自動的に電源を切ってスリープします。

B、再使用が必要な場合はホームキーを押して起動すると再接続できます。

C、電源を入れた状態で、ホームボタンを8秒間長く押して、製品は電源を切って、すべてのLEDランプは消灯します。

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.