

尺寸：105x148.5mm 材质：100g书纸 工艺：骑马钉

英语

SEENDA

2.4G Rechargeable Wireless Keyboard and Mouse User Guide

Model: WGJP-038-3

All Seenda products come with a 12-months warranty policy, please do not hesitate to contact us if you have any questions. Our support team will try our best to provide you with a pleasant shopping experience.
Our email: support@seenda.com
Our website: www.seenda.com

What's in Package

1 * Rechargeable Wireless Keyboard;
1 * Rechargeable Wireless Mouse;
1 * Type-C Charging cable;
1 * Nano Receiver (Inserted on the back of the Mouse);
1 * User Guide;

Specification

Operate systems	Windows 7 and above (with USB ports)
Built-in battery capacity	3.7 V / 280mAh
Charging time	2-3hours
Sleep mode	Turn to sleep mode in 10mins of inactivity
Wake up	Press left/right button to wake up the mouse
Battery's lifespan	1000 times of cycles of charging and discharging
Key lifespan	3 million strokes
Standby time	230hours
Continuous working time	60hours of continuous use
Working range	8m (front); 7m (back)
Working current	≤5 mA
Dimensions	107.2 * 60 * 25.5 mm
Weight	70g

Specification of Mouse:

Operate systems	Windows 7 and above (with USB ports)
Built-in battery capacity	3.7 V / 300mAh
Charging time	2-3hours
Sleep mode	Turn to sleep mode in 10mins of inactivity
Wake up	Press left/right button to wake up the mouse
Battery's lifespan	1000 times of cycles of charging and discharging
Key lifespan	3 million strokes
Standby time	230hours
Continuous working time	60hours of continuous use
Working range	8m (front); 7m (back)
Working current	≤5 mA
Dimensions	107.2 * 60 * 25.5 mm
Weight	70g

Overview

Charging

Low Battery Indicator of the Mouse

Power Indicator of the Mouse:
Flashing red: Low battery / Solid red: Charging / Light off: Fully charged.

Typing lags could be caused by low battery, pls charging your keyboard & mouse in time for best performance.

Multimedia Function Keys

Key	Function	Key	Function
Fn +	Fn lock		Previous track
	Play / Pause		Next track
	Mute		Volume -
	Volume +		Browser
	Search		Email
	Favorites		Save
	Setting		Print
	Calculator		Brightness decrease
	Brightness increase		Screen lock

Pls kindly note: The function of F1-F12 (and the keys with blue character) could only be achieved when you typing it with the FN together.

Using

- Remove the USB receiver from the bottom of the mouse;
- Plug the USB receiver into an available USB port of your computer;
- Toggle switch on to use the mouse and keyboard.

Troubleshooting

- Why isn't the keyboard & mouse working?
Make sure the nano receiver is plugged into your device's USB port. If it is still unresponsive, plug the receiver into another USB port on your device.
- How do I wake up the keyboard or the mouse?
The keyboard will turn to sleep mode after 5 seconds of inactivity. Press any key to wake up.
The mouse will turn to sleep mode after 10 minutes of inactivity. Press right/left button to wake up.

Safety Warning

IMPORTANT: To reduce risk of fire, electric shock, or injury, follow these safety instructions.

⚠ Charging Safety: Use only the provided cable. Charge in a well-ventilated, dry area away from inflammable materials.

⚠ Battery Handling: Do not attempt to replace the item's lithium battery. Battery replacement should be conducted by qualified personnel to prevent hazards.

⚠ Heat Exposure: Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.

⚠ Liquid Exposure: Keep the item away from water and liquids. Do not use if wet until thoroughly dried.

⚠ Damage and Leakage: Cease usage and consult customer service if the item is damaged or the battery leaks.

⚠ Correct Disposal: Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.

⚠ Radio Frequency Interference: This device may cause interference with other electronics. Keep a safe distance from sensitive devices.

⚠ Child Safety: Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage.

For further assistance or information, please contact our customer service.
Email: support@seenda.com

EU Declaration of Conformity

Declared Object: 2.4G Rechargeable Wireless Keyboard and Mouse
Model: SK38-3
Rating: 3.7V≈10mA
Input: 5V≈250mA
Place of Production: Made in China
Manufacturer: Shenzhen Hangshi Electronic Technology Co., LTD
E-mail: chen.zhao@seow.cn
Address: Floor 2, Building A1, Zone G, Democratic West Industrial Zone, Democratic Community, Shajing Street, Bao'an District, Shenzhen City, Guangdong Province, China, 518104

European Representative:
Business name: g.L.L. GmbH
Business address: Baumweg 44/46, 55c, 22363, Hamburg, Germany
Email: g.L.L.DE@xbook.com

It is our sole responsibility to declare that the above products are in full compliance with Directive 2014/53/EU, 2011/65/EU (as amended)

Position: Managing Director
Signature:
Date of Sign: 2022.1.5
EU agent name:
Date of Sign: 2022.1.5

德语

SEENDA

2.4G Wiederaufladbare Kabellose Tastatur und Maus Bedienungsanleitung

Modell: SK38-3

Alle Seenda-Produkte werden mit einer 12-monatigen Garantie geliefert. Bitte zögern Sie nicht, uns zu kontaktieren, wenn Sie Fragen haben. Unser Support-Team wird unser Bestes geben, um Ihnen ein angenehmes Einkaufserlebnis zu bieten.
Unsere E-Mail: support@seenda.com
Unsere Website: www.seenda.com

Packliste

1 * Wiederaufladbare kabellose Tastatur;
1 * Wiederaufladbare kabellose Maus;
1 * Typ-C Ladekabel;
1 * Nano-Empfänger (auf der Rückseite der Maus eingesetzt);
1 * Bedienungsanleitung;

Spezifikation

Betriebssystem	Windows 7 und höher (mit USB-Anschlüssen)
Eingebaute Batteriekapazität	3,7 V / 280 mAh
Ladezeit	2-3 Stunden
Schlafmodus	Wechseln Sie in 5 Sekunden Inaktivität in den Schlafmodus
Aufwachen	Drücken Sie eine beliebige Taste, um die Tastatur aufzuwecken
Lebensdauer des Akkus	1000-fache Lade- und Entladezyklen
Tastelebensdauer	3 Millionen Anschläge
Standby-Zeit	200 Stunden
Dauerarbeitszeit	50 Stunden Dauerbetrieb
Arbeitsbereich	8 m (vorne); 7m (zurück)
Arbeitsstrom	≤5 mA
Abmessungen	438,5 * 129 * 18,7 mm
Gewicht	415g

Spezifikation der Maus:

Betriebssystem	Windows 7 und höher (mit USB-Anschlüssen).
Eingebaute Batteriekapazität	3,7 V / 300mAh
Ladezeit	2-3 Stunden
Schlafmodus	Wechseln Sie in 10 Minuten Inaktivität in den Schlafmodus
Aufwachen	Drücken Sie eine beliebige Taste, um die Tastatur aufzuwecken
Lebensdauer des Akkus	1000-fache Lade- und Entladezyklen
Tastelebensdauer	3 Millionen Anschläge
Standby-Zeit	230 Stunden
Dauerarbeitszeit	60 Stunden Dauerbetrieb
Arbeitsbereich	8m (vorne); 7m (zurück)
Arbeitsstrom	≤5 mA
Abmessungen	107,2*60*25,5 mm
Gewicht	70 g

Überblick

Aufladen

Anzeige für niedrigen Batteriestand der Maus

Betriebsanzeige der Maus:
Rot blinkend: Batterie schwach / Rot durchgehend: Aufladen / Licht aus: Voll aufgeladen.

Tipperverzögerungen können durch schwachen Akku verursacht werden. Bitte laden Sie Tastatur und Maus rechtzeitig auf, um die beste Leistung zu erzielen.

Multimedia-Funktionstasten

Taste	Funktion	Taste	Funktion
Fn +	Fn-Sperre		Vorheriges Lied
	Wiedergabe / Pause		Nächstes Lied
	Stummschalten		Lautstärke verringern
	Lautstärke erhöhen		Browser
	Suche		E-Mail
	Favoriten		Speichern
	Einstellung		Drucken
	Rechner		Helligkeit verringern
	Helligkeit erhöhen		Bildschirm sperren

Hinweis: Die blauen Zeichen und die entsprechenden Funktionen der F1-F12-Serie müssen durch Drücken der Taste Fn zusammen mit der entsprechenden Taste gedrückt gehalten werden.

Installation

- Entfernen Sie den USB-Empfänger von der Unterseite der Maus.
- Schließen Sie den USB-Empfänger an einen verfügbaren USB-Anschluss Ihres Computers an.
- Schalten Sie den Schalter ein, um Maus und Tastatur zu verwenden.

Fehlerbehebung

- Warum funktionieren Tastatur und Maus nicht?
Stellen Sie sicher, dass der Nano-Empfänger an den USB-Anschluss Ihres Geräts angeschlossen ist. Wenn es immer noch nicht reagiert, schließen Sie den Empfänger an einen anderen USB-Anschluss Ihres Geräts an.
- Wie wecke ich die Tastatur oder die Maus?
Die Tastatur wechselt nach 5 Sekunden Inaktivität in den Ruhemodus. Drücken Sie eine beliebige Taste, um aufzuwachen.
Die Maus wechselt nach 10 Minuten Inaktivität in den Ruhemodus. Drücken Sie eine beliebige Taste, um aufzuwachen.

Sicherheitswarnung

WICHTIG: Befolgen Sie diese Sicherheitshinweise, um die Gefahr von Bränden, Stromschlägen oder Verletzungen zu vermeiden.

⚠ Sicheres Aufladen: Verwenden Sie nur das mitgelieferte Kabel. Laden Sie das Gerät in einem gut belüfteten, trockenen Bereich und nicht in der Nähe von brennbaren Materialien auf.

⚠ Handhabung der Batterie: Versuchen Sie nicht, die Lithiumbatterie des Geräts selbst zu ersetzen. Der Batteriewechsel sollte von qualifiziertem Personal durchgeführt werden, um Gefahren zu vermeiden.

⚠ Hitzeeinwirkung: Lassen Sie das Gerät nicht in Umgebungen mit hohen Temperaturen oder direktem Sonnenlicht liegen, da dies zu einer Brandgefahr führen könnte.

⚠ Flüssigkeitsexposition: Halten Sie den Artikel von Wasser und Flüssigkeiten fern. Verwenden Sie es nicht, wenn es nass ist, bis es gründlich getrocknet ist.

⚠ Beschädigung und Auslaufen: Stellen Sie den Gebrauch ein und wenden Sie sich an den Kundendienst, wenn der Artikel beschädigt ist oder die Batterie ausläuft.

⚠ Korrekte Entsorgung: Befolgen Sie die örtlichen Vorschriften für die Entsorgung von elektronischen Geräten und Batterien. Entsorgen Sie sie nicht mit dem Hausmüll.

⚠ Radiofrequenz-Interferenz: Dieses Gerät kann Störungen bei anderen elektronischen Geräten verursachen. Halten Sie einen Sicherheitsabstand zu empfindlichen Geräten ein.

⚠ Sicherheit für Kinder: Bewahren Sie den Artikel und seine Komponenten außerhalb der Reichweite von Kindern auf, um die Gefahr des Verschluckens oder Verschluckens von Batterien zu vermeiden. Lassen Sie Kinder das Gerät niemals unbeaufsichtigt handhaben.

VORSICHT: Die Nichtbeachtung der oben genannten Warnhinweise kann zu schweren Verletzungen oder Sachschäden führen.

Für weitere Hilfe oder Informationen wenden Sie sich bitte an unseren Kundendienst.
Email: support@seenda.com

EU KONFORMITÄTSERKLÄRUNG

Produktname: 2.4G Wiederaufladbare Kabellose Tastatur und Maus
Modell: SK38-3
Nennwert: 3.7V≈10mA
Eingang: 5V≈250mA
Produktionsort: Made in China
Hersteller: Shenzhen Hangshi Electronic Technology Co., LTD
E-mail: chen.zhao@seow.cn
Adresse: Floor 2, Building A1, Zone G, Democratic West Industrial Zone, Democratic Community, Shajing Street, Bao'an District, Shenzhen City, Guangdong Province, China, 518104

Europäisch Vertreter:
Business name: g.L.L. GmbH
Business address: The Imperial, 31-33 St Stephens Gardens, Notting H8, London, United Kingdom, W2 3NA
Email: g.L.L.DE@xbook.com

Es liegt in unserer alleinigen Verantwortung zu erklären, dass die oben genannten Produkte der Richtlinie 2014/53/EU, 2011/65/EU (in der jeweils gültigen Fassung) vollständig entsprechen.

Position: Geschäftsführer
Unterschrift:
Datum der Unterzeichnung: 2022.1.5
Name des EU-Agenten:
Datum der Unterzeichnung: 2022.1.5

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.