

使用产品前,请仔细阅读本说明书,并妥善保管!

合格证
质量合格

合格证
质量合格

合格证
质量合格

本品为女性健康产品,多频多速,将带给您多重快感,带给您另类刺激享受!

产品参数

主体结构	硅胶+ABS	产品颜色	紫色
最大振幅	45度角	产品规格	29*104mm
额定电压	5V	额定功率	1000毫瓦
供电方式	USB充电	额定电流	500mA

规格展示 单位:mm

使用说明

1. 清洁产品,避免将产品直接放入水中清洗,避免产品受损;
2. 为了保护您的皮肤,使用的建议在产品上涂抹润滑液;
3. 初次使用,启动频率不宜过大,以免过度的刺激对您的身体造成不适;
4. 根据您的身体感受,进行频率和速度调节;
5. 使用过程中,如有不适,请及时停止使用;
6. 使用完后,请将产品用清水清洗并擦干,置于干燥通风处;
7. 本产品为女性健康产品,请勿随意丢弃,妥善保管。

按键操作

电源开关键
长按电源键3秒,开启产品主体,短按电源键3秒,进行震动频率调节,长按电源键3秒,关闭电源键3秒,关闭电源。

控制键
长按控制键3秒,开启产品主体,短按控制键3秒,进行震动频率调节,长按控制键3秒,关闭电源键3秒,关闭电源。

电源开关键
长按电源键3秒,开启产品主体,短按电源键3秒,进行震动频率调节,长按电源键3秒,关闭电源键3秒,关闭电源。

充电说明
本产品为USB充电,连接设备USB充电接口,充电时指示灯亮起,充电完成指示灯熄灭。

Before using the product, please read this manual carefully and keep it properly!

QC PASS

QC PASS

QC PASS

This product is for female health and comfort products, 10 frequency 10 speed, in vivo Yin contraction exercise, in vitro for replay lifting.

Product parameters

The material	Silicone + ABS	Color	Purple
The name	45°	Specifications	29*104mm
Voltage	5V	Function	10 Frequency 10 Speed
Power Supply	USB	Current	500mA

Specifications unit:mm

Directions For Use

1. Remove The Product And Clean It With Water Or Disinfectant.
2. In Order To Protect Your Skin, It's Recommended To Use Some Slender Lubricant On The Product Before Use.
3. For The First Time, The Using Frequency Should Not Be Too High To Avoid Excessive Stimulation To Your Muscles Causing Discomfort In The Skin.
4. Adjust The Extension Frequency According To Your Own Body Needs.
5. If You Feel Uncomfortable During Use, Please Stop Using Immediately.
6. After Use, Please Clean The Product With Clean Water And Dry It In A Cool And Ventilated Place.
7. When Disposing Products, Try To Dispose Of Them Safely And Do Not Put Them Away At Will.

Keystrokes

The main products

Power switch
Press The Power Button For 3 Seconds To Open The Main Body Of The Product. Short Press The Power Button For 1 Second To Switch The Vibration Frequency Multi-Frequency And Multi-speed Switch. Short Press The Power Button For 3 Seconds To Turn Off The Power.

The controller

Frequency switch key
When the product is in the control state, press this button every time to switch frequency.

Power switch
Press The Power Button For 3 Seconds To Turn On The Remote Control Of The Product. Short Press The Power Button For 1 Second To Stop The Function Of The Main Product And Press The Power Button For 3 Seconds To Turn Off The Power. Function Indicator Light Goes Off.

Charging instructions
Connect the power cable to the USB charging port of the device. The indicator flashes when charging indicator light is always on when charging is completed. If you feel the vibration obviously weakened, please charge in time.

перед употреблением продукции внимательно прочитайте этот проспект и будьте внимательны!

сертификат

сертификат

сертификат

Этот продукт для женщин, предназначен для использования, чтобы дать вам другое ощущение наслаждения!

параметр продукции

материал	силикон	тип корпуса	пластиковый
максимальная частота	45 градусов	стандартная частота	10 "разных"
максимальная мощность	10W	функция	10 частот 10 скоростей
тип питания	USB зарядка	напряжение	5В

спецификация единиц измерения: мм

инструкция по эксплуатации

1. Удалите продукт, очистите его чистой водой или дезинфицирующим раствором.
2. Для защиты вашей кожи, перед употреблением рекомендуется использовать смазочный крем.
3. Первое применение, бережное отношение к частоте не должно быть слишком высоким, чтобы избежать чрезмерного раздражения мышц, вызывая дискомфорт.
4. Регулирование частоты в соответствии с потребностями собственного тела.
5. Если вы чувствуете дискомфорт во время использования, немедленно прекратите использование.
6. После использования, пожалуйста, очистите продукт чистой водой и высушите в проветриваемом месте.
7. При утилизации продукта, пожалуйста, утилизируйте его безопасно, не выбрасывая произвольно.

клавишная операция

основной продукт

ключ питания
Защелкните основной корпус на 3 секунды, чтобы открыть основной корпус. Коротко нажмите основной корпус на 1 секунду, чтобы переключить частоту вибрации и многофункциональный переключатель скорости. Коротко нажмите основной корпус на 3 секунды, чтобы выключить питание.

контроллер

клавиша переключения частоты
Когда продукт находится в режиме контроля, каждый раз нажимайте на клавишу для переключения частоты.

ключ питания
Нажмите основной корпус на 3 секунды, чтобы включить продукт для дистанционного управления. Коротко нажмите основной корпус на 1 секунду, чтобы остановить функцию основного продукта и нажать основной корпус на 3 секунды, чтобы выключить питание.

описание зарядки
Подключите кабель питания к USB-зарядному порту устройства. Светодиодный индикатор мигает при зарядке, индикатор всегда горит, когда зарядка завершена. Если вы чувствуете, что интенсивность вибрации заметно снижается, зарядите устройство вовремя.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.