# 使用说明书
# K30 头盔耳机

## 安装步骤

通过夹子固定安装

步骤1

将产品固定到背夹上，背夹和头盔之分别贴上魔术贴使其固定，把钢夹扣开固定到头盔左侧边缘即可

步骤2

将耳机魔术贴分别贴到头盔内侧适当耳机位置内

步骤3

将镜片分别贴到头盔两侧魔术贴位置（短线镜片贴左边，长线镜片贴右边）

步骤4

将麦克风魔术贴贴到头盔内侧靠近嘴巴位置贴前后麦克风

（整理好接线及内衬）

步骤5


将插头插入耳机接口

步骤6

安装完成

1

## 按键说明




❶ ……FM切台 开机/关机/接听，挂断，拒接电话/暂停/播放/氛围灯开关
❷ ……FM向前搜台 音量+/下一曲
❸ ……FM向后搜台 音量-/上一曲
❹ ……耳机插口
❺ ……充电插口
❻ ……模式切换/语音助手
❼ ……语音助手，HIF模式切换
❽ ……充电显示/蓝牙连接指示灯
❾ ……屏幕

## 操作说明

**开机键**

开机(关机状态下长按3秒,听到"power on",开机键灯闪两秒)

**关机键**

关机(开机状态下长按3秒,听到"Power off",开机氛围灯关闭)

**配对模式**

配对模式(开机状态下开机键灯闪烁,手机蓝牙打开，搜索 K30 ,连接成功后所有氛围灯常亮)

**接听电话**

接听电话(连接状态下来电,单击开机键，接听电话)

2

**终止通话**

终止通话(通话时单击开机键，结束通话)

**拒接电话**

拒接电话(来电时长按开机键2秒，拒接通话)

**音乐播放/暂停**

音乐播放/暂停(音乐状态下单击开机键)

**音乐+键**

音量加(播放音乐时,单击 + 按键)；下一曲(音乐状态下,长按2秒 + 按键)

**音乐-键**

音量减(播放音乐时,单击 - 按键)；上一曲(音乐状态下,长按2秒 - 按键)

**召唤语音助手**

系统模式切换/语音助手键，召唤语音助手

**氛围灯键**

氛围灯开机配对成功后常亮；单击开机键，音乐播放/暂停；三击开机键，氛围灯开启/关闭。

## 蓝牙状态

开机状态(蓝牙连接成功时,氛围灯常亮)
蓝牙断开连接时,主按键灯进入闪烁
低电报警(开机状态下每隔60秒提示一次"电量低")
充电状态(充电时红常亮,充满灯熄灭)

## FM模式

**模式切换**

长按模式键2秒，可切换蓝牙模式和FM模式

**自动搜台**

长按2S V-向前搜索，长按2S V+向后搜索

3

**电台切换**

单击开机键即可切换电台


**音乐+键**

音量加(播放音乐时,单击 + 按键)

**音乐-键**

音量减(播放音乐时,单击 - 按键)

## 注意事项




充电器提供的功率，必须在电子设备所需的最小0.3瓦和最大3瓦之间，才能达到最大充电速度。

4

# Instruction Manual
# K30 helmet headset

## Installation tutorial

Fixed installation by clamps

Step 1



Secure the product to the back clip, back clip, and helmet
Attach Velcro separately to fix it, and pull the seat clip
Simply fix it to the left edge of the helmet

Step 2



Stick the headphone Velcro separately into the
Bluetooth headphone groove on the inside of the helmet

Step 3



Attach the speakers to the Velcro positions
on both sides of the helmet
(Short line horn on the left, long line horn on the right)

Step 4



Attach the microphone Velcro to the inside of the helmet
near the mouth .Paste the microphone
(organize the tidied and lining)

Step 5



Insert the plug into the headphone jack


Step 6



installation is complete

1

## Installation function description




❶ ……Turn on and off/answer,hang up,refuse to answer/pause/ Ambient lights on and off
❷ ……Volume+/Next song
❸ ……Volume-/Previous song
❹ ……Headphone jack
❺ ……Charging socket
❻ ……Voice assistant
❼ ……Ambient light
❽ ……Charging display/Bluetooth connection indicator
❾ ……Screen

## Key operation instructionss

**Power on button**

Power on/in press and hold for 3 seconds in the shutdown state,hear"power on", Ambient light for 1 second blue,green and orange lights.The ambient light is on)

**Boost**

Power off/press and hold for 5 seconds in the power on state,"hearPower off",Ambient light for 1 second

**Pairing mode**

Pairing mode(When the device is powered off,the red /blue,green and orange light blinks,and the phone Bluetooth is turned on to search for K20 ,After connecting the mobile phone,the red, blue,green and orange lights are bright)

**Answer**

Answer the phone/power down in the connection state,short press to answer the phone

2

**Terminate a call**

Terminate a call(short press to end a call)

**Reject call**

Terminate a call(Long press for 2 seconds)

**Music play/pase tap on music**

Terminate a call(short press to end a call)

**Volume+keys**

Volume Plus(when playing music,shortpress)(Next song(when music state, press and hold for 2 seconds)

**Volume - keys**

Volume Plus(when playing music,shortpress) previous track song(when music state,press and hold for 2 seconds)

**Voice assistant**

Single phase voice assistant key, summon voice assistant

**Atmosphere lights**

After successfully pairing the ambient light, it will remain on for a long time; Click the power button to play/pause music)
Press the power button three times to turn on/off the ambient light.

## Bluetooth indications and prompts

Power on status (when Bluetooth connection is successful, the ambient light stays on)

When Bluetooth is disconnected, the blue light flashes
Low battery alarm (prompts "low battery" every 60 seconds when turned on)
Charging status (red light on continuously during charging, fully charged light off)

## FMPattern

**Mode switch**

Press and hold the mode button for 2 seconds to switch between Bluetooth mode and FM mode.

**Auto-scan**

Press and hold 2S V+ to search forward, press and hold 2S V- to search backward.

**Station switching**

Click the power button to switch stations in sequence.

Volume+


Volume+

Volume-

Volume-

3

## Notes




the power delivered by the charger maust be between min
(0.3)Watts required by the radio equipment,and max
(3)Watts in order to achieve the maximum charging speed.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or nilocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

Important: Change or modifications not expressly approved by the manufacturer responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules.Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

4



Insérez la fiche dans la prise casque



Installation terminée

1

le voyant bleu clignote, le voyant d'ambiance reste allumé)

**Clé d'arrêt**

Éteignez (appuyez longuement pendant 5 secondes à l'état allumé, entendez « Power OFF », toutes les lumières d'ambiance sont éteintes)

**Mode d'appariement**

Mode d'appariement (le voyant bleu de la touche d'allumage clignote à l'état allumé, le téléphone Bluetooth est allumé, recherche K30 , tous les voyants d'ambiance s'allument longtemps après la connexion réussie)

**Répondre au téléphone**

Répondre au téléphone (état de connexion mis sous tension, clé d'allumage unique, répondre au téléphone)

2

pleine lumière éteinte)

## FMModèle

**Changement de mode**

Maintenez **l**e bouton de mode enfoncé pendant 2 secondes pour basculer entre **l**e mode B**l**uetooth et **l**e mode FM.

**Recherche automatique de stations**

Maintenez 2S V+ enfoncé pour rechercher vers **l**'avant, maintenez 2S V- enfoncé pour rechercher vers **l**'arrière.

3



Τοποθετήστε το βύσμα στην υποδοχή ακουστικών



η εγκατάσταση ολοκληρώθηκε

4

**Κουμπί τερματισμού**

Απενεργοποίηση (πατήστε και κρατήστε πατημένο για 5 δευτερόλεπτα ενώ η συσκευή είναι ενεργοποιημένη, ακούστε "Απενεργοποίηση", και όλα τα φώτα περιβάλλοντος θα σβήσουν)

**Λειτουργία ζεύξης**

Λειτουργία ζεύγους (όταν το κουμπί τροφοδοσίας είναι ενεργοποιημένο, το μπλε φως αναβοσβήνει, το πλάφωνο είναι ενεργοποιημένο, αναζήτηση για το K30 και όλα τα φώτα περιβάλλοντος παραμένουν ελαφρώς μετά από επιτυχή σύνδεση)

**Απάντηση στο τηλέφωνο.**

Απάντηση τηλεφωνικών κλήσεων (ενεργοποίηση στον συνδέεται, κουμπί ενεργοποίησης λειτουργίας για ενιαία μηχανή, απάντηση τηλεφωνικών κλήσεων)

1

κατά τη διάρκεια της φόρτισης, πλήρως φορτισμένο φως απενεργοποιημένο)

## FMΠρότυπο

**Αλλαγή λειτουργίας**

Κρατήστε πατημένο το κουμπί λειτουργίας για 2 δευτερόλεπτα για εναλλαγή μεταξύ λειτουργίας Bluetooth και λειτουργίας FM.

**Αυτόματη αναζήτηση σταθμών**

Κρατήστε πατημένο 2S V+ για αναζήτηση προς τα εμπρός, κρατήστε πατημένο 2S V- για αναζήτηση προς τα πίσω.

2

3

4