设计版本号	产品名称 | Product name	比例 | scale	日期 | Date	设计师 | Designer	审核 | Audit
Rev_V0_EN	DR-HEC005S_美规UG	1：1	20251224	Beryl/Dove	Matias/Phil

Hesung innovation 和生创新

材质印刷与技术要求	材质: 铜版纸158G，覆哑膜 印刷要求: 双面彩色印刷，图稿清晰。 对折要求: 上下风琴折页 色值要求：蓝 C90 M70 Y0 K0	字体 | Fonts	Manrope	尺寸 | Size	单页尺寸：160mm x 130mm 总长:520mm

*此页删除不做印刷

图纸设计禁止修改，尺寸以实际刀模图为准

160MM

130MM

520MM

折痕线，不印刷

DREO | Smart Misting Fan 765S

User Guide

Model No.: DR-HEC005S
Rated Power: 96W
Input: 120V~60Hz

Scan the QR code to read the full user manual

Only DREO experts give all the support you need

- Faster response.
- Excellent customer support.
- Hassle-free returns.
- Professional product guidance!
- Satisfying after-sales experience.

Reach out to us, it's easy!
(888) 290-1688 Mon - Fri, 9:00 am-5:00 pm PST/PDT
support@dreo.com
www.dreo.com

Getting the Most Out of Your Appliance

Environment Condition	Recommended Fan Speed Levels	Recommended Mist Levels	How It Feels
Air-Conditioned Room 25-26°C/77-79°F, ~60% Humidity	1-8	1-2	Gentle cooling with light moisture for indoor comfort
Hot & Dry 32-33°C/89.5-91.5°F, ~40% Humidity	9-12	3-4	Strong airflow mist for a refreshing relief
Hot & Humid 32-33°C/89.5-91.5°F, ~80% Humidity	9-12	OFF	Best with a window open, it brings a fresh breezy feel
Extra Hot ~35°C/95°F, ~60% Humidity	Turbo Additional fan & mist level boost beyond max settings.		Full-power cooling and misting when heat peaks

Note:
- Place the appliance about 5 ft. (1.5 m) away for the best cooling performance.
- Turn on oscillation or place the appliance sideways for more even cooling.

Filling the Water Tank

1. Remove the water tank from the base.
2. Open the inner water reservoir lid and fill the tank with room temperature water.
3. Return the water tank to its original position.
4. Place the appliance on a flat, level surface, keeping at least 50 cm/20 inches away from walls or any major obstacles.

ATTENTION:
- Do not operate the appliance if the base has not been installed.
- It is recommended to add purified or distilled water to prevent white powder residue from forming.
- Do not add essential oil into the water tank to avoid damage to the tank.
- Do not place the appliance on the carpet or floor directly.
- Direct the mist away from walls, furniture and electrical appliances.
- It is recommended to place a water-resistant mat under the appliance to catch spills and droplets.

LED Display

Normal/Sleep/Auto/Turbo Mode; WiFi Connection; Humidify Mode; Target Humidity; Mist Level Indicator; Low Water Level; Timer; Ambient Humidity; Fan Speed / Humidity Level / Timer Hour

Control Panel

Power Button
- Turn power on/off.

Mode Button
- Switch between Normal/Sleep/Auto/Turbo Mode.
- Long press for 3 seconds to mute/unmute.

Decrease Button
- 1-12 speed levels.

Increase Button
- 1-12 speed levels.

Timer Button
- Select to set a timer (0-12h).
- Long press for 3 seconds to turn the humidity indicator light on/off.

Mist Level Button
- Adjust mist levels across 0-4 levels.

Auto Humidity Button
- Tap to increase the target humidity by 5% (target humidity ranges from 40% to 90%).

Oscillation Button
- Adjust airflow direction.
- Long press for 5 seconds to start network settings and device pairing.

Humidity Indicator Light

The indicator light will change according to your room humidity level.

Light Color	Humidity Level
Blue	≥71%
Green	31-70%
Orange	≤30%

Is The Water Tank Leaking?

Make sure the water tank is securely attached to the base.

Make sure that no essential oil is added into the water tank.

Make sure the appliance is placed on a flat surface.

If the issue persists, please contact customer support.

Connecting to the DREO App

Scan the QR code to download the DREO app.

OR

Download on the App Store / GET IT ON Google Play

Search "DREO" on Google Play or the App Store.

Look for "**Smart Misting Fan 765S**" when connecting your new appliance.

1. Launch the DREO app and sign in or create account.
Tip: Verify your email address to continue.
2. Hold for 5 seconds to start WiFi connection settings.
Tip: The icon will keep flashing when pairing.
3. Tap + Add Device and select **Smart Misting Fan 765S.**
Tip: Enable bluetooth and plug in the appliance.
4. Now you can control the appliance on your app!
Tip: To restart network setup, hold again for 5 seconds.

*To learn more, read the full user manual on www.dreo.com

IMPORTANT SAFETY INSTRUCTIONS

READ ALL CAUTIONARY MARKINGS ON THE APPLIANCE AND SAFETY INSTRUCTIONS IN THE USER MANUAL BEFORE USE.

DO NOT cover the air inlet and outlet while in operation.

DO NOT use the appliance near flammables and combustibles.

General Safety

1. Children should be supervised to ensure that they do not play with the appliance. Cleaning and maintenance shall not be performed by children without supervision.
2. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
3. Use the appliance as described in the user manual only. Any other use not recommended in the user manual may cause fire, electrical shock, or personal injury.
4. This is not a toy. This is an electrical appliance and must be operated and maintained by an adult. In addition to the water to be vaporized, only any additional liquids advised by the manufacturer for cleaning or fragrance shall be used.

Operation Safety

1. Always place this appliance on a firm, flat and level surface to avoid dropping or tilting.
2. Always place this appliance 12 inches (30 cm) away from the wall or wooden furnitures.
3. DO NOT move this appliance while it is on.
4. DO NOT attempt to repair any parts on this appliance. The inside of this appliance contains no user serviceable parts. All servicing should be performed by qualified personnel only.
5. NEVER leave water in the reservoir when the appliance is not in use.
6. DO NOT permit the area around the appliance to become damp or wet. If dampness occurs, turn the output of the appliance down. If the appliance output volume cannot be turned down, use the appliance intermittently. Do not allow absorbent materials, such as carpeting, curtains, drapes, or tablecloths, to become damp.
7. DO NOT immerse in water and any other liquids.
8. DO NOT use the appliance until the base is installed.
9. DO NOT insert your fingers, pencil and any other objects into the grilles or openings while in operation.
10. Warning: Micro-organisms that may be present in the water or in the environment where the appliance is used or stored, can grow in the water reservoir and be blown in the air, causing very serious health risks when the water is not renewed and the tank is not cleaned properly every 3 days.
11. Be aware that high humidity levels may encourage the growth of biological organisms in the environment.
12. Unplug the appliance during filling and cleaning. Empty and clean the appliance before storage. Clean the appliance before next use.
13. Empty the tank and refill it every third day. Before refilling, clean it with fresh tap water or cleaning agents. Remove any scale, deposits, or film that has formed on the sides of the tank or on interior surfaces, and wipe all surfaces dry.
14. After the appliance is filled with water, don't tilt or crash it when place or moving it. If it is necessary to move the appliance, please move it slowly to avoid overflowing. Tilting the appliance during operation is prohibited. If the appliance is tilted and there's water in it, pull off the power plug immediately. Wait until the appliance is completely dry and then you may turn on the unit. Or you may contact professional after-sales personnel to deal with it.
15. Do not place the appliance under high temperature or low temperature. In summer time, the water may be deteriorated and cause ordor, please add clean water in time. In winter time when indoor temperature is below 32°F (0°C), please add warm water into the water tank if you want to use it. After the operation, please use a towel to dry the water tank.

Electricity Safety

1. Make sure that the voltage of your electricity supply is the same as that indicated on the appliance.
2. Always unplug before cleaning or leaving the appliance unused for a long period of time. Keep your hands dry when plugging/unplugging.
3. Do not operate the appliance with a damaged cord or plug. Discard the appliance or return it to an authorized service facility for examination and/or repair.
4. Do not run the cord under carpeting. Do not cover the cord with throw rugs, runners, or similar coverings. Do not route the cord under furniture or appliances. Arrange the cord away from the traffic area and where it will not be tripped over.
5. The appliance shall not be modified by users, such as by adding supplemental filters to the appliance.
6. WARNING: If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.
7. WARNING: To reduce the risk of fire, electric shock or injury to persons, do not use replacement parts that have not been recommended by the manufacturer (e.g. Parts made at home using a 3D printer).
8. WARNING: To Reduce The Risk Of Fire Or Electric Shock, Do Not Use This Fan With Any Solid-State Speed Control Device.
9. This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions and check the product. If the replacement fuse blows, a short-circuit may be present, and the product should be discarded or returned to an authorized service facility for examination and/or repair.
10. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

Cleaning Safety Instructions

1. Always unplug the appliance before any cleaning or maintenance to avoid the risk of fire, electric shock, or injury to persons.
2. Do not immerse in water or get water inside the motor housing.
3. Do not use any chemical agents when cleaning the appliance.
4. Do not let water splash into the air outlets.
5. Do not overfill the water tank due to the potential risk of electric shock.
6. Always remove the water tank before cleaning the rear grille to prevent accidental water contact with electrical components.
7. Empty and clean the appliance before storage. Clean the appliance before next use.
8. Store in a cool, dry place and cover it to protect from dust.

FOR HOUSEHOLD USE ONLY
READ AND SAVE THESE INSTRUCTIONS

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Battery Replacement

1. Remove the battery cover in the direction indicated by the arrow.
2. Replace with two new AAA 1.5V batteries. Make sure that the positive(+) and negative(-) terminals are positioned correctly.
3. Push the battery cover back into place.

WARNING
- Replace with new batteries of the same type when replacement is required.
- Remove the batteries when the remote control is unused for long period of time.
- Do not attempt to dismantle the batteries.
- Do not dispose the batteries in fire, batteries may explode or leak.
- Chemical burn hazard. Keep batteries away from children.
- Do not mix old and new batteries and Do not mix alkaline, standard (carbon-zinc) or rechargeable (ni-cad, ni-mh, etc.) batteries.
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Remove used batteries promptly.

This remote control has no RF circuit.

User Servicing Instructions (Fuse)

This appliance features a fused safety plug that protects against overload or short-circuit situations. If the fuse blows, please cut off power and follow the below instructions or consult a qualified electrician.

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover. Slide open fuse access cover on top of attachment plug towards blades.
3. Remove fuse carefully. Push the fuse from the other side to remove the fuse.
4. Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse.
5. Close fuse cover. Slide closed the fuse access cover on top of attachment plug.

WARNING
Risk of fire. Do not replace attachment plug.
Contains a safety device (fuse) that should not be removed.
Discard product if the attachment plug is damaged.

DREO CUSTOMER CARE
12-MONTH LIMITED WARRANTY

What is Covered
DREO warrants to you that your product will be free from original defects in materials and workmanship for a period of twelve (12) months from the date of your purchase, when you use your product for intended purposes in accordance with this User Manual.
Please retain your proof of purchase. If you do not retain your proof of purchase, your warranty will start two (2) months from the date of manufacture printed on your product label.

What is Not Covered
This limited warranty only applies to the original purchaser of your product and is non-transferable. This warranty is only valid if your product is used in the country in which you originally purchased it. In addition, this warranty will not apply, and DREO will not be liable for any costs, damages, or repairs, in connection with any of the following:
- Accidents or use of your product with inappropriate force;
- Damage or destruction caused by wrong voltage or unstable electric current;
- Normal wear and tear;
- Careless operation or handling, misuse, abuse, neglect, and/or failure to maintain or use your product in accordance with this User Manual;
- Any partially or completely altered, modified and/or dismantled products;
- Reduction in battery discharge time due to battery age or use (as applicable);
- Products with altered or removed serial numbers;
- Clearing any blockages from the product;
- Purchases from retailers and distributors not authorized by DREO to sell this product;
- Defects caused by or resulting from damages from shipping or handling by any third party not authorized by DREO to ship or handle your product; or
- Defects caused by or resulting from repairs, service, improper maintenance, or alteration to your product or any of its components by anyone other than a repair person authorized by DREO.

Any service and customer support that DREO provides to you under this limited warranty will not extend the duration of this limited warranty.

Warranty Limitations and Exclusions
ANY IMPLIED WARRANTIES RELATING TO YOUR PRODUCT, INCLUDING BUT NOT LIMITED TO THE WARRANTY OF MERCHANTABILITY AND THE WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THE LIMITED WARRANTY SET FORTH ABOVE AND ARE OTHERWISE DISCLAIMED. THIS LIMITED WARRANTY SHALL BE THE SOLE REMEDY OF THE PURCHASER OR USER OF THE PRODUCT, AND DREO SHALL NOT BE LIABLE FOR AN ALLEGEDLY DEFECTIVE OR DAMAGED PRODUCT EXCEPT TO REPAIR OR REPLACE IT IN ACCORDANCE WITH THIS LIMITED WARRANTY. DREO WILL NOT BE LIABLE FOR SPECIAL, INCIDENTAL, INDIRECT, CONSEQUENTIAL DAMAGES OR LOSSES OF ANY NATURE THAT YOU MAY INCUR IN CONNECTION WITH YOUR PURCHASE OR USE OF YOUR PRODUCT.
Some jurisdictions do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This limited warranty gives you specific legal rights, and you also may have other rights which vary from jurisdiction to jurisdiction.

Limited Remedies
If your product fails because of an original defect in material and/or workmanship during the warranty period, DREO will repair or replace (in DREO's sole discretion) your product.
To obtain warranty service on your product, contact us at support@dreo.com or at (888) 290-1688 (available from Monday-Friday, 9:00 AM-5:00 PM PST/PDT) for further instructions.
IN THE EVENT OF AN ORIGINAL DEFECT IN MATERIAL AND/OR WORKMANSHIP, TO THE EXTENT PERMITTED BY LAW, THE REMEDIES SET FORTH IMMEDIATELY ABOVE ARE YOUR SOLE AND EXCLUSIVE REMEDIES.

We're Here to Help!
(888) 290-1688 (Mon - Fri, 9:00 am-5:00 pm PST/PDT)
support@dreo.com
www.dreo.com
DREO PTE. LTD.
112 ROBINSON ROAD, #03-01, ROBINSON 112, SINGAPORE 068902

Intertek US

Rev_EN_1.0

正面

背面

线型	说明
黑色实线	裁切线
红色虚线	正折线
绿色虚线	反折线
红色实线	出血位
粉色色块	粘胶区域

图层使用规范：

1、 备注信息图层为非印刷区域，展示印刷物料基础信息。
2、 刀板线、备注工艺、尺寸层展示印刷工艺部分。
3、 画面信息层展示印刷展示图片与文字。

*电子文档为Adobe Illustrator制作

文件格式：model规格类目日期.AI **（为可编辑原始文档）**
文件格式：model规格类目日期.pdf **（为文件转曲不可编辑文档）**

设计师	审核	产品负责人	法规	采购

审稿
检查事项
会签以"√"形式确认
（负责部门范畴确认）

审稿检查事项	
商标规范	
字符高度	
工艺材质	
颜色标识	
产品文案	
条码检查	
厂　　址	
全 成 分	
警告标语	
执行标准	
产品尺寸	
外/内箱尺寸	
OEM信息*	

产品包装信息

请相关部门确认产品、包装等信息！

*OEM信息：
委托方及被委托方信息（名称、地址、邮编、电话、生产许可证、卫生许可证）