

Wireless Bedwetting Alarm & Potty Training Watch



Model: J012

RoHS

Made in China

Introduction to products:

electric quantity

Child lock

Timing button

Vibration

Music + Vibration

Time display

Press the volume short

Press and hold music to switch

Press and hold mode

Indicator light

Urine moisture warning transmitter

Power indicator light

1. Power supply: Long press for 2 seconds to switch the machine on and off.

2. Mode selection: Long press the mode button for 2 seconds, the mode icon on the screen flickers and jumps, press it once to switch mode selection, adjust to the required mode, and then stop blinking for 2 seconds to automatically determine the current mode.

3. Timing setting: Hold down the button for 2 seconds to start the timing, and the time icon on the screen flashes and pulsates. Press the button once to switch between different times. When the time is adjusted to the required time, it will blink for 2 seconds and stop blinking to automatically determine the selected time. After timing is enabled, long press for 2 seconds to turn off the timing function.

4. Electric power and charging: when the electric power is low, the electric power icon flashes red light, indicating the need for charging. When connected to the charger, the red light breathing indicates charging, and when fully charged, the green light is steady on. In normal use, the green light is steady on when the battery is full.

5. Current mode: Vibration, Sound, Sound + Vibration. When the mode is set to this mode, the icon will be always on, and the corresponding light on the screen will automatically turn off after 1 minute of standby. Press any key to wake up.

6. Warning light: when wet urine is triggered, the red light blinks, the beep and vibration are selected according to the mode, and the blue light blinks when the alarm is triggered regularly. There are two kinds of sounds (the sound and vibration are selected according to the mode).

Product operation:

Step 1 Long press the switch

Step 2 Short press to switch modes

Step 3 The icon flashing stops and the mode is selected

Press the volume short

Press and hold music to switch

Step 1 Long press the time icon to flash

Step 2 Short press to switch time

Step 3 When the icon stops blinking, the time has been selected

Child lock icon

Step 1 Press and hold at the same time, the child lock icon lights up, and the child lock mode has been selected

Step 2 Press and hold at the same time to cancel the child lock function

Reminder: The product enters the energy-saving mode within 15 seconds after any operation is completed, Short press any button to wake up, and the icon will light up.

Product Use :

Please wear the product correctly



Please clamp the sensor in a place where it is easy to get wet

Product Specifications:

	classification	Parameter	Note
Basic parameters	The rated voltage	3.7V	
	Charging voltage	5V±1A	
	Rated current (DC)	130mA / 230mA	230mA max
	Rated power (DC)	0.5W / 0.51W	0.5W max
Product parameters	Product size	58*47*16 54*31*16	
	Color box package size	110*90*50	
	Product net weight	12g±3g ±44g	
	The product gross weight	85g	
	Carton size	Outer inch length 61cm width 29.5cm height 34.5cm	

parts list:

Name	Specification	quantity
The host		1
The child machine		1
Charging line	white 62CM	1
The instructions		1

Беспроводная сигнализация для постельной мочеты & Часы для тренировки горшка



Model: J012

RoHS

Made in China

Введение в продукты:

музыка

батарейка

Кнопка режима

Установи время

Музыка + вибрация

Нажмите на короткое количество времени

Нажмите и удерживайте, чтобы включить и выключить

Нажмите Режим регулировки

Индикатор

Уrine moisture warning transmitter

Power indicator light

1. Источник питания: Длительное нажатие в течение 2 секунд, чтобы включить и выключить машину.

2. Выбор режима: Длительное нажатие кнопки режима в течение 2 секунд, значок режима на экране мерцает и прыгает, нажмите его один раз, чтобы переключить выбор режима, перейти в требуемый режим, а затем прекратите мигать на 2 секунды, чтобы автоматически определить текущий режим.

3. Настройка синхронизации: Удерживайте кнопку в течение 2 секунд, чтобы запустить время, и значок времени на экране отключается и пульсирует. Нажмите кнопку один раз, чтобы переключаться между разными временами. Когда время настроено на требуемое время, оно будет мигать в течение 2 секунд и остановится мигать, чтобы автоматически определить выбранное время. После включения синхронизации нажмите и удерживайте время в течение 2 секунд, чтобы отключить функцию синхронизации.

4. Электричество и зарядка: когда электричество низкое, значок питания мигает красным светом, указывая на необходимость зарядки. При подключении к зарядному устройству дыхание красного света указывает на зарядку, а при полной зарядке зеленый свет горит. При нормальном использовании зеленый свет постоянно горит, когда батарея заполнена.

5. Текущий режим: Вибрация, звук, звук + Вибрация: Когда режим установлен в этот режим, значок всегда будет включен, и соответствующий индикатор на экране автоматически выключится после 1 минуты ожидания. Нажмите любую клавишу, чтобы проснуться.

6. Предупреждающий свет: когда срабатывает влажная моча, красный свет мигает, звуковой сигнал и вибрация выбираются в соответствии с режимом, а синий свет мигает, когда сигнал тревоги регулярно срабатывает. Существует два вида звуков (звук и вибрация выбираются в соответствии с режимом).

Product operation:

Шаг 1 Длительное нажатие на переключатель

Шаг 2 Короткое нажатие для переключения режимов

Шаг 3 Мигающий значок останавливается, и выбран режим

Нажмите на короткое количество громкости

Нажмите и удерживайте музыку, чтобы переключиться

Шаг 1 Длительное нажатие на значок времени, чтобы мигать

Шаг 2 Короткое нажатие для переключения времени

Шаг 3 Когда значок перестает мигать, время было выбрано

Значок дочернего замка


Шаг 1 Нажмите и удерживайте одновременно, значок childlock загорится, и был выбран режим блокировки ребенка.

Шаг 2 Нажмите и удерживайте одновременно, чтобы отменить функцию блокировки детей

Напоминание: Продукт переходит в режим энергосбережения в течение 15 секунд после завершения любой операции. Короткое нажатие на любую кнопку, чтобы проснуться, и значок загорится

Product Use :

Пожалуйста, носите изделие правильно



Пожалуйста, зажмите датчик в месте, где его легко намотать

Технические характеристики продукта

	Классификация	Параметры	Примечание
Основные параметры	Номинальное напряжение	3.7V	
	Напряжение зарядки	5V±1A	
	Номинальный ток (постоянный ток)	130mA / 230mA	230mA max
	Номинальная мощность постоянного тока	0.5W / 0.51W	0.5W max
Параметры продукта	Габариты	58*47*16 54*31*16	
	Габариты упаковки	110*90*50	
	Вес нетто	12g±3g ±44g	
	Вес брутто	85g	
Размер коробки	Внешний размер	длина 61 см ширина 29.5 см высота 34.5 см	

Список запасных частей

Название	Спецификация	Количество
Хост-устройство		1
Дочернее устройство		1
Зарядный провод	белый 62CM	1
Инструкция		1

英文正面

俄文背面

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.