태민 공식 응원봉 V2 QSG

재질 : 종이
사이즈 : 425 × 95 (mm)

	대지 WHITE
	내용 인쇄 BLACK

95 mm

TAEMIN

TAEMIN OFFICIAL LIGHT STICK V2
QUICK START GUIDE & QUALITY ASSURANCE

QUICK START GUIDE

건전지 교체

제품의 하단 건전지 커버를 돌려서 분리합니다. 3개의 건전지 방향을 잘 확인하고 삽입합니다.



1. 본체 하단 스틱형 커버를 돌려 열어주세요.
2. 동봉된 교체용 배터리 커버로 교체해주세요.

버튼 사용법

- 모드 변경 : 버튼을 누르면 아래와 같은 순으로 LED 모드가 변경됩니다.

✦ LONG PRESS - LIGHT OFF

CLICK	1	2	3	4	5	6	7
OBJECT LIGHT	WHITE	YELLOW	MINT	YELLOW	MINT	YELLOW / MINT FLOW	YELLOW / MINT FLOW
MAIN LIGHT	WHITE	YELLOW	MINT	YELLOW / MINT FLOW	YELLOW / MINT FLOW	YELLOW	MINT
CLICK	8	9	10	11	12	13	
OBJECT LIGHT	YELLOW	YELLOW	MINT	MINT	WARM AMBER	WARM WHITE	
MAIN LIGHT	YELLOW BLINK	YELLOW FLICKER	MINT BLINK	MINT FLICKER	WARM AMBER	WARM WHITE	

- 종양 제어 오드 : 배터리를 제경하고 공연장에 입장하신 후, 버튼을 눌러 응원봉의 LED가 켜진 상태로 만들어 주세요.
이 상태에서 방도의 버튼 조작 없이 장시 기간(시)이 경과 제어를 통해 자동으로 제어됩니다.
(공연장에서 종양 제어로 제어가 시작되면 응원봉의 버튼을 눌러 색상 변경을 할 수 없습니다.)

(!) 주의
건전지 소켓을 거꾸로 넣으면 응원봉이 동작하지 않고, 소켓의 접촉부가 파손될 수 있습니다.
AAA 알카라인 건전지를 사용하세요. 망간 건전지를 사용하지 마세요.
여러 공연 시 새 알카라인 건전지를 사용하세요.
새 건전지와 사용한 건전지를 같이 사용하지 마세요.
다른 제조사의 제품을 같이 사용하지 마세요.

QUALITY ASSURANCE

품질 보증서

- 본 제품은 엄밀한 품질 관리와 검사 과정을 거쳐 만들어진 제품입니다.
- 보증 기간은 구입한 날로부터 6개월이며, 보증 기간이 지난 경우 A/S가 불가합니다.
- A/S를 이용하실 때에는 반드시 본 보증서와 구매 영수증을 제시하시기 바랍니다. (온라인 구매 시, 사이트 구매 내역서 첨부)
- 제품 A/S 접수에는 고객 부담입니다. (왕복 배송비)
- 보증서는 대한민국 내에서만 유효합니다.
- 제품 외관의 흠집이나 이물질이 있는 경우, 미사용 제품에 한하여 구매 후 7일 이내 교환 및 반품이 가능합니다.
- 보증 기간 6개월 이내라도 정상적인 작동시 고객의 부주의 및 과실, 천재지변, 분해나 수정 등으로 인해 발생하는 제품의 고장은 A/S 대상에서 제외합니다.
- 공식 판매처에서 구매하지 않은 제품이나 부품의 사용으로 인해 발생한 문제에 대해서는 보증 기간 이내라도 A/S 대상에서 제외합니다.
- 본 제품의 아웃박스는 제품보호용으로 제작되었으므로 이사한 흠집, 변색 등의 사유로 교환/반품은 불가합니다.

보증 내용

동작 불량 A/S
- PCB 불량에 의한 동작 불량
- 스위치 접점 불량에 의한 동작 불량

건전지 소켓 유상 A/S
- 건전지 소켓 파손 및 부식에 의한 동작 불량
- 건전지 소켓은 보증 기간이 지난 후에도 유상A/S 가능합니다.

주의

- 정식 위탁처 있는 직은 부품을 포함할 수 있습니다.
- 제품을 물에 담그지 마십시오.
- 제품이 동작 중일 때 발생 부분을 눈으로 확석로 바라보지 마십시오.
- 건전지 누수방을 확인하시고 올바른 방향으로 넣어주세요.
- 사용한 건전지와 새 건전지를 함께 사용하지 마십시오.
- 지시문안이나 고온 그리고 습한 장소에 보관하지 마십시오.
- 제품이 손상될 경우 사용을 중지하십시오.
- 분해하거나 개조하지 마십시오.
- 사용하지 않거나 방전 시에는 건전지를 제거해 주십시오.
- 건전지 전항이 낮을 경우에는 LED가 동작 중 점주다가 꺼집니다. 새 알카라인 건전지로 교환해주세요.
- 제품의 소프트웨어 버전 및 기능의 제조사의 사정에 따라 다를 수 있으며, 사용자에게 사전 공지 없이 변경될 수 있습니다.

A/S가 불가능한 소비자 과실 부분

- 외부의 충격에 의한 기구 및 회로 부품 파손의 경우
- 잘못 건전지 사용에 의한 회로부 파손의 경우
- 동작 상태에서 제품을 물에 넣거나, 우천 시 사용 후 기기 내부에 습기가 찬 경우

QUICK START GUIDE

Batteries replacement

Rotate the battery cover on the bottom of the product to remove it. Insert batteries, making sure the polarity is correct.



1. Twist the stick battery cover at the bottom of the product to remove it.
2. Replace it with the included replacement battery cover.

How to use the power button

- Normal Mode : Press the button to change the LED mode in order of

✦ LONG PRESS - LIGHT OFF

CLICK	1	2	3	4	5	6	7
OBJECT LIGHT	WHITE	YELLOW	MINT	YELLOW	MINT	YELLOW / MINT FLOW	YELLOW / MINT FLOW
MAIN LIGHT	WHITE	YELLOW	MINT	YELLOW / MINT FLOW	YELLOW / MINT FLOW	YELLOW	MINT
CLICK	8	9	10	11	12	13	
OBJECT LIGHT	YELLOW	YELLOW	MINT	MINT	WARM AMBER	WARM WHITE	
MAIN LIGHT	YELLOW BLINK	YELLOW FLICKER	MINT BLINK	MINT FLICKER	WARM AMBER	WARM WHITE	

- Central Control Mode : After entering the concert hall with a lightstick equipped with 3 AAA size batteries, press the button to turn the LED light on. Then it will be controlled automatically. While it is being controlled at the concert hall, you cannot change the color by pressing the button.

(!) Caution
If the battery socket is inserted upside down, the light stick may not work and the terminal of the socket may be damaged.
Use AAA alkaline batteries. Do not use manganese batteries.
Insert new alkaline batteries for each performance.
Do not use new and used batteries together.
Do not use batteries from different manufacturers together.

QUALITY ASSURANCE

Warranty of product

- This product is manufactured through strict quality control and inspection process.
- The warranty period is six months from the date of purchase.
C/S is not available if the warranty period has been passed.
- Please present this certificate and purchase receipt when you ask for C/S.
(If purchased online, attach the purchase statement.)
- The customer service application fee should be paid by the customer. (Round-trip shipping fee etc.)
- The warranty is valid only in Korea.
- If there are any defects or foreign substances on the appearance of the product, you can get exchange or return within 7 days after purchase only for unused products.
- Even within 6 months of warranty period, product failures caused by normal abrasion, customer carelessness and negligence, natural disaster, disassembly or modification are excluded from the C/S list.
- For problems caused by the use of products or parts not purchased from official stores, Even if it is within warranty period, it will not be subject to warranty.
- The outer box of this product is designed for product protection, so exchange/return is not possible due to minor scratches or discoloration.

Contents of warranty

Malfunction C/S
- Operation problems due to PCB failure.
- Operation problems due to bad contact of switch.

The battery socket paid C/S
- The battery socket malfunction due to breakage or corrosion.
- The battery socket can be paid for after the warranty period.

Caution
- May contain small parts with risk of suffocation.
- Do not put the product into water.
- Do not look at LED part when the light stick is on.
- The batteries should be inserted with the correct polarity.
- Do not use used batteries with new batteries.
- Do not store in direct sunlight, high temperature and humid place.
- If the product is damaged, please stop using it.
- Do not disassemble or remodel.
- Remove the batteries when the product is not in use or discharging.
- If the battery power is low, the LED stops working and then goes out. Then change it for new alkaline batteries.
- The software version and function of the product may vary depending on the manufacturer's circumstances and change without prior notice to the use.

The following are consumer negligence which cannot get C/S

- In case of breakage of mechanism and circuit parts due to external impact.
- In case of circuit breakage due to use of bad batteries.
- In case of the product is put in water during operation, or the inside of device is damp after use in rainy weather.

QUICK START GUIDE

更换电池

旋转产品底部的电池盖并将其取下。确认好极性后装入电池。





1. 旋转产品底部的手柄电池盖并将其打开。
2. 更换为随附的替换电池盖。

使用按钮

- 模式变更 : 按下按钮,LED模式将按照以下顺序改变。

✦ LONG PRESS - LIGHT OFF

CLICK	1	2	3	4	5	6	7
OBJECT LIGHT	WHITE	YELLOW	MINT	YELLOW	MINT	YELLOW / MINT FLOW	YELLOW / MINT FLOW
MAIN LIGHT	WHITE	YELLOW	MINT	YELLOW / MINT FLOW	YELLOW / MINT FLOW	YELLOW	MINT
CLICK	8	9	10	11	12	13	
OBJECT LIGHT	YELLOW	YELLOW	MINT	MINT	WARM AMBER	WARM WHITE	
MAIN LIGHT	YELLOW BLINK	YELLOW FLICKER	MINT BLINK	MINT FLICKER	WARM AMBER	WARM WHITE	

- 中央控制模式 : 连接电池进入会场后,将按钮按点亮LED。
在此状态下不进行任何操作,到满已中央控制自动控制灯效。
(在会场内)通过中央控制模式自动控制时,无法变换应援棒的颜色。

(!) 注意
如果将电池装反,将无法启动,并且插座的接触部分有可能会损坏。
请使用AAA碱性电池. 请勿使用锰电池。
每次登录会时都使用新电池。
请使用新的碱性电池进行各种性电池。
请勿将新电池与旧电池混合使用。

FCC

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with RF exposure requirement.

FCC ID : 2BQUK-TAEMINV2
Freq : LE : 2400 ~ 2483.5 MHz
433MHz Rx Only

상 호 : (주)코번글로벌
기자재 명칭 : OFFICIAL LIGHT STICK
모델명 : TAEMIN OFFICIAL LIGHT STICK V2
정격전압 : 4.5V
제조자 : SHENZHEN KONIA TECHNOLOGY CO.,LTD
제조국가 : 중국
R-R-COg-BLS-P.IDA-110

005-103960

A/S 접수방법

미사용 제품 또는 해능합에 따라 정상적으로 사용 중 발생한 문제에 대해서 구매처 A/S 접수처로 연락해 주세요.
만약, 구매처 A/S 접수처와 연락이 되지 않으시면 아래 접수처 전화/이메일로 연락 주시면 확인 후 안내해 드리겠습니다.

보증 책임자 : (주)코번글로벌
A/S 주소 : 한기도 남양주 와부읍 고래산로 122번길 21
E-mail : kgjhotlick@coganglobal.com
전화 : 1544-4205 (안내 내용을 들으시고 2번 공식 응원봉 문의를 눌러주세요.)

구매 정보	구매처	구매일
고객란	이름	전화
	주소	

TAEMIN

95 mm

85 mm | 85 mm | 85 mm | 85 mm | 85 mm | 85 mm