Quick Start Guide

F21

Mini Printer

EN DE

English

1. Product Introduction

1.1 Packing List

Selfadhesive Paper Roll × n

The quantity and specifications of the paper roll(s) are tailored to the package you've chosen.

1.2 Printer Parts Instruction





2. Getting Started

2.1 Downloading the App

Search for the "FaithTag" app on App Store® or Google Play™ for download and installation.

FaithTag

Download on the App Store

GET IT ON Google Play

FaithTag

2.2 User Guide

Before starting printing, please ensure that the paper roll is properly tucked into the paper compartment. For detailed instructions, refer to the manual section "3. Replacing the Paper Roll".

01 To turn on the printer, long press the Power Button for three seconds until the Indicator Light is on.

02 Open the "FaithTag" app.

03 Grant permissions.

04 Click [Connect] on the top.

05 Connection complete. Tap the homepage to view scriptures.

06 View scripture details, then tap Print.

07 Access preview, then tap [Print].

08 Printing is completed.

09 Tear off the label along the Paper Cut.

10 Remove the backing.

11 Stick the label onto a dry, flat surface.

The software interface is for reference only. Please refer to the actual operating page for accurate information.

3. Replacing the Paper Roll

12 Take out a brand new paper roll.

Please skip this step if the paper roll you have is not newly purchased and boxed.

13 Push the Cover Open Button towards the arrow to take out the Paper Roll Spindle.



14 Pull movable damper to remove the paper roll to be replaced.



Some paper rolls include tubes. Remove the paper tube after running out.

15 Insert one section of the spindle into the paper roll to be installed.

16 Reinstall the Movable Damper and push it to the edge of the paper roll.



17 Remove the Anti-loosening Sticker from the paper roll.

18 Place the paper roll in the Paper Compartment.

19 Pull the Paper Roll out until it extends beyond the Paper Output Slot, and then close the Top Cover.

4. Additional Instructions

4.1 Button Instructions

Button Type	Operation	Function
Power Button	Long press for 3s	Power on/off
	Double press when printer is on	Print a selftest page

4.2 Indicator Light Instructions

Status	Meaning	Advised Action
Solid White Light	Functioning Fully Charged in the on state	/
Lights out	Fully charged in the off state	/
Slow Flashing White Light	Charging	/
White light is flashing quickly	No paper installed	Install paper
	Printer overheated	Pause printing for 5~10 min
	Top Cover open	Close Top Cover
	Low battery	Charge battery for 1h (or at least 20 min for quick usage)
No light indication After long press of Power Button for 3s	Battery depleted	Charge for 2~3 hours

5. Safety Instructions

5.1 Manual Cutter and Print Head Instructions



Warning: Sharp edges on Manual Cutter! Do not touch the edges.

Warning: HOT component! Touching it when it is hot can cause burns to your fingers. Please wait for at least 30 minutes after turning off the power before touching it.

5.2 Charging Instructions

1. Please prepare your own power adapter (DC 5V/2A) with a Type-A port.
2. Insert the Type-C end (flat end) of the USB cable into F21's Type-C Charger Port and plug the Type-A end (wide end) into the Type-A port of the power adapter.
3. When the printer is charging, please check the status of the Indicator Light. When the Indicator Light is charging, the indicator light will be flashing slowly with a "white light".
4. Please charge for at least 20 minutes to meet quick usage; charging for 2-3 hours will complete the charging, or the following two states indicate full charge: when turned on, the indicator light stays "white"; when turned off, the light goes out.
5. As the printer may heat up during charging, avoid placing it on materials such as cotton or linen.
6. Once the battery is fully charged, please unplug the charger promptly.

Avoid using the printer while charging. Using the printer while charging may lead to reduced charging speed, compromised print quality, and shortened battery life.

5.3 Cleaning and Maintenance

Please make sure the printer is turned off before performing any cleaning or maintenance.

If you encounter issues such as blank lines, blurry print, or missing characters, it may be caused by dirt on the Print Head. Please follow these steps.

1 If you have just finished printing, wait for at least 30 minutes for the Print Head to cool down completely.

2 Use a cotton swab dipped in alcohol or a print head cleaning pen (purchased separately) to gently wipe the surface of the Print Head about 5 times to remove any dust and stains.

3 Wait 5-10 minutes for the alcohol to evaporate completely. Thus, the cleaning is done, and you can continue using the printer.



6. Information to User

6.1 FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely tocause harmful interference in which case the user will be required to correct the interference at his own expense.

The device has been evaluated to meet general RF exposure statement.

The device can be used in portable exposure condition without restriction.

6.2 ISED NOTICE(Canada)

~English:

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

IC RF exposure statement:

The device has been evaluated to meet general IC RF exposure requirement. The device can be used in portable exposure condition without restriction.

~French:

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes :

(1) L' appareil ne doit pas produire de brouillage.

(2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

IC Déclaration d'exposition aux RF:

L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF d'IC. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

WARNING

Please pay attention to electrical safety. Do not disassemble, crush or puncture the battery. This product is not a toy.

Bitte achten Sie auf elektrische Sicherheit. Zerlegen, zerquetschen oder durchstechen Sie die Batterie nicht. Dieses Produkt ist kein Spielzeug.

Veuillez noter la sécurité électrique. Ne pas démonter, écraser ou piquer la batterie. Ce produit n'est pas un jouet.

Si prega di prestare attenzione alla sicurezza elettrica. Non smontare, schiacciare o perforare la batteria. Questo prodotto non è un giocattolo.

Preste atención a la seguridad del consumo de electricidad. No retire, aplaste ni perfore la batería. Este producto no es un juguete.

Lütfen elektrik güvenliğine dikkat edin. Bateriyi değiştirme, ezma veya yumuşatma. Bu ürün oyuncak değil.

Por favor, preste atenção à segurança elétrica. Não desmonte, esmague ou perfure a bateria. Este produto não é um brinquedo.

Proszę zwrócić uwagę na bezpieczeństwo elektryczne. Nie demontuj, nie miażdż ani nie przebijaj akumulatora. Ten produkt nie jest zabawką.

Warning: Operation of this equipment in a residential environment could cause radio interference.

Special Notes

The company assumes full responsibility for the revision and explanation of this manual, exercising utmost diligence to guarantee its accuracy. Nevertheless, please note that any technical improvements to the product, accessories, software interfaces, etc. in this manual serve solely as illustrations and references. Due to product updates and upgrades, the actual product may vary slightly from the images. Please refer to the physical product for accurate representations.

Quick Start Guide F21 Mini Printer EN DE English 1. Product Introduction 1.1 Packing List Printer ×1 Quick Start Guide ×1 Type-C Cable ×1 Paper Roll Spindle ×1 Selfadhesive Paper Roll × n The quantity and specifications of the paper roll(s) are tailored to the package you've chosen. 1.2 Printer Parts Instruction Top Cover Indicator Light Power Button Paper Output Slot Type-C Charger Port Reset Hole Print Head Paper Roll Paper Roll Spindle Paper Compartment Cover Open Button 2. Getting Started 2.1 Downloading the App Search for the "FaithTag" app on App Store® or Google Play™ for download and installation. FaithTag Download on the App Store GET IT ON Google Play FaithTag 2.2 User Guide Before starting printing, please ensure that the paper roll is properly tucked into the paper compartment. For detailed instructions, refer to the manual section "3. Replacing the Paper Roll". 01 To turn on the printer, long press the Power Button for three seconds until the Indicator Light is on. 02 Open the "FaithTag" app. 03 Grant permissions. 04 Click [Connect] on the top. 05 Connection complete. Tap the homepage to view scriptures. 06 View scripture details, then tap Print. 07 Access preview, then tap [Print]. 08 Printing is completed. 09 Tear off the label along the Paper Cut. 10 Remove the backing. 11 Stick the label onto a dry, flat surface. The software interface is for reference only. Please refer to the actual operating page for accurate information. 3. Replacing the Paper Roll 12 Take out a brand new paper roll. Please skip this step if the paper roll you have is not newly purchased and boxed. 13 Push the Cover Open Button towards the arrow to take out the Paper Roll Spindle. 14 Pull movable damper to remove the paper roll to be replaced. Movable Damper Some paper rolls include tubes. Remove the paper tube after running out. 15 Insert one section of the spindle into the paper roll to be installed. 16 Reinstall the Movable Damper and push it to the edge of the paper roll. Movable Damper 17 Remove the Anti-loosening Sticker from the paper roll. 18 Place the paper roll in the Paper Compartment. 19 Pull the Paper Roll out until it extends beyond the Paper Output Slot, and then close the Top Cover. Paper Output Slot 4. Additional Instructions 4.1 Button Instructions Button Type Operation Function Power Button Long press for 3s Power on/off Double press when printer is on Print a selftest page 4.2 Indicator Light Instructions Status Meaning Advised Action Solid White Light Functioning Fully Charged in the on state / Lights out Fully charged in the off state / Slow Flashing White Light Charging / White light is flashing quickly No paper installed Install paper Printer overheated Pause printing for 5~10 min Top Cover open Close Top Cover Low battery Charge battery for 1h (or at least 20 min for quick usage) No light indication After long press of Power Button for 3s Battery depleted Charge for 2~3 hours 5. Safety Instructions 5.1 Manual Cutter and Print Head Instructions Manual Cutter Print Head Warning: Sharp edges on Manual Cutter! Do not touch the edges. Warning: HOT component! Touching it when it is hot can cause burns to your fingers. Please wait for at least 30 minutes after turning off the power before touching it. 5.2 Charging Instructions 1. Please prepare your own power adapter (DC 5V/2A) with a Type-A port. 2. Insert the Type-C end (flat end) of the USB cable into F21's Type-C Charger Port and plug the Type-A end (wide end) into the Type-A port of the power adapter. 3. When the printer is charging, please check the status of the Indicator Light. When the Indicator Light is charging, the indicator light will be flashing slowly with a "white light". 4. Please charge for at least 20 minutes to meet quick usage; charging for 2-3 hours will complete the charging, or the following two states indicate full charge: when turned on, the indicator light stays "white"; when turned off, the light goes out. 5. As the printer may heat up during charging, avoid placing it on materials such as cotton or linen. 6. Once the battery is fully charged, please unplug the charger promptly. Avoid using the printer while charging. Using the printer while charging may lead to reduced charging speed, compromised print quality, and shortened battery life. Power Adapter with Type-A Port (not included) DC 5V/2A USB Type-C Port USB Type-A Port 5.3 Cleaning and Maintenance Please make sure the printer is turned off before performing any cleaning or maintenance. If you encounter issues such as blank lines, blurry print, or missing characters, it may be caused by dirt on the Print Head. Please follow these steps. 1 If you have just finished printing, wait for at least 30 minutes for the Print Head to cool down completely. 2 Use a cotton swab dipped in alcohol or a print head cleaning pen (purchased separately) to gently wipe the surface of the Print Head about 5 times to remove any dust and stains. 3 Wait 5-10 minutes for the alcohol to evaporate completely. Thus, the cleaning is done, and you can continue using the printer. Print Head 6. Information to User 6.1 FCC WARNING This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely tocause harmful interference in which case the user will be required to correct the interference at his own expense. The device has been evaluated to meet general RF exposure statement. The device can be used in portable exposure condition without restriction. 6.2 ISED NOTICE(Canada) ~English: This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. IC RF exposure statement: The device has been evaluated to meet general IC RF exposure requirement. The device can be used in portable exposure condition without restriction. ~French: L' émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d' Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L' exploitation est autorisée aux deux conditions suivantes : (1) L' appareil ne doit pas produire de brouillage. (2) L' appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement. IC Déclaration d'exposition aux RF: L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF d'IC. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction. WARNING Please pay attention to electrical safety. Do not disassemble, crush or puncture the battery. This product is not a toy. Bitte achten Sie auf elektrische Sicherheit. Zerlegen, zerquetschen oder durchstechen Sie die Batterie nicht. Dieses Produkt ist kein Spielzeug. Veuillez noter la sécurité électrique. Ne pas démonter, écraser ou piquer la batterie. Ce produit n'est pas un jouet. Si prega di prestare attenzione alla sicurezza elettrica. Non smontare, schiacciare o perforare la batteria. Questo prodotto non è un giocattolo. Preste atención a la seguridad del consumo de electricidad. No retire, aplaste ni perfore la batería. Este producto no es un juguete. Lütfen elektrik güvenliğine dikkat edin. Bateriyi değiştirme, ezma veya yumuşatma. Bu ürün oyuncak değil. Por favor, preste atenção à segurança elétrica. Não desmonte, esmague ou perfure a bateria. Este produto não é um brinquedo. Proszę zwrócić uwagę na bezpieczeństwo elektryczne. Nie demontuj, nie miażdż ani nie przebijaj akumulatora. Ten produkt nie jest zabawką. Warning: Operation of this equipment in a residential environment could cause radio interference. Special Notes The company assumes full responsibility for the revision and explanation of this manual, exercising utmost diligence to guarantee its accuracy. Nevertheless, please note that any technical improvements to the product, accessories, software interfaces, etc. in this manual serve solely as illustrations and references. Due to product updates and upgrades, the actual product may vary slightly from the images. Please refer to the physical product for accurate representations.

Kurzanleitung

F21

Mini-Drucker

EW DE

Deutsch

1. Produktübersicht

1.1 Lieferumfang

Selbstklebende Etikettenrolle × n

Die Anzahl und Spezifikationen der Etikettenrolle entsprechen dem bestellten Set.

1.2 Druckerkomponenten





2. Schnellstart

2.1 App herunterladen

Suchen Sie im App Store® oder Google Play™ Store nach der App „FaithTag" und laden Sie sie herunter und installieren Sie sie.

FaithTag

Download on the App Store

GET IT ON Google Play

FaithTag

2.2 Verwendungshinweise

Stellen Sie vor dem Druckbeginn sicher, dass das Papierrolle korrekt in das Fach eingelegt ist. Detaillierte Anweisungen finden Sie im Handbuch unter „3. Papierrolle wechseln".

01 Halten Sie Taste Ein-/Ausschalten 3 Sekunden lang gedrückt, bis die Anzeige leuchtet.

02 Öffnen Sie die App „FaithTag".

03 Informationen autorisieren.

04 Klicken Sie oben auf[Verbinden].

05 Verbindung hergestellt. Tippen Sie auf die Startseite, um die Heilige Schrift anzuzeigen.

06 Heilige Schrift anzeigen, dann [Drucken] antippen.



07 Vorschau öffnen, dann [Drucken] antippen.

08 Drucken abgeschlossen.



09 Reißen Sie das Etikett entlang des Ausgabeschlitzes ab.



10 Trägerpapier entfernen.



11 Kleben Sie das Etikett auf eine trockene und ebene Oberfläche.

Die Software-Oberfläche dient nur zur Veranschaulichung. Bitte beachten Sie die tatsächliche Betriebsseite für genaue Informationen.

3. Etikettenrolle wechseln

13 Neue Etikettenrolle herausnehmen.

Ignorieren Sie diesen Schritt, wenn es sich nicht um eine brandneue Etikettenrolle handelt, die Sie gerade gekauft wird.

14 Ziehen Sie die Deckelöffnungstaste in Pfeilrichtung, um den Papierrollenhalter herauszunehmen.

15 Ziehen Sie die bewegliche Anschläge heraus und entfernen Sie die zu erwartende Papierrolle.

Einige Papierrollen enthalten Papierreste, die nach Gebrauch entfernt werden müssen.

16 Legen Sie die Etikettenrolle ein.

17 Die bewegliche Anschläge befestigen und festziehen.

Die bewegliche Anschläge

18 Entfernen Sie den Schutzaufkleber.

19 Legen Sie die Etikettenrolle in das Papierfach ein.

20 Ziehen Sie die Etikettenrolle heraus, und schließen Sie das Papierfach, wenn sie über den Ausgabeschlitz hinausragt.

4. Mehr Hilfe

4.1 Tasten

Tastentyp	Bedienen	Funktion
Taste Ein-/Ausschalten	3 Sekunden lang drücken	Ein-/Ausschalten
	Doppelklicken im eingeschalteten Zustand	Testseitendruck

4.2 Anzeigelampe

Status	Beschreibung	Bedienen
Die weiße Anzeige ist konstant an	Richtig funktionieren / Im eingeschalteten Zustand vollständig aufgeladen	/
Das LICHT ist aus	Im ausgeschalteten Zustand vollständig aufgeladen	/
Weißes LICHT blinkt langsam	Wird aufgeladen	/
	Kein Papier eingelegt	Legen Sie Papier ein
Weißes LICHT blinkt schnell	Drucker überhitzt	Druckpause für 5 bis 10 Minuten
	Öffnen Sie den Gehäusedeckel	Schließen Sie den Gehäusedeckel

Status	Beschreibung	Bedienen
Weißes Licht blinkt schnell	1 Stunde aufladen (kann bis zu dreimal benötigen, um vollständig aufgeladen zu werden)	/
Taste Ein/Ausschalten 3 Sekunden lang gedrückt und die Anzeige leuchtet nicht	Akku schwach	1 bis 3 Stunden lang aufladen
	Akku leer	

5. Sicherheitshinweise

5.1 Manueller Abschneidevorrichtung und Druckkopf

Warnung: Nicht berühren wegen der scharfen Kanten.

Warnung: Heißes Bauteil! Beim Berühren dieses Bauteils können Verbrennungen an den Fingern auftreten. Bitte warten Sie eine halbe Stunde nach dem Ausschalten des Druckers, bevor Sie das Bauteil berühren.

5.2 Ladeanweisungen

1. Bitte beschaffen Sie sich einen 5V DC/2A Gleichstromadapter mit einem Typ-A-Anschluss.
2. Verbinden Sie das USB-Ladekabel Typ-C (flaches Ende) mit dem Typ-C-Ladeanschluss des F21-Druckers. Verbinden Sie das USB-Ladekabel Typ-A (breites Ende) mit dem Typ-A-Anschluss des Netzadapters.
3. Wenn der Drucker aufgeladen werden muss, überprüfen Sie bitte den Status der Drucker-Statusanzeige. Wenn der Drucker aufgeladen wird, blinkt die Anzeigeleuchte langsam mit einem "weißen Licht".
4. Bitte laden Sie mindestens 20 Minuten lang auf, um eine schnelle Verwendung zu ermöglichen. Die Aufladung dauert 2-3 Stunden oder die folgenden zwei Zustände weisen darauf hin, dass sie vollständig aufgeladen ist: eingeschaltet die Anzeigeleuchte "weiß"; ist ausgeschaltet Zustand erlischt das Licht.
5. Während des Ladevorgangs kann der Drucker sich erwärmen. Stellen Sie den Drucker nicht zum Aufladen auf Gegenstände aus Baumwolle oder Leinen.
6. Nach Abschluss des Ladevorgangs ziehen Sie bitte das Ladegerät rechtzeitig ab.

Benutzen Sie den Drucker nicht während des Ladevorgangs.Die Verwendung des Druckers während des Ladevorgangs kann zu einer verringerten Ladegeschwindigkeit, der Druckqualität und der Lebensdauer der Batterie beeinträchtigen.



5.3 Reinigung und Wartung

Stellen Sie sicher, dass der Drucker vor der Durchführung von Reinigung und Wartung vom Stromnetz getrennt ist.

Wenn Sie gerade gedruckt haben, warten Sie bitte eine halbe Stunde, damit sich der Druckkopf vollständig abkühlen kann.

Tauchen Sie einen Wattestäbchen in Alkohol oder verwenden Sie einen speziellen Druckkopfreinigungsstift (separat erhältlich), wischen Sie ihn etwa 5-Mal hin und her, um Staub, Flecken usw. von der Oberfläche des Druckkopfes zu entfernen.

Warten Sie 5-10 Minuten, bis der Alkohol vollständig verflüchtigt ist. Nach der Reinigung ist das Gerät wieder zu verwenden.

Besondere Hinweise

Das Unternehmen ist allein verantwortlich für die Überarbeitung und Erklärung dieser Kurzanleitung und bemüht sich, deren Inhalt korrekt darzustellen. Bitte beachten Sie jedoch, dass technische Verbesserungen erfolgt keine separate Benachrichtigung. Die in dieser Kurzanleitung enthaltenen Abbildungen von Produkten, Zubehörteilen, Softwareschnittstellen usw. dienen lediglich der Veranschaulichung und sind als Referenz gedacht. Aufgrund von Produktaktualisierungen und Upgrades können geringfügige Unterschiede zwischen dem tatsächlichen Produkt und den Abbildungen auftreten. Bitte beachten Sie das tatsächliche Produkt.

Kurzanleitung F21 Mini-Drucker EW DE Deutsch 1. Produktübersicht 1.1 Lieferumfang Drucker ×1 Kurzanleitung ×1 Type-C Datenkabel×1 Etikettenrollenhalter ×1 Selbstklebende Etikettenrolle × n Die Anzahl und Spezifikationen der Etikettenrolle entsprechen dem bestellten Set. 1.2 Druckerkomponenten Gehäusedeckel Anzeigelampe Taste Ein-/Ausschalten Ausgabeschlitz Type-C Ladeanschluss Reset-Loch Druckkopf Etikettenrolle Etikettenrollenhalter Papierfach Deckelöffnungstaste 2. Schnellstart 2.1 App herunterladen Suchen Sie im App Store® oder Google Play™ Store nach der App „FaithTag" und laden Sie sie herunter und installieren Sie sie. FaithTag Download on the App Store GET IT ON Google Play FaithTag 2.2 Verwendungshinweise Stellen Sie vor dem Druckbeginn sicher, dass das Papierrolle korrekt in das Fach eingelegt ist. Detaillierte Anweisungen finden Sie im Handbuch unter „3. Papierrolle wechseln". 01 Halten Sie Taste Ein-/Ausschalten 3 Sekunden lang gedrückt, bis die Anzeige leuchtet. 02 Öffnen Sie die App „FaithTag". 03 Informationen autorisieren. 04 Klicken Sie oben auf[Verbinden]. 05 Verbindung hergestellt. Tippen Sie auf die Startseite, um die Heilige Schrift anzuzeigen. 06 Heilige Schrift anzeigen, dann [Drucken] antippen. 07 Vorschau öffnen, dann [Drucken] antippen. 08 Drucken abgeschlossen. 09 Reißen Sie das Etikett entlang des Ausgabeschlitzes ab. 10 Trägerpapier entfernen. 11 Kleben Sie das Etikett auf eine trockene und ebene Oberfläche. Die Software-Oberfläche dient nur zur Veranschaulichung. Bitte beachten Sie die tatsächliche Betriebsseite für genaue Informationen. 3. Etikettenrolle wechseln 13 Neue Etikettenrolle herausnehmen. Ignorieren Sie diesen Schritt, wenn es sich nicht um eine brandneue Etikettenrolle handelt, die Sie gerade gekauft wird. 14 Ziehen Sie die Deckelöffnungstaste in Pfeilrichtung, um den Papierrollenhalter herauszunehmen. 15 Ziehen Sie die bewegliche Anschläge heraus und entfernen Sie die zu erwartende Papierrolle. Einige Papierrollen enthalten Papierreste, die nach Gebrauch entfernt werden müssen. 16 Legen Sie die Etikettenrolle ein. 17 Die bewegliche Anschläge befestigen und festziehen. Die bewegliche Anschläge 18 Entfernen Sie den Schutzaufkleber. 19 Legen Sie die Etikettenrolle in das Papierfach ein. 20 Ziehen Sie die Etikettenrolle heraus, und schließen Sie das Papierfach, wenn sie über den Ausgabeschlitz hinausragt. Ausgabeschlitz 4. Mehr Hilfe 4.1 Tasten Tastentyp Bedienen Funktion Taste Ein-/Ausschalten 3 Sekunden lang drücken Ein-/Ausschalten Doppelklicken im eingeschalteten Zustand Testseitendruck 4.2 Anzeigelampe Status Beschreibung Bedienen Die weiße Anzeige ist konstant an Richtig funktionieren / Im eingeschalteten Zustand vollständig aufgeladen / Das LICHT ist aus Im ausgeschalteten Zustand vollständig aufgeladen / Weißes LICHT blinkt langsam Wird aufgeladen / Kein Papier eingelegt Legen Sie Papier ein Weißes LICHT blinkt schnell Drucker überhitzt Druckpause für 5 bis 10 Minuten Öffnen Sie den Gehäusedeckel Schließen Sie den Gehäusedeckel Status Beschreibung Bedienen Weißes Licht blinkt schnell 1 Stunde aufladen (kann bis zu dreimal benötigen, um vollständig aufgeladen zu werden) / Taste Ein/Ausschalten 3 Sekunden lang gedrückt und die Anzeige leuchtet nicht Akku schwach 1 bis 3 Stunden lang aufladen Akku leer 5. Sicherheitshinweise 5.1 Manueller Abschneidevorrichtung und Druckkopf Manueller Abschneidevorrichtung Druckkopf Warnung: Nicht berühren wegen der scharfen Kanten. Warnung: Heißes Bauteil! Beim Berühren dieses Bauteils können Verbrennungen an den Fingern auftreten. Bitte warten Sie eine halbe Stunde nach dem Ausschalten des Druckers, bevor Sie das Bauteil berühren. 5.2 Ladeanweisungen 1. Bitte beschaffen Sie sich einen 5V DC/2A Gleichstromadapter mit einem Typ-A-Anschluss. 2. Verbinden Sie das USB-Ladekabel Typ-C (flaches Ende) mit dem Typ-C-Ladeanschluss des F21-Druckers. Verbinden Sie das USB-Ladekabel Typ-A (breites Ende) mit dem Typ-A-Anschluss des Netzadapters. 3. Wenn der Drucker aufgeladen werden muss, überprüfen Sie bitte den Status der Drucker-Statusanzeige. Wenn der Drucker aufgeladen wird, blinkt die Anzeigeleuchte langsam mit einem "weißen Licht". 4. Bitte laden Sie mindestens 20 Minuten lang auf, um eine schnelle Verwendung zu ermöglichen. Die Aufladung dauert 2-3 Stunden oder die folgenden zwei Zustände weisen darauf hin, dass sie vollständig aufgeladen ist: eingeschaltet die Anzeigeleuchte "weiß"; ist ausgeschaltet Zustand erlischt das Licht. 5. Während des Ladevorgangs kann der Drucker sich erwärmen. Stellen Sie den Drucker nicht zum Aufladen auf Gegenstände aus Baumwolle oder Leinen. 6. Nach Abschluss des Ladevorgangs ziehen Sie bitte das Ladegerät rechtzeitig ab. Benutzen Sie den Drucker nicht während des Ladevorgangs.Die Verwendung des Druckers während des Ladevorgangs kann zu einer verringerten Ladegeschwindigkeit, der Druckqualität und der Lebensdauer der Batterie beeinträchtigen. USB Typ-C Ende Adapter für Typ-A-Anschluss (nicht im Lieferumfang enthalten) 5V Gleichstrom, 2A USB Typ-A-Anschluss 5.3 Reinigung und Wartung Stellen Sie sicher, dass der Drucker vor der Durchführung von Reinigung und Wartung vom Stromnetz getrennt ist. Wenn Sie gerade gedruckt haben, warten Sie bitte eine halbe Stunde, damit sich der Druckkopf vollständig abkühlen kann. Tauchen Sie einen Wattestäbchen in Alkohol oder verwenden Sie einen speziellen Druckkopfreinigungsstift (separat erhältlich), wischen Sie ihn etwa 5-Mal hin und her, um Staub, Flecken usw. von der Oberfläche des Druckkopfes zu entfernen. Warten Sie 5-10 Minuten, bis der Alkohol vollständig verflüchtigt ist. Nach der Reinigung ist das Gerät wieder zu verwenden. Druckkopf Besondere Hinweise Das Unternehmen ist allein verantwortlich für die Überarbeitung und Erklärung dieser Kurzanleitung und bemüht sich, deren Inhalt korrekt darzustellen. Bitte beachten Sie jedoch, dass technische Verbesserungen erfolgt keine separate Benachrichtigung. Die in dieser Kurzanleitung enthaltenen Abbildungen von Produkten, Zubehörteilen, Softwareschnittstellen usw. dienen lediglich der Veranschaulichung und sind als Referenz gedacht. Aufgrund von Produktaktualisierungen und Upgrades können geringfügige Unterschiede zwischen dem tatsächlichen Produkt und den Abbildungen auftreten. Bitte beachten Sie das tatsächliche Produkt.