

FRONT



Trailmate Speaker/Lantern User Guide

SKU: 602-KM-TSL-BG



Bluetooth® Name: KUMA-SPEAKER

Speaker Operation

Power On: Hold down for 3 seconds to turn ON/OFF. Bluetooth will also turn on.

Bluetooth: Double click and wait 3 seconds to initiate Bluetooth connection. (If you choose to connect 2 devices, power on and connect one at a time)

Click to **Pause/Play**, hold down to switch from:

→ **Bluetooth** >> **FM mode** >> **White Noise mode**

Click to **increase volume**, hold down for next track.

Click to **decrease volume**, hold down for previous track.

“White Noise” Operation

Timer Shut Off: While in “White Noise” mode, set shutdown time. Press to switch from 30 min (1 beep), to 60 min (2 beeps), to 90 min (3 beeps).

Click and hold “+” or “-” buttons to scroll through 4 options for white noise sounds. (Water, Birds, Fire, Frogs)

Phone Call Operation

Click to **answer or hang up** a phone call. Hold down to **reject a call**. Double click to **make a call**.

Lantern Operation

Light On/OFF: Long press for light to turn ON/OFF. Double click for white light or warm light selection.

Increase Brightness: Click to increase light brightness.

Decrease Brightness: Click to decrease light brightness.

Product Specifications

Product Dimensions:	115 x 115 x 200mm (not including handle)
Product Weight:	1.65 lbs / 745g
Battery Capacity:	Battery - 3.7V, 4400mAh
Battery Time - Audio:	Approx. 4-5 hrs (dependent on the audio volume/content, and light use)
Battery Time - Lantern:	Approx. 24 hrs (when audio off)
Battery Time - Audio and Lantern	Approx. 4 hrs (dependent on the audio volume/content, and light use)
Battery Time - Talk	Approx. 4 hrs
USB-A Output:	5V, 1A
Full Charge Time	Approx. 6-7 hrs
Speaker Specifications:	Full frequency speaker: 16 core speaker 2 x 45mm + low-frequency diaphragm - 1pc
Audio Power Output:	15W (2 x 7.5W) RMS

kumaoutdoorgear.com



Trailmate Haut-Parleur/Lanterne - Mode d'emploi

SKU: 602-KM-TSL-BG



Bluetooth® Nom: KUMA-SPEAKER

Operation d’haut-parleur

Mise sous tension : maintenez enfoncé pendant 3 secondes pour allumer/éteindre. Bluetooth s’allumera également.

Bluetooth : double-cliquez et attendez 3 secondes pour lancer Bluetooth connexion. (Si vous choisissez de connecter 2 appareils, allumez et connectez-vous un à la fois)

Cliquez pour mettre en **pause/lire**, maintenez enfoncé pour basculer de :

→ **Bluetooth** >> **mode FM** >> **mode du Bruit Blanc**

Cliquez pour **augmenter le volume**, maintenez enfoncé la touche pour la piste suivante.

Cliquez pour **diminuer le volume**, maintenez enfoncé la piste précédente.

Operation du bruit blanc

Arrêt de la minuterie : En mode Bruit blanc, réglez l’heure d’arrêt. appuyez pour passer de 30 min (1 bip), à 60 min (2 bips), à 90 min (3 bips).

Cliquez sur les boutons « + » ou « - » et maintenez-les enfoncés pour faire défiler 4 options pour les bruits blancs. (Eau, Oiseaux, Feu, Grenouilles)

Operation du téléphone cellulaire

Cliquez pour **répondre ou raccrocher** un appel téléphonique. Maintenez enfoncé pour **rejeter un appel**. Double-cliquez pour **passer un appel**.

BACK

Operation du lanterne

Lumière allumée/éteinte : appuyez longuement pour que la lumière s’allume/s’éteigne. Double-cliquez pour la sélection de lumière blanche ou de lumière chaude.

Augmenter la luminosité : cliquez pour augmenter la luminosité de la lumière.

Diminuer la luminosité : cliquez pour diminuer la luminosité de la lumière.

Spécifications du produit

Dimensions du produit:	115 x 115 x 200mm (sans poignée)
Poids du produit:	1.65 lbs / 745g
Capacité de la batterie:	Batterie - 3.7V, 4400mAh
Durée d’exécution - Audio :	Environ 4 à 5 heures (en fonction de l'audio volume/contenu et utilisation légère)
Durée d’exécution - Lanterne :	Environ 24 hrs (quand le son est désactivé)
Durée d’exécution : Audio et Lantern	Environ 4 heures (en fonction de l'audio volume/contenu et utilisation légère)
Durée d’exécution - Téléphone :	Environ 4 heures
Sortie USB-A :	5V, 1A
Temps de charge complet	Environ 6 à 7 heures
Spécifications du haut-parleur :	Haut-parleur pleine fréquence : 16 cœurs 2 x 45 mm + diaphragme basse fréquence - 1 pc
Puissance de sortie audio :	15W (2 x 7.5W) RMS

kumaoutdoorgear.com

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without restriction.

kumaoutdoorgear.com