

MINISO

USER MANUAL

使用說明書

Windproof Noise-Reducing
Single-Ear Wireless Earphone

Écouteur sans Fil Mono

سماعة لاسلكية مفردة - عازلة للضوضاء

Auricular Inalámbrico Individual
con Reducción de Ruido

防風降噪單耳無線耳機

MODEL: S1

使用商品前請仔細閱讀本使用說明書，並妥善妥善保管。

PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT PROPERLY.

Cautions

1. Keep out of reach of children, to avoid danger caused by improper use of children.
2. Use the product under reasonable volume and time period to avoid hearing damage.
3. Do not use the product while driving, riding a bicycle, operating machinery, or working on something that requires you to pay attention to external sounds.
4. Do not store or use the product in an environment where the temperature is lower than -10 °C, or higher than 45 °C. If the ambient temperature is too high or too low, faults may occur.
5. Avoid contact with water or other liquids to avoid damage to the internal circuit of the product.
6. Do not disassemble, hit, squeeze the product, or throw the product into fire to avoid explosion. If the battery bulges or leaks, stop using it.
7. Do not use the product during thunderstorms. Thunderstorms can cause abnormal operation of the device and increase the risk of electric shock.
8. When using this device, please keep at least 15 cm away from implanted medical devices (such as pacemakers, etc.).
9. Due to the characteristics of Bluetooth technology, the strength of the signal is related to the specific use environment. If there are more overlapping wireless signals nearby or there is strong electromagnetic wave interference, the signal received by the product will become weaker or even disconnected.
10. If the product will not be used for a long time, please charge the product once every three months to avoid battery over-discharge damage.
11. Store using the product before cleaning or maintaining it. Please wipe the equipment with a clean, dry soft cloth for cleaning.
12. It is recommended to use a charger from a brand manufacturer with certification, with an output voltage of 5V. Please avoid using fast-charging chargers with output voltage exceeding 5V to avoid excessive charging damage.

Specifications

BT Version: V6.0
BT Name: MINISO-S1
Music Playback Time: Around 15h
Earphone Battery Capacity: 120mAh

Rated Input: 5V = 120mA
Charging Time: 2h
Charging Port: USB-C
Transmission Distance: 10m

Product Diagram

①

②

③

④

⑤

⑥

① Battery Level Display
② Charging Port
③ Multifunctional Button

Functions

Power On/Off

Once the earphone is powered on, it automatically enters pairing mode. At this time, the light in the battery level display area will start flashing.

Search for "MINISO-S1" on your smartphone or BT device and pair with the earphone

When the earphone is turned on again, it will automatically reconnect to the previously paired smartphone or BT device as long as BT is enabled on the phone or device)

Automatic Re-connection

If the earphone disconnects because it moves out of range, it will automatically reconnect to the device once it returns within the effective range

Automatic Shut Down

If the earphone does not connect to any device within 5 minutes, it will automatically power off

Press multifunctional button once to play/pause

Press multifunctional button twice to move to next track

or phon

Music Control

Press multifunctional button three times to move to previous track

Press multifunctional button once to receive/end a call

Press multifunctional button for around 2 seconds to reject a call

Voice Assistant

Press multifunctional button four times to activate the voice assistant

Charging Display

While charging, the display shows the battery level; when fully charged, the display shows 100

Troubleshooting

1. Wireless earphone fails to be paired with the phone.
Solution: Check if the earphone is in pairing mode, and whether the phone has BT function on. Check the list on your phone, remove earphone from the list, follow the instructions of user manual to pair the earphone with your phone again.
2. Cannot turn on the wireless earphone.
Solution: Check the battery to see if it is low.
3. Can't the battery of the wireless earphone be replaced?
Answer: No. The lithium polymer battery in the earphone is irreplaceable.
4. The wireless earphone got disconnected with the phone within 10 meters.
Solution: BT is wireless so that it is very sensitive to object between the earphone and the connected device. Check if there are any metal or other objects that may affect the connection within the effective distance.
5. Cannot hear audio playing when the earphone is connected to the computer or phone.
Solution: Check whether the computer's audio input is already connected to microphone and whether the Bluetooth in the computer supports A2DP protocol. Make sure the volume is up on your phone or computer.
6. Can I separate the Apps on my phone through the earphone after connecting the wireless earphone to the phone?
Answer: Some apps may not support being operated through the earphone due to their settings.

Accessories

Device:1, User Manual*1, USB-C Charging Cable*1

FCC Warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause interference,
(2) This device must accept any interference received, including interference that may cause undesired operation of the device.
No stocker parts and n'utlisez pas le produit dans un environnement où la température est inférieure à -10 °C ou supérieure à 45 °C. Si la température ambiante est trop élevée ou trop basse, des dysfonctionnements peuvent survenir.
6. Évitez tout contact avec de l'eau ou d'autres liquides afin de ne pas endommager le circuit interne du produit.
7. N'utilisez pas le produit pendant les orages. Les orages peuvent provoquer un fonctionnement anormal de l'appareil et augmenter le risque de choc électrique.
8. Lorsque vous utilisez cet appareil, maintenez une distance d'au moins 15 cm avec les dispositifs médicaux implantés tels que les stimulateurs cardiaques, etc., et on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the distance between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

IC WARNING

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSSI's. Operation is subject to the following two conditions:
(1) This device may not cause interference,
(2) This device must accept any interference received, including interference that may cause undesired operation of the device.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) No stocker parts and n'utlisez pas le produit dans un environnement où la température est inférieure à -10 °C ou supérieure à 45 °C. Si la température ambiante est trop élevée ou trop basse, des dysfonctionnements peuvent survenir.
6. Évitez tout contact avec de l'eau ou d'autres liquides afin de ne pas endommager le circuit interne du produit.
7. N'utilisez pas le produit pendant les orages. Les orages peuvent provoquer un fonctionnement anormal de l'appareil et augmenter le risque de choc électrique.
8. Lorsque vous utilisez cet appareil, maintenez une distance d'au moins 15 cm avec les dispositifs médicaux implantés tels que les stimulateurs cardiaques, etc., et on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the distance between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC Warning

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause interference,
(2) This device must accept any interference received, including interference that may cause undesired operation of the device.
No stocker parts and n'utlisez pas le produit dans un environnement où la température est inférieure à -10 °C ou supérieure à 45 °C. Si la température ambiante est trop élevée ou trop basse, des dysfonctionnements peuvent survenir.
6. Évitez tout contact avec de l'eau ou d'autres liquides afin de ne pas endommager le circuit interne du produit.
7. N'utilisez pas le produit pendant les orages. Les orages peuvent provoquer un fonctionnement anormal de l'appareil et augmenter le risque de choc électrique.
8. Lorsque vous utilisez cet appareil, maintenez une distance d'au moins 15 cm avec les dispositifs médicaux implantés tels que les stimulateurs cardiaques, etc., et on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the distance between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Schéma du Produit

①

②

③

④

⑤

⑥

① Indicateur de Niveau de Batterie
② Port de Chargement
③ Bouton Multifonction

Mode d'Emploi

Fonction

Instructions

Marché / Arrêt Automatique

Appuyez sur le bouton multifonction pendant environ 3 secondes

Appairage d'Appareils

Une fois l'écouteur allumé, il passe automatiquement en mode d'appariage. À ce moment-là, le voyant situé dans la zone d'affichage du niveau de batterie commencera à clignoter.
Recherchez « MINISO-S1 » sur votre smartphone ou votre appareil Bluetooth, puis appairez avec l'écouteur.

Reconnexion Automatique

Si l'écouteur se déconnecte parce qu'il sort de la zone de couverture, il se reconnectera automatiquement à l'appareil dès qu'il reviendra dans la zone de couverture.

Arrêt Automatique

Si l'écouteur ne se connecte à aucun appareil dans les 5 minutes, s'éteint automatiquement.

Commande Musicale

Appuyez une fois sur le bouton multifonction pour lancer la lecture ou mettre en pause.
Appuyez deux fois sur le bouton multifonction pour passer à la piste suivante.
Appuyez trois fois sur le bouton multifonction pour passer à la piste précédente.

Appels Téléphoniques

Appuyez une fois sur le bouton multifonction pour prendre ou mettre fin à un appel

Assistant Vocal

Appuyez quatre fois sur le bouton multifonction pour activer l'assistant vocal.

Affichage de l'État de Charge

Pendant la charge, l'écran affiche le niveau de la batterie ; une fois la charge terminée, l'écran affiche 100

Dépannage

1. L'écouteur sans fil ne parvient pas à être apparié avec votre téléphone.
Solution : Vérifiez si l'écouteur est en mode d'appariage et si la fonction BT de votre téléphone est activée. Vérifiez la liste des appareils sur votre téléphone, supprimez l'écouteur de la liste, suivez les instructions du manuel d'utilisation pour appairer à nouveau l'écouteur avec votre téléphone.
2. Nous ne pouvons pas allumer l'écouteur sans fil.
Solution : Vérifiez si la batterie est faible.
3. La batterie de l'écouteur sans fil peut-elle être remplacée ?
Réponse : Non, la batterie lithium-polymère intégrée dans l'écouteur n'est pas remplaçable.
4. L'écouteur sans fil s'est déconnecté du téléphone à moins de 10 mètres.
Solution : Le BT étant sans fil, il est très sensible aux objets situés entre l'écouteur et l'appareil connecté. Vérifiez s'il y a des objets métalliques ou autres pouvant affecter la connexion dans la distance effective.

Accessoires

Appareil*1, Manuel d'Utilisation*1, Câble de Charge USB-C*1

AVERTISSEMENT IC

Le présent appareil contient des émetteurs/récepteurs exempts de licence conformes au CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. Son fonctionnement est soumis aux deux conditions suivantes :
(1) Cet appareil ne doit pas provoquer d'interférences;
(2) Cet appareil doit accepter toute interférence, y compris les interférences susceptibles d'en compromettre le fonctionnement.
Cet émetteur ne doit pas être installé ou utilisé conjointement avec une autre antenne ou un autre émetteur. L'appareil a été évalué comme conforme aux exigences générales relatives à l'exposition aux radiofréquences (RF). L'appareil peut être utilisé dans des conditions d'exposition portables sans restriction.

Appels Téléphoniques

Appuyez une fois sur le bouton multifonction pour prendre ou mettre fin à un appel

Assistant Vocal

Appuyez quatre fois sur le bouton multifonction pour activer l'assistant vocal.

Affichage de l'État de Charge

Pendant la charge, l'écran affiche le niveau de la batterie ; une fois la charge terminée, l'écran affiche 100

Dépannage

1. L'écouteur sans fil ne parvient pas à être apparié avec votre téléphone.
Solution : Vérifiez si l'écouteur est en mode d'appariage et si la fonction BT de votre téléphone est activée. Vérifiez la liste des appareils sur votre téléphone, supprimez l'écouteur de la liste, suivez les instructions du manuel d'utilisation pour appairer à nouveau l'écouteur avec votre téléphone.
2. Nous ne pouvons pas allumer l'écouteur sans fil.
Solution : Vérifiez si la batterie est faible.
3. La batterie de l'écouteur sans fil peut-elle être remplacée ?
Réponse : Non, la batterie lithium-polymère intégrée dans l'écouteur n'est pas remplaçable.
4. L'écouteur sans fil s'est déconnecté du téléphone à moins de 10 mètres.
Solution : Le BT étant sans fil, il est très sensible aux objets situés entre l'écouteur et l'appareil connecté. Vérifiez s'il y a des objets métalliques ou autres pouvant affecter la connexion dans la distance effective.

[illegible]