



English			
Copyright © 2025 Samsung Electronics America, Inc. Samsung and Samsung Galaxy are trademarks of Samsung Electronics Co., Ltd. Other company names and marks are the property of their respective owners. Bluetooth® is a registered trademark of Bluetooth SIG, Inc. worldwide.			
- Visit <i>www.samsung.com</i> to access the product information. This content may not be available depending on the region. - Your consumer rights are governed by the law of the country in which you purchased the product. Please contact your service provider for more information.			
Device layout			
a	Thumbstick	h	B button
b	Menu button	i	A button
c	X button	j	Home button
d	Y button	k	Battery cover
e	Grip button	l	Battery cover button
f	Trigger	m	Wrist strap
g	Indicator light		

Indicator light

Color	Status
Flashes red, green, and blue	The controller is in Bluetooth pairing mode.
Flashes blue three times	Bluetooth is connected.
Green (stays on for 5 seconds after inserting a battery)	The battery power is high (more than 60%).
Yellow (stays on for 5 seconds after inserting a battery)	The battery power is medium (between 30%and 59%).
Red (stays on for 5 seconds after inserting a battery)	The battery power is low (between 10% and 29%).
Flashes red	Low battery
Continuously blue	Power on

Holding the controllers

- Insert the wrist strap loop into the wrist strap connection hole and attach it to the hook to secure it to the controller.
- Adjust the wrist strap to fit both of your wrists. (A)

Pairing the controllers with the HMD

- Press the battery cover button to slide the battery cover down to open it and remove the insulating paper.
- Insert the battery according to the polarity (+/-) and slide the battery cover back until it clicks into place. (B)
- Wear the HMD (Head Mounted Display).

- Open **Settings** on your HMD, select **Input → Controllers**, and follow the on-screen instructions to connect the controllers.
 - If the controllers are disconnected from the HMD, the controllers will enter standby mode. To reconnect them, hold a controller or press either the A/B button or the X/Y button on the controllers to end standby mode. The controllers will be connected to the HMD that was previously connected.
 - Do not recharge the provided battery (AA).

Using the controllers

Action	Function
Pressing	- Select an item by pressing the Thumbstick or Trigger. - Items can be picked up from the ground in some games or apps by pressing the Grip button.
Moving	Move your wrist to move the pointer left, right, up, and down on the screen.
Pushing the Thumbstick	- Push the Thumbstick up or down to move. You can also scroll up or down on a webpage or list. - Push the Thumbstick left or right to move the next or previous item.
Opening the menu	Open the menu in some games or apps by pressing the Menu button.
Opening the Home screen	Press the Home button to open the Home screen.


Action	Function
Capturing and recording the screen	- Capture the screen by pressing the Home button and Trigger simultaneously. - Record the screen by pressing and holding the Home button and Trigger simultaneously.
Entering Bluetooth pairing mode	Enter Bluetooth pairing mode by pressing and holding the Home button and A button or the Menu button and X button simultaneously for more than 3 seconds.

Cautions

- Use caution to avoid damaging this product.
- Do not expose the product to humidity, solvents or high temperatures. Doing so may stain, wrinkle, discolor or distort it.
 - If there is debris on the product, wipe the surface clean before using it.
 - Avoid placing the product in hot or humid environments. If the product is exposed to direct sunlight, its color or form may change.
 - Be careful not to scratch the product with sharp objects such as nails.
 - When using this product, some customers may experience allergic reactions, such as itching, eczema, or swelling. If you experience any of these symptoms, stop using the product and consult a physician.

Safety information

- Read all safety information before using the device to ensure safe and proper use.
- Use manufacturer-approved batteries, accessories, and supplies.
 - Do not touch the device with wet hands.
 - Do not drop or cause an impact to the charger or the device.
 - Do not allow children or animals to chew or suck the device.
 - Do not disassemble, modify, or repair your device.



각 부분의 이름			
a	엄지 스틱	h	B 버튼
b	메뉴 버튼	i	A 버튼
c	X 버튼	j	홈 버튼
d	Y 버튼	k	건전지 덮개
e	그립 버튼	l	건전지 덮개 버튼
f	트리거	m	손목 스트랩
g	상태표시등		

상태표시등

색상	상태
빨간색, 녹색, 파란색 깜박임	• 블루투스 페어링(연결) 모드
파란색 3번 깜박임	• 블루투스 연결됨
녹색(건전지를 삽입한 후 5초 동안 켜짐)	• 배터리 잔량이 60% 이상
노란색(건전지를 삽입한 후 5초 동안 켜짐)	• 배터리 잔량이 30% 이상, 60% 미만
빨간색(건전지를 삽입한 후 5초 동안 켜짐)	• 배터리 잔량이 30% 미만
빨간색 깜박임	• 배터리 부족
파란색 켜짐	• 전원 켜짐

컨트롤러 착용하기

- 손목 스트랩 연결 홈에 손목 스트랩 고리를 밀어 넣은 후 겹이에 고리를 걸어 고정하세요.
- 손목 스트랩을 조절하여 양쪽 손목에 알맞게 착용하세요.(A)

HMD와 컨트롤러 페어링(연결)하기

- 건전지 덮개 버튼을 눌러 건전지 덮개를 아래로 밀어 연 후 절연지를 제거하세요.
- 극성(+/-)에 맞게 건전지를 삽입한 후 딸깍 소리가 날 때까지 건전지 덮개를 밀어 넣으세요.(B)
- HMD(Head Mounted Display)를 착용하세요.
- HMD에서 설정을 열고 입력 → 컨트롤러를 선택해 화면의 안내에 따라 컨트롤러를 연결하세요.

-  HMD와 컨트롤러의 연결이 끊어진 경우 컨트롤러가 페어링(연결) 대기 모드로 진입합니다. 다시 연결하려면 한 쪽 컨트롤러를 잡거나 컨트롤러의 A/B 버튼 또는 X/Y 버튼 중 하나를 눌러 대기 모드를 해제하세요. 이전에 연결한 HMD와 자동으로 연결됩니다.
- 제공된 건전지(AA Battery)는 충전하여 사용할 수 없습니다.

컨트롤러 사용하기

동작	기능
한 번 누르기	- 엄지 스틱 또는 트리거를 눌러 원하는 항목을 선택합니다. - 그립 버튼을 눌러 일부 게임이나 앱에서 바닥에 떨어져 있는 물건을 잡을 수 있습니다.
이동하기	손목을 움직여 화면의 포인터를 상하좌우로 움직입니다.
엄지 스틱 밀기	- 웹 페이지나 목록에서 화면을 위아래로 이동할 수 있습니다. - 좌우로 밀어 이전 또는 다음 항목으로 이동합니다.

동작	기능
메뉴 실행하기	메뉴 버튼을 눌러 일부 게임이나 앱에서 사용할 수 있는 메뉴를 실행합니다.
홈 화면 실행하기	홈 버튼을 눌러 홈 화면을 실행합니다.
화면 캡처 및 화면 녹화하기	- 홈 버튼과 트리거를 동시에 눌러 화면을 캡처합니다. - 홈버튼과 트리거를 동시에 길게 눌러 화면을 녹화합니다.
블루투스 페어링(연결) 모드 진입하기	홈 버튼과 A 버튼 또는 메뉴 버튼과 X 버튼을 동시에 3초 이상 길게 눌러 블루투스 페어링(연결) 모드로 진입합니다.

취급 시 주의 사항

- 제품이 파손/훼손되지 않도록 사용에 주의하세요.
- 습기, 화학물질 및 고온에 노출될 경우 얼룩, 주름이 생기거나, 변색/변형될 수 있습니다.
 - 제품에 이물질이 묻었을 경우 깨끗하게 닦은 후 사용하세요.
 - 제품 보관 시에는 온도나 습도가 높은 곳을 피하세요. 제품을 직사광선에 직접 노출할 경우 색상이나 형태가 변할 수 있습니다.
 - 손톱 등 날카로운 물체에 제품이 긁히지 않도록 주의하세요.
 - 체질에 따라 알레르기, 간지럼, 습진, 붓는 증상이 생길 수 있습니다. 제품 사용 중에 위의 증상이 발생할 경우 사용을 멈추고 의사와 상담하세요.

안전을 위한 주의 사항

- 사용하기 전에 자세히 읽고, 반드시 지켜 주시기 바랍니다.
- 액세서리 및 부속품은 반드시 삼성전자에서 제공하거나 승인한 정품을 사용하세요.
 - 젖은 손으로 제품을 만지지 마세요.
 - 제품을 떨어뜨리는 등 심한 충격을 주지 마세요.
 - 어린이나 유아 또는 애완동물이 제품을 빨거나 물어뜯지 않도록 주의하세요.
 - 사용자 임의로 제품을 개조하거나 분리, 수리하지 마세요.

FCC ID : A3LETOI610L / A3LETOI610R
IC : 649E-ETOI610L / 649E-ETOI610R

FCC Part 15.19

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Part 15.21

Any changes or modifications (including the antennas) to this device that are not expressly approved by the manufacturer may void the user's authority to operate the equipment.

ISED Notice

This device complies with ISED (Innovation, Science and Economic Development Canada) licence exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference.
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Avis d'ISDE

Ce produit est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

1. L'appareil ne doit pas produire de brouillage.
2. L'utilisateur doit accepter tout brouillage radioélectrique subi par l'appareil, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC and IC RF Radiation Exposure Statement:

This equipment complies with FCC and IC RF Radiation exposure limits set forth for an uncontrolled environment.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with a minimum distance of 0cm between the radiator and your body.

RF du FCC et IC d'exposition aux radiations: Cet équipement est conforme à l'exposition de FCC et IC rayonnements RF limites é-tablies pour un environnement non contrôlé. L'antenne pour ce transmetteur ne doit pas être même endroit avec d'autres émetteur sauf conformément à FCC et IC procédures de produits Multi-émetteur.

Cet équipement doit être installé et utilisé avec une distance minimale de 0cm entre le radiateur et votre corps.