



English

Instruction Manual

About the manuals

1. Instruction Manual (this manual)
2. (Startup Guide)

The Startup Guide describes the following:

- Basic operating instructions of your WALKMAN®
- How to access the “Help Guide”, which contains all of the operating instructions and explanations of customer support websites ,etc.
- How to access useful PC applications websites on the internet

While browsing is free, you may be charged a communication fee according to your carrier contract.

Notes for using Walkman

Note for battery

- To prevent battery deterioration, charge the battery at least once every six months or every year.

About volume operation (Only for countries/areas complying with European Directives)

An alarm (beep) and a warning [Check the volume level] are meant to protect your ears when you turn the volume up to a level that is harmful for your ears for the first time. You can cancel the alarm and warning by pressing any button.

Note

- You can turn up the volume after canceling the alarm and warning.
- After the initial warning, the alarm and warning repeat every 20 cumulative hours that the volume is set to a level that is harmful for your ears. When this happens, the volume is turned down automatically.
- If the volume is set to a level that is harmful for your ears and you turn off the Walkman, the volume is turned down to a level that is safe for your ears automatically.

Bluetooth capabilities

You can listen to music stored on your Walkman from Bluetooth audio devices such as headphones or speakers.

Pairing (first time the device is used)

1. Set the Bluetooth audio device to pairing mode. (Refer to the device’s instruction manual.)
2. From the Home menu of your Walkman, select [Bluetooth] - [Add Device (Pairing)] - the Bluetooth audio device to pair with. After pairing is completed, the Bluetooth connection is made automatically.

Connecting (subsequent uses)

1. Turn on the paired Bluetooth audio device and set it to standby.
2. From the Home menu of your Walkman, select [Bluetooth] - [Connect to Audio Device] - the paired Bluetooth audio device to connect with.

Disconnecting

From the Home menu of your Walkman, select [Bluetooth] - [Disconnect Audio Device].

Symptom & Remedy

Your Walkman cannot charge the battery or is not recognized on your computer.

- The USB cable (supplied) is not connected to a USB connector on your computer properly. Disconnect the USB cable, and then reconnect it.
- When you use your Walkman for the first time, or if you have not used the Walkman for a long time, it may take a few minutes to be recognized by the computer. Check that the computer recognizes the Walkman after you have connected it to the computer for about 10 minutes.

Your Walkman does not operate or the power does not turn on.

- You cannot operate your Walkman while it is connected to a computer. Disconnect the Walkman from a computer.

Compliance & Information

Information on laws and trademarks

For information on laws, regulations and trademark rights, refer to “Important Information” contained in the supplied software. To install it, open [WALKMAN] folder in your WALKMAN’s memory after connecting to your computer.

Windows user: [FOR_WINDOWS] - [Help_Guide_Installer(.exe)]

Mac user: [FOR_MAC] - [Help_Guide_Installer_for_mac]

After installing the software, double-click the shortcut or the alias icon generated on your desktop.

About the in-ear headphones

The earbuds seal your ears. Therefore, be aware that there is a risk of damage to your ears or eardrums if strong pressure is applied to the earbuds or the earbuds are suddenly removed from your ears. After use, be sure to take the earbuds off your ears gently.

About the headphones

- Avoid playing the unit at so loud a volume that extended play might affect your hearing.
- At a high volume outside sounds may become inaudible. Avoid listening to the unit in situations where hearing must not be impaired, for example, while driving or cycling.
- As the headphones are of open-air design, sounds go out through the headphones. Remember not to disturb those close to you.

Design and specifications are subject to change without notice.

Español

Manual de instrucciones

REPRODUCTOR DE MÚSICA DIGITAL

POR FAVOR LEA DETALLADAMENTE ESTE MANUAL DE INSTRUCCIONES ANTES DE CONECTAR Y OPERAR ESTE EQUIPO. RECUERDE QUE UN MAL USO DE SU APARATO PODRÍA ANULAR LA GARANTÍA

Glosario de términos

Ordenador: Computadora

Acerca de los manuales

1. Manual de instrucciones (este manual)
2. (Guía de inicio)

En la Guía de inicio se explica lo siguiente:

- Instrucciones de funcionamiento básico del WALKMAN®
- Cómo se accede a la “Guía de Ayuda” donde se incluyen todas las instrucciones de funcionamiento y explicaciones sobre los sitios web de asistencia al cliente, etc.
- Cómo se accede a útiles sitios web de aplicaciones para PC en Internet

Aunque la navegación es gratuita, puede cobrarse una tarifa de comunicación según lo estipulado en el contrato del operador.

Notas sobre la utilización del Walkman

Nota sobre la batería

- Para evitar que la batería se deteriore, cárguela al menos una vez cada seis meses o cada año.

Funciones Bluetooth

Puede escuchar la música que tenga almacenada en su Walkman a través de dispositivos de audio Bluetooth, como auriculares o altavoces.

Emparejamiento (la primera vez que se usa el dispositivo)

1. Active el modo de emparejamiento del dispositivo de audio Bluetooth. (Consulte el manual de instrucciones del dispositivo).
2. En el menú Inicio de su Walkman, seleccione [Bluetooth] - [Añadir disp. (emparejar)] - dispositivo de audio Bluetooth que se va a emparejar. Una vez finalizado el emparejamiento, la conexión Bluetooth se establece automáticamente.

Conexión (usos posteriores)

1. Encienda el dispositivo de audio Bluetooth emparejado y póngalo en estado En espera.
2. En el menú Inicio de su Walkman, seleccione [Bluetooth] - [Conectar a disp. de audio] - dispositivo de audio Bluetooth que se va a conectar.

Desconexión

En el menú Inicio de su Walkman, seleccione [Bluetooth] - [Desconectar disp. de audio].

Síntoma y solución

El Walkman no puede cargar la batería, o el ordenador no lo reconoce.

- El cable USB (suministrado) no está conectado correctamente al conector USB del ordenador. Desconecte el cable USB y, a continuación, vuelva a conectarlo.
- La primera vez que utilice el Walkman o tras no haberlo utilizado durante un período de tiempo considerable, es posible que pasen algunos minutos hasta que el ordenador lo reconozca. Compruebe si el ordenador ha reconocido el Walkman unos 10 minuto después de haberlo conectado al ordenador.

El Walkman no funciona o no se enciende.

- El Walkman no puede utilizarse mientras está conectado a un ordenador. Desconecte el Walkman del ordenador.

Cumplimiento e información

Información relativa a leyes y marcas comerciales

Para obtener información sobre legislación, normativa y derechos de marcas comerciales, consulte la “Información importante” que se suministra con el software. Para realizar la instalación, abra la carpeta [WALKMAN] incluida en la memoria del WALKMAN después de conectarlo al ordenador.

Usuario de Windows: [FOR_WINDOWS] - [Help_Guide_Installer(.exe)]

Usuario de Mac: [FOR_MAC] - [Help_Guide_Installer_for_mac]

Tras instalar el software, haga doble clic en el acceso directo o en el icono de alias generado en el Escritorio.

Acerca de los auriculares internos

Las almohadillas cierran herméticamente los oídos. Por tanto, tenga en cuenta que sus oídos o tímpanos pueden sufrir daños si se aplica una presión excesiva en las almohadillas o si las almohadillas se retiran de los oídos de forma repentina. Después de utilizarlas, retire las almohadillas de los oídos suavemente.

Acerca de los auriculares

- Evite escuchar la unidad a un volumen muy alto, ya que la escucha prolongada afectaría su oído.
- A un volumen alto, el sonido exterior puede llegar a ser inaudible. Evite escuchar la unidad en situaciones en las que no deba perder la audición, por ejemplo, conduciendo un automóvil o en bicicleta.
- Como los auriculares son de diseño abierto, el sonido se emite al exterior. Procure no molestar a las personas que estén cerca de usted.

Requisitos de alimentación

Batería recargable de lones de Litio incorporada, cc 3,7 V (Batería recargable de iones de Litio integrada) Alimentación USB (Puerto Serial Universal USB A) de cc 5 V

El diseño y las especificaciones están sujetos a cambio sin previo aviso.