

CHERRY MW 8C ADVANCED

Wireless Mouse with Bluetooth® and RF Transmission

441025-00_DE-EN-FR-IT-ES-IT-NL-SV-NO-DK-FI-PL-CS-SK-ZH-MW 8C Sep 2021
[UW-810a+Mod.-JF-81]_3R-V1

DE BEDIENUNGS-ANLEITUNG

- ① Buchse für Ladekabel
- ② DPI-Umschaltungs
- ③ Status-LED für Ladestand der Batterie, Audioschaltung, Bluetooth- oder Funkverbindung
- ④ Browser vor
- ⑤ Browser zurück
- ⑥ Schalter aus (off)/Bluetooth (RF)/Bluetooth (BT)
- ⑦ Taste für Bluetooth-Verbindung
- ⑧ Empfänger für Funkverbindung

Bevor Sie beginnen ...

Jedes Gerät ist anders! In der Bedienungsanleitung erhalten Sie Hinweise zur effektiven und zuverlässigen Verwendung.

- Lesen Sie die Bedienungsanleitung aufmerksam durch.
- Bewahren Sie die Bedienungsanleitung auf, auf die Sie an einem Benutzer weitergeben.

Die CHERRY MW 8C ADVANCED ist eine kabellose Maus zur Bedienung von PCs/Notebooks. Funktionen zu weiteren Produkten, Downloads und vielem mehr, besuchen Sie bitte www.cherry.de.

1 Zu Ihrer Sicherheit

Erstursungsgefahr durch Verschlucken von Kleinteilen

- Bewahren Sie das Gerät außerhalb der Reichweite von Kindern unter 3 Jahren auf.

„Repetitive Strain Injury“ = „Verletzung durch wiederholte Beanspruchung“

RSI entsteht durch, wenn sich ständig wiederholende Bewegungen und/oder:

- Richten Sie Ihre Arbeitspostur ergonomisch ein.
- Positionieren Sie Tastatur und Maus, so dass sich Ihre Oberarme und Handgelenke, um Ihre Körpermitte befinden und ausgestreckt sind.
- Machen Sie mehrere kleine Pausen, ggf. mit Dehnübungen.
- Ändern Sie oft Ihre Körperhaltung.

2 Beschädigungen vermeiden

Löschen von Speicherdaten und Beschädigung von mechanischen Uhren durch Magnet in der Maus

- Bringen Sie keine Speichergeräte, wie Magnetkarten oder externe Festplatten, und keine mechanischen Uhren näher als 10 cm zur Maus.

3 Maus mit dem PC/Notebook verbinden

Sie können die Maus über Bluetooth mit dem PC/ Notebook verbinden oder mit dem Empfänger über eine 2.4 GHz-Funkverbindung.

3.1 Maus über Bluetooth verbinden

Bluetooth-Version

Sie benötigen einen PC/Notebook mit einem Bluetooth-Empfänger, der mindestens Bluetooth 4.0 unterstützt.

- Öffnen Sie an Ihrem PC/Notebook die Suche nach Bluetooth-Geräten (zum Beispiel unter „Einstellungen > Geräte > Bluetooth“).
- Folgen Sie den Anweisungen der Software.
- Stellen Sie auf der Unterseite der Maus den Schalter auf „BT“.
- Aktivieren Sie die Bluetooth-Verbindung der Maus, indem Sie den Knopf an der Unterseite der Maus drücken.

Falls die blaue LED nicht blinkt:

- Falls die blaue LED nicht blinkt:
- Es besteht bereits eine Verbindung der Maus mit einem anderen PC/Notebook. Schalten Sie diesen PC/Notebook aus oder deaktivieren Sie die Verbindung an diesem PC/Notebook.
- Falls die rote LED der Maus schnell blinkt, ist die Verbindung fehlerhaft.
- Versuchen Sie es erneut.

3.2 Maus über Empfänger verbinden

Der Empfänger befindet sich in einem Fach an der Unterseite der Maus und wird durch einen Magneteten geschützt.

- Ziehen Sie den Empfänger aus dem Gehäuse.
- Schließen Sie den Empfänger möglichst an einer USB 2.0-Buchse des PCs/Notebooks an. Diese hat eine weiße oder schwarze Führung.
- Stellen Sie auf der Unterseite der Maus den Schalter auf „RF“.

Die Maus ist mit einem PC/Notebook verbunden.

Der Empfänger befindet sich in einem Fach an der Unterseite der Maus und wird durch einen Magneteten geschützt.

- Ziehen Sie den Empfänger aus dem Gehäuse.
- Schließen Sie den Empfänger möglichst an einer USB 2.0-Buchse des PCs/Notebooks an. Diese hat eine weiße oder schwarze Führung.
- Stellen Sie auf der Unterseite der Maus den Schalter auf „RF“.

4 Empfänger in der Maus verstecken

Der Empfänger ist so klein, dass er auch beim Transport eines Notebooks in der USB-Buchse bleiben kann. Zum Schutz vor Verschmutzung und Verlust ziehen Sie den Empfänger ab und deponieren ihn in der Maus.

5 Mausuntergrund

Eine helle, strukturierte Fläche als Mausuntergrund kann die Effektivität der Maus, spart Energie und gewährleistet eine optimale Bewegungserkennung. Eine spegelfläche ist als Mausuntergrund nicht geeignet.

6 DPI-Zahl der Maus einstellen

Mit der Höhe der DPI-Zahl steigt die Geschwindigkeit der Maus.

- Drücken Sie die DPI-Taste auf der Mausoberseite. Die LED blinkt je nach Einstellung:
 - 1x = 400 dpi, 2x = 1000 dpi, 3x = 1600 dpi, 4x = 3200 dpi

Die Einstellung wird in der Maus gespeichert und bleibt auch beim Ausschalten erhalten.

7 Maus ein-/ausschalten

Die Maus schaltet bei Nichtbenutzung in einen Schlaf-Modus, in dem sie fast keine Energie benötigt. Um den Tastendruck schaltet sie sich automatisch wieder ein.

Weil sie im Energieparasitismus trotzdem Energie verbraucht, sollten Sie sie bei längeren Nichtbenutzung und zum Transport manuell ausschalten.

- Schieben Sie den Schalter auf der Mausunterseite in die entsprechende Position:
 - Aus = off
 - Ein (Funktion) = RF
 - Ein (Bluetooth) = BT

8 Akku laden

Wenn die Spannung des Akkus der Maus nachlässt, blinkt die DPI-Taste (10, danach stoppt das Signal. Dies geschieht, wenn Sie nach dem Starten des PCs/Notebooks mit der Maus arbeiten oder sie aus dem Schlaf-Modus wecken. Rechtzeitiges Laden verlängert die Lebensdauer des Akkus.

- Verbinden Sie das Ladekabel mit der Buchse der Maus und einem USB-Anschluss oder einem USB-Netzadapter.
- Ihre Stromquelle (PC/Notebook) muss eingeschaltet sein. Sie können während des Ladevorgangs weiterarbeiten, die DPI-Taste der Maus leuchtet rot.

Wenn die DPI-Taste der Maus erlischt, ist der Akku der Maus voll geladen. Die Ladeschaltung verhindert ein Überladen.

9 Maus reinigen

1. Schalten Sie die Maus aus.
HINWEIS: Beschädigung durch aggressive Reinigungsmittel oder Flüssigkeit in der Maus

- Verwenden Sie zur Reinigung keine Lösungsmittel wie Benzin oder Alkohol und keine Scheuermittel oder Scheuerschwämme.
- Verhindern Sie, dass Flüssigkeit in die Maus gelangt.

2. Reinigen Sie die Maus mit einem leicht feuchten Tuch und etwas mildem Reinigungsmittel (z. B. Geschirrspülmittel).

3. Trocknen Sie die Maus mit einem fusselfreien, weichen Tuch.

10 Falls die Maus nicht funktioniert

- Schalten Sie die Maus aus und wieder ein.
- Laden Sie die Maus über das Ladekabel (siehe 8 „Akku laden“).
- Entfernen Sie Störgegenstände zwischen der Maus und dem PC/Notebook. Störend sind vor allem metallische oder elektrische Gegenstände, wie Kabel, Lautsprecher oder USB-Hubs.
- Verringern Sie den Abstand zwischen der Maus und dem PC/Notebook.
- Falls es bei der Nutzung von USB 3.0-Geräten in der direkten Umgebung des Empfängers zu Störungen kommt: Verwenden Sie für den Empfänger das USB 2.0-Gerät, um die Entfernung des Anschlusses, ein zusätzliches Kabel oder einen USB-Hub.

10.1 Störung der Bluetooth-Verbindung beseitigen

Prüfen Sie, ob der interne Empfänger Ihres PCs/Notebooks mindestens dem Bluetooth-Standard 4.0 entspricht. Niedrigere Versionen werden nicht unterstützt.

- Wenn sich Ihr PC/Notebook im Standby-Modus befindet, ist ein Aufwecken über Bluetooth-Geräte nicht möglich. Schalten Sie den PC/Notebook manuell ein.
- Falls die Maus bereits mit einem anderen PC/Notebook verbunden ist, können Sie keine Verbindung herstellen. Schalten Sie den ersten PC/Notebook aus oder deaktivieren Sie die Verbindung.

Betrieb mehrerer Bluetooth-Geräte an einem PC/Notebook

Wenn Sie viele Bluetooth-Geräte anschließen, können die im PC/Notebook integrierten Bluetooth-Empfänger überfordert sein.

- Schalten Sie unbeteiligte Bluetooth-Geräte aus.
- Entfernen Sie die Maus in der Bluetooth-Software und fügen Sie sie als neues Gerät wieder hinzu.
- Verbinden Sie einen externen Bluetooth-Empfänger.
- Schließen Sie die Maus über den Empfänger an.

10.2 Störung der Verbindung über den Empfänger beseitigen

- Schließen Sie den Empfänger an einer USB 2.0-Buchse des PCs/Notebooks an. Idealerweise hat diese eine weiße oder schwarze Führung. An USB 3.0-Buchsen (blaue Führung) kommt es manchmal zu Verbindungsproblemen.
- Schließen Sie den Empfänger an einer anderen USB 2.0-Buchse am PC/Notebook an.
- Verringern Sie den Abstand zwischen dem Empfänger und der Maus, indem Sie den Empfänger an einer USB-Buchse anschließen, die sich an der Maus befindet.
- Verwenden Sie ein USB-Verlängerungskabel, um den Empfänger möglichst nah an der Maus zu platzieren.

11 Geräte entsorgen

- Entsorgen Sie Geräte mit diesem Symbol nicht mit dem Hausmüll.
- Entsorgen Sie Geräte, entsprechend den gesetzlichen Vorschriften, bei Ihrem Händler oder den kommunalen Sammelstellen.

12 Technische Daten

Bezeichnung	Wert
Versorgungsspannung	Maus: 3,7 VDC ±5 % Empfänger: 5,0 VDC ±5 %
Ladespannung	Typ. 5,0 VDC
Ladestrom	Max. 300 mA
Stromaufnahme	Maus: max. 10 mA Empfänger: max. 25 mA
Batterie	Aufladbare Lithium-Ionen-Batterie, 550 mAh
Sendefrequenz	2400,0 ... 2483,5 MHz
Sendeleistung	Max. 10 mW (EIRP)
Bluetooth	4.2
Temperaturbereich	-15 °C ... +40 °C
Betriebstemperatur	0 °C ... +40 °C

13 Kontakt

Cherry Europe GmbH,
Cherrystraße
91775 Auerbach/OPH
Internet: www.cherry.de
Telefon: +49 (0) 164 2061-1000
*zum Ortsteil aus dem deutschen Festnetz, abweichend von den Angaben der Mobilfunkanbieter

14 EU-Konformitätserklärung

Hierby erklärt die Cherry Europe GmbH, Auerbach/OPH, Deutschland, dass dieser Produkt die Richtlinie 2014/53/EU entspricht. Den vollständigen Text der EU-Konformitätserklärung finden Sie unter folgender Internet-Adresse: www.cherry.de/compliance.

EN OPERATING MANUAL

Designation	Value
Supply voltage	Maus: 3,7 VDC ±5 % Receiver: 5,0 VDC ±5 %
Charging voltage	Typ. 5,0 VDC
Charging current	Max. 300 mA
Current consumption	Maus: max. 10 mA Receiver: max. 25 mA
Battery	Rechargeable lithium ion battery, 550 mAh
Operating frequency	2400,0 ... 2483,5 MHz
Effective radiated power	Max. 10 mW (EIRP)
Bluetooth	4.2
Storage temperature	-15 °C ... +40 °C
Operating temperature	0 °C ... +40 °C

15 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

16 Storing the receiver in the mouse

The receiver is so small that it can stay in the USB socket of a laptop while being transported. To avoid any damage, you can also pull out the receiver and deposit it in the mouse to protect it from dirt and loss.

17 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

18 Surface under the mouse

The mouse is most effective on a light-colored, textured surface, which saves energy and ensures optimal motion detection.

A reflective surface is not suitable for using the mouse on.

19 Setting the DPI rate of the mouse

The speed of the mouse pointer increases with the level of the DPI rate. To change the DPI rate, press the DPI button on the top of the mouse. The LED flashes according to the setting:

- 1x = 400 dpi, 2x = 1000 dpi, 3x = 1600 dpi, 4x = 3200 dpi

20 Switching the mouse on/off

The mouse switches to a sleep mode, which requires nearly no energy, when it is not in use. It switches on again automatically the first time a button is pressed. However, the mouse will consume power if it remains in sleep mode, therefore you should switch it off manually for longer periods of disuse or for transport.

21 Charging the battery

Push the switch on the bottom of the mouse to the corresponding position:

- Off
- Shut down = off
- On = RF
- On = Bluetooth

22 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "BT". The mouse is connected with your PC/Laptop.

23 Surface under the mouse

The mouse is most effective on a light-colored, textured surface, which saves energy and ensures optimal motion detection.

A reflective surface is not suitable for using the mouse on.

24 Setting the DPI rate of the mouse

The speed of the mouse pointer increases with the level of the DPI rate. To change the DPI rate, press the DPI button on the top of the mouse. The LED flashes according to the setting:

- 1x = 400 dpi, 2x = 1000 dpi, 3x = 1600 dpi, 4x = 3200 dpi

25 Switching the mouse on/off

The mouse switches to a sleep mode, which requires nearly no energy, when it is not in use. It switches on again automatically the first time a button is pressed. However, the mouse will consume power if it remains in sleep mode, therefore you should switch it off manually for longer periods of disuse or for transport.

26 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

27 Storing the receiver in the mouse

The receiver is so small that it can stay in the USB socket of a laptop while being transported. To avoid any damage, you can also pull out the receiver and deposit it in the mouse to protect it from dirt and loss.

28 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

29 Surface under the mouse

The mouse is most effective on a light-colored, textured surface, which saves energy and ensures optimal motion detection.

A reflective surface is not suitable for using the mouse on.

30 Setting the DPI rate of the mouse

The speed of the mouse pointer increases with the level of the DPI rate. To change the DPI rate, press the DPI button on the top of the mouse. The LED flashes according to the setting:

- 1x = 400 dpi, 2x = 1000 dpi, 3x = 1600 dpi, 4x = 3200 dpi

31 Switching the mouse on/off

The mouse switches to a sleep mode, which requires nearly no energy, when it is not in use. It switches on again automatically the first time a button is pressed. However, the mouse will consume power if it remains in sleep mode, therefore you should switch it off manually for longer periods of disuse or for transport.

32 Charging the battery

Push the switch on the bottom of the mouse to the corresponding position:

- Off
- Shut down = off
- On = RF
- On = Bluetooth

33 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

34 Surface under the mouse

The mouse is most effective on a light-colored, textured surface, which saves energy and ensures optimal motion detection.

A reflective surface is not suitable for using the mouse on.

35 Setting the DPI rate of the mouse

The speed of the mouse pointer increases with the level of the DPI rate. To change the DPI rate, press the DPI button on the top of the mouse. The LED flashes according to the setting:

- 1x = 400 dpi, 2x = 1000 dpi, 3x = 1600 dpi, 4x = 3200 dpi

36 Switching the mouse on/off

The mouse switches to a sleep mode, which requires nearly no energy, when it is not in use. It switches on again automatically the first time a button is pressed. However, the mouse will consume power if it remains in sleep mode, therefore you should switch it off manually for longer periods of disuse or for transport.

37 Charging the battery

Push the switch on the bottom of the mouse to the corresponding position:

- Off
- Shut down = off
- On = RF
- On = Bluetooth

38 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

39 Surface under the mouse

The mouse is most effective on a light-colored, textured surface, which saves energy and ensures optimal motion detection.

A reflective surface is not suitable for using the mouse on.

40 Setting the DPI rate of the mouse

The speed of the mouse pointer increases with the level of the DPI rate. To change the DPI rate, press the DPI button on the top of the mouse. The LED flashes according to the setting:

- 1x = 400 dpi, 2x = 1000 dpi, 3x = 1600 dpi, 4x = 3200 dpi

41 Switching the mouse on/off

The mouse switches to a sleep mode, which requires nearly no energy, when it is not in use. It switches on again automatically the first time a button is pressed. However, the mouse will consume power if it remains in sleep mode, therefore you should switch it off manually for longer periods of disuse or for transport.

42 Charging the battery

Push the switch on the bottom of the mouse to the corresponding position:

- Off
- Shut down = off
- On = RF
- On = Bluetooth

43 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

44 Surface under the mouse

The mouse is most effective on a light-colored, textured surface, which saves energy and ensures optimal motion detection.

A reflective surface is not suitable for using the mouse on.

45 Setting the DPI rate of the mouse

The speed of the mouse pointer increases with the level of the DPI rate. To change the DPI rate, press the DPI button on the top of the mouse. The LED flashes according to the setting:

- 1x = 400 dpi, 2x = 1000 dpi, 3x = 1600 dpi, 4x = 3200 dpi

46 Switching the mouse on/off

The mouse switches to a sleep mode, which requires nearly no energy, when it is not in use. It switches on again automatically the first time a button is pressed. However, the mouse will consume power if it remains in sleep mode, therefore you should switch it off manually for longer periods of disuse or for transport.

47 Charging the battery

Push the switch on the bottom of the mouse to the corresponding position:

- Off
- Shut down = off
- On = RF
- On = Bluetooth

48 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

49 Surface under the mouse

The mouse is most effective on a light-colored, textured surface, which saves energy and ensures optimal motion detection.

A reflective surface is not suitable for using the mouse on.

50 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

51 Storing the receiver in the mouse

The receiver is so small that it can stay in the USB socket of a laptop while being transported. To avoid any damage, you can also pull out the receiver and deposit it in the mouse to protect it from dirt and loss.

52 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

53 Surface under the mouse

The mouse is most effective on a light-colored, textured surface, which saves energy and ensures optimal motion detection.

A reflective surface is not suitable for using the mouse on.

54 Setting the DPI rate of the mouse

The speed of the mouse pointer increases with the level of the DPI rate. To change the DPI rate, press the DPI button on the top of the mouse. The LED flashes according to the setting:

- 1x = 400 dpi, 2x = 1000 dpi, 3x = 1600 dpi, 4x = 3200 dpi

55 Switching the mouse on/off

The mouse switches to a sleep mode, which requires nearly no energy, when it is not in use. It switches on again automatically the first time a button is pressed. However, the mouse will consume power if it remains in sleep mode, therefore you should switch it off manually for longer periods of disuse or for transport.

56 Charging the battery

Push the switch on the bottom of the mouse to the corresponding position:

- Off
- Shut down = off
- On = RF
- On = Bluetooth

57 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

58 Surface under the mouse

The mouse is most effective on a light-colored, textured surface, which saves energy and ensures optimal motion detection.

A reflective surface is not suitable for using the mouse on.

59 Setting the DPI rate of the mouse

The speed of the mouse pointer increases with the level of the DPI rate. To change the DPI rate, press the DPI button on the top of the mouse. The LED flashes according to the setting:

- 1x = 400 dpi, 2x = 1000 dpi, 3x = 1600 dpi, 4x = 3200 dpi

60 Switching the mouse on/off

The mouse switches to a sleep mode, which requires nearly no energy, when it is not in use. It switches on again automatically the first time a button is pressed. However, the mouse will consume power if it remains in sleep mode, therefore you should switch it off manually for longer periods of disuse or for transport.

61 Charging the battery

Push the switch on the bottom of the mouse to the corresponding position:

- Off
- Shut down = off
- On = RF
- On = Bluetooth

62 Connecting the mouse with a PC/Laptop

The receiver is in a compartment on the bottom of the mouse and is held in place by a magnet.

- Pull the receiver out of the housing.
- Connect the receiver to a USB 2.0 port on your PC/Laptop (this usually has a white or black guide).
- Set the switch on the bottom of the mouse to "RF". The mouse is connected with your PC/Laptop.

63 Surface under the mouse

The mouse is most effective on a light-colored, textured surface, which saves energy and ensures optimal motion detection.

A reflective surface is not suitable for using the mouse on.

64 Setting the DPI rate of the mouse

The speed of the mouse pointer increases with the level of the DPI rate. To change the DPI rate, press the DPI button on the top of the mouse. The LED flashes according to the setting:

- 1x = 400 dpi, 2x = 1000 dpi, 3x = 1600 dpi, 4x = 3200 dpi

65 Switching the mouse on/off

The mouse switches to a sleep mode, which requires nearly no energy, when it is not in use. It switches on again automatically the first time a button is pressed. However, the mouse will consume power if it remains in sleep mode, therefore you should switch it off manually for longer periods of disuse or for transport.

