EI-7534

HYPERDRONE RACING STARTER KIT

For ages 14+
A1 14 Jahre
A partir de 14 ans
A partir de 14 jaar
A partir de 14 años
Da 14 anni in su

Hornby Skew Whiff Two Manufactory Ltd declares that the radio equipment 04769 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address: www.silverlit.com/certificate

MFR No. 04769

Delivery contents

Precautions, Warning & Statement

The crossed-out dustbin symbol indicates that batteries, rechargeable batteries, button cells, battery packs, etc. must not be put in the household waste. Batteries are harmful to the health of humans and animals and pollute the environment from health risks. If the toy is out of use, please use common household tool to break the product for build-in batteries removal. Please contact your local waste disposal for replaceable battery operated toy, then take the battery out from the toy. Dispose of battery in accordance with your local battery recycling or disposal laws.

WEEE
When this appliance is out of use, please remove all batteries and dispose of it in environmentally friendly manner at the local collecting points for waste electrical and electronic equipment. Other components can be disposed of in domestic refuse.

Safety Precautions:

Warning: Conversion or modifications to this product not expressly approved by the party responsible for compliance could void the user's authority to operate the product.
- The charging cable is tailor-made for the LiPo rechargeable battery used in quadcopter. Do not use it to charge any battery other than that in the quadcopter.

FCC Statements

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and
(2)This device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.
These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Special notes:
- Please read the operation instructions carefully prior to the first use.
- This product intended to be used in domestic area (house and garden) only. Do not charge or modify anything on the quadcopter.

Battery warnings:
- Non-rechargeable batteries are not to be exchanged.
- Rechargeable batteries are to be removed before being charged. (Transmitter and Station)
- Rechargeable batteries are only to be charged under adult supervision.
- Different types of batteries or new and used batteries are not to be mixed. (Transmitter and Station)
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with correct polarity.
- Exhausted batteries are to be removed from this product. (Transmitter and Station)
- The supply terminals are not to be short-circuited.
- Do not mix old and new batteries. (Transmitter and Station)
- Do not mix alkaline, standard (carbon-zinc) or rechargeable batteries. (Transmitter and Station)

Quadcopter is equipped with a LiPo rechargeable battery, please pay attention to the following cautions for safety use:
- Do not dispose the battery in fire or heat.
- Do not cut or leave the battery near a heat source such as fire or heater.
- Do not strike or throw the battery against hard surface.
- Do not immerse the battery in water, and keep the battery in a cool dry environment.
- Avoid overcharging, only use the battery charger specifically for that purpose.
- Do not over discharge the battery.
- Do not connect the battery to any electrical outlet.
- Do not directly solder the battery and pierce the battery with a nail or other sharp object.
- Do not put the battery alone the battery together with metal objects such as necklaces, hairpins etc.
- Do not disassemble or alter the battery.
- Charge the battery every 6 months.

Notes:
- Nine alkaline batteries are recommended to use in this product to obtain best and maximum performance.
- This product must only be used with the recommended charger.

Battery requirements (Station):

	Power Supply	⎓
	Rating	4.5 V DC , 0.9 W
	Batteries	3 x 1.5 V "AA"/LR6/AM3 (not included)

Battery requirements (Transmitter):

	Power Supply	⎓
	Rating	4.5 V DC , 0.2 W
	Batteries	3 x 1.5 V "AA"/LR6/AM3 (not included)

Battery requirements (Quadcopter):

Power Supply	⎓
Rating	3.7 V DC , 12 W
Batteries	1 x 3.7 V LiPo battery (included)
Capacity	280 mAh

Care and Maintenance:
- Keep the product away from the product when it is not being used for a long period of time. (Transmitter only)
- Regularly examine for damages to the plug, enclosure and other parts. In the event of any damage, the product must not be used with the transmitter charger until the damage has been repaired.
- Keep the product dry. Clean it with a cloth.
- Keep the product away from direct heat.
- Do not submerge the product into water that can damage the electronic assemblies.

TIP SAFETY

- Quadcopter piloting requires specific skills and should be learned under direct supervision of an experienced adult.
- Never operate this product if it has damaged parts.
- Do not fly the quadcopter near the face, eyes, hair, clothes or any obstructions are within the flying range of this quadcopter.
- For safe use, the room where the toy is used must be sufficiently large.
- Do not fly the quadcopter in the vicinity of water and power lines.
- Always keep your eyes on the quadcopter and prevent it from landing or crashing near your head, your body, or on other people.
- Stand during operation in order to get out of the way of the quadcopter in case of malfunction.
- Always switch the quadcopter and the transmitter off when not operating.
- *Warning!* Do not touch the running rotors. Keep hands, hair and loose clothes away from moving parts to avoid injury.
- Never hold or throw any object(s) into the running rotors.
- Do not fly the quadcopter when the LED lights are fade to avoid injuries.
- Keep this instruction manual for future reference.

The normal function of the product may be disturbed by Strong Electromagnetic Interference. If so, simply reset the product to resume normal operation by following the instruction manual. In case the function could not resume, please use the product in other location.

GET IT ON Google Play — Android is a trademark of Google Inc. Google Play is a trademark of Google Inc.

Available on the App Store — Apple, the Apple logo, iPhone, iPad and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc.

Parts Identification



	QUADCOPTER CONTROL MODE	RACING CONTROL MODE
	(Normal Quadcopter Control)	(Similar to RC Car Control)
1	Mount Buttons (press once to lock on opponent)	
2	HX Lock Battery Indicator	
3	FLYSync Indicator	
4	Throttle / Up-Down (Yaw)	Forward
5	Down (Down Trim)	Backward
6	ROW Trim	Slide Left
7	ROW	Slide Right
8	Forward	Left
9	Backward	Right
10	Left / Right	Turn Left / Right
11	Racer Control Mode	
12	Quadcopter Control Mode	
13	Power (ON/OFF)	
14	FLYSync Trimmer (Pitch)	
15	FLYSync Trimmer (Roll)	
16	Auto Take-off / Landing / Flip (press & hold over 2s)	
17	Fly Mode Switch	
18	Flip (centre)	

Battery Installation & Charging

Transmitter Battery Installation (*Make sure the power switch is on "OFF" position.)

Station Battery Installation (*Make sure the power switch is on "OFF" position.)



Note: When the power indicator on the transmitter starts blinking, replace the batteries.

Charging the Quadcopter

Note: 1. The quadcopter can operate for about 4~6 minutes per every 20-40 minutes charging.
2. Before recharging the battery, wait 10 - 15 minutes for it to cool down.

Flying Your Hyperdrone

TIP CONTROLLING

For controlling the sticks on transmitter, try not to push the sticks immediately any extreme positions. It should be like steering a bicycle rather than pressing computer game sticks.
- For the novice pilot (after the trimming procedure is completed), it is highly recommended to focus exclusively on learning to control the throttle stick first. If the quadcopter is flying too high, too low, too fast or too slow, then it is difficult to control. Be important to keep the throttle stick at a constant altitude of around 1 meter with very gentle inputs on the throttle stick. Once the pilot masters this, he may start learning to take control with the direction stick.

1. Procedure for PAIR / SYNC the quadcopter and transmitter
2.4 GHz technology allows for many quadcopters to fly without signal interference. A connection, PAIR / SYNC, must be made between the transmitter and the quadcopter before flying. To complete these steps to PAIR/SYNC the quadcopter and the transmitter:
- Turn the ON/OFF switch of Quadcopter to ON position and the red LED lights on the Quadcopter will flash (fig. 1). Then place it on the ground.
- Switch ON the transmitter and the Red LEDs light on the Quadcopter will flash (fig. 2). Push the throttle sticks to top then pull down, to bottom (fig. 3). The power indicator on transmitter will light up. The pair/sync procedure is completed.

Self Calibration
Place the Quadcopter on a horizontal surface.
Pull the left and right stick to lower left corner (fig. 4). After 8 seconds, You will hear a "BEEP BEEP" sound. The red LED lights on the Quadcopter will flash. Release the sticks, the quadcopter now.
(Only do the Self-Calibration when Quadcopter has an imitation fly.)

2. Flying Environment Requirements
2.1. Before your first flight, please study this Instruction Manual and understand all the features and controls. For those who do not have any RC flying experience, it is highly recommended to seek advice from more experienced person.
2.2. DO NOT fly in bad weather, such as rain, wind or fog.
2.3. The environment should be open and void of buildings or no other obstacles.
2.4. Do not fly near high voltage power lines, communication towers, water towers, trees, lakes and rivers etc.
2.5. Try to avoid interference between the transmitter and other wireless equipment.

3. Trimming The Quadcopter (Quadcopter Control Mode Only)
- Gently push the throttle stick up to raise the quadcopter about 0.5 to 1 meter above the ground.

4. Flight Control (Racer Control Mode)

Fly up and down:
The right stick controls the quadcopter elevation.
Push the stick forward and the quadcopter will ascend.
Pull the stick downward and the quadcopter will descend.
Only small amounts of stick position changes are required for smooth flying.

Turn left and right:
Push the right stick toward left to turn the quadcopter counterclockwise, and push the throttle stick toward right to turn it clockwise.

Forward and backward:
Maintain the quadcopter at a certain height. Push the direction stick upward to move the quadcopter forward. Pull it downward to fly the quadcopter backward.

Flying sideways:
Push the direction stick left to fly the quadcopter sideways to the left. Push it right to fly the quadcopter sideways to the right.

5. Flight Control (Quadcopter Control Mode)

Fly up and down:
The left stick controls the quadcopter elevation.
Push the stick forward and the quadcopter will rise.
Pull the stick downward and the quadcopter will descend.
Only small amounts of stick position changes are required for smooth flying.

Turn left and right:
Push the left stick toward left to turn the quadcopter counterclockwise, and push the throttle stick toward right to turn it clockwise.

Forward and backward:
Push the right stick upward to fly the quadcopter forward. Pull it downward to fly the quadcopter backward.

Flying sideways:
Push the right stick left to fly the quadcopter sideways to the left. Push it right to fly the quadcopter sideways to the right.

6. Lift-off Procedure (After Trimming Procedure):
- Put the quadcopter on a smooth surface. Uneven floor surface will affect its lifting off.
- Slowly increase the throttle.
- DO NOT look at the transmitter but focus on the quadcopter.
- The quadcopter will lift off the ground. Hover ground, reduce the throttle slightly.
In the worst case, quadcopter will go back to the floor, but that is better than crashing against the ceiling!
- VERY gently add the throttle if the quadcopter goes down.
- VERY gently reduce the throttle if the quadcopter goes up.
- For turning, give short and small inputs to the direction stick. (Most beginners will easily overcontrol the quadcopter)
- For moving forward, turn the quadcopter pointing to more open space before pushing the forward buttons.

7. Flight control: Take off and altitude control

7.1 Auto take-off & landing

Press "Auto take off / landing" button (fig. 5A). Quadcopter flies up to a standard level and hover in the air (fig. 5B).
Press again "Auto take off / landing" button. Quadcopter will land automatically.
Press and hold over 2 seconds for emergency stop.

7.2 Manual take off
Push up the altitude stick to ascend the Quadcopter (fig. 6A), push down to descend, release to lock the altitude (fig. 6B).

8. Arming motors:
Push the throttle stick and lower left corner and right stick to lower right corner simultaneously and the motors will start spinning (fig. 7A & 7B). Push the altitude stick up to ascend the Quadcopter.
After descending the Quadcopter, disarm the motors by pushing both sticks at the same time as picture shown. (fig. 7D)

9. Fly mode setting (Quadcopter Control Mode)

Vertically press one time the altitude stick, you will hear a "BEEP" sound to indicating **Beginner Mode**. Press again to enter **Intermediate Mode** after hears a "BEEP BEEP" sound. You can enter into the **Advance Mode** after you press one more time the button and hear "BEEP BEEP BEEP" sound.

10. 360° Flip

Keep the Quadcopter flying smoothly in the air. Vertical press the direction stick once, now you can pull the direction stick to achieve front, back, left, right side flip.

Note: The battery is low, if the power indicator on the transmitter will start blinking.

App Operation Steps

Viewer App requirements: IOS - minimum iOS 8.0 or above, Android - minimum Android 4.4 or above
Prepare your device to set up the operation procedure following the below steps :

TIP GAME RECORD:

Install "Silverlit Hyperdrone" game app on your smart device to view your game record

Racing Game

Battling Mode



TIP SHOOTING MECHANISM:

- When your Quadcopter is within the Shooting Range of either other Quadcopters or Station, your TX will show sound effects.
- When your Quadcopter is being rotected-on by the Station, you can leave the Shooting Range within 1s or you will get attacked

Effects of being Attacked:

When your Quadcopter gets attack once, it will drop energy 7 HO & SHO alternatively for 3 times.
After the animation, it will be in defensive status (ignore any other attack) for 3s.

When your Quadcopter gets attack again within 3s after the last being attacks, it drains 10X for 5 x for fast speed. After the animation, it will be in defensive status for 10s.

When your Quadcopter gets attack again within 3s after the last being attacks, it drains 15X for 5 x for fast speed. After the animation, it will be in defensive status for 15s.

Trouble Shooting

Symptom	Cause	Correction
Motor does not turn	- ON/OFF Switch is OFF - Low battery	- Set switch to ON - Recharge battery (ies)
The arrow indicator on transmitter blinking	- Weak power of transmitter	- Change new batteries in transmitter
The quadcopter does not react.	- FlySync process does not established.	- Reset the trim parameters. - Re-establish the FlySync process.
The station does not react or malfunctions.	- Operation may not run properly due to ESD	- Switch off the station and turn on again
Lots of control.	- Another radio control device using the same frequency and channel is operated near your quadcopter and the station	- Move to another place where without radio frequency interference from another device. - The normal range for quadcopter is up to 20 meters.