USER GUIDE

Wireless Bluetooth Earbuds



INDEX

BASIC SETUP
SETTING UP AND FITTING 02
OVER-EAR FITTING 14
USING THE EARBUDS
ACCESSORIES 31
CHARGING THE BATTERY 31
PAIRING 33
COMMANDS 37
SPECIFICATION 38
WARRANTY 39

01

02

SETTING UP AND FITTING

01 WHAT'S INSIDE

03

02 EARBUD ORIENTATION

EAR TIP ANGLE DESIGN FOLLOWS INWARD DIRECTION OF YOUR EAR CANAL FOR A SNUG FIT.

CONTROLS AND MIC ON **LEFT** SIDE

04

03 THE RIGHT SIZE FOR GREAT SOUND PERFORMANCE

HEARING IS BELIEVING
Great sound can only be believed with the right size eartip.

ADD STABILITY AND COMFORT
Recommended if the eartip moves out of place due to body movement resulting in a reduction in audio quality.
The earbud stabilizers hold the earbuds in place to a more comfortable and secure fit.

05

04 PROPER FITTING

ATTACH AN EAR TIP AND FAN YOUR EARBUDS TO A BLUETOOTH ENABLED DEVICE. TRY EACH EAR TIP TO DETERMINE THE BEST FIT AND SOUND PERFORMANCE.

The best music performance is only achieved with the right ear to eartip seal.

NEED TO PAIR?
See page 33-37 for pair your earbuds.



06

05 COMFORT AND SECURITY

INSTALL THE EAR STABILIZER TO HOLD THE EARBUDS IN PLACE TO A MORE COMFORTABLE AND SECURE FIT.

07

THE EAR STABILIZERS CAN BE ADJUSTED FOR BEST FIT. POSITION THE EAR STABILIZER AS SHOWN AND GENTLY ADJUST OVER THE NOZZLE.

08

THE STABILIZERS ARE ONLY AVAILABLE FOR THE TYPE OF EAR TIPS INDICATED IN THE ILLUSTRATION.

09

10

06 Connected

11

12

13

OVER-EAR FITTING

14

15

THE OVER-EAR FITTING OPTION IS DESIGNED FOR PURE LISTENING PLEASURE.
THE MICROPHONE AND CONTROLS ARE LOCATED BEHIND THE EAR IN THIS FITTING OPTION.
WHILE OVER-EAR FITTING IS A GREAT WAY TO LISTEN TO MUSIC,
SOME ADJUSTMENT IS REQUIRED TO FIT THE EARBUDS CORRECTLY.

16

17

01 YOU CHOOSE YOUR EAR TIPS FOR COMFORT AND STABILITY...

NOW IT'S TIME TO EXPERIENCE PURE MUSIC PLEASURE.
THIS IS THE OVER-EAR FITTING OPTION.

IT IS NOT NECESSARY TO REMOVE THE EARBUD STABILIZERS TO ADJUST THEM FOR AN OVER-EAR FITTING.

18

02 COMFORTABLY SECURED

INSERT THE EARBUD IN YOUR EAR AND ADJUST AS THE EAR STABILIZER NEEDED FOR MAXIMUM COMFORT.

IT IS BEST TO TEST EACH EAR TIP TO DETERMINE THE BEST FIT AND SOUND PERFORMANCE.

19

INSTALL THE EAR STABILIZER OVER THE EARBUD AS SHOWN.

TO ADJUST THE FIT, ROTATE THE STABILIZER ON THE EARBUD.

20

THE EARBUD AND EAR TIP DESIGN IS INTENDED TO FIT COMFORTABLY IN THE EAR CANAL. IN COMBINATION WITH THE EARBUD STABILIZER, YOUR EARBUDS MAKE LISTENING TO MUSIC SHEER ECSTASY.

21

03 EAR BUD ORIENTATION

OVER LEFT EAR:
Controller and MIC location

THE EAR TIP IS SPECIFICALLY DESIGNED FOR A SPECIFIC EAR. CORRECT FIT FOR BEST RESULTS USE THE LEFT EARBUD IN THE LEFT EAR.

22

04 CORD MANAGEMENT CLIPS

23

OVER-EAR MODE REQUIRES LESS CORD. SO BEFORE FITTING, INSTALL THE CORD MANAGEMENT CLIPS TO SECURE THE SLACK FOR A CUSTOMIZED FIT.
SEE NEXT STEPS.

24

MAKE AN "S" SHAPE WITH THE MIDDLE SECTION OF THE CORD.



25

INSERT CORD INTO THE 2 SLOTS IN EACH CLIP AS SHOWN.

26

USE YOUR FINGER TO GENTLY INSERT THE EARBUDS IN YOUR EAR



27

TAKE OFF HEADPHONES. INSERT CORD INTO THE FINAL ROUNDED SLOTS. PUT HEADPHONES BACK ON. NOW YOU ARE READY TO GO!

28

05 CONNECTED

29

USING THE EARBUDS

30

ACCESSORIES

Wireless bluetooth earbuds
Carrying case
1 ear stabilizer pair (LARGE)
1 ear stabilizer pair
2 cord management clips
1 USB cable
1 quick start guide

CHARGING

Before using your Bluetooth earbuds, make sure you fully charge them to extend the life of the battery.

1. To access the USB port (controller box), pull back the cover to expose the USB port.
2. Insert the USB cable into the port. The LED light starts red and the blue one charging is complete.
3. Fully charged earbuds take 2 hours.
4. To check earbuds' battery status: Turn earbuds on, tap volume up or down to trigger a status response.
   - When listening to music, tap Power and wait for blue LED flashes. Tap volume up or down to trigger a status response.

31

AUDIBLE "BATTERY LOW"
Approx. 3 mins prior to empty.

ARE HEADPHONES ON? IS BATTERY LOW?
LED flashes:
Red: Low battery / Power on
Blue: During connected
OR: Powered on

MICRO USB PORT
To access the port, pull back to expose the micro USB port. 1.5+ hrs for full charge provides 5 hours of playtime. 30 mins charging provides 90 minutes of playtime.

LED STATUS
Red: LOW battery
Blue: Earbuds connected/in Charging
Red / Blue Alternating: Pair Mode
LED off: Powered Off

AUDIBLE PROMPTS
Voice Prompts: "Refer to charge/pairing"
Press the + & - button for 2 seconds to toggle Voice Prompt on.
Press the + & - button for 5 seconds to restore factory settings.

* Voice guide supported: English, Français, Deutsch, Italiano, Español, Chinese and Japanese. Voice Text List: Battery Power on, Power off, Select Language (English, Italiano, Español, Français, Deutsch), Pairing, Pairing successful, Low battery, Charge, Incoming, Battery Low, Battery Charge, Battery Fully, Disconnect, Connected, Power on, Power off.

32

PAIRING TO YOUR PHONE / MUSIC DEVICE THE FIRST TIME

1. Press and hold the audio/call button for more than four seconds. The LED flashes an alternating red and blue indicating the pairing process is ongoing.
2. Turn on the Bluetooth on your phone/device and allow it to search for new devices.
3. Select the (NOODLEBUDS) to initiate pairing. If a password is necessary, enter 0000. After successfully pairing to your phone/device, an audible prompt "Headset connected" is heard.
4. If the pairing is not successful, power down the earbuds by pressing the the audio/call button for four seconds. Repeat the pairing process once again.

33

34

PAIRING WITH A BLUETOOTH ADAPTER

Once the initial pairing has taken place, you may want or require to pair to other smart devices.

1. Set the earbuds in pairing mode. If earbuds are powered off, press and hold the audio/call button until the audible "pairing" sounds. The LED alternates between blue and red to indicate a pairing mode.
2. Activate the Bluetooth function on your smart device and allow it to search for devices.
3. On your smart device list, select (NOODLEBUDS). If a password is necessary, enter 0000. After successfully pairing to your phone/device, an audible prompt "headset connected" is heard.

35

PAIRING WITH SEVERAL BLUETOOTH DEVICES

Once a device is paired to the Handsfree Bluetooth Earbuds, you do not need to pair it again.
Up to eight smart devices can be paired to the earbuds. Follow the same instructions as provided previously to pair new devices.
Once the total of eight devices are paired and upon pairing the ninth device, the oldest paired device will be deleted from the memory list.
Switching between paired devices is easy. Turn off the Bluetooth function on the smart devices to disconnect them from the Wireless Bluetooth Earbuds.
Turn on the Bluetooth function of the device that requires the connection and, from the device list, press the (NOODLEBUDS) to re-connect.

36

37

SPECIFICATIONS

Bluetooth v3.0 specification support	up to 10 meters/approx.
Profiles	HFP v1.5, HSP v1.2, A2DP v1.2, AVRCP v1.5
Effective Range	approx. 10 meters (30 feet)
Operating time	music play time approx. 5 hours
Standby time	more than 200 hours, < 1MA drain in sleep mode
Input voltage	DC 5V 300mA
Charging time	approximately 1.5 hours
Dimensions	24.5(H) x 15.7(W) mm earbud size, 840 mm cord length
Weight	approx 24.4g

38

WARRANTY, CARE & MAINTANANCE

Full warranty, care and maintenance details at http://www.noodlebuds.com

NOODLEBUDS, Noodle and the NOODLEBUDS and Noodle logos are trademarks of Noodle Technology. All rights reserved. Other trademarks and trade names are those of their respective owners. Noodle Technology, Inc. ("Noodle") reserves the right to revise this publication and to make changes to the content hereof without obligation of Noodle to notify any person of such revision or changes. Noodle Technology, Inc. makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. Noodle Technology, Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Noodle Technology, Inc. to notify any person of such revision or changes.

Copyright 2014 Noodle Technology, Inc. All rights reserved. Noodle and the Noodle logo are trademarks of Noodle Technology, Inc. Bluetooth is a trademark owned by Bluetooth SIG, Inc. and licensed to Noodle Technology, Inc. All other trademarks and trade names are those of their respective owners. Noodle Technology, Inc. reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Noodle Technology, Inc. to notify any person of such revision or changes.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

39

REGISTER YOUR DEVICE TO RECEIVE UPDATE INFORMATION

http://www.noodlebuds.com

40

GREAT MUSIC REQUIRES GOOD EARS

Avoid prolonged periods of use
and excessive audio levels.
The use of earbuds around road traffic is not advisable.

41