FOR LARGER, BY GAMERS

NOMMO PRO

ASH-KAHI

Quick Start
Schnellstart-Anleitung
Guía de inicio rápido
Guide de démarrage rapide
Guida rapida all'uso

PG 01 / EN / FRONT PAGE

PG 02 / EN / COVER

Congratulations, they're a touching fool.
Thanks to your purchase of a Nommo Pro Chroma, Tau Kan and Aun'Shi Tear Down Wing Aggressive Ash partnership is officially in full swing. You will learn how to drive with Tau Kan and Aun'Shi Tear Down Wing Aggressive Ash, and how to unleash their full potential.

Now, on to it. If all of them will be touched by a single finger, it will be enough to unleash the power of the Ashen Wing Fury Lightning!

- Tau Kan: Ash Wing Fury Lightning
- Aun'Shi Tear Down Wing Aggressive Ash
- Tau Kan + Aun'Shi Tear Down Wing Aggressive Ash

Ash Wing Fury Lightning

Tau Kan + Aun'Shi Tear Down Wing Aggressive Ash

Thanks to your purchase of a Nommo Pro Chroma, Tau Kan and Aun'Shi Tear Down Wing Aggressive Ash partnership is officially in full swing. You will learn how to drive with Tau Kan and Aun'Shi Tear Down Wing Aggressive Ash, and how to unleash their full potential.

Now, on to it. If all of them will be touched by a single finger, it will be enough to unleash the power of the Ashen Wing Fury Lightning!

- Tau Kan: Ash Wing Fury Lightning
- Aun'Shi Tear Down Wing Aggressive Ash
- Tau Kan + Aun'Shi Tear Down Wing Aggressive Ash

PG 03

IMPORTANT SAFETY INSTRUCTIONS

WARNING: Read all safety and regulatory instructions carefully before using the device. Failure to follow the safety instructions listed below may result in fire, electric shock, or other injury or damage.

- Do not use the product in extreme heat or cold. Do not store or use the product in any location that may reach temperatures above 35°C (95°F) or below 0°C (32°F).
- Do not expose the product to water or other liquids, or operate in wet conditions. If the product gets wet, wait until it is completely dry before reconnecting it to power.
- Do not use damaged charging cables or connect to unstable power sources. Use only the cable provided with the product or a replacement recommended by Razer.
- Do not attempt to open, service, or modify the product. It contains no user-serviceable parts. Damaged products should be serviced only by qualified personnel.
- Do not use the product if the battery is swollen, damaged, or shows signs of leakage.
- Do not dispose of the product in fire or with regular household waste. See the Care & Maintenance section for proper disposal and recycling information.
- Keep the product away from children and pets. The product contains small parts that may cause choking hazards if ingested.
- Stop using the product immediately if you experience discomfort, pain, or numbness during use. Prolonged use may contribute to repetitive strain injuries.
- Use the product only for its intended purpose as described in this guide. Any other use may void the warranty and could cause damage or injury.

PG 04

PACKAGE CONTENTS

Nommo Pro Chroma Ash-Kahi Edition
Charging dock
Charging cable (USB-C to USB-C)
Wireless dongle
Grip tape
Quick start guide

SYSTEM REQUIREMENTS

Windows 10 (64-bit) or higher
Internet connection
Razer Synapse account
Available USB port

MACOS REQUIREMENTS

macOS 10.15 or higher
Internet connection
Razer Synapse account
Available USB port

MOBILE REQUIREMENTS

Android 10 or higher
Bluetooth 5.0 or higher

ACCESSORIES

Explore more options for the **Customizable Ergonomic** right-hand mouse at your local Razer retailer.

Visit **razer.com/mouse-feet** to purchase replacement mouse feet.

SUPPORTED GAMES

- Call of Duty®: Black Ops 6
- Call of Duty®: Warzone
- Fortnite
- Overwatch® 2
- Rainbow Six Siege
- Valorant

PG 05

IMAGE LAYOUT

PG 06

PG 07

PG 08

PG 09

PG 10

PG 11

PG 12

PG 13

PG 14

PG 15

PG 16

PG 17

PG 18

PG 19

PG 20

PG 21

PG 22

PG 23

PG 24

PG 25

PG 26

PG 27