

US UK Dear user Thank you for choosing REDRAGON product. To protect your rights and for better customer service, please read the following warranty rules carefully. 1. Within 18 months of purchase date, repair is guaranteed for failure due to electrical circuit problems. Other damages, such as disassembly, hard impacts, submersion into water, plugging into improper current or voltage, and damage caused by natural disasters such as fire, flood, or earthquake are not included. 2. Consumable parts (such as foot pads) and spare parts replacement are not included in our warranty. 2.4G/OFF/BT mode switch PAIR 2.4G receiver storage slot Type C port 1	O.S. Support Win XP/Vista/Win7/Win8/Win10/Mac OS X/Linux/Android How to connect the numpad with device Wired Connection [2.4G/OFF/BT] switch on "OFF". Connect the numpad to computer with Type-C USB cable. The computer will recognize and configure the numpad automatically. After the pairing is successful, the "USB" character will be displayed on the screen. 2.4G Wireless Connection [2.4G/OFF/BT] switch on "2.4G"; the numpad backlight is green light flash, insert the USB receiver into your computer USB port, the numpad will connect with computer automatically. BT Connection [2.4G/OFF/BT] switch on "BT", the numpad backlight is blue light quick flash, turn on your device BT function and searching for available BT devices, it will find "BT 5.0 Numpad" device name. Select the BT name to pair. Knob control Press and hold the knob button for 3s to switch between lighting effect adjustment and volume adjustment. 1. When the knob buttonswitches to the backlight switching, the left indicator flash 3 times then steadily on. Press the knob button to cydic switch 14 light patterns. Turn the knob to adjusting backlight brightness. 2. When the knob switches to the volume control, the right indicator flash 3 times then steadily on. Press theknob button to mute. Turn the knob to adjusting volume. 2	PC/CAL Mode Switch 1. Press the [PC/CAL]key, the PC icon lights up, the current mode is numpad mode. 2. Press the [PC/CAL] key, the CAL icon lights up, the current mode is calculator mode. Function Key 1. [SEND] key, press it to send the current calculation result of CAL mode to current window. (Excel, txt, word...) 2. [AC] key, clear the current calculation results. (when PC mode is "ESC" key) 3. [NUM] key (Num pad lock), valid in PC mode, when activated, the LED under this key is red light. Power Save Mode On 2.4G wireless/BT connection mode, when numpad without any operation over 3 minutes, the numpad backlight will turn off to save the battery, when numpad without any operation over 15 minutes, the numpad will enter sleep mode, press any key to wake up. When not in use for a long time, please turn the numpad mode switch to OFF. Restore factory settings Press and hold [AC] for 3 seconds. Warning: Charging Input: 5V==2A max Built-in Li-thion battery 1 unit FAQ 1. If the keyboard doesn't respond, please check if the keyboards USB cable is correctly inserted into the corresponding USB port on the computer, or try another USB port on the computer. 2. If you spill liquid on the keyboard, please unplug the keyboards USB cable from the computer immediately. Wipe off excess liquid and put the keyboard in a dry and ventilated place. Make sure the keyboard is dried naturally before the next use. 3	BATTERY SAFETY GUIDELINES DO NOT replace the battery with a different model. DO NOT use this product if the battery shows signs of damage including, but not limited to tearing, deformation, leakage, or the smell of electrolytic material. DO NOT touch the battery if material is leaking and seek immediate medical attention if any material comes into contact with your skin or eyes. DO NOT expose the battery to liquid, heat sources, electricity (outside of the product itself), or other non-standard operating condition. DO NOT remove the battery except for proper disposal and recycling as required by local laws and regulations. DO NOT impact, bend, alter, dissemble, or otherwise damage the battery as the contents are volatile, hazardous, and can be harmful. ! CAUTION: Failing to follow all safety guidelines may result product damage, explosion, fire, and/or electric shock. This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference. (2) This device must accept any interference, including interference that may cause undesired operation of the device. Cet appareil contient des émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement économique Canada. Le fonctionnement est soumis aux deux conditions suivantes : (1) Cet appareil ne doit pas causer d'interférences. (2) Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil. 4	FCC Statement Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. REDRAGON QUALITY ASSURED 5
---	---	--	---	---

PT Prezado usuário, Obrigado por escolher a marca REDRAGON . Para proteger seus direitos e oferecer um melhor atendimento ao cliente, pedimos que você observe as regras da nossa garantia. 1. Dentro do período da garantia, os reparos são garantidos nos casos de falha devido a problemas no circuito elétrico. Danos causados pela desmontagem, por impactos violentos, imersão em água, ligação em correntes ou voltagens incorretas e danos causados por desastres naturais, como incêndios, inundações ou terremotos, não estão incluídos. 2. Peças que sofrem desgaste (como pés) e a substituição de peças avulsas não estão incluídas em nossa garantia. 2.4G OFF BT PAIR 2.4 Compartimento de armazenamento do receptor Porta tipo C 6	Compatibilidade com SO Win XP/Vista/Win7/Win8/Win10/Mac OS X/Linux/Android Como conectar o nmpad ao dispositivo Conexão com fio [2.4G/OFF/BT] passe para "OFF".Conecte o numpad ao computador com o cabo USB Tipo-C.O computador vai reconhecer e configurar o numpad automaticamente.Após a conclusão do pareamento, o texto "USB" será exibido na tela. Conexão sem fio 2.4 G Coloque a chave [2.4G/OFF/BT] na posição "2.4G"; a luz de fundo do teclado numérico piscará em verde. Em seguida, insira o receptor USB na porta USB do computador. O teclado numérico será conectado automaticamente. Conexão BT Coloque a chave [2.4G/OFF/BT] na posição "BT"; a luz de fundo do teclado numérico piscará rapidamente em azul. Ative o BT do seu dispositivo e procure por dispositivos disponíveis. Será exibido o nome "BT 5.0 Numpad".Selecione o nome do dispositivo BT para fazer o pareamento. Controle por botão Mantenha o botão do seletor pressionado por 3 segundos para alternar entre o ajuste do efeito de iluminação e o ajuste de volume. 1. Quando o botão do seletor passar para o modo de alternância de retroiluminação, o indicador esquerdo piscará três vezes e depois permanecerá aceso.Pressione o botão do seletor para alternar entre 14 efeitos de iluminação.Gire o botão para ajustar o brilho da retroiluminação. 7	2. Quando o seletor passar para o modo de controle do volume, o indicador direito piscará três vezes e depois permanecerá aceso.Pressione o seletor para silenciar.Gire o botão para ajustar o volume. Alternância de modo PC/CAL (computador/calculadora) 1. Pressione a teda [PC/CAL]; o ícone PC acenderá, indicando que o modo atual é o modo teclado numérico. 2. Pressione a tecla [PC/CAL]; o ícone CAL acenderá, indicando que o modo atual é o modo calculadora.. Tecla de função 1. Teda [SEND]: pressione-a para enviar o resultado atual do modo calculadora para a janela em uso.(Excel, txt, word...) 2. Teda [AC]: limpa os resultados atuais da operação.(se estiver em modo PC, funciona como tecla "ESC") 3. Teda [NUM] (bloqueio numérico): válida no modo PC; se ativa, o LED abaixo dessa tecla acende em vermelho. Modo de economia de energia Nos modos de conexão sem fio 2.4G ou Bluetooth, se o teclado numérico ficar inativo por mais de 3 minutos, a luz de fundo será desligada para economizar bateria. Se permanecer sem uso por mais de 15 minutos, o teclado numérico entrará em modo de suspensão. Pressione qualquer tecla para reativá-lo. Se não for utilizar o teclado por um longo período, coloque a chave de modo na posição OFF. Restaura configurações de fábrica Pressione e segure [AC] por 3 segundos. 8	Aviso: corrente de carga: 5V== 2A máx Bateria de íon de lítio embutida, 1 unidade. Dúvidas frequentes 1. Se o teclado não responder, verifique se o cabo USB do teclado está inserido corretamente na porta USB correspondente no computador, ou experimente outra porta USB no computador. 2. Se você derramar líquido no teclado, desconecte o cabo USB do teclado do computador imediatamente. Enxugue o excesso de líquido e coloque o teclado em um local seco e ventilado. É importante que o teclado seque naturalmente antes de utilizá-lo. REDRAGON QUALITY ASSURED 9	REDRAGON QUALITY ASSURED COVE wireless DIGITAL DISPLAY MECHANICAL NUMPAD Please scan here to download user manual User manual
---	---	--	---	--

封面

型号	HL K733-RGB-WL/7487		备注：尺寸：100x100mm (折页) 材质：80g书写纸 印刷：单黑色双面印刷					Eastemtimes Tech
名称	说明书							
日期	2025-10-21							
页码	1 OF 1		文件编号					
绘图	雷国建	审核	香敏琪	核准		版本	A.0	