Tenda

Quick Installation Guide

Wireless HD Video Security Kit
K4W-3TC/K8W-3TC

Please read this guide before you start with the quick setup for this security kit upon the first use. For product or function details, please go to www.tendacn.com to download the user guide.

Package contents

The K8W-3TC kit is taken as an example here. The actual product prevails.



Appearance

NVR





Ports	Description
⏚	Grounding terminal Connect the grounding terminal of the NVR to the earth or the grounding terminal of the building with a grounding cable to prevent static electricity or lightning from damaging the NVR.
POWER	Power port Use the included 12 V/ 2 A power adapter to power on the NVR.
LAN	10/100 Mbps auto-negotiation Ethernet port. Used for connecting the router, switch, etc.
HDMI	HDMI port Connect your monitor or TV to this port using an HDMI cable for high-definition audio and video output.
VGA	VGA port. Connect your monitor to this port using an VGA cable for video signals.
USB	USB 2.0 port. Used for connecting a mouse, an USB storage device, etc.

Camera





1 Install the HDD

Tips
- Tenda does not include any HDD. Please prepare it by yourself. It is recommended to use the HDD dedicated for surveillance.
- Please back up your existing the HDD's data or all of the power of the NVR, otherwise the HDD may not be detected or even be damaged.
- You may need a screwdriver. Please prepare it by yourself.

❶ Unfasten the screws on the bottom, then remove the cover of the NVR. Reserve the screws for later use.



❷ Align the SATA connector of the HDD with the SATA slot on the motherboard of the NVR, and then insert the HDD into the slot until it is tightly fixed.



❸ Mounting the cover with the previously removed screws.



❹ Take out 2 screws from the NVR installation package, and screw them into the two screw holes closest to the SATA connector. Reserve about 2 mm between the screw head and the HDD for subsequent installation.



❺ Take out the remaining screws from the NVR installation package, and screw them into the HDD screw holes to fix the HDD.



2 Connect the device

The K8W-3TC kit is taken as an example here.

Make all cameras near the NVR, and power on the cameras first (12 V/ 1 A), then power on the NVR (12 V/ 2 A).

The cameras and the NVR will automatically establish connections within 2 minutes. When the LED indicator of the cameras turn solid blue, the NVR successfully adds the cameras and starts recording.





Tips
If the NVR fails to automatically add cameras, refer to Q1 in FAQ.

3 Install the camera

Install the camera to the monitoring location as required.
- The camera needs to be placed within the wireless coverage of the NVR.
- The distance between the NVR/camera and the wireless router, induction cooker, microwave oven, and refrigerator should be more than 1 meter.
- The antennas of the NVR and the camera are placed vertically.

Fix the camera

The camera supports ceiling and wall installation.

Tips
- Please make sure the ceiling is strong enough to withstand three times the weight of the camera.
- You may need to prepare a hammer drill, a drill bit, a rubber hammer, a screwdriver, and a ladder for the installation.





Adjust the monitoring angle

Loosen the orientation knob, adjust the orientation of the camera as required, then tighten the knob.



Install waterproof kit

Install the waterproof kit and wrap the end with waterproof tape for the Ethernet port and power port if the camera is installed outdoors.

Note
The included waterproof kit is not suitable for the Ethernet cable with protection cover on the crystal head. See the example on the right.

Please follow the steps below to install the waterproof kit when the Ethernet port of the camera is connected to an Ethernet cable.
❶ Put the C-ring on the Ethernet port of the camera.
❷ Pass the Ethernet cable through the fix nut, the waterproof ring and the waterproof jacket in proper order. Then connect it to the Ethernet port of the camera.
❸ Rotate to fix the waterproof jacket to the Ethernet port of the camera, insert the waterproof ring into the waterproof jacket and fasten the fix nut.



4 Basic configuration

Local management

Startup

Tips
Use the included power adapter to power on the NVR. Abnormal power supply will damage the device.

Connect the 12 V/ 2 A power adapter to the power port of the NVR, and plug the power adapter into the power socket to start up the NVR.

Shut Down

Note
Do not directly cut off the power of the NVR to force a shutdown, otherwise it may damage the HDD, lead to a loss of data or videos, or even damage the NVR.

After connecting the mouse and monitor to the NVR, perform the following settings on the NVR's management page (exit the Full Screen interface):

Click ⏻ in the upper right corner, click **Shut Down**, and then click **OK**. When **The Device is Shut Down. Please Cut Off the Power** appears on the screen, unplug the power adapter of the NVR.

Quick setup

After connecting the mouse and monitor to the NVR, you can perform quick setup.

❶ Set **Login Password**, enter your **Email Address**, then click **Activate**.

❷ If you want to use a pattern to unlock the management page, please draw an unlock pattern. Otherwise, click **Do Not Use Unlock Pattern** and skip to step ❸.



❸ Ensure that the connection status is **Connected**, then click **Next**.

Tips
If the connection status is **Disconnected**, try the following options:
- Ensure that the LAN port connection of the NVR is normal.
- Ensure that the DHCP server function of the router to which the NVR is connected is enabled.

❹ Ensure that the cloud status is **Online** and click **OK**.

Tips
- If the cloud status is **Offline**, please ensure that the router to which the NVR is connected can access the Internet and the Internet function is enabled.
- You can also manage the NVR through the TDSEE App. Please refer to **App Management** in this guide for details.

Settings completed. You can preview real-time video, play back the recordings and manage monitoring devices, etc.

App management

After the cloud service of the NVR is enabled and the cloud status is online, you can add and manage the NVR through the TDSEE App.

❶ Download the TDSEE App.
After the mobile phone is connected to the internet successfully, download and install the **TDSEE** App onto your mobile phone by scanning the QR code or by searching for **TDSEE** in the Google Play or App Store.

QR Code
Or
GET IT ON Google Play
Download on the App Store

❷ Ensure that the NVR is powered on and working properly.

❸ Run the **TDSEE** App and follow the instructions to complete user registration. Enter the **Home** page, then tap **Add a device** or ⊞ in the upper right corner of the home page.

Note
To ensure that the login password of the NVR can be kept through the TDSEE App, please register with the reserved email address when activated the NVR.

❹ Scan the QR code on the label at the bottom of the NVR or scan the QR code on the **Cloud Service** page, then follow the instructions in the App.

After added the NVR, you can remotely preview real-time video, play back the recordings and check alarm messages through the TDSEE App.

FAQ

Q1. What should I do if the NVR fails to automatically add the camera?

A1. Try the following solutions:
- Ensure that the LED indicator of the **NVR** is on, if the LED indicator is off, please check the power supply.
- Ensure that the LED indicator of the **camera** is blinking blue quickly, if not, please reset the camera and try again.
  Reset method: Hold down the **Reset** button for about 5 seconds and release it when the LED indicator blinks blue quickly or you hear a prompt tone.
- Add the camera on the management page of the NVR.

Q2. What should I do when the video preview is not smooth or the camera is often offline?

A2. Try the following solutions:
- Ensure that the distance between the NVR/camera and the wireless router, induction cooker, microwave oven, and refrigerator is more than 1 meter.
- If the distance is too far between the NVR and the camera, please adjust the location of the NVR or the camera to shorten the distance.
- If there are too many obstacles (such as walls, glass doors, etc.) between the NVR and the camera, please adjust the location of the NVR or the camera to reduce the obstacles.

Q3. How to add a new camera when the NVR is under stable operation?

A3. Please ensure that the number added cameras has not reached the limit. Then try the following steps:
❶ Ensure that the new camera is under default settings. If not, please reset it first.
❷ Place the new camera near the NVR and power it on.
❸ The NVR will automatically detect the camera. Add the camera after you verify the S/N on the pop-up window is correct.
❹ Unplug the power of the camera and install the camera to the monitoring location as required.

Q4. What should I do if there is no video for playing back on the NVR?

A4. Try the following solutions:
- Ensure that the HDD is working properly.
  Navigate to **Settings > Storage Management > HDD Management**.
  - If the HDD is not detected, please shut down the NVR first, reinstall the HDD and start up the NVR.
  - If the HDD is under abnormal status, please shut down the NVR first, reinstall the HDD and start up the NVR. If the problem persists, please format the HDD.
  - If the formatting fails, please shut down the NVR first, replace the HDD and start up the NVR.
- Ensure that the recording plan is normal.
  Navigate to **Settings > Storage Management > Recording Schedule**, ensure that:
  - The channel recording schedule is enabled.
  - The recording time and recording type have been set properly. If not, please set and save according to the actual situation.

CE Mark Warning (K2T6):
This is a Class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.
This equipment should be installed and operated with a minimum distance 20cm between the device and your body.
The mains plug is used as disconnect device, the disconnect device shall remain readily operable.
NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

CE Mark Warning (N3W-8H & N3W-8H)
This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.
The equipment should be installed and operated with a minimum distance 20cm between the device and your body.
The mains plug is used as disconnect device, the disconnect device shall remain readily operable.
NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

Declaration of Conformity (K2T6)
Hereby, SHENZHEN TENDA TECHNOLOGY CO., LTD. declares that the radio equipment type K2T6 is in compliance with Directive 2014/53/EU.
The full text of the EU declaration of conformity is available at the following internet address:
http://www.tendacn.com/cn/service/declaration_of_conformity.html
Operating Frequency:
2.4 GHz: 2412-2483.5MHz (CH1~CH13)
EIRP Power (Max):
2.4 GHz: 19dBm
Software Version: V1.0.X

Declaration of Conformity (N3W-8H & N3W-8H)
Hereby, SHENZHEN TENDA TECHNOLOGY CO., LTD. declares that the radio equipment type N3W-8H/N3W-8H is in compliance with Directive 2014/53/EU.
The full text of the EU declaration of conformity is available at the following internet address:
http://www.tendacn.com/cn/service/declaration_of_conformity.html
Operating Frequency:
2.4 GHz: IEEE802.11b/g/n/ax (HT40): 2412-2483.5MHz (CH1~CH13)
EIRP Power (Max):
2.4 GHz: 20dBm
Software Version: V11.1.1.10

Caution (K2T6):
Adapter Model: EN0720A12DE, EN0720A12DZ
Manufacture: SHENZHEN HENGBAIHUN NETWORK TECHNOLOGY CO., LTD.
Input: 100-240V AC, 50/60Hz 0.6A
Output: 12V DC, 1A
DC Voltage

Caution (N3W-8H & N3W-8H):
Adapter Model: EN1220A12DE, EN1220A12DZ
Manufacture: SHENZHEN HENGBAIHUN NETWORK TECHNOLOGY CO., LTD.
Input: 100-240V AC, 50/60Hz 0.7A
Output: 12V DC, 2A
DC Voltage
Camera is used outdoors, NVR and Adapter are used indoors.

RECYCLING
This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

Operating Temperature: +30°C ~ 60°C (K2T6)
Operating Humidity: <70% ~ 95% RH, non-condensing (K2T6)
Operating Temperature: -0°C ~ 40°C (N3W-8H & N3W-8H)
Operating Humidity: <70% ~ 95% RH, non-condensing (N3W-8H & N3W-8H)

FCC Statement (K2T6)
This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.
Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Radiation Exposure Statement
This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules.
This equipment should be installed and operated with minimum distance 20cm between the device and your body.
Caution!
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
Operating frequency: 2412~2462(MHz)
NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

FCC Statement (N3W-8H & N3W-8H)
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
— Reorient or relocate the receiving antenna.
— Increase the separation between the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.
Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Radiation Exposure Statement
This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules.
This equipment should be installed and operated with minimum distance 20cm between the device and your body.
Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.
Operating frequency: 2412~2462(MHz)
NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

Technical Support
Shenzhen Tenda Technology Co., Ltd.
6-8 Floor, Tower A3, NO.1001, Zhongshanyuan Road, Nanshan District, Shenzhen, China. 518052
USA/Canada: 1-800-570-5892
Toll Free: 7 x 24 hours
Canada Hotline: 1-800-570-5892
Toll Free: Mon ~ Fri 9 am ~ 6 pm PST
Hong Kong Hotline: 00852-44501999
Global Hotline: +86 755-6765 7180 (China Time Zone)
Website: www.tendacn.com
E-mail: support@tenda.com.cn

Copyright
© 2021 Shenzhen Tenda Technology Co., Ltd. All rights reserved.
Tenda is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Specifications are subject to change without notice.