

MINISO

USER MANUAL

使用説明書

Jelly Series Three-Mode Rechargeable Double-Layer Crystal-Like Mouse
Série Jelly Souris Rechargeable Trois Modes
ماوس مزدوج الطبقة قابلة للشحن بثلاثة أوضاع
Ratón Recargable de Tres Modos, Serie Jelly
果凍系列三模充電雙層透明水晶滑鼠
MODEL: M17CTM

使用產品前請仔細閱讀本使用說明書，並請妥善保管。
PLEASE READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT AND KEEP IT PROPERLY.

Cautions

1. Do not use the product in a damp or humid environment.
2. Avoid dropping, bumping, or knocking the product to prevent malfunctions or damage.
3. It is recommended to replace the battery regularly to avoid low battery levels affecting performance.
4. Ensure the USB connection is properly secured to ensure the product operates correctly.
5. Do not attempt to disassemble or repair the product yourself.
6. If the product will not be used for an extended period, remove the battery to prevent leakage and potential damage.

Product Diagram

1.Left Button

2.Scroll Wheel

3.Right Button

4.DPI Adjustment Button

5.Mode Button

9.Mouse Feet

6.USB-C Charging Port

7.Power Switch

8.Receiver Slot

10.USB Receiver

Specifications

Rated Voltage: 3.7V
Rated current: 60mA
Wireless Transmission Distance: 6-8m

Dimensions:
105.8mm x 66.6mm x 38.1mm
Net Weight: 95.6g

Usage

Function

Instructions

Power On/Off

Move the power switch to ON position

2.4G Connection

Remove the receiver from the bottom of the mouse and plug it into your computer. Turn on the power switch, then use mode button to switch to 2.4G mode. The mouse will then be ready to use

BT Connection

Turn on the power switch, then use mode button to switch to BT mode, press the mode button for 3 seconds to enter pairing mode

DPI

By pressing the DPI adjustment button the value changes as follows: 800, 1600, 2400 (default), 3200, 6400 DPI.

Wired Connection

No matter which mode the mouse is in, or whether the power switch is turned on or off, connecting the mouse to the computer with a USB cable will automatically switch it to USB wired mode

Contents

Wireless mouse × 1, receiver × 1, charging cable × 1, user manual × 1

FCC Warning

This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions:
This device may not cause harmful interference, and This device must accept any interference received, including interference that may cause undesired operation.
Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:--Reorient or relocate the receiving antenna. --Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. --Consult the dealer or an experienced radio/TV technician for help.
FCC Radiation Exposure Statement:
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

WEEE Warning

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the ground water and get into the food chain, damaging your health and well-being.

The charging device is not included.

The power delivered by the charger must be between min [2.5] Watts required by the product, and max [5] Watts in order to achieve the maximum charging speed.

Attention

1. N'utilisez pas le produit dans un environnement humide ou mouillé.
2. Évitez de laisser tomber, de heurter ou de cogner le produit afin de prévenir tout dysfonctionnement ou dommage.
3. Il est recommandé de remplacer régulièrement la pile afin d'éviter qu'un niveau de pile faible n'altère les performances.
4. Assurez-vous que la connexion USB est correctement branchée afin de garantir le bon fonctionnement du produit.
5. N'essayez pas de démonter ou de réparer le produit vous-même.
6. Si le produit n'est pas utilisé pendant une longue période, retirez la pile afin d'éviter toute fuite et tout dommage potentiel.

Schéma du Produit

1.Bouton Gauche

2.Molette de Défilement

3.Bouton Droit

4.Bouton de Réglage DPI

5.Bouton de Mode

9.Patins de Souris

6.Port de Chargement USB-C

7.Interrupteur d’Alimentation

8.Logement du Récepteur

10.USB Récepteur

Mode d'Emploi

Fonction

Instructions

Mise sous/ hors Tension

Placez l'interrupteur d'alimentation sur la position ON.

Connexion 2.4G

Retirez le récepteur situé sous la souris et branchez-le à votre ordinateur. Activez l'interrupteur d'alimentation, puis utilisez le bouton Mode pour passer en mode 2.4 G. La souris est alors prête à l'emploi.

Connexion BT

Allumez l'appareil, puis utilisez le bouton Mode pour passer en mode BT ; appuyez sur le bouton Mode pendant 3 secondes pour passer en mode d'appairage

DPI

En appuyant sur le bouton de réglage de la résolution (DPI), la valeur change comme suit : 800, 1 600, 2 400 (par défaut), 3 200, 6 400 DPI.

Connexion Filaire

Quel que soit le mode dans lequel se trouve la souris, et que l'interrupteur d'alimentation soit activé ou désactivé, le fait de la brancher à l'ordinateur à l'aide d'un câble USB la fera automatiquement passer en mode filaire USB.

Contenu

Souris sans fil × 1, récepteur × 1, câble de charge × 1, manuel d'utilisation × 1

The dispositif de chargement n'est pas inclus.

La puissance délivrée par le chargeur doit être comprise entre min [2.5] Watts requis par le produit, et max [5] Watts afin d'atteindre la vitesse de charge maximale.

تخضير

1. لا تستخدم المنتج في الأماكن الرطبة
2. تجنب إسقاط أو ضرب المنتج لتجنب حدوث تلف أو عطل
3. استبدل البطارية بانتظام لتجنب التأثير على الأداء
4. تأكد من إخراج الاتصال بشكل صحيح لضمان عمل المنتج بشكل صحيح
5. لا تحاول تفكيك أو إصلاح المنتج بنفسك
6. في حالة عدم استخدام لفترة طويلة قم بإزالة البطارية لتجنب التلف

المواصفات

البيانات المنتج: 3.7 فولت
القدرة المقتن: 60 ملي أمبير
الوزن الصافي: 95.6 غرام

مسافة النقل اللاسلكي: 6-8 م

[illegible]