正面

反面

Mini A4 Printer

User Manual

Made in China

Product Information

Product name：58IN A4 Printer
Model：MP800
Input：5V⎓2A
Interface：Type-C
Thermal Paper：(Black mark folding paper：210x297mm
or 25cm1.95m)

Dimensions：29mx24mmx10.36x2.0kn1.75kn)
Weight：500g

Contents Checklist

App Printing Driver Download

1. Install PosPrint app (available in Apple App Store and Google Play Stersion your mobile device

PosPrint

App Store　Google Play

2. Turn on Bluetooth on your mobile device

3. Press and hold the power button for 3 seconds to turn on the printer，Press the power button twice to print a pairing code

4. Open the PosPrint app and scan the pairing code to connect prosprinter
5. Start printing via app
6. Tearing off the printed
7. Replacing the paper roll

PC Application

1. One end of the USB cable connects to the computer，and the other end connects to the one USB socket of the printer

2. Please turn on the printer
3. Download the printer driver and install it in the computer

Mac(Sonoma)　Windows（Driver）

4. Select printer model "A4 Printer" in the Windows PC；
5. Select printer model "A 4x Printer" in the MAC PC；
6. Open a document，select the connection printer to print successfully.

Operating Instructions

Startup & Shutdown

Power on：Long press the power button 5S until the indicator light goes off

Shutdown：Long press the power button 5S until the indicator light goes off

LED Indications

Flashing Red light	Charged
Green light	Fully charged
Flashing Green light	Bluetooth connection
Flashing Blue light	Automatic Feed paper
Flashing Red light	Low power
Red light	Out of paper or overheated

Questions

Q：No connection into the printer now found when the APP detect the device?

A：Verify that the Bluetooth state is turned on;

Q：The printer cannot print anyone?

A：Confirm whether the Bluetooth of the phone is on and rule out the possibility of connecting to the printer

Q：Why the printer cannot print?

C：Whether the print head is overheated, please wait for the print head to cool before trying to print.

Q：Restart the printer, if still cannot solve, please press the reset key to reset;

Q：Why is the printed out of white paper without content?

A：Check whether the thermal paper is installed in the wrong way installed correctly. Please try placing the opposite side of the printing paper.

Q：Is the power button a flash light?

A：The power is low, low power, please keep charging.

B：Check whether the thermal paper has been used up and replace the paper in time.

C：Check whether it is in the shut state.

Safety Precautions

- Always use a 5V USB charger for the thermal printer to prevent any damage or failure
- Do not use the thermal printer in places of high humidity or extreme temperatures
- Do not allow the thermal printer to get wet for extended by handling it with wet hands or spilling beverages on them
- Do not touch metal parts around the Print Head immediately after printing
- Do not touch the roller blades
- Do not disassemble or modify the thermal printer
- Do not step or lie on the thermal printer
- Stop using the thermal printer if you notice abnormal odor, overheating, deformation or anything unusual while using or storing it
- When the thermal printer is not being used,store it out of the reach of children and pets，keep it in a cool，dry place
- Do not allow children or pets to play with the thermal printer or paper rolls in their mouth，If any object has been swallowed,seek medical attention

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference，and (2) This device must accept any interference received，including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party in charge of compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device，pursuant to part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and，if not installed and used in accordance with the instructions，may cause harmful interference to radio communications.

However，there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception，which can be determined by turning the equipment off and on，the user is encouraged to try to correct the interference by one or more of the following measures:

—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End user must follow the specific operating instructions to satisfy RF exposure compliance.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated in conjunction with any other device or transmitter.

书单页尺寸：70mmx110mm
纸张材质：105g双铜纸
工艺：4折页