正面

说明书

Manual

反面

感谢您选择此款智能手机！

本手机是一款基于 Android 操作系统的智能手机，操作界面简洁清晰，让您充分享受智能移动。为了安全、有效的使用本手机，使用前请仔细阅读使用说明书。

■ **安全开机**

在飞机上，加油站等禁止使用手机的场所，或者使用手机会引起干扰或危险时，请不要使用手机。

■ **请安全禁一**

开车时请勿使用手机，以免妨碍安全驾驶。

■ **在获得授权的区域禁关机**

在飞机上，在医疗设备附近应关机。

■ **干扰**

移动通信可能会受无线电干扰从而影响性能。

■ **防水**

此手机不防水，请保持其干燥。

■ **专业化服务**

请勿拆解或拆卸手机。只有授权的机构才可维修本手机。

■ **安装SIM卡或USIM卡**

1. 在手机左侧，找到SIM卡或USIM的卡槽；
2. 在卡槽上有对应的SIM卡或USIM卡存储卡的插卡方式，请根据图案所示方式插卡；
3. 如果未插入SIM卡或USIM卡，则仅能使用手机的非网络服务和部分功能表。
4. 请勿将存储卡插入SIM卡或USIM卡槽。

■ **为电池充电**

◇ 可使用随机自带的充头和数据线直接给手机充电，或将手机与电脑连接进行充电。

◇ 电池电量不足时，手机会发出警告音并显示电量不足信息。如果电池电量过低，手机会自动关机。

◇ 可在充电时使用手机，但这会延长电池完成充电的时间。

◇ 在充电时手机会发热，该现象属于正常情况，不会影响手机的使用寿命或性能。

◇ 如手机无法正常充电，请将手机拿到售后服务中心检测。

■ **格式化TF卡存储**

在主菜单，选择设置→存储→存储信息→格式化TF存储，格式化SD卡存储前，要备份存储在手机中的所有重要数据，制造商保留服务不包括因用户操作导致的数据丢失。

■ **开机和关机**

开机：长按【开关机键】

关机：长按【开关机键】，然后选择关机。

飞行模式：下拉主界面，然后选择云上角图标飞行模式。

■ **触摸屏**

在触屏操作注意事项：

◇ 为了避免刮伤触摸屏，请勿使用尖锐的工具。

◇ 请勿让触摸屏接触其他电子设备，静电放电可能会造成触摸屏发生故障。

◇ 请勿让触摸屏潮湿。在潮湿环境中可能会发生故障。

◇ 使用手机前请留下触摸屏保护膜。

◇ 触摸屏不会对尖锐工具的触碰产生反应。

◇ **可执行以下操作控制触摸屏：**

◇ 点击：用手指点击来选择或启动功能表、选项或应用程序。

◇ 点击并紧按住：紧按住项目2秒钟以上，可弹出选项列表。

◇ 滑动：点击并向上、向下、向左或向右拖动手指来移动列表的中的项目。

◇ 拖放：用手指点击并紧按住一个项目，然后拖动手指来移动项目。

◇ 双击：查看照片时，用手指点击两次可以放大或缩小。

◇ 调整背景时可用：在桌机模式下，然后选择设置→显示→休眠→休眠时间。

■ **锁定或解锁触屏**

可以锁定触摸屏和按钮，以防止任何意外手机操作。锁定：按下【开关机键】，解锁：按下【开关机键】然后根据屏幕提示，手动解锁。

■ **设置壁纸**

可以设置壁纸来自定义桌机屏幕或锁屏界面（壁纸可以自定义相册的图片）。

◇ 锁屏壁纸：设置锁屏界面图像。

◇ 桌面壁纸：设置桌面壁纸。

◇ 动态壁纸：可以设置动态壁纸

■ **在待机屏幕上移动项目**

点击并按住要移动的项目，振动后将项目拖动到所需位置。

■ **从待机屏幕移除项目**

点击并按住要移除的项目，振动后将项目拖动到屏幕上方垃圾桶图标。

■ **使用快捷方式面板**

在待机模式下或使用应用程序时，在触摸屏幕顶端指示图标和区域，向下滑动手指，打开快捷方式面板。可以启动或取消无线网络等其他功能，并访问通知的列表。如您想，通讯、活动或处理状态，如欲隐藏列表，请向上滑动列表的下边框。在快捷方式面板中左右滑动快捷图标，可操作以下选项：

◇ **可执行以下操作控制触摸屏：**

◇ 点击：用手指点击来选择或启动功能表、选项或应用程序

◇ 点击并紧按住：紧按住项目2秒钟以上，可弹出选项列表。

◇ 滑动：点击并向上、向下、向左或向右拖动手指来移动列表的中的项目。

◇ 拖放：用手指点击并紧按住一个项目，然后拖动手指来移动项目。

◇ 双击：查看照片时，用手指点击两次可以放大或缩小。

◇ 调整背景时可用：在桌机模式下，然后选择设置→显示→休眠→休眠时间。

■ **锁定或解锁触屏**

可以锁定触摸屏和按钮，以防止任何意外手机操作。锁定：按下【开关机键】。解锁：按下【开关机键】然后根据屏幕提示，手动解锁。

◇ 长按项目并拖动到屏幕上方垃圾桶图标。

◇ 窗口小部件

在待机屏幕和应用程序菜单，选择添加小部件，选任意一个小部件长按，拖动到待机。

◇ **自定义手机**

根据个人喜好自定义主菜单和桌面滑屏特效等。

◇ **设置解锁图案**

在主菜单界面，然后选择设置→日期和时间，然后设定时间和日期并设定其他选项。

◇ **打开或关闭触摸音效**

在主菜单界面，然后选择设置→声音和通知→标准→点击右边设置→选择触摸音效并开关。

◇ **调整铃声音量**

按上或下音量按钮可调整铃声音量。

◇ **切换到振动模式**

使手机振动或解除振动，请执行以下方式操作：

1. 快按音量键直接调整铃声音量。
2. 在待机模式下，按住【开关机键】，然后选择振动模式。

◇ **更改铃声**

可以查看按类型筛选的通话记录。

在主菜单界面，然后选择设置→声音和通知→标准→点右边设置→铃声，默认选项是显示音/信息铃声类，从列表中选择铃声，然后选择确定。

◇ **选择单机屏幕的墙纸**

待机模式下，按下MENU键→壁纸→选择需要的壁纸类型。

◇ 调整显示屏的亮度

1. 在主菜单界面，然后选择设置→显示→亮度。
2. 关闭自动调整亮度选项。
3. 拖动滑块以调整亮度的级别。

注意：提示屏的亮度会影响手机消耗电池电量的速度！

◇ **设置静音**

1. 在主菜单选择设置→音频→静音。
2. 根据屏幕提示和示例图案并连接下一步。
3. 拖动手指至少连接四个点，画出图案后点击继续。

4. 重新绘制图案并连接以确认。

◇ 设定解锁图案后，每次开机时都会要求输入解锁图案，如不想手机每次要求输入解锁图案，选择设置→安全→屏幕锁定→选择锁定图案→关闭。选择设置→安全→屏幕锁定→选择锁定图案→无（选择"无"后，屏幕将不会被上锁）。

◇ 如忘记解锁图案，需要将手机带至客服中心解锁。

◇ 对于因使用非法软件造成的密码或私人资料丢失或泄露，本公司概不负责。

◇ **设置解锁图案**

在主菜单界面，然后选择设置→日期和时间，然后设定时间和日期并设定其他选项。

◇ **打开或关闭触摸音效**

在主菜单界面，然后选择设置→声音和通知→标准→点击右边设置→选择触摸音效并开关。

◇ **调整铃声音量**

按上或下音量按钮可调整铃声音量。

◇ **切换到振动模式**

使手机振动或解除振动，请执行以下方式操作：

1. 快按音量键直接调整铃声音量。
2. 在待机模式下，按住【开关机键】，然后选择振动模式。

◇ **更改铃声**

可以查看按类型筛选的通话记录。

在主菜单界面，然后选择设置→声音和通知→标准→点右边设置→铃声，默认选项是显示音/信息铃声类，从列表中选择铃声，然后选择确定。

◇ **选择单机屏幕的墙纸**

待机模式下，按下MENU键→壁纸→选择需要的壁纸类型。

◇ 调整显示屏的亮度

1. 在主菜单界面，然后选择设置→显示→亮度。
2. 关闭自动调整亮度选项。
3. 拖动滑块以调整亮度的级别。

注意：提示屏的亮度会影响手机消耗电池电量的速度！

◇ **功能菜单**

包含联系人、快捷按号、设置选项。

■ **信息**

创建、发送、接收、查看、管理短信(SMS)或彩信(MMS)。

■ **音乐**

手机音乐播放器收听自己喜爱的音乐。

◇ 视手机软件而定，某些文件格式不受支持。

◇ 如文件大小超过可用的存储空间，打开文件时会出错

◇ 将音乐文件传输到手机中方式：

1. 从无线 Web 下载。
2. 通过数据线拷贝。
3. 通过蓝牙传输。

■ **图库**

查看存储的图片及播放其中的动画。

■ **录音**

保存语音记录，可以设置自己喜欢的音质和录音模式。

■ **时钟**

可以设置闹钟，查看世界时间，使用计时器和秒表功能。

■ **浏览器**

手机无线上网，浏览网页、下载文件等功能。

■ **文件管理**

管理手机存储中的图片、视频、音乐、游戏、文档以及其他资料内容。

1. 手机存储内资料除MP3、MP4和图片文件外，系统文件请不要随便移动和删除。

2. 建议安装手机存储管理的APK安装包，若自行安装APK文件包，出现死机重启现象，厂商不承担任何责任。

■ **日历**

可以查看日期、查看农历、设置日历事件。

■ **电子邮件**

配置电子邮件账户，可发送或接收电子邮件。

■ **视频**

可以查看、删除和管理视频文件。

■ **通讯录**

创建和管理手机在手机或者SIM卡或USIM卡上的联系人的信息，可保存联系人的姓名、手机号码、家庭电话号码、

电子邮件地址及更多信息。

■ **计算器**

可执行数学计算功能。

■ **设置**

◇ **WLAN**

设置WLAN的状态，网络通知，添加网络等。

◇ **蓝牙**

设置蓝牙状态、搜索蓝牙设备、修改蓝牙名称。

◇ **SIM卡**

◇ SIM卡管理：此功能可选择关闭或打开SIM卡，选择数据连接和网络设置由运营商打开。

◇ 默认短信应用：设置默认短信应用。

◇ **手机**

◇ 飞行模式：可以禁用所有语言服务。

◇ 网络共享与便携式热点：可以使用无WLAN热点，USB共享网络，蓝牙共享网络，网络共享与便携式热点设置。

◇ VPN：可以添加VPN配置文件。

◇ 移动网络：设置数据漫游、2G服务、偏好网络等。

◇ **显示**

设置与显示相关的功能，如屏幕待机时间、自动旋转屏幕、屏保、屏幕锁定通知、调节亮度等。

◇ **声音和通知**

◇ 安装不明来源：可以设置为无、滑动、图案、PIN、密码等。

◇ 自动锁定：选择自动锁定时间。

◇ 加密手机：具体信息请查看其说明。

◇ SIM卡锁定：

1. 锁定SIM卡：输入PIN码后开启锁定SIM卡功能。
2. 更改PIN码：先输入原PIN码，再输入两次新的PIN码。

◇ 显示密码：开启和关闭显示密码。

◇ 设备管理器：查看或停用设备管理器。

◇ 未知来源：开启此选项允许安装非知来源的应用。

◇ 数据保护：保护数据，防止非法访问。

◇ 手机防盗：远程控制手机或远程销毁数据。

◇ 存储类型：显示存储的类型。

◇ 信任的凭据：显示信任的CA证书。

◇ 清除凭据：删除信任的凭证内容，并重设密码。

◇ 应用程序权限：为安全和隐私管理应用程序权限。

■ **帐户**

添加帐户：更改自动同步功能的设定或管理要同步的帐户

■ **语言和键盘**

可以选择语言，设置键盘，选择输入法。

■ **备份和重置**

恢复出厂设置，会清除手机上所有的数据。

■ **日期和时间**

◇ 自动确定日期和时间：使用网络提供时间。

◇ 自动确定时区：使用网络提供的时区。

◇ 设置日期：手动设置当前日期。

◇ 设置时间：手动设置当前时间。

◇ 选择时区：设定本地时区。

◇ 使用24小时格式：设定24小时制显示时间。

■ **定时开关机**

设置手机开关机的时间。

■ **无障碍**

无障碍设置操作应用。

■ **打印**

连接打印机打印所需要的图片等文件。

■ **关于手机**

查询有关手机的状态、型号、系统版本、硬件版本、法律信息、手机型号、版本号、兼容信息等。

■ **常见问题与解决方法**

为节省您的时间和不必要的花费，请在联系专业售后服务前，自己可以进行以下简单检查。

◇ 无法启动手机

◇ 检查是否按住【开关机键】键至少 1 秒以上。

◇ 检查电池电量是否已经充。请充电。

◇ **启动手机，有信息显示**

◇ 输入开机密码时，选用了自动上锁功能，必须在使用前输入开机密码。

◇ 输入PIN码：选用了每次开机时输入PIN 的功能，启动手机必须输入PIN 码。

◇ 输入PUK 码：连续三次输入错误 PIN 码，会锁死 SIM十，此时应输入获取提供的 PUK 码解锁。

◇ **SIM卡错误**

◇ SIM卡金属面有污染，用软布清除等擦试金属接触点。

◇ SIM卡未装好，按照使用手册说明正确安装。

◇ SIM卡损坏，与您的网络服务供应商联系。

◇ **无法连接网络**

◇ 信号弱，请移到信号强的地方重试。

◇ 超出网络服务商的网络覆盖区。

◇ SIM卡无效，与您的网络供应商联系。

◇ **号码无法呼出**

◇ 请确认拨号后是否按下拨号键。

◇ 请确认是否因欠费而被禁止呼叫。

◇ 请确认SIM卡是否有效。

◇ 请确认是否设置了呼叫限制功能。

◇ 请确认是否设置了固定拨号功能。

◇ **通话质量差**

◇ 请检查是否音量调节不合适。

◇ 在接收不良地区使用手机。如高楼附近或地下室，无线电波无法有效传达。

◇ 在通话密集时期使用手机，如上下班时间，线路拥塞造成无法通话。

◇ **号码无法呼入**

◇ 请确认手机已开机，且连接网络。

◇ 请确认是否因欠费而被禁止呼入。

◇ 请确认 SIM 卡是否有效。

◇ 请确认是否设置了呼叫限制功能。

◇ **联系人无法听到声音**

◇ 请确认麦克风已经打开

◇ 请确认手机下部的麦克风靠近您的嘴巴。

◇ **待机时间短**

◇ 待机时间与网络的系统设置有关，处于接收不良的区域，收不到信号时，话机将持续发射以找寻基站，会消耗大量电池电量，造成待机时间变短。请移到信号强的地方使用或暂时关闭手机。

◇ 需要更换电池，请更换新电池。

◇ **无法充电**

◇ 接触不良，检查插头是否连接好。

◇ 污染或氧化，请用干净的毛刷和酒精擦拭金属接触点。

◇ 在低于 0 C 或高于 45 C 的环境中，请改变充电环境。

◇ 电池或充电器损坏，需更换。

◇ 如上述指导信息无法解决问题，请联系售后服务。

Thank you for choosing this smartphone!

This mobile phone is a smart phone based on Android operating system. The operation interface is simple and easy to use, so that you can fully enjoy the comfortable experience.In order to use this phone safely and effectively, please read the instruction manual carefully before use.

■ **Safety Precautions**

Do not use your mobile phone when it is forbidden to use your mobile phone or if it may cause interference or danger.

■ **Traffic safety first**

Do not use your mobile phone while driving, so as not to interfere with safe driving.

■ **Observe the prohibited areas.**

Please comply with the relevant restrictions or regulations.Shut down on airplanes or near flammable materials, chemicals or medical equipment.

■ **Interference**

Mobile communications can be subject to radio interference, which can affect performance.

■ **Waterproof**

This phone is not waterproof, please keep it dry.

■ **Specified assistance**

Do not disassemble the phone and accessories. Only authorized organizations can repair the phone.

■ **Install SIM or USIM card**

1. On the left side of the phone, find the card slot of the SIM card.
2. There is a corresponding SIM card and memory card card insertion method on the card slot, please insert the card according to the pattern shown.
3. If you do not have a SIM or USIM card inserted, you can only use your phone's network service and some of the menus.
4. Do not insert the memory card into the SIM card slot.

■ **Charging the battery**

◇ The mobile phone can be charged directly with their own charging heads and data lines, or connected to a computer for charging.

◇ When the battery is low, the phone will sound a warning tone and display a low battery message. If the battery is too low, the phone will automatically shut down.

◇ The phone can be used while charging, but this will extend the battery charging time.

◇ The phone will heat up when charging, this phenomenon is normal and will not affect the life or performance of the phone.

■ **Format TF card storage**

In the main menu, select Settings --Storage --Store Information--Format TF Storage.

Before formatting the TF card storage, remember to back up all the important data stored on your phone. The manufacturer warranty service does not include data loss due to user actions.

■ **Power On and Off**

On: Long press the switch key.

Off: Long press the switch key, and then choose to shut down.

Flight mode: Pull down the main interface, and then select the upper right icon flight mode.

Touch screen

Notes for Touch Screen:

◇ To avoid scratching the touch screen, do not use sharp tools.

◇ Do not allow the touch screen to touch other electronic devices. Electrostatic discharge may cause the touch screen to malfunction.

◇ Do not let the touch screen touch the water. The touch screen may malfunction in a humid environment or when exposed to water.

◇ In order to achieve the best results, please remove the touch screen protective film before using the phone.

◇ For the best performance, tap the touch screen with your fingertip.

The following operations can be performed to control the touch screen.

◇ Click: Click once with your finger to select or launch a menu, option, or application.

◇ Click and hold: hold down the item for more than 2 seconds to pop up a list of options.

◇ Scroll: Click and drag your finger up, down, left or right to move to the items in the list.

◇ Drag and drop: Click and hold an item with your finger, then drag your finger to move the item.

◇ Double click: When viewing a photo, tap twice with your finger to zoom in or out.

◇ The backlight time can also be adjusted.In standby mode,then select Settings--display--Sleep--Sleep time.

■ **Lock or unlock the touch screen and buttons**

The touch screen and buttons can be locked to prevent any accidental phone operation.

To lock,press [Switch button],To unlock, press [Power On/Off] and follow the on-screen prompts to manually unlock.

■ **Select wallpaper source**

You can set the wallpaper to customize the standby screen or lock

screen interface(the wallpaper,can customize the pictures in the album).

◇ Lock screen wallpaper:set lock screen interface image.

◇ Desktop wallpaper: set desktop wallpaper.

◇ Live Wallpaper: You can set live wallpaper.

■ **Move items on the idle screen**

Click and hold the item you want to move.Drag the project to the desired location after the project vibrates.

➢ **Remove item from standby screen**

Click and hold on the item to be removed, then drag the item to the trash can above the screen after vibration.

➢ **Use the shortcut panel**

When in standby mode or while using the app, touch the indicator area at the top of the screen and drag your finger down.Open the shortcuts panel. You can activate or deactivate other features such as wireless connections and access a list of notifications, such as messages, calls, events, or processing status. To hide the list, drag the bottom border of the list up.

Swipe the shortcut icon left and right in the shortcuts panel to use the following options.

◇ WLAN：Turn WLAN connection on or off. Long click this icon to enter the WLAN settings interface.

◇ Data connection: start or close the data connection.

◇ Bluetooth: Turn Bluetooth wireless connection on or off.

◇ Airplane mode: Activate or deactivate flight mode.

◇ Scene mode: standard, mute, switch between conference and outdoor mode.

◇ One-click dialup: Click to end the background application and release some memory.

◇ Brightness: Adjust the brightness of the screen.

◇ Battery: Shows device power usage.

◇ Dormancy:Adjust the delay time for the screen to automatically turn off.

◇ Orientation lock screen: After clicking, the device is off screen and locked.

◇ Settings: You can set the shortcut function and sequence display in the shortcut panel.

■ **Access application**

Open phone lock,Scroll left or right to other application screens,Select and Sort application,Press the Home button to return to the main standby screen.

◇ **Light sensor:** A built-in motion sensor that detects the direction of the phone. If you rotate your phone while using certain features, the phone interface will automatically switch to landscape mode. If you want to set the interface does not change

with the rotation of the phone,Open the shortcuts panel at the top of the screen and select Auto Rotate. Alternatively select Setting --Display--Rotation Settings--Auto or Keep Portrait.

■ **Widget**

In the screen interface, click the MENU key, select Add widgets, select any widget long press, drag to standby.

■ **Custom phone**

Customize your phone to your personal preferences: themes and desktop aldshance effects, etc.

◇ **Set current time and date**

In the main menu interface, then select Settings --> Date & Time,Set time and date and change other options.

◇ **Set the ringtone and volume**

In the main menu interface, then select Settings --> Sounds & Notifications--Standards--click on the right setting--select the tuoshi tone On or Off.

◇ **Adjust the ringer volume**

Press the up or down volume button to adjust the ringer volume.

◇ **Switch to vibration mode**

To shake or de-vibrate your phone, do one of the following.

1. Switch directly in the shortcut panel mood mode.
2. In standby mode, press and hold [Switch button],Then select the vibration mode.

◇ **Change ringtones**

In the main menu interface, then select Settings --> Sound & Notifications--Standards--Point Right Settings --Phone Ringtone/Black Receipt Notification Tone/ Message Ringtone. Select a ringtone from the list and select OK.

◇ **Select the wallpaper of the standby screen**

In standby mode, press menu--wallpaper--select the type of wallpaper to be set.

◇ **Adjust the brightness of the display**

1. In the main menu interface, then select Settings --Display --Brightness.
2. Turn off the button on the auto-adjust brightness.
3. Drag the slider to adjust the level of brightness.

The brightness level of the display affects the speed at which the phone consumes battery power.

◇ **Set the phone time and date**

◇ Condyle setting steps

1. In the main menu interface, then select Settings - Security --Screen Lock --Pattern.
2. Watch the screen prompts and sample patterns and choose Next.
3. Drag your finger to connect at least four points and draw a

pattern.Choose to continue.

4. Redraw the pattern to confirm.Select confirmation.

◇ After setting the unlock pattern, you will be asked to enter the unlock pattern each time you turn it on. If you want your phone to no longer require an unlock pattern, select Settings --> Security --> Screen lock --> Draw the lock set pattern --> None.

◇ Note: If you select "None", the screen will not be locked.

◇ If you forget to unlock the pattern, you need to bring your phone to the customer service center to unlock it.

◇ The manufacturer shall not be liable for the loss of password or personal data or other damage caused by the use of illegal software.

◇ **Use SIM card or USIM card**

1. The phone can be locked by activating the PIN code provided with the SIM card or USIM card.

◇ In the main menu interface, then select Settings--Security --Settings SIM card lock mode--Lock SIM card.

◇ Enter your PIN and choose OK.If you activate the PIN lock, you must enter your PIN every time you turn it on.

◇ If the PIN code is entered incorrectly three times, the SIM card or USIM card will be locked. You must enter your PIN unlocking key (PUK) to unlock your SIM card or USIM card.

◇ The SIM card or USIM card is locked due to incorrect PUK input, please the card is permanently locked, please.

◇ **Dial**

Call and receive calls through available options during a call, or customize and use call-related features.

◇ **call records**

Can view all call history filtered by type.

1. In standby mode, click the dial button to enter the dialing interface and dial the phone.
2. In the call log interface, you can press the call type of the call.
3. Select the record for which you want to view detailed call information.

◇ **Dialpad**

Click the icon in the lower left corner of the main interface to close or pop up the dial pad to operate the contacts recorded in the call. Each time you dial or contact number, the contact automatically joins the call history page.

◇ **Function menu**

Includes contacts, speed dials, setup options.

■ **Information**

Create, Send, Receive, View, Manage Text Messages (SMS) or Multimedia Messages (MMS).

■ **Music**

➢ Listen to your favorite music using the music player.

1.Depending on the phone software, some file formats are not supported.

2.If the file size exceeds the available storage space, an error occurs when opening the file.

➢ Add music transfer music files to your phone.

1.Download from wireless web

2.Copy through data line

3.Transmission via Bluetooth

■ **Album**

View images on your memory card and play them.

■ **Recorder**

Help you quickly save your voice recordings, you can set your favorite sound quality and recording mode.

■ **Clock**

You can set an alarm, view world time, use timers and stopwatch functions.

■ **Browser**

Mobile wireless Internet access, browsing web pages, downloading files, etc.

■ **Document management**

Open all your pictures, videos, music, documents and other kinds of files stored in your phone's memory card.

1.In standby mode, click the dial button to enter the dialing interface and dial the phone.

2. In the call log interface, you can press the call type of the call.

3. Select the record for which you want to view detailed call information.

■ **Dialpad**

Click the icon in the lower left corner of the main interface to close or pop up the dial pad to operate the contacts recorded in the call. Each time you dial or contact number, the contact automatically joins the call history page.

■ **Function menu**

Includes contacts, speed dials, setup options.

■ **Information**

Create, Send, Receive, View, Manage Text Messages (SMS) or Multimedia Messages (MMS).

■ **Contact**

Create and manage a list of personal or corporate contacts stored on your phone's memory or SIM card or USIM card. Save contact's name, mobile number, home phone number, email address, and more.

■ **Calculator**

Perform mathematical calculations directly on your phone.

■ **Setting**

◇ **WLAN**

Set WLAN status, network notification, add network, etc.

◇ **Bluetooth**

Set Bluetooth status, search for Bluetooth devices, and modify Bluetooth nicknames, etc.

◇ **SIM card**

◇ SIM card management: This function can choose to close or open the SIM card; select whether the data connection and international roaming are open;

2.Default SMS app: Set default SMS app.

◇ **More**

1.Airplane mode: All language services can be disabled.

2.Network and sharing and portable hotspots: WLAN hotspots, USB sharing networks, Bluetooth shared networks, network sharing and portable hotspot settings

3.VPN: You can add a VPN profile.

4.Mobile network: set up data connections, 4G services, roaming services, etc.

◇ **display**

Set functions related to mobile phone display, such as screen standby time, auto-rotate screen, interactive screen saver, screen lock notification, brightness adjustment, wireless display, etc.

◇ **Sound and notification**

1.Set the phone mode. Default mode: standard, mute, conference, outdoor mode.

2.Set phone ringtones, message ringtones, volume, etc., as well as set custom profiles.

◇ **Storage**

View phone and TF card storage

◇ **battery**

View phone battery usage

◇ **Application**

Manage applications locally and change administrative settings for installed applications.

◇ **Safety**

1.Screen lock mode: set to slide, pattern, PIN, password.

2.Auto lock: select auto lock time.

3.Encrypted phones: Please see their instructions for specific information.

4.Set the SIM card lock:

1Lock the SIM card: Click to lock the SIM card, enter the PIN code and turn on the lock SIM card function.

2) Change SIM card PIN: Enter the original PIN code first, then enter the new PIN code twice.

5.Show password: Turns the display password on and off.

6.Device Manager: View or deactivate Device Manager.

7.Unknown sources: Whether to allow the installation of a location-sourced app, it can be turned on and off.

8.Credential storage: Manage credential storage.

9.Mobile phone theft: remotely lock the phone or remotely destroy the data.

10.Storage Type: Shows the type of storage.

11.Trusted credentials: Use certificates and credentials to ensure secure use of individual applications.

12.Install from phone storage: Install the encryption certificate stored in the phone storage.

13.Clear credentials: delete the contents of the voucher in the phone and reset the password.

App permissions: Manage app permissions for security and privacy.

➢ **Account**

Add account: Change the settings of the auto sync feature or Manage accounts to sync.

➢ **language and keyboard**

Language and input method: you can choose the language, set the keyboard, select the input method.

➢ **Backup and reset**

Backup and reset: Restoring the factory default settings will erase all data on the phone, please be cautious.

➢ **Date and time**

1.Automatically determine date and time: use the network to provide time.

2.Automatically determine the time zone: Use the time zone provided by the network.

3.Set date: Set the current date manually.

4.Set time: Set the current time manually.

5.Select time zone: set local time zone.

6.Use 24-hour format: set to display time in 24-hour format.

➢ **Timer switch**

Set the time when the phone is turned on and off.

➢ **No barrier**

Barrier-free setup operation application.

➢ **Print**

Connect the printer to print the necessary images and other files.

➢ **About mobile phone**

Query information about your phone, such as system upgrades, status information, legal information, phone model, version number, processor, etc.

■ **Common problems and solutionsin**

Order to save your time and unnecessary expenses, please the following simple check before contacting professional aftersales service.

➢ **Cannot turn on**

1.Check if you press and hold the [Power On/Off] key for at least 1 second.

2.Check if the battery is exhausted, please charge.

➢ **Start the phone, there is information display**

1.Enter the phone lock password and select the auto lock function. You must enter the phone password before using it.

2.Enter the PIN code and select the function to enter the PIN every time you turn it on. You must enter the PIN code.

3.Enter the PUK code: Connect the error PIN code three times and lock the SIM card. Enter the PUK code provided by the operator.

➢ **SIM card error**

1.The metal surface of the SIM card is dirty. Wipe the metal contact point of the SIM card with a clean cloth.

2.If the SIM card is not installed, install the SIM card correctly according to the instruction manual.

3.SIM card is damaged, contact your network service provider.

➢ **Unable to connect to network**

1.The signal is weak. Please move to a strong signal and try again.

2.Exceeding the network coverage area of the network service provider.

3.Invalid SIM card, contact your network provider.

➢ **The number cannot be called out**

1.Please confirm whether the dialing button is pressed after dialing.

2.Please confirm if the call is forbidden due to arrears.

3.Please confirm if the SIM card is valid.

4.Please confirm if the call barring function is set.

5.Please confirm if the fixed dialing function is set.

➢ **Poor call quality**

1.Please check if the volume adjustment is not suitable.

2.Using mobile phones in poorly received areas, such as near high-rise buildings or basements, radio waves cannot be transmitted.

3.Use the phone during a call-intensive period, such as after work hours, the line is congested and the call cannot be made.

➢ **Number cannot be called in**

1.Please confirm that the phone is turned on and connected to the network.

2.Please confirm if you are prohibited from calling due to arrears.

3.Please confirm if the SIM card is valid.

4.Please confirm if the call restriction function is set.

➢ **Contacts can't hear you**

1.Please confirm that the microphone is turned on.

2.Please keep the microphone in the lower part of the phone close to your mouth.

➢ **Short standby time**

1.The standby time is related to the system settings of the network and may be in an area where reception is poor. When the signal is not received, the phone will continue to broadcast to find the base station, which consumes a large amount of battery power, resulting in a shorter standby time. Please move to a place with strong signal or temporarily turn off the phone.

2.Need to replace the battery, please replace the battery.

➢ **Unable to charge**

1.Poor contact, check if the plug is connected.

2.Dirty, wipe cell phone charger with clean cloth.

3.When charging in an environment below 0°C or above 45°C, please change the charging environment.

4.Charger or battery is damaged, battery needs to be replaced.

5.If the above information does not help you solve the problem, please record your phone model and serial number, authorization or insurance policy information, and a clear description of the problem, then contact your local after-sales service provider.

Attention:

Explosion hazard if you replace it with the wrong type of battery.Always dispose of used batteries as instructed!

It is forbidden to use any non-factory tool on this product, otherwise there may be unrecoverable faults. Select the root phone does not enjoy the warranty!

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Specific Absorption Rate (SAR) information:

This WCDMA digital mobile phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies.

The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: WCDMA digital mobile phone has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the phone kept 10mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain an 10mm separation distance between the user's body and the back of the phone. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.