INDUCTION WATCH FUNCTION DESCRIPTION



1.After the code is successfully turned on, touch the power button and the watch will stop working, and the indicator light will be on. Press again to cancel the pause and switch to the normal working state.

2.Press the finger button for 2 seconds to switch the function mode.
(Left tilt of the watch means left rotation, right tilt means right rotation)

3. Lightly press the finger button to release the equation to spray the mist, and lightly press the finger button again to release the equation to spray the mist again.
(Multiple operations can be repeated continuously)



DISPLAY OF SUCCESSFUL OPERATION OF CODE MATCHING





REMOTE CONTROL INSTRUCTIONS

INSTRUCTIONS:



BATTERY DESCRIPTION:

USE TWO AA 1.5V NON-RECHARGEABLE BATTERIES

REMOTE CONTROL CAR DESCRIPTION

BATTERY DESCRIPTION:



THE CAR USES A 3.7V RECHARGEABLE LITHIUM BATTERY

CONFIGURE USB CHARGING CABLE AND RECHARGEABLE BATTERY

COOL SPRAY:
(WITH LIGHTS)



DISTRIBUTION WATER DISPENSER

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.