Cisco Digital Transport Adapter HDMI+F2.2 Remote Control



The Keys Including:

1.DTA Power
2.Mute
3.Exit
4.Info
5.0-9 Digits
6.Enter
7.Channel -/-
8.Channel +/+
9.Last
10.Menu
11.Pagem
12.Pagep
13.Right Arrow
14.Left Arrow
15.PROG

Welcome

The Cisco Digital Transport Adapter (DTA) remote controls the volume, mute, and channel/channel up/down on directly connected TVs. Use the instructions in this guide to set up and use your Cisco DTA remote.

Important Information About Your Remote

The remote control is originally programmed for DTA only.

If you are Programming TV Mode the remote, you need to go to Program The Remote to control your TV.

Batteries

Use two AAA batteries.
Check the diagram inside the battery compartment to ensure the batteries inserted in the correct direction.

Note: Batteries not to be replaced within two minutes of removal to retain programmed TV code.

⚠ Caution: This remote contains batteries that are not of a type that the children under the age of 6.

Program the Remote to Control Your TV

Program the remote control for TV following these steps:

1.Turn on the TV.

2.Press and hold "PROG" for three seconds or until the LED turns on then press "TV" key (the LED will blink once and stay on).

3.Find the four digit device code for your TV brand. Press and release the four numeric keys.

4.If the device is valid, the LED will blink two times and the remote is ready to control the device code is invalid, the LED will blink three times, either input another code or cancel the remote. Programming by pressing the "TV" key.

Automatic Code Search

If the device code for your TV brand can't be found in the list, please try to search the device code automatically by following steps:

1. Turn on TV device manually.

2. Press and hold "PROG" key for three seconds or until the LED turns on.

3. Press "CH+" key to enter the automatic code search mode. The remote will transmit the TV power code to the TV every 2 seconds and the LED will flash at the same time. When you see the TV device is powered off, the remote has found a valid group device code.

4. Press "TV" key to save the code and to exit the search mode.

Pairing between Remote Control and Target Device (DTA)

Your remote control can be paired with a Cisco Digital Transport Adapter (DTA) of a specific pairing code (behind your TV for example).

1.Turn on the target (DTA) device.

2.Press and hold "PROG" for three seconds or until the LED turns on, then press "PROG" key.

3.The LED on the remote control flashes about 5s indicates the device is in pairing mode.

4.The DTA will prompt the user, via a message on TV to enter a unique five digit number.

5.If the new digits entered are correct, the target DTA prompt the user that pairing is successful.

6.If the new digits entered are incorrect, the target DTA prompt the user that pairing fails and the remote control code is unchanged.

Unpairing Scenario

Once paired with the target DTA, the remote can be unpaired using the following sequence:
1.Press and hold "PROG" key for three seconds or until the LED turns on.
2.Press <9> <9> <7>, the LED will blink two times quickly to show the procedure is successful.

Switching between DTA and TV mode for Volume/ Mute Control

To control DTA Volume and Mute, use the following steps:

1.Press and hold "PROG" key for three seconds or until the LED turns on.

2.Press "VOL+" key.

To control TV Volume and Mute, use the following steps:

1.Press and hold "PROG" key for three seconds or until the LED turns on.

2.Press "VOL+" key.

Default state: the remote is initially assigned to control DTA Volume and Mute.

Trouble Shooting

If there is no response when you press any key on the remote control, **please** check the **Batteries** are installed correctly for remote.

Check the Batteries

Are the batteries inserted correctly? Are the batteries drained? You may try to replace the batteries with the new ones.

Check the DTA

Is the DTA connected to the rear of the TV? Is the DTA power cord connected? Is the cable attached? Is the DTA power cord connected to the power outlet?

Check the TV

Is the TV power cord connected to the power outlet? Is the TV turned to the correct channel? Is TV work with the DTA?

Check the TV Code List

If your TV's brand not listed in the code list? Sometimes there is more than one code for a TV's brand, please try to use different codes.

If you can't find your TV's brand in the list or you can't program your remote successfully, you should contact your TV's manufacturer.

•Run Auto Search Mode.

TV Brand and Code List

3M	0071 0753
A. B. Systems	0060 0080 0084
Acoustic	0060 0080
Acp	0060 0080 0084
Acr	0060 0080
Acuson(ultra)	2561
Adc	0060 0080
Adcom	0060 0080
Addison	0020 0029
Adi	2145
Admiral	0175 0220 0223
Adtec	0060
Advent	0060 0080
Aea	0060 0080
Aeg	0060 0080
Affinity	0075 0080
Agfa	0060 0080 0084
Aiko	0020 0060 0080 0084 0175 0176 0180
Aim	0060 0080 0084 0175 0176 0180
Airtech	0175
Akai	0000 0001 0002 0003 0004 0005 0006 0007 0008 0009 0010 0011 0012 0013 0014 0015 0016 0017 0018 0019 0020 0021 0022 0023 0024 0025 0026 0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037 0038 0039