BLUETOOTH PLAY & TYPE KEYPAD PS4

Model: BGK116

Product picture:

Product introduction

This PS4 controller wiress keyboard makes it easier for the players to chat with friends and relatives in PS4 & PS Vita platform. This device is easy to install ,take out and connect with any version of PS4 original controller as well, and provides convenient and useful functions like text type, Internet chat, and game playing.

Product Features

1.To communicate with your friends conveniently by the voice chat and typing with this wireless controller.
2.Fit well with your your PS4 controller, install and take out simply.
3.Easy to operate , good hand feeling.
4.The original style of the PS4 controller will not be destroyed when the wireless keyboard is fit on. This wireless keypad would be embedded perfectly with the PS4 controller.

User Manual

Functional Buttons:

1:ENTER key
2:Right Shift key
3:Shift Up key
4:Shift Down key
5:Indicator light
6:Left Shift key
7:MICRO USB charging port
8:Audio Output Socket
9:SPACE key
10:Bluetooth Mode key
11:Power Switch
12:Backspace key
13:Number/Letter switch key
14:Caps lock key
15-16:26 Letter and Character input keys(area)
17:0-9 Number input keys(area)
18:Audio connector
19:Loudspeaker

Specification:

1. Connect your PS4 console with the display device and then turn on it.
2. Turn on the power switch of the wireless keyboard, the blue indicator will light up once.
3. Long press Press Blutooth Mode Key about 2 seconds to seach and pair the wireless keyboard. The blue indicator flashes while the pairing and will light off once the pair if finished successfully. The keyboard will go into sleeping mode to save the power if no any connection in 3minutes after pair.
4. Click the operation manual of PS4 console:"*SETTINGS-DEVICES-BLUETOOTH DEVICE*" to find the device name of the keyboard "Bluetooth Keyboard" and then click it to pair it with your PS4 console according to operation notice step by step.
5. After pairing successfully, select the same name as the controller and you are ready to use this wireless keyboard.
6. Connect the 3.5 Audio Connector of the keyboard with the Audio output Jack of P4 controller to install it well with the P4 controller then voice will be output from the loudspeaker of the wireless keyboard.
7. The Audio Output Socket of the keyboard provide the same function with the Audio Output Socket of original PS4 controller, you can insert or connect the Headphones /Microphones for using.
8. Keypad tone: each time you press the button, a "Deee" sound can be heard.
9. After the Bluetooth connection is broken, the wireless keyboard will automatically go into sleeping mode. At this moment you can press any key to automatically connect back if the keyboard is in the effective connection area and PS4 console is turned on. If it cannot automatically connect back, please turn on its power key again on the keyboard.
10. Hold the @#: /ABC key, and then press the needed symbol key, you can type the corresponding symbol.
11. Caps lock key "L2 ⇧": Click this button to lock the capital letter typing, and click again to return to lowercase typing.
12. When the red light is flashing, which means that the power of the wireless keyboard is too low to warn you to charge it . While the charging, the red light lights up and it will light off once the keyboard is full charged.
13. If the product is not be used for a long time, please charge it one time within two months, which can protect the battery and extend battery life.

Electrical Parameter:

1. Charging voltage: DC 5V
2. Charginging current:120MA
3. Quiescent current: ≤30uA
4. Bluetooth distance: ≤10 m
5. Bluetooth version: V3.0

Product maintenance and precautions

1. The keyboard can be used only when the PS4 host is pairing successfully to the controller keyboard.
2. Do not knock on or beat the product strongly.
3. Liquid or small metal are not allowed to come into the product.
4. Do not use and store the product in a hot or humid environment.

FCC Warning

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- o Reorient or relocate the receiving antenna.
- o Increase the separation between the equipment and receiver.
- o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- o Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

User Manual

User Manual