WG9750/8G-BT

Tablet computer series
The user manual

TABLET android

Instruction

Please read the precautions and important tips in the instructions before use.

Catalog

	Chapter One (overview)
1-1	Appearance
1-2	Buttons
1-3	Open and shut down
1-4	Open and shut down standby mode
1-5	Lock and Unlock the screen
1-6	Homepage information column
1-7	Text input
	Chapter two (Browser)
2-1	Browser
	Chapter three (Applications)
3-1	Camera
3-2	Gallery
3-3	Video Player
3-4	Music
3-5	Calendar
3-6	Calculator
3-7	FileBrowser
3-8	Application installation
3-9	Video output
3-10	Simulation Game
3-11	Download
3-12	E-mail
	Chapter four (Establishment)
4-1	Sound settings
4-2	wireless networks settings
4-3	Display settings

Chapter One Overview

1-1 Appearance

Picture for reference only. Please subject to specific products.

1-2 Buttons

Power button

Long press the button ■ about 2-3 seconds to open the screen.

When open the tablet, short press the ■ to enter the off screen state and short press again to light up the screen.

Volume

[redacted] this to adjust the volume

Set up

This key [redacted] to set up the applications

1-3 Open and shut down

Open

Long press the power button ■ on the right side, A9 sign and pictures will show up in turn until in the interface.

Shut down

Long press the power button ■ , then the screen shows "sure?", you like to shut down, press ensure to shut down.

In charging state when the tablet is off press the right upper "power button" it will shows "charging" Figure, enter again to click "power button", the equipment will be opened.

1-4 Open and close standby mode

Open the standby mode

In boot mode, you can tap the power button ■ on the upper right side of the tablet ,for system will into the sand by mode which can save power.

Close the standby mode

In the stand by mode, light tap of the power button on the right side to wake up the device, enter the normal state.

1-5 Lock and unlock the screen

Lock

You can set up the sleep time in system of-displays.

The system will sleep automatically and lock the screen to the standby mode if without any inserts to when reaches the power of standby time.



Unlock

Move the sign ■ to unlock, show as below.

Drag this ■ to unlock the screen and enter the application interface.

1-6 Homepage information columns

1-7 Text input

When use the tablet, you can use the virtual keyboard to enter text numbers, symbols directly by touching screen. After selecting the Android input method ,for default keyboard show as below.

To switch the numbers and letters, please press this [redacted]

To switch the capitalized between letters please press this [redacted]

Chapter two:Internet

2-1 Browser

Requires network support: before using a web browser, if there are network supporting problems, please contact your network operator or the seller provider.

Tablet's web browser can connect to the Internet via WiFi to satisfy your business and individual network needs.

Please touch this ■ to set up the WiFi so that can use the browse normally.See as picture:

Touch ,hold ■ in the application list to enter the browser pages, the default home page is the «Recently Viewed» showing recently viewed pages.

Browser supports the following features:

Enter the URL-touch the ,to get the soft keyboard, then to let the URL.

Bookmark-touch click this ■ to add into the bookmark.

Touch this ■ to read the favorite website that collected.

Touch this ■ to search the internet

Touch this ■ to add new browser.

Touch this ■ to close the browser

Chapter three: Application

3-1 Camera

Touch this ■ in the application list to enter the camera, the views showed on the screen and you can do the following as picture:

Camera

Click this ■ to get four shot.

* ■ setting ": to set up ■ white balance, ■ exposure, ■ save ■ start.

Video

Click this ■ to video and do the relevant operation.

* ■ setting " ■ white balance setting ■ setup ■ save ■ click this to start video

View photos and videos

In pictures preview interface, click on the screen to preview photos, also you can set up the pictures to slides.

3-2 Photos

Click here ■ in the application list which including all the pictures:

Click this ■ can classify the pictures by time and place. Click this ■ to enter the camera. Click this ■ to choose the album to edit or delete.

Click this ■ to enter slides show when you enter to album.

3-3 Video player

Touch this ■ in the Video player

You can see the Videos in ■ and ■ files.

There are some control areas at the bottom after you enter the video player.

Play interface: ■ list, ■ random play, ■ repeat

Artists

In the camera page, it is sorted according to the artist ,if artists click on one, you will open the artist's related album and song list, then you can click songs to play.

Album

The album page shows all albums in the list, sliding it can browse all. Click on the album cover will transfer to the album back automatically. When all music shows, click again on the songs begin to play.

3-5 Calendar

Touch this ■ in Calendar, the default page shows the months, click the ■ to the day.

Date views: long press in the events to refresh, view, edit, and delete. Click on the blank area can set up new events; long press the blank area, you can ball new events or display/non display the lunar day view.

Week views: Long presses the events to refresh, view, edit, and delete events; long press the blank area you can tribal events or display/non display the lunar weeks view.

Month view: long press date to bold new calendar items or display/not display the lunar month view

Agenda: list all events click to read the details

In any views, when you switch to other date, week or month, all can be back to today or week or month now by touching «today» button

3-4 Music

Touch here ■ in the music player. Music can be played by artists or album classifications. This page displays the songs alphabetically.

Click the songs you want to listen and get into selected state to play.

Click on the screen playing swell display being played album page; there will be lyrics shows under the page right.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy

and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

o Reorient or relocate the receiving antenna.

o Increase the separation between the equipment and receiver.

o Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

o Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to the device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Specific Absorption Rate (SAR) information:

This TABLET meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

FCC RF Exposure Information and Statement The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. Device types: TABLET (FCC ID: 2AC7Z-WG9750/8G-BT) also meet the USA SAR limit. This device was tested for typical body-worn operations with the back of the handset kept 35cm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 35cmseparation distance between the user's body and the back of the handset. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 0.5 cmmust be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet minimum separation distances, comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.

The company reserves the right to vary the product design product pictures and content are for reference only, and specifications of the right,then without prior notic. Specifications appearance please to sales kind prevail.



You can also click here to search task menus, edit,creation and share.

3-6 Calculator

Touch here in the application list to get into the calculator.

3-7 Document browsers

Touch here in the application list, it supports the file files stated in copy in this two places:internal memory and SD card.

Touch the button , when it turn to yellow, you can edit the file.

Edit

Touch this , and tick the file including positions,pasteletter copy,choose , click on the list, click this to copy when done, tap . Then click this , to remove when done, click ok and then click this to paste. Delete, choose one file then click this , and click ok to delete.

3-8 Application installation

Touch here in the application list, will search all installed APK files automatically. It searches the APK file from and .

Touch the selected APK application directly for installion and unloading

3-9 Video output

Touch here in the application list, choose the resolution of the video output.

System has 720P and 1440P two kind of resolutions.

3-10 Simulation Game

In the application list click here to connect the handle to the game,there will be AC,PS,MD, GBA,FC APK file in the Mobi Guide.

Different equipment installs different simulator

Handle

Space, back, select, start

Different keys set different in the game

3-11 Downloads

Click here in the application list, you can preview the downloading or clear document contents.

Click download file to stop or delete the download contents.

3-12 E-mail

Require the internet support before using e-mail,if there are problems in network supporting, please contact your network operator.

Add account

If you are the first time to use email, get into a mailbox interface directly to set up an account according to instruction.

If you want to add more mailboxes,click<Settings> on the top of the page to add more mailboxes, and then select<add account>.

Draft e-mail

In <inbox> page, you can click to this on the right page top to draft mail quickly. In the draft box page, you can: Add more recipients quickly.

Enter the recipient address in recipient input box or click on the contact in the contact list of recipients to choose mail address; you can copy,close or send input address.

Write email subject and text content.The text area support copy,chose operations;

Add attachment

Add attachments from the document management,when it successfu, the name will show on<New e-mail> page,you can click to select to open or remove them.

Reply,forward mail

Click the right page preview area of the tool bar <reply>,<reply all>or<forwarding>choices. The basic operation is same with the draft e-mail.

Chapter four: System setting

Click here to enter the system setting interface.

4-1 Sound setting

Sound setting,click this to sound setting page. You can choose mute switch which can get more detailed settings if you need.Click <Ring>,<Notice>,<Alarm>,<Keyboard>,<Touch> and <Ring> to set up the kind of volume and choose the prompt operation sound and the bell and software click tone switch voice.

4-2 Internet setting

This setting module includes: the wireless local area network Settings

The wireless local area network Settings

Open wireless LAN switches,the system will scan available wireless network automatically and display the wireless local area network in the list.

Among them,if the local area networks have the sign behind it,that represents the networks don't need a password, can be connected directly.

This sign represents the network has been encryption,it needs to enter the password to connect.

You can choose the network from the list you want,click it to connect directly,also you can click the <advanced>option to set up the

<IP and gateway>,then click<connected to the network>; you can also select <add wireless local area network>, to add by hand.

Network notice: open the switch, it will notice if there any open network.

Install wireless local area network certificate: the Wireless local area network loading and Unloading.

MAC address: to show the WAC address

4-3 Display setting

Display Settings contains: wallpaper Settings, dormancy time, brightness,automatic rotating Settings.

Wallpaper setting

In the wallpaper setting, you can set up the wall paper and dynamic wallpaper, the wallpaper can be chosen from gallery.

Standby screen

When the screen in light state a period of time, it will automatically lock to save the power if without any operations.

Brightness

This can set adjust brightness manually to get the lightness you want.

Tips:

You can set up the font size according to individual's income, show more or good or only small, ordinary, big bags.

Dial telephone

1. in the standby mode, enter the area code and telephone number.
2. press the [ ] to call.
3. if you want to end a call, press the [ ].

Answer the phone

1. when the mobile phone get a call, press the [ ] to answer.
2. if you want to end a call, press the [ ].

Adjust the ring volume

If you want to adjust the sound volume:

1. in the stress mode, select set up → scene mode
2. select the scene mode → edit → voice.
3. press the (optional) → edit.
4. select ceming call's ring volume.
5. roll left or right can adjust the volume size.
6. press the (select).
7. press the (optional) → storage.

Adjust call volume:

During a call, press the volume up or down keys to adjust the volume.

Send and see the short message sending

If u want to send a short message:

1. in the stress mode, select information, send new information → short message.
2. input text information.
3. press the (optional) → send
4. enter the recipient mobile phone numbers.
5. press (option) → enter the message.

Send MMS:

1. in the stress mode, select information, send a new message → MMS.
2. select theme.
3. enter the theme and press the key.
4. select the picture and video → add a picture or add video, then add pictures or videos.
5. select the sound → add a sound, that sound is added.
6. select the attachment.
7. input information of text and press enter.
8. press the (optional) → send, select the recipient and send information.

If you want to view the SMS or MMS :

1. in the stress mode, select the information → my Information → the inbox.
2. select SMS or MMS.

Warning Safety warning

Mobile phone will be kept far from children and pets

The mobile phone and accessories are kept far from children or pets. Children or pets can swallow small parts what may lead to suffocation or injured.

Hearing protection

Using the headphones with a very high volume ring damage your hearing. Please set up so calling or listening to music with a minimum volume.

Carefully install the mobile phone and equipment

Make sure that the mobile phone or other device is fixed firmly in vehicles. Cannot install the mobile phone and accessories inside or around the area of the air bag open.If the wireless equipment installation is improper, when the rapid expansion of air bag, it can cause serious injury

Be careful to treat and disposal of the battery and charger

- Use only the battery and charger of the company's allowance designed for mobile phone. The battery and charger not compatible with may cause danger or damage of the mobile phone.
- Don't put the battery into the fires. A depleted battery should be dealt in accordance with the local regulations.
- Don't move mobile phone battery around a heating device, in or upper, such as a microwave oven, or oven or radiator, battery overheating could explode.
- Do not squeeze or puncture the battery bar. To avoid the battery in the external pressure, otherwise it will lead to an internal short circuit and overheating.

Avoid the interference with pacemaker

Manufacturers and wireless technology research department of independent study group recommend that it must maintain at least 15CM (6 inches) between the mobile phone and a pacemaker zoop, in order to avoid the interference of pacemaker. If you suspect that mobile phone interfere with pacemakers or other medical equipment, mobile phone should be shut down immediately, meanwhile, in contact with the manufacturers of pacemaker or medical equipment and seek guidance.

Close mobile phone in any explosive environments

At the gas station repair station or any place near flammable items or chemicals, do not use the mobile phone. In warning signs of the closed mobile phone, then make sure to close mobile phone. In or around the fuel or chemical storage and transportation area or explosive places, mobile phone may cause an explosion or fire. Do not store or carry flammable liquid, gas or explosives, in or nearby the buses with mobile phone or accessories.

Reduce injury risk from repetitive motion

When playing a mobile phone to send messages or playing games, easily take mobile phone, gently press the button, the use of special functions (such as template and the prediction of the input reduced times to press the button, and text often.

Warning Safety precautions

Traffic safety first

Don't use a mobile phone while driving, and abide by all the rules and regulations of limit the use mobile phone when driving. If possible, use a hands-free kit to ensure safety.

Observe all safety warning and provisions

Comply with the provisions of the restriction of the use of mobile phone in some areas.

Only allow to use of the company's special accessories.
Use incompatible accessories may damage the mobile phone or cause injury.

Shutdown the mobile phone nearby the medical equipment

Mobile phone may interfere with the medical equipment in the hospital or health care institutions. Please comply with all rules, or protect warning and medical staff instructions.

Shut down or turn off the wireless function by airplanes

Mobile phone may interfere with airline equipment. Please comply with all requirements of airlines, and close mobile phone or switch off the wireless function under the airline personnel requirements.

To protect the battery and charger to prevent damage

Do not use the charger in the outdoor environment. The charger in a very high (below 0°C/32°F or 45°C/113°F above), extreme temperature will reduce the lifespan of battery and charging capacity. The battery should be stored in a dry place.
Prevent battery from the metal objects, otherwise it might make the battery "+" and "-" pole of the battery is connected, to cause temporary or permanent damage.
Do not use damaged charger or battery.

Be careful to properly handle the mobile phone

Dust for the mobile phone wet, liquid may cause serious damage. Do not touch mobile phone by wet hands. Water may cause damage of mobile phone, manufacturers have not warranty for that.
Do not use of store mobile phone in the dusty or dirty places, otherwise it will damage the operating parts of mobile phone.
Do not use the magnetic electronic equipment, keep mobile phone prevent from impact or rada, so as not to cause serious damage.
Not to break paint. The paint will block the existing parts of mobile phone and hinder the normal use. Mobile phone and memory card may be influenced by the magnetic field and damaged. Do not use the protect bags or accessories with magnetic shell, and don't let the mobile phone long-term exposure to magnetic fields nearby.

Avoid interference with other electronics

A mobile phone radio frequency signal, may interfere with unshielded or shield improper electronic devices, such as pacemakers, hearing aids, medical equipment and other home use or car use electronic equipment. Please consult with the electronic equipment manufacturers, in order to solve the interference problem encountered.

Important information

Use the mobile phone in a normal position

Don't touch the bulb in
antenna position of
mobile phone.

Only qualified personnel can repair the mobile phone

Repaired mobile phone by unqualified personnel may cause damage, and out warranty.

To ensure that the longest of the service life of battery and charger

Continuous charging battery do not take more than one week, overcharging may shorten the battery life.
If the battery is not used for a long time, it will gradually discharge. Make sure to be charged before use.
When Charger is not used, please cut off the power.
The battery can be used only for the intended use.