THOMSON

MOBILE MULTIMEDIA SPEAKER

User Manual

English/Japanese QYTM-G628

1. Preface

In order to make your player fully function, please read this manual carefully before use, and master the connection method and operation points of this system. We have carried out various explorations in design, manufacturing process, and user-friendly operation to meet your needs.

Please keep this Manual properly for future reference.

Open the package, please confirm the following accessories carefully, and keep them together to avoid loss.

2. List of Accessories

Wireless Speaker Box *1 User's Manua * 1 Charging Cable * 1

3. Specifications

Loudspeaker: 3 inch
Input voltage: DC 5V
Output power: 5W*2
Support: Bluetooth, TF, USB, FM, TWS mode,RGB Light Mode
Battery: Built-in 1200mAh rechargeable Li-battery
Operation range: 10M
Frequency response: 80Hz-13KHz
Distortion: ≤10%
S/N ratio: ≥80dB
FM frequency range: 87.5-108.0Mhz

4. Description of Parts



1.Speaker modes button(Mode1:Blue-Connect; Mode2:FM Mode; Mode3:USB/TF)。Long-press to connected the TWS
2.Play/Pause/SCAN(Auto search in FM mode)。 Long-press the button can connected or disconnected the Bluetooth
3.Previous song/Volume-
4.Next song/Volume+
5.RGB light mode / Long-press can close or open the light
6.USB slot
7.TF card slot
8.Mirco USB Charging port (DC 5V)
9.LED indicate
10.OFF/ON

5. How To Connect The Wireless Speaker

Turn on the speaker unit and the Mobile or other devices, and search for the unit's model name "G628" to pair the two devices.
Once paired before, it will automatically connect after the unit is turned on.

6. Bluetooth

Turn on the speaker and it will come into the Wireless mode directly. After pairing the device, it can play the music. short press " ⏯ " button to Play/Pause. short press " ⏮ " or " ⏭" button to previous track or next track.long press "⏮" or "⏭" button to increase or decrease the Volume.

7. USB/TF Card

Insert the U flash memory or TF card into the USB/TF slot, the speaker will read the MP3 format music automatically. short press " ⏯ " button to Play/Pause. short press " ⏮ " or " ⏭ " button to be previous track or next track long press " ⏮ " or " ⏭ " button to increase or decrease the Volume.
PS: The memory size of USB devices which can be supported up to 32GB.

8. FM Radio

Short press ⏯/SCAN to search FM channels automatically. This operation will scan all FM stations and Pre-record them to memory. The scan procedure will take several minutes and cannot be interrupted. Once completed, short press "⏮" or "⏭" button to to previous channel or next channel.long press " ⏮ " or " ⏭ " button to increase or decrease the Volume.

9. RGB

There are three different RGB light modes. Short press " ☼ " button to switch between different RGB modes. The last used RGB light mode will be stored in the speaker memory before switching it off, and it will be restored once the speaker unit is powered on the following time. Long-press " ☼ "button can open/close the light.

10. TWS

Two the same model speakers can be connected to one wireless device at the same time. First, turn the speakers on, then choose one unit and long press its "M" button for several seconds; then you will hear the sound of "Ding~" to indicate that the two units have paired successfully. Please ensure before pairing that the two units are not connected with other devices.

11. Charging

Plug the USB cable into the speaker's charging port and connect to the power source. The RED LED indicator on panel will be lit when the unit is charging. When it full the RED LED light will close.

12. Led Light Statue

Statue	Blue light	Red light
Quick flashing	Searching blue-connect / FM SCAN	/
Slow flashing	Playing	/
Long bright	Pause / No music playing	Charging

13. Simple troubleshooting solutions

Trouble	Solutions
Low volume or distortion	1. Check the audio volume and adjust it to the right size 2. Battery low , need to be charged
Music discontinuity	1. There is an obstacle between the mobile device and the Bluetooth device. Please remove the obstacle. 2. Beyond the effective connection distance.
Pairing failure	1.Check if the phone is in the pairing state. 2.The speaker has been successfully paired with other equipment. Please disconnect the pairing with other equipment first. 3.Delete the original device name on your phone and re-pair.

This product has been manufactured and sold under the responsibility of MAXTALENT INDUSTRIAL Limited.

Thomson and the Thomson logo are trademarks used under license by MAXTALENT INDUSTRIAL Limited.

Further information at www.maxtdigital.com/THOMSON.

Any other product, service, company, trade or product name and logo referenced herein are the property of their respective owners.

Manufacture: Shenzhen Qiuyu Electronic Co.,Ltd
Website: www.maxtdigital.com/THOMSON
Support: service@maxtdigital.com
Made in China
V1.0

THOMSON

1.序文

プレーヤーの機能を十分に発揮させ、ご使用の前にこの取扱説明書を必ずお読みになり、本システムの接続方法や操作の要点をご確認ください。お客様のニーズに合わせて、設計、製造工程、使いやすさなど、さまざまな検討を行ってきました。

なお、お読みになられた後は、ご使用時にいつでも見られますよう大切に保管してください。

パッケージを開封し、以下の部品をよく確認し、紛失しないよう大切に保管してください。

2.付属品のリスト

ワイヤレススピーカーボックス*1 ユーザーのマヌア*1 充電ケーブル*1

3.スペシフィケイション

スピーカー：3インチ
インプットボルテージ：DC5V
アウトプットパワー：5W*2
サポート：ブルーコネクト、TF、USB、FM、TWSモード、RGBライトモード
バッテリー：内蔵の充電式1200mAhリチウムイオン
作動範囲：10M
周波数応答：80Hz-13KHz
ディストーション：10%
S/N比：80dB
マルチメディア入力：TF、USB
FM周波数範囲：87.5-108.0Mhz

4.部品の説明



1. スピーカーモードボタン（モデル：ブルーコネクト；モード2：FMモード；モード3：USB/TF）/TWSを接続するには長押しします
2. 再生/一時停止/スキャン（FMモードでの自動検索）/ボタンを長押しすると、ブルーコネクトを接続または切断できます
3. 前の曲/ボリューム-
4. 次の曲/ボリューム+
5. RGBライトモード/長押しすると、ライトを開閉できます
6. USBスロット
7. TF カードスロット
8. Mirco USB充電ポート（DC5V）
9. 充電LED
10.オフ/オン

5.ワイヤレススピーカーの接続方法

スピーカーユニットとモバイルまたはその他のデバイスの電源を入れ、ユニットのモデル名「G628」を検索して2つのデバイスをペアリングします。

この前にペアリングした場合には、電源が入っていれば、これら2つのデバイスは自動的に接続されます。

6.ワイヤレス

スピーカーの電源を入れると、ワイヤレスモードになり、デバイスをペアリングにすると、音楽が再生されます。「⏯」ボタンを短押しして再生/一時停止します。「⏮」または「⏭」ボタンを短押しして前の曲または次の曲になり、「⏮」または「⏭」ボタンを長押しして音量を増減します。

7. USB/TFカード

UフラッシュメモリまたはTFカードをUSB/TFスロットに挿入すると、スピーカーボックスがMP3形式の音楽を自動的に読み取ります。「⏯」ボタンを短押しして再生/一時停止します。「⏮」または「⏭」ボタンを短押しすと、前の曲または次の曲になり、「 ⏮ 」または「⏭」ボタンを長押しして音量を増減します。

PS：USBデバイスのメモリサイズは最大32GBまでサポートできます。

8. FMラジオ

⏯/SCANを短押ししてFMチャンネルが自動的に検索され、これにより、すべてのFMステーションがスキャンされ、メモリに予め記録されます。スキャンプロセスには数分かかり、中断することはできません。完了すると、「⏮」または「⏭」ボタンを短押しして前の曲または次の曲にし、「⏮」または「⏭」ボタンを長押しして音量を増減します。

9. RGBライトモード

RGBライトモードは3種類あり、「☼」ボタンを短く押して、異なるRGBモードを切り替えることができ、最後に使用したRGBライトモードは、電源を切る前にスピーカーメモリに保存され、次にスピーカーユニットをオンにすると復元されます。☼ボタンを長押しするとライトが開閉します。

10. TWS

2つの同じモデルのスピーカーを同時に1つのワイヤレスデバイスに接続することができ、まず、スピーカーの電源を入れてから、1つのユニットを選択し、その「モード」ボタンを数秒間長押しします。次に、「ジャン～」の音が聞こえ、2つのユニットが正常にペアリングされたことを示します。ペアリングする前に、2つのユニットが他のデバイスに接続されていないことを確認してください。

11.充電

USBケーブルをスピーカーの充電ポートに差し込み、電源に接続します。

ユニットが充電中にパネルのレッドLEDインジケータが点灯し、完全に充電になると、レッドLEDライトが閉じます。

12. LEDライトスタチュー

スタチュー	ブルーライト	レッドライト
クイックフラッシング	クイックフラッシング ブルーコネクトの検索/FM SCAN	/
スローフラッシング	プレー	/
ロングブライト	一時停止/音楽が再生されない	充電

13. 簡単なトラブルシューティングソリューション

トラブル	ソリューション
低音量またはディストーション	1. 音量を確認して適切に調整します 2. バッテリー残量が少なく、充電する必要があります
音楽の不連続性	1. モバイルデバイスとブルートゥースデバイスの間に障害物があり、障害物を取り除いてください。 2. 有効接続距離を超えています。
ペアリング失敗	1. 携帯電話がペアリング状態にあるかどうかを確認します。 2. スピーカーが他のデバイスとペアリングされ、他のデバイスとのペアリングを解除してください。 3. 携帯電話の元のデバイス名を削除し、再ペアリングします。

本製品は、MAXTALENTINDUSTRIALLimitedにより製造および販売されています。

ThomsonとThomsonロゴは、MAXTALENT INDUSTRIAL Limitedからのライセンスに基づき使用されています。

詳細については、www.maxtdigital.com/THOMSONをご覧ください。

ここで参照されるその他の製品、サービス、会社、商社、または製品名、ロゴは、すべてそれぞれの所有者の財産です。

メーカー：深セン秋雨電子株式会社
ウェブサイト：www.maxtdigital.com/THOMSON
サービスメールボックス：service@maxtdigital.com
Made in China
V1.0

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

•Reorient or relocate the receiving antenna.

•Increase the separation between the equipment and receiver.

•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

•Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and any part of your body.

添加FCC认证警示语

QYTM-G628六折页(风琴折)

160*110mm

Pantone Grey 432 C

Pantone 199C