WATERPROOF WIRELESS SHOWER SPEAKER

USER MANUAL

Model: 72XXX



Bluetooth®

Safety Instructions

Read this manual carefully before putting the speaker into use.

Keep the device away from heat, direct sunlight and sharp edges.

Do not insert any metal object into the device. Risk of short circuit!

To avoid a static charge, do not use the device in an extremely dry climate.

Do not repair the unit yourself but contact an authorized specialist.

Product Overview





Accessories Included

1 USB Charging Cable

Charging The Battery

This speaker is powered by rechargeable lithium battery. Charge the battery as follows:

1 Insert the charging cable into the DC SV socket on the unit. Connect the USB plug into a PC or AC /DC adapter. The LED indicator turns red and the battery is being charged.

2 When the battery is fully charged, the red LED indicator turns off.

Pairing Your Shower Speaker To Your Mobile Phone

1.Press on /off button

2.Turn on your Bluetooth on your cell phone and search for "SHOWER SPEAKER" and connect. Once connected you can enjoy streaming through your speaker.

Tips:

Please make sure the speaker is in power off mode When trying to activate the pairing mode.

1 Turn on your mobile phone and activate the Bluetooth function.

2 Search for devices: "SHOWER SPEAKER" will showup.

3 Pair your device with "SHOWER SPEAKER". If password is needed, type in"0000", After "SHOWER SPEAKER" is paired with your device, connect it to your device.

Tip:

Once this speaker is paired and connected to your mobile phone, and speaker is on, it will connect to your mobile phone automatically as long as the Bluetooth in your mobile phone is on

Button description

On/Off: To switch on or off the unit

Short press for the previous song.long press for turning down the volume.

Short press for the next song, long press for turning up the volume.

Phone: To pick up or hang up a phone call

Play/Pause the music

Notes & tips:

1. You can press Phone button twice quickly to redial the last phone number.

Troubleshooting

Problems	Reasons	Solutions
Can not switch the speaker on	Battery empty	Charge the battery
Unable to pair the speaker	Speaker is already switched on, and it is not in pairing mode.	Refer to the section of "Pairing Your Shower Speaker To Your Mobile Phone"

Technical Specifications

Support:	3.0+EDR
Range:	10 meters
Transmitting frequency:	2.4G Hz
Power supply:	DC5V/100-120mA
Battery:	3.7V 400mAh lithium
Charging time:	approx. 4 hours
Operating time:	approx. 2 hour
IP grade:	IPx4

IC Statement

This device complies with Industry Canada's license-exempt RSSs.
Operation is subject to the following two conditions:
(1) This device may not cause interference; and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.

The Bluetooth® word mark and logos are registered trademarks owned by the Bluetooth SIG, Inc. and any use of such marks by CJ Global is under license. Other trademarks and trade names are those of their respective owners.

Distributed by CJ Global Inc.
2010 Maple Ave Fair Lawn NJ 07410

All rights reserved.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver.

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions (1)this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

IC Statement

This device complies with Industry Canada' s licence-exempt RSSs. Operation is subject to the following two conditions:

(1) This device may not cause interference; and

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

The term "IC: " before the certification/registration number only signifies that the Industry Canada technical specifications were met. This product meets the applicable Industry Canada technical specifications.

Le pr é sent appareil est conforme aux CNR d'Industrie Canada applicable aux appareils radio exempts de licence. L'exploitation est autoris é e aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radio é lectrique subi, m ê me si le brouillage est susceptible d'en compromettre le fonctionnement