YD-4020

Home Pet™

Remote Dog Trainer User Manual

MODEL: YD-4020

PLEASE READ THIS ENTIRE GUIDE BEFORE BEGINNING

Important Safety Information

CAUTION Proper Collar use:

Remote Dog Trainers are used for teach your dogs to learn the association between it's behaviour and your correction.

Then, you'll have a better-behaved pet.

Manufacturer does not assume any liability for the improper use of a Remote Dog Trainer.

CAUTION Proper Fit:

Any improper fit can cause the contact points to rub the skin and cause irritation.

If the unit is too loose , the contact points will not make proper contact which in turn your dog will not receive consistent stimulation.

A collar worn for too long or too tight on the pet's neck may cause skin damage. For proper collar fit , please see page 8

Thank you for choosing Home Pet brand. After teaching and training, you will have a better-behaved pet.

Contents

Components included in this package-- 4

Digital Display on the Transmitter-------- 5

Remote Transmitter---------- 6

Receiver Collar---------- 7

To Turn the Receiver Collar On---------- 7-8

Fit the Receiver collar on your dog-------- 8

How to teach your pet the positive commands --- 8

How to correct your dog unwanted behaviour --- 9

Charging the Transmitter---------- 9

Charging the collar ---------- 9

Troubleshooting ---------- 10

Test Light Instructions ---------- 10

Components

Features

Range up to 400 yard depending on the way you hold the Remote Transmitter and other factors such as weather, transmission from other radio devices may affect the maximum range.

Digital Display

Digital Display

- Transmit the signal
- Indicate your battery's power level
- Indicate battery charging
- Indicate Dog I up to Dog 5 after add on additional collar and program collar for Dog number.

TONE •Tone 1-2-3-4-5 for positive command tones such as "sit", "Heel",etc.

SHOCK • Five Different shock level from mild to Intense gradually

Remote Transmitter

- Transmits the signal to the Receiver Collar.
- The Transmitter automatically turns ON and OFF after when you press any button,it may automatically turn on.It may automatically turn off transmitter after 30 seconds.

Receiver Collar

To Turn the Receiver Collar on

1. Power on: Press and hold the "on /off button"for 2 seconds till RED LED ON.
2. Power off: Press and hold the "on/off button" for 2 seconds till RED LED flash twice and then turn off.
3. Code: At factory, Receiver collar is coded with Dog 1. Additional Collar Code: With the collar powered OFF, press and hold on/off Button "till" ON/L BATT's RED LED light on. At the same time, press the associated "dog" number by "SET" key on the transmitter and press "Tone" key on the transmitter which generate a beep sound and "ON/L BATT's RED LED flash one time, This represent 2ND dog coding successful. For coding other dogs 3-5,it repeats the same process same as Dog 2.
4. After completion of code process, you may command the dog by pressing the associated "DOG" number on the transmitter. NOTE: you can reprogram the collar at any time fora different dog number.

Fit the Receiver Collar on you Dog

The collar should be fitted properly so that the contact points press firmly against the dog's skin. To assure a proper fit, you should be able to fit a finger in between the contact points and your dog's skin see picture B center the contacts Points underneath your dog's neck, see picture A.

CATION

If the collar is fitted loosely, the collar may move around the dog's neck, resulting inconsistent stimulus .If the collar is too tight, the contact points may rub the skin and cause irritation or infection.

Mark the desired length of the belt of the collar and reserve some length for the growth of young pet, then, cut off the excess and use lighter to trim the collar, see picture C.



How to teach your Pet the positive commands

Before using Remote Dog Trainer. to correct your pet, it need to spend 15 minutes for first 2 or 3 dogs to tench your dog to create association of the tone with reward. Then , your dog will soon associate each positive tone with the command . you wish For example, you assign Tone 1 to the "come", once you press this Tone 1,it will command your dog to "come" for another 5 positive Tones, you may repeat the same process to teach your dog to recognize your command.

How to correct your Dog unwanted Behavio

When your dog is doing bad behaviour such as digging ,your may press STIM key as negative command to teach dog to stop it .

If your dog keeps on this unwanted behaviour, you may activate shock level 1 for a short time (about ½ second). If shock level 1 cannot cause your dog to stop the undesirable behaviour , you may progress to more intense shock levels 2-5.The Remote Dog Trainers have 5 different shock levels to allow you to choose the best for your pet.

Charging the Transmitter

When the battery is low, symbol will flash Charging process:

1. Remove the rubber protector over the Dc charging port and insert DC plug of the cable in to the charging port.
2. When charging is completed, symbol will light on .
3. Place the rubber protector back over the Dc Charging Port.

Charging the Collar

When the battery is low, the "L. BATT LED" light on,Charging Process:

1. Remove the rubber protector, over the Dc charging port and insert Dc plug of the cable into the charging port, The "CHG LED" light on.
2. When charging is completed, "CHG LED" light turns off.

NOTE: charging cable is Dc Plug at one end and th other end is USB connected to all USB chargers.

Trouble shooting

My dog is not responding to the collar

- Check whether the Collar has been turned ON and make sure to have programming your collar properly.
- Make sure the collar strap to be tight enough so both contact points are touching the dog's skin.
- If your dog's coat is un us ally long or thick, yor may need to trim down the hair on the dog's neck, so both contact points are touching the skin.
- The battery may be low. Check for Low Battery LED and recharge if necessary.

The transmitter has no range,or stimulation is less when the dog is farther away.

- Make sure your fingers are not touching the antenna as this may cause the range to substantially decrease.
- Maximum range for any radio frequency device occurs with flat terrain. Heavy brush, trees, hills or moisture will affect the range of your unit. For best range, hold the transmitter verti-cally above your head, and/or by moving to higher ground.
- Large metal structures will affect the range, such as cars, chain-link dog runs, metal buildings, and radio towers. For best results, operate away from these structures.

My unit is not holding a charge.

- Check to make sure the metal pin inside the charging port is straight and firm in the center and that the pin is not wobbly, broken or missing.
- Make sure there is no dirt or debris is the charging port. if there is ,clean the dirt out with a cotton swab and some rubbing alcohol.

Test Light Instructions

1. Turn the Receiver Collar on .
2. Hold the Test Light Contacts to the Contact Points.
3. Press a Stimulation button on the Remote Transmitter.
4. The Test Light will flash. Note: At higher Stimulation Levels, the Test Light will flash brighter.
5. Turn the Receiver Collar off.

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a **Class B** digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

RF Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.