Ordec

User Manual
Ture Wireless Earbuds

Model: OD-E1

Changchun Changji Technology Co., LTD.
www.orderdeal.com | sales@orderdeallock.com
No. 1-1-1, Xiyuan Road, Jiutai District,
Qasar District, Changchun, Jilin, 130000, P.R. China
EC REP: EPCOS OHG

CE RoHS WEEE

Contents

English ---------- 01 ~ 13
Italiano ---------- 14 ~ 30

Thank you for purchasing the Ordec OD-E1 Ture Wireless Earbuds. Please read this user manual carefully and keep it for future reference. If you need any assistance, please contact our support team with your product model number and your Amazon order number.

Package Contents

- Ture Wireless Earbuds
- Charging Case
- Type-C Cable
- User Manual

Product Diagram

Specifications

Earbuds

Model	OD-E1
Technology	V5.3, AAC, aptX, aptX HD, aptX LL, aptX TWS+, aptX Adaptive
Frequency Response	20Hz-20KHz
Sensitivity	96.5dB SPL at 1kHz(1mW)
Operating Frequency	2.402-2.480GHz
Impedance	32 ohm ±10%
Microphone Type	MEMS Omnidirectional x2Pcs
Microphone Sensitivity	-38dB ±2dB (0dB=1V/Pa, 1KHz)
Microphone Frequency Range	100Hz - 8KHz
Output Power	0.5mW (Max)
Channel Mode	Dual Mono
Battery Type	3.7V 40mAh x2 (Earbuds)
Working Time	Up to 4 hours
Weight	5g / 0.17oz

Charging Case

Charging Input	DC 5V
Charging Current	500mA (Max)
Battery Type	3.7V 1000mAh (480mAh)
Number of earbuds recharge	1 (Approx.)
Weight	47.5g / 1.67oz

Getting Started

Charging

Place the Ture charging case before first use. To charge, connect the case to a USB Charger or charging port with the included USB-C cable. When the LED charging indicator turns ON, the case is fully charged. Charging takes approximately 1 hour. The earbuds can be charged in the case when not in use. Earbuds 5 times. The earbuds should be stored in the case when not in use. When the earbuds are charging in the case (with the case itself not charging), the charging indicator will flash green (with solid red). When the indicator turns off, the earbuds are fully charged.

Pairing

Pairing with the earbuds in the case:

1. Take the left and right earbuds out of the case. They will turn on automatically and enter pairing mode. Pairing lasts for 3 minutes.
2. After the earbuds have connected successfully, the LED indicator on the earbuds will flash blue and red. This indicates they are ready to pair.
3. Turn on the pairing function on the device you want to pair with the earbuds.
4. From the list of available devices, find and select "OD-E1".
5. If a code or PIN is requested for pairing, enter "0000".

Regular Use After Pairing

Once the earbuds are successfully paired with your device, they can be switched on and off as follows:

- Take the earbuds out from the charging case and they will turn on automatically.
- To power off, put the earbuds back into the charging case and they will automatically turn off.

Using the Left Right Earbud Only

Pairing with single earbuds in the case:

1. Take the left/right earbud out
2. Turn on the pairing function on the device you want to pair with the earbud
3. From the list of available devices, find and select "OD-E1"

Notes:

- When you turn on the earbuds, they will automatically reconnect to the last paired device or enter pairing mode if no paired device is found.
- If the earbuds are not connected to a device within 3 minutes of being turned on, they will hold the touch sensitive panel on both earbuds for 10 seconds.
- In pairing mode, the earbuds will automatically turn off after 5 minutes if no connection is made.
- If one of the earbuds has no sound output, put both earbuds back into the charging case and take them out again.
- The maximum wireless operating range is 10m (33ft). If you exceed this range, the connection will be lost and the earbuds will enter pairing mode. The connection will be re-established if you re-enter the wireless range within 3 minutes. The earbuds will automatically reconnect to the last paired device. To connect with other devices, enter the previous pairing steps.

Controls & LED Indicators

Dismissing Audio

Dismiss incoming calls or wireless stream audio from your device to the earbuds. Music will automatically pause when you receive an incoming phone call and resume once the call has ended.

Single tap on either earbud	Hold the touch sensitive panel on either earbud
Tap on other voice assistant	Long press the left earbud for 2 seconds

LED Status Indicator (Earbuds)	Status
Flashing blue and red	Pairing mode
Solid blue	Connected
Solid red	Charging
Off (after charging)	Fully charged

Taking Calls

Answer an end a call	Double-tap either earbud to answer an end a call. Hold the touch sensitive panel on either earbud for 1 second to answer the second call and hold the touch sensitive panel on both earbuds for 2 seconds
Reject an incoming call	Long press either earbud for 2 seconds
Switch between two calls	Long press on either earbud for 2 seconds. Hold the touch sensitive panel on both earbuds for 2 seconds to reject the second call
Mute/unmute a call	Long press either earbud for 2 seconds
Siri/Google Assistant	Long press on either earbud for 2 seconds. Hold the touch sensitive panel on both earbuds for 2 seconds

FAQ

The earbuds are on, but not connecting to my device

If the earbuds are on but not connecting to your device, you need to put them back in pairing mode. Please follow the instructions in the Pairing section of the manual.

I've connected the earbuds with my smartphone but can't hear any sound

Double-check the volume level on your smartphone and the earbuds. Some smartphones require you to set up the earbuds as an audio output device before they can stream audio. Please refer to the user manual, news, answer or other device pieces make sure it supports the A2DP profile.

The sound isn't very clear or the caller can't hear my voice clearly

Adjust the volume on your smartphone and the earbuds. Try moving closer to your smartphone to rule out the possibility of interference or wireless range-related issues.

FAQ

What's the wireless range of the earbuds?

The maximum range is 10m (33ft). However, the actual range depends on environmental factors. For optimal performance, keep your device connected within 5m (16ft) of the earbuds. Exceeding this range may result in audio delays, disconnections and reduced audio between the earbuds and your device.

The earbuds won't turn on

Try charging the earbuds for a while. If the earbuds still won't power on, please contact our support team at the email address given in Warranty & Customer Support.

Can I use earbuds back in the charging case, but the earbuds are still connected

In this case, the charging case is likely to be out of power. You will need to charge the case.

Product Care & Use

- Keep away from liquids and extreme heat
- If you don't plan to use the earbuds for an extended period, do this may cause permanent hearing damage or loss.

Warranty & Customer Support

For warranty information, please refer to the section on at the address below that corresponds with your region. Please include your Amazon order number and product model number.

Amazon US orders: sales@orderdeallock.com
Amazon EU orders: sales@orderdeallock.com
Amazon CA orders: sales@orderdeallock.com

*Please note, Ordec is not an authorized distributor on Amazon and cannot fulfill orders. If you have purchased OD-E1 earbuds from Amazon, please contact our support team to process a warranty claim.

CE Statement

Max RF power: 5mW
Frequency Range: 2.402GHz - 2.480GHz
RF exposure assessment has been performed to prove that this unit will not generate the Harmful EM emission above the reference level as specified in EC Council Recommendation (1999/519/EC).

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Excessive sound pressure from earphones and headphones can cause hearing loss.

Hereby, our company declares that this radio equipment type (Ture Wireless Earbuds, OD-E1) is in compliance with Directive (EU) 2015/2053.

Notice: This device may be used in each member state of the EU.

Grazie per aver acquistato gli auricolari Ordec OD-E1 Ture Wireless. Si prega di leggere attentamente il presente manuale d'uso e di conservarlo per riferimenti futuri. Se ci fosse bisogno di assistenza, è possibile contattare il nostro team di supporto comunicando il numero di modello del prodotto e il numero d'ordine Amazon.

Contenuto della confezione

- Auricolari Ture Wireless
- Cassa di ricarica
- Cavo Type-C
- Manuale utente

Schema del prodotto

Specifiche

Auricolari

Modello	OD-E1
Tecnologia	V5.3, AAC, aptX, aptX HD, aptX LL, aptX TWS+, aptX Adaptive
Risposta Frequenza	20Hz-20KHz
Sensibilità	96.5dB SPL (a 1kHz(1mW))
Frequenza Operativa	2.402-2.480GHz
Impedenza	32 ohm ±10%
Tipo di microfono	MEMS Omnidirezionale x2Pcs
Sensibilità del microfono	-38dB ±2dB (0dB=1V/Pa, 1KHz)
Gamma di Frequenza Microfono	100Hz - 8KHz
Potenza di Uscita	0.5mW (Max)
Modalità della batteria	Mono x 2 pcs
Batteria	3.7V 40mAh x2 (Auricolari)
Tempo di funzionamento	Fino a 4 ore
Peso	5g

Cassa di ricarica

Ingresso di ricarica	DC 5V
Corrente di ricarica	500mA (Max)
Tipo di batteria	3.7V 1000mAh (480mAh)
Numero di ricariche degli auricolari	1 volta (circa)
Peso	47.5g

Per Iniziare

Ricarica

Caricare completamente il case di ricarica prima del primo utilizzo. Per la ricarica, collegare il case a un caricatore USB o a una porta di ricarica con il cavo ricarica con il cavo USB-C in dotazione. Quando l'indicatore di carica a LED si spegne, il case è completamente carico. La ricarica richiede circa 2 ore. e. dopo essere stato completamente caricato. Le cuffiette può ricaricare 5 volte. Le cuffiette devono essere conservate nel case quando non vengono utilizzate. Quando gli auricolari sono in carica nel case (con il case stesso non in carica), gli indicatori LED sugli auricolari diventeranno rosso fisso. Quando gli indicatori si spengono, gli auricolari sono completamente caricati.

Accoppiamento

Inizione con gli auricolari nel case:

1. Togliere l'auricolare sinistro e destro dalla custodia. Si accenderanno automaticamente e entreranno in modalità di accoppiamento. Durata 3 minuti.
2. Dopo che gli auricolari si sono collegati con successo, gli indicatori LED sugli auricolari lampeggeranno in blu e rosso. Questo indica che sono pronti per essere accoppiati.
3. Attivare la funzione di accoppiamento sul dispositivo che si desidera accoppiare con gli auricolari.
4. Dall'elenco degli dispositivi disponibili, trovare e selezionare "OD-E1".
5. Se per l'accoppiamento è necessario un codice o un PIN, inserire "0000".

Uso regolare dopo l'accoppiamento

Una volta che gli auricolari sono stati accoppiati con successo, si disattivano, possono essere accesi e spenti come seguo:

- Prendere le cuffiette dal case e si accenderanno automaticamente
- Per spegnerle, riponete gli auricolari nel case di ricarica e si spegneranno in automatico

Usare solo l'auricolare destro/sinistro

Inizione con gli auricolari nel case:

1. Rimuovere l'auricolare sinistro/destro.
2. Attivare la funzione di accoppiamento sul dispositivo che si desidera accoppiare con l'auricolare.
3. Dall'elenco degli apparecchi disponibili, trovare e selezionare "OD-E1".

Note

- Quando si accendono gli auricolari, questi si ricollegano automaticamente all'ultimo dispositivo cui sappiamo a entrarno in modalità di accoppiamento se non è stato trovato alcun dispositivo.
- Per cancellare l'elenco degli accoppiamenti, rimuovete ambedue gli auricolari dal case di ricarica e tenete premuto il pannello sensibile al tocco su entrambe le cuffiette per 10 secondi.
- In modalità di accoppiamento, gli auricolari si spengono automaticamente dopo 5 minuti se non viene collegato nessun dispositivo.
- Se uno degli auricolari non ha suono, mettete ambedue gli auricolari nel case di ricarica e togliete di nuovo.
- La portata di funzionamento senza fili è di 10m. Se si supera questo limite, la connessione si interromperà e le cuffiette entreranno in modalità di accoppiamento. Se si rientra nel raggio d'azione entro 3 minuti, la connessione si ripristinerà. Le cuffiette si riconnetteranno automaticamente all'ultimo dispositivo. Per il collegamento con altri dispositivi, fare riferimento alle fasi di accoppiamento precedenti.

Controlli e Indicatori LED

Audio in dissenso

Una volta accoppiato, è possibile trasmettere in modalità wireless l'audio in dissenso dal dispositivo agli auricolari. Quando si riceve una chiamata in ingresso, la musica si metterà automaticamente in pausa e riprenderà dopo la chiamata.

Tap qualsiasi	Tocca due volte sul pannello sensibile al tocco su uno dei due auricolari
Passare alla tracca successiva	Tenere premuto il pulsante destro per 2 secondi
Passare alla traccia precedente	Tenere premuto il pulsante sinistro per 2 secondi

Effettuare chiamate

Rispondere o terminare una chiamata	Tocca due volte l'auricolare per rispondere o per terminare una chiamata. Tieni premuto il pulsante sensibile al tocco per 1 secondo per rispondere alla seconda chiamata. Il pulsante sensibile al tocco su entrambe le cuffiette per 2 secondi per rifiutare la seconda chiamata
Rifiutare una chiamata in arrivo	Tenere premuto uno dei due auricolari per 2 secondi
Passare da una chiamata a l'altra	Tenere premuto uno dei due auricolari per 2 secondi
Silenziare/Riattivare una chiamata	Tenere premuto uno dei due auricolari per 2 secondi
Siri/Assistente Google	Tenere premuto uno dei due auricolari per 2 secondi. Tieni il pulsante sensibile al tocco su entrambe le cuffiette per 2 secondi

Indicatore di stato a LED (auricolari)	Stato
Blu e rosso lampeggiante	Modalità accoppiamento
Blu fisso	Connesso
Rosso fisso	Ricarica
Off (dopo la ricarica)	Carico completato

FAQ

Gli auricolari sono accesi ma non si collegano al mio dispositivo

Per riattivare una connessione tra gli auricolari e il dispositivo, è necessario riportarli in modalità accoppiamento. Si prega di seguire le istruzioni nella sezione Accoppiamento del manuale d'uso.

Ho abbinato una connessione con lo smartphone ma non si sente alcun suono

Controllate il livello del volume sul vostro smartphone e sugli auricolari. Alcuni smartphone richiedono l'installazione degli auricolari come dispositivo con uscita audio prima di trasmettere l'audio. Se si è in difficoltà, un telefono inviato a un altro dispositivo, assicurarsi che questo supporti il profilo A2DP per il migliore invio/ricevere.

FAQ

Il suono non è molto chiaro o la persona che chiama non riesce a sentire chiaramente la mia voce

Aumentare il volume sul vostro smartphone che sugli auricolari. Provate ad avvicinarvi al vostro smartphone per escludere la possibilità di interferenze o problema legato al raggio di funzionamento delle modalità wireless.

Qual è la portata wireless degli auricolari?

La portata massima è di 10m. Tuttavia, la portata effettiva dipenderà anche da fattori ambientali. Per delle performance ottimali, mantenete il proprio dispositivo entro 5m (16ft) dagli auricolari. Superare questa portata può causare ritardi nell'audio, disconnessioni e ridotta qualità audio tra gli auricolari e il dispositivo.

I miei auricolari non si accendono

Provate a tenere sotto carica gli auricolari. Se gli auricolari non si accendono, contattate l'assistenza all'indirizzo riportato di seguito.

Ho smaltito gli auricolari nel case di ricarica, ma gli auricolari sono ancora collegati

In questo caso, il probabile che il case di ricarica sia scarico. Sarà necessario ricaricarlo.

Dichiarazione CE

Livello di potenza radio:
RF massima EIRP: 5mW
Gamma di frequenza: 2.402GHz - 2.480GHz
RF esposizione valutazioni hanno dimostrato che questo dispositivo non supera il livello di elementi elettromagnetici di radiofrequenza (RF) raccomandato dal consiglio EC (1999/519/EC).

ATTENZIONE RISCHIO DI ESPLOSIONE SE LA BATTERIA VIENE SOSTITUITA CON UNA DI TIPO ERRATO. SMALTIRE LE BATTERIE USATE SECONDO LE ISTRUZIONI.

Un'eccessiva pressione sonora proveniente da cuffie e auricolari può causare una perdita dell'udito.

Ti pregio di notare che Ordec può offrire solo il servizio di post-vendita per i prodotti acquistati direttamente da Ordec.

Hereby, Ordec declares that this radio equipment type (Ture Wireless Earbuds, OD-E1) is in compliance with Directive (EU) 2015/2053.

NOTE: Il dispositivo può essere utilizzato in ogni stato membro della UE.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.