
英文做封面

100.00 mm

100.00 mm

USER MANUAL

SMC-PAD POCKET



I. Packing list

- SMC-PAD POCKET
- USB-C Charging Cable
- User manual

II. Type of Connection

■ USB Connection (Plug the cable through the USB port to the Windows/Mac to will succeed to be recognized. When (■) is in charging state, the LED (■) is in charging at the same time.)

Red light: charging, Green light: charging complete.

■ Wireless Connection

1.Turn on the BT (■) Connector

software from the official website

(Search for "SMC-Pad01")


2.Open Audio (■) Setup.

3.Click the BT Icon.

4.Wait for BT name to connect the device.

If the connection unsuccessful, check the steps Connection Methods.

■ Wireless Adapter (Plug Wireless Adapter & into Windows/Mac, connection was successful, the LED (■) stay on.



Note: Wireless Adapter A and B are not within the package need to buy additionally.

Low Battery Indicator: When the device has less than power, Pad 16 will flash.

III. Panel Overview



① Back of device

Switch : Turn on/off the device

Power Indicator : Pre-Industry light illuminates red ■ charging and turn green when fully charged.

USB-C Port : USB connection and charging at the same time.

② Pads

Screen Pad1 back-16 pads + sh-

Pad1 Screen Pad 2 Pad 3 Pad 4

Pad 5 Pad 6 Pad 7 Pad 8

Pad 9 Pad 10 Pad 11 Pad 12

Pad 13 Pad 14 Pad 15 Pad 16

③ Control Mapping

Control Mapping : Switch to specific pads using the ■ Suite software (PC/Mac, cable connection) or ■ Suite app (iOS/Android, wireless connection). Save your custom mappings as presets for quick access. Available controls include:

1.Note Repeat: Trigger notes repeatedly based on Note and Tempo settings

2.Note Adjustment: Increase/Decrease

3.Octave Adjustment: ■ Increase/decrease

4.Bank Function (Next/Previous)

5.Latch

III. Panel Overview

Presets select: 1+6 :

Holding Presets 1 + 6 then then turn on the device will step into the corresponding pad.

Presets 1 pad map to 16 audio fpc drums.

Presets 2 pin map to garage band drums.

Presets 6 pin defined the Pads 1+16 to use as control button :

Pad1 Screen Pad 2 Pad 3 Pad 4

Pad 5 Pad 6 Pad 7 Pad 8

Pad 9 Pad 10 Pad 11 Pad 12

Pad 13 Pad 14 Pad 15 Pad 16

② Control Mapping

Control Mapping : Switch to specific pads using the ■ Suite software (PC/Mac, cable connection) or ■ Suite app (iOS/Android, wireless connection). Save your custom mappings as presets for quick access. Available controls include:

1.Note Repeat: Trigger notes repeatedly based on Note and Tempo settings

2.Note Adjustment: Increase/Decrease

3.Octave Adjustment: ■ Increase/decrease

4.Bank Function (Next/Previous)

5.Latch

IV. Software Parameters Introduction


The following content is the introduction to the ■ Suite software for Windows/Mac. Download the software from the website to change the parameters of the SMC-Pad Pocket.



- Time: Adjust note repeat rate relative to tempo (1/4 to 1/32t)
- Tempo: Set the base pace (in bpm (BPM)) for note repeat.
- Swing: Apply rhythmic variation to repeated notes (0%–100%)
- Sync: Synchronize with external ■ clock sources (via DAW software

To enable the sync function, assign the ■ last part of the device in your DAW's preferences settings.

- Latch: Enable or disable note repeat after pad release



IV. Software Parameters Introduction

Pad Modes:

Switch between Note mode (default) and Control mode in Control mode, pads function as assignable buttons rather than note triggers.



Control Types:

- **Note:** Send standard ■ note messages
- **CC Toggle:** Toggle between two CC values with each press
- **Momentary:** Send one CC value on press, another on release
- **Program Change:** Send ■ program change messages
- **Custom Type:** Send fixed System Exclusive (SysEx) messages

Channel: Assign ■ channels to individual pads/zones

- **Relay:** Customize the ■ relay for each pad
- **Model:** Set the minimum velocity threshold for pad triggering
- **Polyphony:** Set the maximum number of pads for overlapping
- **Color:** Assign custom colors to pads for visual organization

IV. Software Parameters Introduction



- **Pad Curve:** Adjust the velocity response curve for all pads. When set to 5, it represents full velocity.
- **Pad Bank:** Access 7 banks of 16 pads each, providing 112 unique ■ notes.
- **Aftertouch:** Enable/disable pressure sensitivity for expressive control.

V. Technology Parameters

Product Dimensions	140mm(L) x 100mm(W) (Selected)
Product Weight	130g
Pads	16 RGB Backlit Pads with Velocity-sensitive and Pressure Touch
Buttons	4 Function Buttons
Power	Battery supported or USB-C bus-powered
Battery Model Number	503450
Battery Nominal Voltage	3.7V
Battery capacity	1150mAh

VI. FCC Warning Statement

- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a ■ Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular ■ installation. If this equipment does cause harmful interference to radio or ■ television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

— Reorient or relocate the receiving antenna.

— Increase the separation between the equipment and receiver.

— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

— Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1)This device may not cause harmful interference.

(2)This device must accept any interference received, including interference that may cause undesired operation.

VII. Connection Method

Our device is a ■ plug-and-play device, which means when using a USB cable, it won't need any driver. Software that supports ■ ■ will automatically recognize the device.

Windows for Windows. Download and install the BT ■ ■ Connector from the QR code below to use our devices with both (Requires Windows 10 or later).

Windows for Mac:

1.Open the Audio ■ ■ Setup.

2.Click ■ ■ Device.

3.Click the BT Icon.

4.Find the device and click "Connect".

Windows for iOS/Android: For iOS/Android devices, it requires software that supports BLE ■ ■. Connect the SMC-Pad Pocket within software like GarageBand, FL Studio Mobile, or Cubasis LE.



Web suite for windows



Web suite for mac



BT Midi Connector

中文

一. 连接连接

■ SMC-PAD POCKET.

■ USB-C连接线.

■ 用户指南.

二. 连接连接

■ USB连接: 将电缆插入USB端口连接到 Windows/Mac.

连接后将成功识别。连接时，SMC-PAD将指示进行充电。

（红灯：正在充电，绿灯：充电完成）

■ 无线连接:

Windows的话:

1.点击下面的下载BT ■ ■ Connector软件 (从官方网站下载)

2.打开音频 ■ ■ 设置。

3.点击BT图标 ■ ■ 。

4.等待设备 ■ ■ 下载。

5.将BT名称连接到设备。

按下这些连接连接的步骤，确保建"**连接方法**"**步骤。**

■ 无线适配器: 将无线适配器插入 Windows/Mac.

各电池将连接时成功表示连接成功。

■ ■ USB-C to C连接线.

无线连接：使用无线适配器 A 和 B 的包装 **将无线适配器连接到 ■ ■ 的步骤**

（注意：如果连接了无线适配器 A 和 B，则不需要单独购买适配器）

注意：当您的键盘 A 和 B 不在包装内时，需要单独购买。

电量指示灯：当设备电量不足时，PAD 16 将开始闪烁。

三. 功能介绍



① 设备背面

开关：打开/关闭设备

电量指示灯：充电时亮红灯，充满时亮绿灯。

USB-C端口：用于有线连接和同时充电

② 灯光面板 (Pads)

16 个带有RGB背光的打击垫，具有力度感应和 Polyphonic Aftertouch（压后触控）功能。



③ 灯光映射

灯光映射：允许您将预设的灯光垫，然后将其保存为自定义预设。可用的控制包括：

1.音符重复：根据音符设置和速度触发音符

2.音符调整：增加/减少

3.八度调整：增加/减少

4.Bank功能（下一个/上一个）

5.锁存

三. 功能介绍

创建新的 ■ ■ 预设并保存为自定义预设。可用的控制包括：



① 设备背面

开关：打开/关闭设备

电量指示灯：充电时亮红灯，充满时亮绿灯。

USB-C端口：用于有线连接和同时充电

② 灯光面板 (Pads)

16 个带有RGB背光的打击垫，具有力度感应和 Polyphonic Aftertouch（压后触控）功能。

③ 灯光映射

灯光映射：允许您将预设的灯光垫，然后将其保存为自定义预设。可用的控制包括：

1.音符重复：根据音符设置和速度触发音符

2.音符调整：增加/减少

3.八度调整：增加/减少

4.Bank功能（下一个/上一个）

5.锁存

四. 软件参数介绍

以下内容将介绍 ■ Suite软件（适用于Windows/Mac）的功能，以调整下载的软件预设参数 SMC-Pad Pocket的参数。



- **速率（Rate）**：控制音符重复的速率（1/4 至 1/32）
- **节奏（Tempo）**：为音符重复设置每分钟节拍（BPM）
- **摇摆（Swing）**：为重复的音符引入节奏变化（0%–100%）
- **同步（Sync）**：与外部时钟（如DAW软件）同步

要启用同步功能，请在DAW的偏好设置中将设备的 ■ ■ 最后一部分。

- **锁定（Latch）**：在松开垫后启用或禁用音符重复



四. 软件参数介绍

可选择模式：

在音符模式（默认）和控制模式之间切换。在控制模式下，触垫起到按下并释放的按钮，而不是音符触发器。



按触类型：

- **■ ■ (Note)**：发送标准 ■ ■ 音符信号
- **CC 切换（CC Toggle）**：每次按下时在两个CC值之间切换
- **瞬时（Momentary）**：按下时发送一个CC值，释放时发送另一个
- **程序更改（Program Change）**：发送 ■ ■ 程序更改信息
- **自定义（■ ■ 发送固定的 System Exclusive）消息**

通道（Channel）：为单个垫板指定 ■ ■ 通道

速率（Rate）：调整力度响应曲线 ■ ■ 垫板。

最大力度（Velocity）：设置触发垫板所需的最小力度阈值

最大力度（Velocity）：设置触发垫板所需的最小力度阈值

颜色（Color）：为垫板指定颜色以实现视

五. 软件参数介绍



- **力度曲线调整（Pad Curve）**：调整所有打击垫的力度响应曲线（在调整到5时，打击垫感受力度为满力度（即 ■ ■ 最大值））。
- **打击垫组（Pad Bank）**：访问7组16打击垫，提供112个独特 ■ ■ 音符
- **触后（Aftertouch）**：启用/禁用压感控制

五. 技术参数

产品尺寸	140mm(L) x 100mm(W) (如下图所示)
产品重量	130g
垫板	16个带有速度响应和压感响应的RGB背光垫板
按钮	4个功能按钮
电源	可使用电池或通过USB-C总线供电
电池型号	503450
电池标称电压	3.7V
电池额定容量	1150mAh
接口	USB-C to C

六. 连接指南

我们的设备是一个 ■ ■ 即插即用设备，这意味着使用USB电缆时，不需要任何驱动程序。支持 ■ ■ 的软件将自动识别该设备。

Windows电脑用户：从下列的二维码下载并安装BT ■ ■ Connector，以连接方式连接我们的设备（要求Windows 10或更高版本）。

Mac电脑连接：

1.打开音频 ■ ■ 设置

2.打开 ■ ■ 工作区

3.点击BT图标

4.查找设备并点击"连接"

iOS/Android连接指南：对于iOS/Android设备，它需要支持BLE ■ ■ 的软件。在GarageBand、FL Studio Mobile或Cubasis LE等软件中连接SMC-Pad Pocket。



Web suite for windows

Web suite for mac

BT Midi Connector

SMC-PAD POCKET打击垫 - 中英文说明书					备注
版本	V01	比例	1:1	日期	2024-10-23
排版	关关	印刷	黑白双面印刷	尺寸	折后:100x100mm
材质	书纸80克	工艺	骑马钉		
审核	赵文			公司	珠海笙科智能科技有限公司