USERMANUAL

Display information



M functions

- Press
- Press and hold

1) Press the M button to switch among System time/Timer/Thermostat, 3 main windows
2) Press and hold the M button under certain program slot initiate a new program on the slot.

M functions

- Press
- Press and hold

1) Choose the 1,2,3,4 slot press to turn on/off the slot.

2) Under programming status, press the OK button to confirm and process

3) Press and hold OK button will change the HEAT/COOL mode under manual temp mode

●-● functions

- Press
- Press and hold

1) Choose the program slots

2) Press button increase or decrease the digit in programming and setting mode, press and hold -/+ to fast increase/decrease.

Pair to socket

STEP1
Press and hold the - and + button for 3 secs to activate the remote control pairing mode. The icon CONNECT flashes indicating the remote is in pairing mode

STEP2
Press and hold the button for 3 secs, the LED will turn to flashing RED, indicate the socket is under pairing mode.

STEP3
Wait for seconds, the red LED on socket will stop flashing, the icon CONNECT on remote stays on indicating the socket and remote is paired

Features

The OTS200 got powerful programming ability to deal with various timer and temperature demand

Features:

- Advanced timer and thermostat control capability
- Wireless auto pairing 2.4Mhz control system
- Timer control with preset weekly, weekday, weekend and each day windows
- Each preset can programmed for individual needs for start and stop times
- Each preset can programmed for individual needs for temperature start and stop times
- Each programmable program can be applied individually Sunday through Saturday.
- 4 timer programs and 4 thermostat programs available, 8 programs can run at the same time.
- Easy to view auto shut down LED backlit LCD screen
- Detail icons indicate the setting and programming steps.
- 12 and 24 hours setting for time
- C-Celsius and F Fahrenheit
- DST- Daylight saving time selection, saves resetting all the programs.
- Low battery alert image, appears when the battery should be replaced.
- Operating Manual easy to follow step by step set up detail using product imaging guide.
- Memory function for easy recall and viewing of the preset programs.
- Safety protection built in with fl own relay control for overload protection and also its own fuse protection
- Socket is PC material and is fire retardant.

Quick Start(manual override)

Press the OK button to roll switch between
- manual temp setting
- stay ON
- stay OFF

* NOTE:
1) Manual operation above will override all slot programs, and set all running slots into "OFF" status.
Vice verse, turning on slots program will erase all manual setting.
2) Manual operation will features in the switch "ON/OFF" icons stay ON while slot program will feature in the "ON/OFF" icons flashing.

Quick Start(manual override)

Under manual temp setting mode press and hold OK button to switch between HEAT and COOL mode, press -/+ to set target temperature.

press and holds to witch between HEAT and COOL mode

Manually temp setting by -/+ button
2 seconds later,execute the settled temp.



Quick Start(program status)

Activate either of the slots program will erase the manual setting, and execute the slot program(s).



PROGRAMMED TIMER IS RUNNING

PROGRAMMED THERMOSTAT MODE IS RUNNING

Setting Process — Set system time

In system interface

select 12/24hr using -/+ button

set day/hour/minute

set DST on/off

set temperature display format

finish and return

Process — Set timer

In timer interface

choose the slot to be programmed

To program the start time you want, choose from the 4 preset modes: Full, Weekday, Weekend, and Weekly multiple days.

program hour/minute

program the end time(ET), next day will follow the ST day

program hour/minute

Note — Set timer

Something you should know on Start time ST and End time ET

Weekly day select means you can program the timer in routine daily ON/OFF operation on devices, or an ON/OFF operation from one specific day to another.

Routine daily operation,most use friendly

In the circumstance you choose 3 types of day modes above in the ST programming, the ET will follow the selected ST day.
the switch will be powered on/off base the time you programmed for your every routine.

Specific day operation

If you choose a specific day in a week as ST, then you can choose any day as ET. the switch will be turned ON/OFF base on the specific ST day and time to ET day and time in a range of one week, and the program will repeat every week.

Process full week — Set thermostat

In thermostat interface

choose the slot to be programmed



Choose heat mode or cool mode

Set target temperature

press -/+ choose time range, choose FULL

Process Period(Prd) — Set thermostat

In thermostat interface

choose the slot to be programmed



set day/hour/minute follow the setting process in timer

set day/hour/minute, follow the setting process in timer

Period(Prd) temperature program

Allow the user program overlapping days of the week in specific working days or hours the temperature or time ON/OFF.
Example one setting from Monday to Thursday or Sunday to Wednesday

Full week temperature program

The programmed thermostat temperature is activated on a continuous basis everyday of the week.

Display slot info.

Users can view their programmed time or temperature by selecting the slot in TIMER mode and THERMOSTAT mode, user are allow to close or open the slot easily.

Step1: Go the timer or thermostat mode

Step2: Select the target slot you want to view, the programmed start time and end time will scroll in 1 second and repeat, all other information is displayed as well.

Step3: press the OK button to turn off this slot, press again to recover the slot



NOTE :
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer
could void your authority to operate this equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television
reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.
Compliance statement:
This device has been evaluated to meet the general RF exposure requirement. It can be used in portable exposure condition without restriction.

Caution in programming

1. **The timer and thermostat will not live same time, the last mode turned on will be executed.**
2. **Don't overlap the time period in timer programming, if the overlapping happens, the end result might not be same as you wish**
3. **Don't overlap the time period in thermostat programming, if the overlapping happens, the executing result might not be same as you wish**
4. **Don't make 2 or more conflicted temperatures setting run at the same time, that might cause the plug execute a wrong action.**
5. **For the life of product, please make sure to turn off unwanted slots.**