Ckyrin
Link contact to comfortable

中文 ------------------------------ (1-12)

English ------------------------------ (13-24)

智能手表说明书

当您打开智能手表的包装盒时，请核对包装盒内包括：



首次开机





主菜单

多运动模式

天气

需要插入SIM卡，开启移动数据网络后，更新当地天气。

关于手表

APK下载/安装/连接

手机助手连接APK操作步骤：

APP推送消息设置：

温馨提示：

您也可以通过KirinX官方论坛、Facbook、售后联系我们服务电子邮件等。我们的工程师会为你提供必要的技术支持。

http://bbs.ckyrindigi.com

@CkyrinWatches.official

www.ckyrindigi.com

after-sales@ckyrinwatch.com

深圳市宝安区宝民一路广场大厦1012室

深圳市吉威国际科技有限公司

User Manual for Smart Watch

Please check that you have the following items when you open the box

1. Ckyrin Smart Watch * 1
2. 4pin magnetic USB charging data cable * 1
3. Watch Instruction Manual * 1
4. Suction card pin * 1
5. Charging and charging compartment * 1
6. 5pin Micro interface charging data cable*1

First Boot

- Press the power key for 2s, the watch will then show the boot screen. The first time you boot the watch it will take a bit longer to start. This is due to apps getting ready. Please, be patient and do not try to turn off the watch.
Once it finishes, you will be able to choose your preferred language.
- If you want to change the language you can do so going to Settings -> Language and input -> Language.

Charging the watch

- During the first use, it's recommended to fully charge the battery to extend its longevity. Plug the watch dock to the supplied USB cable and use a computer or a wall charger to charge it. Then place the watch on top and it will automatically start charging



SIM Card Installation

1. Insert the two steel pins on the card ring or the bottom cover of the power bank into the corresponding two small holes in the SIM card cover;
2. Rotate 15 ° clockwise
3. Hold the SIM card cover with a suction cup
4. Lift the bottom cover vertically with a suction cup
5. Insert the SIM card into the card holder

- Please note that this watch only supports Nano-SIM cards.

Power Key Functions

- Long press to turn on the watch;
- Turn off the screen by pressing it once;
- If you are inside an app, press it once to go back;
- Long pressing the button for 2 seconds will open the power menu, allowing you to power off or reboot the watch, as well as open the recent apps view or to change between a square or round screen interface.
- If the watch has crashed, long pressing the power button for 15 seconds will reboot it.

Back function key

- In the second level menu and below, short press the return key to return to the previous level menu.

Gesture control

- In the watch interface, sliding up will bring up the pedometer interface, showing steps and distance during the week. Then, sliding to the left will show steps, distance and calories during from that day.
- In the watch interface, sliding down will show basic information (battery level, date and time, network information and Bluetooth status). Sliding to the left will show the quick toggle menu for WiFi, Bluetooth, rotation lock, brightness, etc. Continue to swipe left to enter the cleaning / music / weather interface.

- In the watch interface, sliding left will show pending notifications.
- By sliding to the right from the watch interface, the main menu will pop up. All apps are available there. Then, sliding one more time to the left you will access the sport menu.

Round and square screen function

1. Most of the Android apps aren't optimized to work on round screens, and expect

a device with a square screen. The main function of this feature is to make the interface smaller so that it fits in a square inside the round watch screen.
2. To enable square screen mode, press the power button during 2 seconds until the power menu shows up. Then, press the round icon on the top of the screen and it will change to a square. You have successfully enabled square screen mode.
3. To disable square screen mode, press the power button during 2 seconds until the power menu shows up. Then, press the square icon on the top of the screen and it will change to a circle. You have successfully disabled square screen mode

Menu user guide

Watch Face

1. The main watch screen will show one of the many available watch faces.
2. By pressing and holding the screen you will enter the watch face settings mode

3. You can select or download any of the available watch faces to set it as your default one.
4. Custom watch face:Sliding left to the end and press the setting icon,click camera to capture new photo or click gallery to select existed picture as watch face.

Applications list

The basic applications included are: Contacts, Phone, Messaging, Settings, Browser, Downloads, Calendar, Clock, Gallery, Music, Sound Recorder, File Manager, Fitness, Weather, Voice Search, Play Store, Maps, Camera, Heart Rate Monitor and Mobile Assistant, System optimization, App market.

Main menu functions

Contacts

Add, sync and delete contacts. Before synchronizing the contacts, make sure Bluetooth is paired with your phone.

Phone / call history / contact list

- Input the desired phone number and press the call icon.
- In the dialing interface, slide left to access the recent call history.
- In the call history interface, slide to the left to enter the contact list and search the desired contact.

Messaging

Receive, read, reply and delete SMS messages.

Browser

You can browse the internet using a WiFi or 4G connection.

Download

All the files downloaded by the browser will be shown here.

Calendar

You can check the date, day and month of the year.

Clock / Timer / Stopwatch / Alarm

- You can check different time zones.
- Sliding to the left will let you access the different timer, stopwatch and alarm interfaces.

Gallery

- Click to enter the gallery, you will be able to browse photos and see all your Pictures and videos.
- To delete a file, open it and click it and click the trash bin icon to delete it.

Music

- You can play, pause, skip or repeat songs on the watch internal storage;
- Tap the volume icon to adjust it;
- By paring up Bluetooth headphones, you can play music through them;
- To add new songs, simply connect the watch to your computer and copy them to the device internal memory.

Sound Recorder

- Touch the record icon to start recording. Touching it again will end the recording, giving you the option to either save or delete it.

- To play a recording, access the recordings list and choose the one you want to play. To delete it, do a long press on it and click on delete.

File transfer

- Connect the dock to the computer using the provided USB cable. Then, place the watch on the dock and go to Settings -> Connection -> USB and tap on Transfer files. A new device will appear on the computer, and you will be able to copy files to and from it.
- By opening the file manager, you will see the total and free memory space. By tapping again, you will access the filesystem where your files will be shown. From there, you will be able to see, modify, create or delete files and folders.

Multi-sport mode

Multi-sports mode includes running, walking, bike riding, basketball, football, ping-pong, badminton and rope skipping. When entering to one of those modes, you will be able to enter the target time, target kilometers and target calories.

Weather

You will need an active internet connection for it to work. Then, the local weather information will be updated automatically.

Camera

Click to enter to the camera and take pictures or videos. It's recommended to put set the brightness to 100% to get better results.

Heart Rate

Before getting in the heart rate menu, make sure you have your watch on your

wrist. To get a good result, gently press the watch to your skin. Then, tap the screen to start the test and try not to move until the result appears on the screen.

Mobile assistant

You can use the remote-control functions (capture, music, file transfer, device search) by downloading the app Wiiwatch 2 on your phone(explained later)

Settings

Allows you to control different settings like sound, screen, main menu style, connectivity, gestures, low power mode, language and input, date and time, factory reset, uninstall apps and more.

Sound

Here you can choose the ringtone, alarm sound, volume levels, etc.

Display

- Brightness and screen timeout settings are available here.
- Do not open always time if not needed, as it would consume the standby time.

App list style

You can choose between a menu with an arc shape or a normal list.

Connect

Click on the connect icon to configure Bluetooth, WIFI, WIFI Hotspot, USB, Airplane Mode, GPS, Mobile data etc.

Gestures

Enable or disable wrist gestures and pedometer auto-start on boot.

Language and Input

- Click on it to access the language configuration and choose the desired language. You can long-press the language bar and move it to the first row to change the default language.
- Click to access the virtual keyboard configuration. The keyboards installed by default are: Android Keyboard, Google Pinyin and Voice input. You can choose which one you want to use.

Date and Time

- The date and time will automatically be updated when connected to the internet or using the GPS.
- To adjust the date and time manually, uncheck the "Automatic date and time". You can also uncheck the "Automatic timezone" option. Finally, configure the date and time.

Factory reset

You can delete all device information and restore the device to a factory state.

Uninstall app

You can uninstall apps from the device, as well as stop apps installed by default.

About Watch

- In the "About Watch" menu you will be able to find the developer options as well as the status of the watch, model number, Android version and OTA updates.
- **OTA updates:** Before the update, make sure the watch is at least 50% charged. The updates will only be available via WiFi. To avoid errors, we recommend not using the watch during this process. Once the update has finished, the watch will restart automatically. This can take more than 10 minutes, don't power off the watch, be patient.
Once you see the home screen, the update will have finished.

Download and install WiiWatch 2

- **For Android users:** the app is supported on Android 7.0 and later. To check your Android version, go to Settings -> About phone.
- **For iOS users:** the app is supported on iOS 11.1 and later. To check your iOS version, go to Settings -> General -> Information

Method 1: get WiiWatch 2 for iPhone and Android users:

Mobile Assistant -> Scan the QR code to download and install the app on your phone.

Method 2: get WiiWatch 2 for Android users:

Search "WiiWatch 2" on Google Play and download the app.

Method 2: get WiiWatch 2 for iPhone users:

Search "WiiWatch 2" in the AppStore and download the app.

Mobile Assistant connection with WiiWatch 2

1. Enable Bluetooth both on your watch and your phone.
2. Scan the QR code shown in the watch with WiiWatch 2. Once it's connected successfully the Bluetooth pairing interface will show up. Finally, WiiWatch 2 will display all the watch information.
3. Once the watch is connected, various functions can be used, such as music control, device search, calls and notifications via Bluetooth, etc.
4. Press on Health inside WiiWatch 2 to display the current exercise data, as well as current and previous health rate values stored on the watch.
5. Click sports interface to switch sports mode freely.
6. Click clock face to download new clock faces in your watch; download clock faces from phone is not supported for IOS.

APP notification reminder setting

1. Allow WiiWatch 2 to send you notifications on the phone, or you would not receive any notifications.
2. Enter settings on the phone, find power saving mode, allow Wiiwatch 2 to run in the background.

3. If installed Anti-virus software on the phone, find Wiiwatch 2 on the software and allow it to run in the background.

Tips

- The charging base is magnetic. Please, make sure it's clean and free of objects before charging the watch.
- The battery can't be removed. Due to the internal power drain of the watch, it could empty the battery if it's not used during a long time. To avoid it, try charging the watch at least once a week.
- If the watch hasn't been used in a long time, it could have discharged itself. In that case you should wait at least 10 minutes after plugging in the watch for it to recover a normal state. It's recommended to use a 5v 1A USB wall charger.
- A bad use of the device could cause it to hang. To restart the watch, keep pressing the power button for at least 10 seconds until it shuts down.

You can also contact us through KirinX official forum, Facbook,after-sales service email,etc. Our engineers will provide you with the necessary technical support.

http://bbs.ckyrindigi.com

@CkyrinWatches.official

www.ckyrindigi.com

after-sales@ckyrinwatch.com

Headquarters : GuangCheng Building 1012, BaoMing Road,BaoAn District, Shenzhen City, P.R.C

Leiwei technology Co., LTD

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.
Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.
This Smart Phone meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health.

The SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue for front of face and 4.0 W/kg averaged over 10 gram of tissue for wrist. Device types: S10 (FCC ID: 2AW57S10) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for Front of face is 1.157W/kg and when properly worn on the Wrist is 1.653W/kg. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 10mm separation distance between the user's front of face and a 0mm separation distance between the user's wrist. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.