TOMMY HILFIGER

TOMMY EARBUDS 333
USER MANUAL

AIR SPORT

NOISE CANCELLING WIRELESS EARBUDS

Bluetooth™

Charge Directions and Use:

- Fully charge the earphones before using them for the first time.
- Plug the USB charging cable into the controller of the headphones.
- The LED light will turn blue when the earphones are fully charged.

Attention: Please use the original included charging cable to connect the earphones to your computer or compatible USB charging device.

Basic Use:

Power on: Press & hold multi-function button until blue LED goes on.

Power off: Press & hold the power button until red LED goes on.

Pairing: When unit is powered off, press & hold the multi-function button for about 10-15 sec until blue & red LED lights begin to blink. The unit is now in paring mode. Make sure your Bluetooth enabled device is discoverable. In Available Devices choose "TOMMY EARBUDS 333" and select "Pair".

Volume control: While listening, press the V+ button to increase volume, or the V- button to decrease volume.

Music track: While listening, press & hold the V+ button for the next song, press & hold the V- button for the previous song.

Pause/Play: While listening, press the multi-function button to pause music. Press the button again to play music.

Answer/End call: Tap the multi-function button.

Reject call: Press the multi-function button for 2-3 seconds.

Redial last number: Double click the multi-function button to redial.

LED Indicator:

Low battery warning: Red LED flashing.

Charging: Red LED on when charging and blue LED on when fully charged.

Bluetooth connected: Blue LED flashing slowly.

Power on/off: When turning the earphones on the LED light will blink blue. When turning off the LED will turn red.

Bluetooth pairing: Blue and red LED flashing rapidly together.

Pairing The Bluetooth Earphones:

Pairing the device is quite simple. Put the earbuds and compatible Bluetooth device close to each other (no more than 3 feet apart). When powering on the SVES ELECTRONICS earbuds press and HOLD down the center power button on the controller. The voice prompt will say **"Ready to pair"**

*** DO NOT release the power button for another 10-15 sec and the LED indicator lights should begin to blink red and blue. Your device is now in pairing mode.

From here you'll have to navigate through Bluetooth Settings on your mobile device and choose **"SVES-EP333"** from the list of all available Bluetooth devices within range. This should begin the pairing sequence.

After pairing is successfully completed, you will hear a tone in the earphones indicating that the connection has been established and the voice prompt will state "Your Device is Now Paired."

Now you can use your Tommy Earbuds 333 to listen to music and make phone calls.

SPECIFICATIONS

Bluetooth Profiles	HSP,HFP,A2DP,AVRCP
Operation Range	33 Ft/360o
Frequency Range	20Hz-20,000Hz
Lithium-Ion Battery	3.7V/60mAh
Charging Voltage	DC4.75-5.25V
Charging Time	About 2 Hours
Playing Music Time	Up to 5 Hours
Talk Time	Up to 5 Hours
Standby Time	Up to 200 Hours

Warnings and Notes:

- Do not store unit in a high temperature environment, including intense sunlight or heat. Do not place unit near fire or other excessively hot environments.
- Be cautious of excessive drops, bumps, abrasions or other types of impact. If there is any damage to the battery such as dents, punctures, tears, deformities of corrosion, due to any cause, discontinue use and contact manufacturer or dispose of in an appropriate manner.
- Do not disassemble or attempt to modify or replace any part of this unit.
- Do not expose unit to moisture, snow or submerge it in liquid.
- Do not use unit in the vicinity of flammable fumes or gases (such as propane tanks or large engines).
- Do not attempt to operate unit using any other method than directed.

TECHNICAL SUPPORT:

Please do not attempt to fix the product by yourself. If you are experiencing any problems with the product please do not return it to the store you bought it from. You can contact our technical support representatives and they will assist you with any questions you might have.

Questions? Visit our support page online at www.sveselectronics.com

WARRANTY REGISTRATION

To register your SVES Electronics product please visit www.sveselectronics.com

TOMMY HILFIGER

TOMMY EARBUDS 333
USER MANUAL

AIR SPORT

NOISE CANCELLING WIRELESS EARBUDS

Bluetooth™

FRANÇAIS

INSTRUCTIONS DE CHARGE ET UTILISATION:

- Chargez complètement les écouteurs avant de les utiliser pour la première fois.
- Branchez le câble de charge USB fourni sur le port de charge micro USB (4) du contrôleur du casque.
- Le voyant LED(3) s'allume en rouge lorsque les écouteurs sont en charge. Lorsque les écouteurs sont complètement chargés, le voyant (3) s'allume en bleu ou s'éteint complètement (pour économiser la batterie).

Attention: Veuillez utiliser le câble de charge d'origine inclus pour connecter les écouteurs à votre ordinateur ou à un périphérique de charge USB compatible.

Mise sous tension: Appuyez sur le bouton multifonction (2) et maintenez-le enfoncé jusqu'à ce que le voyant bleu(3) s'allume.

Mise hors tension: Appuyez sur le bouton multifonctions (2) et maintenez-le enfoncé jusqu'à ce que le voyant rouge (3) clignote et que l'appareil s'éteigne.

LE JUMELAGE DE L'APPAREIL EST ASSEZ SIMPLE: placez les écouteurs et l'appareil compatible Bluetooth® à proximité l'un de l'autre (pas plus de 3 pieds).

et les voyants DEL(3) devraient commencer à clignoter en rouge et bleu. Votre appareil est maintenant en mode d'association. L'invite vocale indiquera "Votre appareil est prêt à être jumelé"

De là, vous devrez naviguer à travers les paramètres Bluetooth® sur votre appareil mobile et choisir "Tommy earbuds 333" dans la liste de tous les appareils Bluetooth® disponibles à portée. Cela devrait commencer la séquence d'appariement.

Une fois l'association terminée avec succès, vous entendrez une invite vocale indiquant "Connected"

Vous pouvez désormais utiliser vos écouteurs Tommy Bluetooth® pour écouter de la musique et passer des appels téléphoniques.

Contrôle du volume: Pendant l'écoute, appuyez sur le bouton + (1) pour augmenter le volume ou sur le bouton - (5) pour le diminuer.

Music Track: Pendant l'écoute, maintenez enfoncé le bouton + (1) une fois pour passer à la chanson suivante, maintenez enfoncé le bouton - (5) pour revenir à la chanson précédente.

Pause / Lecture: Pendant l'écoute, appuyez une fois sur le bouton multifonction (2) pour mettre en pause la musique. Appuyez à nouveau sur le bouton pour écouter de la musique.

Répondre / Terminer un appel: Lorsque vous recevez un appel, appuyez sur le bouton multifonction(2) pour accepter l'appel. Lorsque l'appel est terminé, appuyez à nouveau sur le bouton pour terminer l'appel.

Rejeter l'appel: Lorsque vous avez un appel entrant, maintenez le bouton multifonctions(2) pendant 1-2 secondes pour le rejeter.

Recomposition du dernier numéro: double-cliquez sur le bouton multifonction (2) pour recomposer.

CONNEXION ET VEILLE:

Lorsque les écouteurs Bluetooth® sont allumés, ils se connectent automatiquement au dernier appareil compatible connecté à portée, puis il passe automatiquement en mode veille et est prêt à l'emploi.

Support technique / Enregistrement de garantie

SUPPORT TECHNIQUE:
En cas de problèmes, veuillez contacter nos représentants du support technique.

Visitez notre page de support en ligne sur www.sveselectronics.com

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.