H076

简易指南

1.包装清单

感谢您选用我们的产品。
请确认您所购买的产品包装是否完整，如果有包装损坏或是有任何配件短缺的情形，请尽快与您的经销商联系。

☐ 整机 x 1
☐ 简易使用指南 x 1
☐ 电源适配器 x 1
☐ 壁挂 x 1

2.产品规格

处理器	- RK3576
显卡	- ARM Mail G52 MC3 GPU
内存	- LPDDR4x 2GB/4GB/8GB
存储	- 1 x EMMC5.1 32GB/64GB/128GB - 1 x Micro SD 卡
网络	- 1 x RJ45，10/100/1000Mbps
Wireless	- Module，WIFI+BT，XB547NF WiFi6/BT5.2
前IO接口	- 1 x PowerButton with Blue Led - 1 x Recovery - 1 x USB 3.1 Gen1 Type-A - 1 x USB 2.0 Type-C，支持 OTG - 1 x IR - 1 x MIC-in & Line-out 二合一接口 - 1 X TF
后IO接口	- 2 x HDMI OUT - 1 x HDMI IN - 1 x USB3.0，1 x USB2.0 - 1 x RJ45 - 1 x DC IN
左IO接口	- 1 x RS232 COM - 2 x ANT
右IO接口	- 1 x 锁孔 - 2 x ANT（预留）
操作系统	- Android 13
电源输入	- 12V/3A DC IN
环境要求	- 工作温度：-5℃~50℃，存储温度：-20℃~70℃ - 工作湿度：10%~90% 无凝结
整机尺寸	- 149 x 128 x 26 mm

3.IO接口

前面板接口



后面板接口



左面板接口



右面板接口

- Power Button：电源开关键
- Recovery：长按进入烧录系统模式，或是按一下进入系统恢复界面
- TF：TF 卡插槽
- SIM：SIM 卡插槽
- Type-C：TYPE-C 连接端口
- USB3.0：USB3.0 连接端口
- 二合一接口：耳机、麦克风二合一接口
- DC IN：DC 电源接口
- LAN：RJ-45 网络接口
- USB 2.0：USB2.0 连接端口
- HDMI OUT：高清晰度多媒体显示输出接口
- HDMI IN：高清晰度多媒体显示输入接口
- ANT：天线端子
- COM：RS232串口
- Kensington Lock：防盗锁插孔

产品中有害物质的名称及含量

部件名称	有毒有害物质或元素					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
电路板组件	X	O	O	O	O	O
内存	X	O	O	O	O	O
CPU	X	O	O	O	O	O
SSD	X	O	O	O	O	O
线材	X	O	O	O	O	O
结构件	X	O	O	O	O	O
散热模组	X	O	O	O	O	O
WIFI蓝牙模块	X	O	O	O	O	O
天线	X	O	O	O	O	O
配件	O	O	O	O	O	O

O：表示部件的有害物质含量符合GB/T 26572《电子电气产品中限用物质的限量要求》的限值要求。
X：表示部件的有害物质含量超出GB/T 26572《电子电气产品中限用物质的限量要求》的限值要求，但是符合《达标管理目录限用物质应用例外要求》。
*：电路板组件包括印刷电路板及其构成的零部件，如电阻、电容、集成电路、连接器等。

H076
Simple User's Guide

1.Package Checklist

Thank you for choosing our products.
Before using your product, please make sure your packaging is complete, if there have been damaged or you find any shortage, please contact your dealer as soon as possible.

☐ The Machine x 1
☐ Simple User's Guide x 1
☐ Power Adapter x 1
☐ Wall mount x 1

2.Product Configuration

CPU	- RK3576
Graphics	- ARM Mail G52 MC3 GPU
Memory	- LPDDR4x 2GB/4GB/8GB
Storage	- 1 x EMMC5.1 32GB/64GB/128GB - 1 x Micro SD card
Ethernet	- 1 x RJ45, 10/100/1000Mbps
Wireless	- Module, WIFI+BT, XB547NF WiFi6/BT5.2
Front IO interface	- 1 x PowerButton with Blue Led - 1 x Recovery - 1 x USB 3.1 Gen1 Type-A - 1 x USB 2.0 Type-C, support OTG - 1 x IR - 1 x MIC-in & Line-out Two In One connector - 1 X TF
Rear IO interface	- 2 x HDMI OUT - 1 x HDMI IN - 1 x USB3.0, 1 x USB2.0 - 1 x RJ45 - 1 x DC IN
Left IO interface	- 1 x RS232 COM - 2 x ANT
Right IO interface	- 1 x Kensington Lock - 2 x ANT (Reserve)
Operating System	- Android 13
Power Input	- 12V/3A DC IN
Environment	- Operating Temperature: -5℃~50℃ - Storage Temperature: -20℃~70℃ - Operating Humidity: 10%~90%(non-condension)
Dimensions	- 149 x 128 x 26 mm

3.IO Interface

Front panel



Rear panel



Left panel



Right panel

- Power Button: Pressing the power button, the machine is turned on
- Recovery: Long press to enter the system flashing mode, or press once to enter the system recovery interface
- TF: TF Card Slot
- SIM: SIM Card Slot
- Type-C: TYPE-C Connecting Port
- USB3.0: USB3.0 Connecting Port
- 2-in-1 Interface: Headphone and Microphone 2-in-1 Interface
- DC IN: DC Power Interface
- LAN: RJ-45 network connector
- USB 2.0: USB2.0 Connecting Port
- HDMI OUT: High Definition Multimedia Display Output Interface
- HDMI IN: High Definition Multimedia Display Input Interface
- ANT: Antenna Terminal
- COM: RS232 Serial Port
- Kensington Lock: Kensington Lock Jack

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.