PRODUCT MANUAL

产品手册

V1.1

NO. 128A-41

ELECTRIC TOYS

< 套装内容 >
PACKAGE CONTENTS

< 产品详细信息 >
PACKAGE DETAILS

< 运程控制功能 >
REMOTE CONTROL FUNCTIONS

< 电池安装 >
BATTERY INSTALLATION

< 产品和遥控电池安装完成后 >
After the product and the remote control battery are installed,

< 使用 >
OPERATION

< 警告 >
WARNINGS

产品本身
Product body
遥控器
Remote Control
溅雪
Dropper
产品手册
Product Manual
锂电池
Lithium Battery
注水口
Water Inlet
电池盖
Battery Cover
驱动开关
Power Switch
1.产品电池
Product battery
电池安装
Lithium Battery
3 X 1.5V AA
(不含)
not included
1.1开电池盖 Unscrew and open the battery cover.
2.按正确方向插入3节AA电池 Insert 3 AA batteries in the correct direction.
3.盖上电池盖并扭上 Close the battery cap and lock it.
如果长时间不使用，请务必关闭并取出电池。
If the product will not be used for a long time,
make sure to turn it off and remove the battery.
演示
Demo
喷雾模式2
Spray mode 2
喷雾模式1
Spray mode 1
音乐/声音
Music/sound
左转
Turn left
右转
Turn Right
向前
Forward
后退转弯
Back and turn
2.遥控器电池
Remote Control Battery
2 X 1.5V AA
(不含)
not included
1.1开电池盖 Unscrew and open the battery cover.
2.按正确方向插入2节AA电池 Insert 2 AA batteries in the correct direction.
3.盖上电池盖并扭上 Close the battery cap and lock it.
如果长时间不使用，请务必关闭并取出电池。
If the remote control will not be used for a long time,
make sure to remove the batteries.
1.配对
Pairing
产品和遥控电池安装完成后
产品底部的开关可以配对成功
After the product and the remote control battery are installed,
the switch at the bottom of the product can be paired successfully
2.向前,后退转弯
向前
Forward
后退转弯
Back and turn
Press the up arrow button on the remote control to move the product forward,
and click the down button on the remote control to move the product back and turn
按遥控器上的向上箭头键向前移动，
点击遥控器向下按键将产品后退转弯
3.喷雾功能
喷雾
Spray Function
1.Please make sure there is water inside the
water tank before using the spray function
2.Fill the dropper with water, open the lid and
pour the water in the dropper into the water
injection port, cover the water injection port
after completion
3.Press these 2 spray buttons once to light
spray,divided into 2 spray modes
1.使用前需要加满水，请确认
水箱内有水
2.将喷壶盖取下，打开盖子再将喷
壶里的水注入注水口，完成后
盖住注水口
3.按这2个喷雾按钮一次
即可喷出，分为＝种喷雾模式
4.音乐/声音 Music/sound
按一次声音键激发音乐,长按3秒关闭所有声音
Press the sound key once to play music
press and hold for 3 seconds to turn off all sounds.
5.演示 Demo
按演示键一次即可进行自动演示
Press the demo key once for automatic demo
Demo 音乐/声音 Music/sound
注水口 Water Inlet
电池盖 Battery Cover
驱动开关 Power Switch
1.1开电池盖 Unscrew and open the battery cover.
2.按正确方向插入3节AA电池 Insert 3 AA batteries in the correct direction.
3.盖上电池盖并扭上 Close the battery cap and lock it.
如果长时间不使用，请务必关闭并取出电池。
If the product will not be used for a long time,
make sure to turn it off and remove the battery.
1.产品电池
Product battery
电池安装
Lithium Battery
3 X 1.5V AA
(不含)
not included
使用
Using
尺寸: 20.8X6.1X2.5英寸 Dimensions: 20.8X6.1X2.5英寸
产品电池类型:1.5VAA电池 Battery Type For Product:1.5V AA battery
最大控制距离：(13米 Max Control Distance: (13 m
远程控制距离:1.5VAA电池 Battery Type For Remote Control:1.5V AA battery
工作温度范围:32° 到 104°F (0° 到 40°C)
Operating Temperature Range:32° to 104°F (0° to 40°C)
2.配对
Pairing
产品底部的开关可以配对成功
the switch at the bottom of the product can be paired successfully
产品和遥控电池安装完成后
After the product and the remote control battery are installed,
按演示键一次即可进行自动演示
Press the demo key once for automatic demo
演示 Demo
音乐/声音 Music/sound
按一次声音键激发音乐,长按3秒关闭所有声音
Press the sound key once to play music
press and hold for 3 seconds to turn off all sounds.
4.音乐/声音 Music/sound
轻弹枪（款式2&3）
Light Spray (Model2&3)
NO. 1.2&3-41
NO. 1.2&3-6&2
加水
Add Water
喷雾功能
1.使用前需要加满水，请确认
水箱内有水
2.将喷壶盖取下，打开盖子再将喷
壶里的水注入注水口，完成后
盖住注水口
3.按这2个喷雾按钮一次
即可喷出，分为＝种喷雾模式
3.喷雾功能
喷雾
Spray Function
向前
Forward
后退转弯
Back and turn
2.向前,后退转弯
按遥控器上的向上箭头键向前移动，
点击遥控器向下按键将产品后退转弯
Press the up arrow button on the remote control to move the product forward,
and click the down button on the remote control to move the product back and turn
1.开电池盖 Unscrew and open the battery cover.
2.按正确方向插入2节AA电池 Insert 2 AA batteries in the correct direction.
3.盖上电池盖并扭上 Close the battery cap and lock it.
如果长时间不使用，请务必关闭并取出电池。
If the product will not be used for a long time,
make sure to remove the batteries.
2.遥控器电池
Remote Control Battery
2 X 1.5V AA
(不含)
not included
演示
Demo
喷雾模式2
Spray mode 2
喷雾模式1
Spray mode 1
音乐/声音
Music/sound
左转
Turn left
右转
Turn Right
向前
Forward
后退转弯
Back and turn
1.产品电池
Product battery
电池安装
Lithium Battery
3 X 1.5V AA
(不含)
not included
使用
Using
1.1开电池盖 Unscrew and open the battery cover.
2.按正确方向插入3节AA电池 Insert 3 AA batteries in the correct direction.
3.盖上电池盖并扭上 Close the battery cap and lock it.
如果长时间不使用，请务必关闭并取出电池。
If the product will not be used for a long time,
make sure to turn it off and remove the battery.
注水口
Water Inlet
电池盖
Battery Cover
驱动开关
Power Switch

< 产品详细信息 >
PACKAGE DETAILS

< 套装内容 >
PACKAGE CONTENTS

产品本身 Product body	遥控器 Remote Control	溅雪 Dropper	
产品手册 Product Manual	锂电池 Lithium Battery		

1.According to the instructions provided in the manual. Some of the parts need to be assembled and adjusted by adults.
2.Please use it under the guidance of an adult.
3.Please promptly put away the packing materials so as not to cause harm to children.
4.Do not operate on a location where water is trapped or under the rain. Parts of the product may malfunction if exposed to water.
5.Do not touch the rotating wheel to avoid injury.
6.The product contains small parts that may pose a risk of ingestion or suffocation.
7.To remotely control the product on the road or in a crowd to avoid accidents
8.Disconnect the rechargeable USB cable before cleaning, the toy.
9.If you observe electrical charges during product usage turn off the device immediately.
10.When installing or replacing the battery,pay attention to the correct polarity of the battery.
11.The product uses 1.5V aa batteries
12.It is strictly prohibited to do the following actions such as but not limited to disassemble,modify,crash,puncture,drop,throw in a fire or any other means of causing damage to the product to avoid harm to the user and other participants.
13.Do not expose the battery to prolonged exposure to sunlight to prevent danger.
14.It is advisable to store the battery at a temperature below 30°C Do not store it in a place with heat,high temperature,or humidity to avoid danger.
15.Non-rechargeable batteries cannot be charged.
16.Do not mix old and new or different types of batteries.
17.Do not disassemble the battery or modify the battery to avoid the risk of fire or explosion
18.After the battery is used, it should be taken out of the product.
19.Stop using the battery as soon as it gives a foul smells or suddenly becomes hot, deformed, discolored, or other abnormal situation during use or charging.

20.Drained batteries should be removed immediately.
21.Do not cause the electrical supply of the wiring port to short circuit.
22.If you do not use the product for a long time, remove the batteries
23.Instructions contains important product information,please give time to read for a better product experience.

< 一般信息 GENERAL INFORMATION >

FCC注意:

本设备符合FCC规则第15部分。
操作受以下两个条件限制:
(1)本设备不能造成有害干扰，且本设备必须接受任何接收到的干扰，包括可能导致不希望的操作干扰。

FCC Notice:

This devive complies with Prat 15 of the FCC Rules.
Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

注:根据FCC规则第15部分，本设备已经过测试，符合B类数字设备的限制。这些限制旨在为住宅设施提供合理的保护，防止有害干扰。
该设备产生使用并能辐射射频能量，如果不按照说明书安装和使用，可能会对无线电通信造成有害干扰。但是，不能保证在特定的安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰，可以通过关闭和打开设备来确定，鼓励用户尝试通过以下一种或多种方法来纠正干扰。

NOTE:This equipment has been tested and found to comply with the limits for a Class B digital device,according to Part 15 of the FCC Rules. These Limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment

generates uses and can radiate radio frequency energy and,
If not installed and used in accordance with the instructions, may cause harmful interference to radio communications.However,there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio of television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures

措施:

— 重新定位或安置接收天线。
— 增加设备与接收器之间的距离
— 将设备连接到与接收器连接的电路不同的电路插座上。
— 向经销商或有经验的无线/电视技术人员寻求帮助。

Measures:

— Reorient or relocate the receiving antenna.
— Increase the distance betwenn the equipment and receiver.
— Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
— Consult the dealer or an experienced radio/TV technician for help.

警告:未经合规责任方明确批准的，更改或修改，可能会使用户失去操作设备的权限。

WARNING:Changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

射频接触

该设备符合FCC辐射接触限值规定的不受控制的环境。
本设备安装和操作时，散热器与身体之间的距离不受限制。

RF Exposure

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.

IC注意:

该设备符合加拿大工业免许可证RSS标准。
操作受以下两个条件限制:
(1)本装置不得造成干扰;
(2)本设备必须接受任何干扰，包括可能导致设备不希望的操作干扰。

IC Notice:

This device complies with Canada' s Industry licence-exempt RSS standard(s).Operation is subject to the following two conditions;
(1) This device may not cause interference;
(2) This device must accept any interference.Including interference that may cause undesired operation of the device.

CAN NMB-3 (B)

射频接触

辐射接触声明:

该设备符合IC辐射接触限制规定的不受控制的环境。
本设备安装和操作时，散热器与身体之间应保持20厘米的最小距离。

CAN NMB-3(B)

RF Exposure

Radiation Exposure Statment;

This equipment complies with IC radiation exposure limits set forth for an uncontrolled environment. This equiment should be installed and operated with minimum distance 20cm between the radiator& your body.

电池警告:

1. 如果不遵守所有的使用说明，可能会导致严重的伤害，电池不可修复的损坏，并可能导致火灾、烟雾或爆炸。
2. 充电或使用前一定要检查电池的状态。
3. 如果电池损坏，发出恶臭或显示过热，变色，变形和泄漏迹象，请更换电池。
4. 不要使用电池以外的任何东西。电池总是使用平衡充电器。
 建议您不要使用本产品附带的充电器以外的其他充电器。
5. 电池温度不能超过60°°C(140°F)，否则可能导致电池损坏或燃烧。
6. 禁止在易燃表面、易燃产品附近或车辆内充电
 (最好将电池放置在不易燃、绝缘的容器中)。
7. 不要将电池暴露在潮湿或阳光直射的地方，或将其储存在温度超过60°C的地方(例如阳光下的汽车)。
8. 一定要把它放在孩子够不到的地方。
9. 电池使用不当可能导致火灾、爆炸或其他危险。
10. 不可充电电池不能再次充电。
 可充电电池只能在成年人的监督下使用。
11. 不同类型的电池和新、旧电池不能混合
12. 电池插入正确的极性。
13. 电源端子应使用好，避免短路。建议定期检查变压器和电池充电器，检查电源线、插头、外壳和其他部件是否有损坏。
 如果观察到损坏，在修复之前不得使用。
14. 包装必须保存，因为它包含了重要的信息。
15. 该玩具只能连接到具有标志的II类设备。

BATTERY WARNING:

1.Failure to follow all the instructions may result in serious injury, irreparable, damage to the battery and may cause a fire, smoke or explosion.
2.Always check the battery' s condition before charging or using it.
3.Replace the battery if damaged, gives a foul odor or show signs of overheating,discoloration,deformation and leakage.

4.Never use anything other than the approval charger battery.
 Always use a balancing charger for battery. It is recommended that you do not to use any other charger than the one provided with the product.
5.The battery temperature must never exceed 60°C (140°F)
 otherwise the battery could be damaged or ignite.
6.Never charge on a flammable surface,near flammable products or inside a vehicle(perferably place the battery in a non-flammable and nonconductive container).
7.Never expose the battery to moisture or direct sunlight,or store it in a place where temperatures could exceed 60°C(car in the sun,for example).
8.Always keep it out of reach from children.
9.Improper battery use may result in a fire, explosion or other hazard
10.Non-rechargeable batteries are not charged again,Rechargeable batteries are only to be charged with the supervision of an adult.
11.Different types of batteries or new or used batteries which are different are not be mixed.
12.Batteries are to be inserted with the correct polarity.
13.The supply terminal should be used well to avoid a short circuit.
 Examination of the transformer and battery charger regularly is encouraged to check any damage in the cord,plug, enclosure and other parts. If damage is observed,it must not be used until it has been repaired.
14.The packaging has to be kept since it contains important information.
15.The toy is only to be connected to Class II equipment bearing the symbol.

MANUFACTURER INFORMATTION

Manufactured by
Shantou Chenghai Nanhong Toys Factory No. 1-1, Huangqingmang, Longtian, Guangyi Street, Chenghai District, Shantou City, Guangdong Province