尺寸：85x55mm
红色线条表示折叠线
2023.3.23

正面

Power Bank

USER MANUAL

Specification

Normal version:

Battery Capacity	10000mAh
Type C Input	5V⎓2.5A（Max）
USB Output 1	5V⎓2.1A(Max)
USB Output 2	5V⎓2.1A(Max)
Wireless output	5W
Dimension	150x71x17.3 mm

Package Contents



Power Bank x1 | Charging Cable x1 | User Manual x1

Product Introduction

Thank you for purchasing this protable power bank,Before using the power bank, Please read the manual carefully and follow the instructions to operate properly.

Product Features

① Power button
② Type–C Input
③ USB 1 output
④ USB 2 output
⑤ Wireless Charger
⑥ LED indicators:
LED1: Wireless charging indicator
LED2–5: Battery power indicators



Operating Instruction

1. Charging Power Bank



1.Connect the Type C connector of a USB cable into the related input port, and connect the USB connector to a power supply with USB output (not included). It is recommeded to use USB power supply with current 1–2A.
2.When charging, the Indicator lights will flash. Each light indicates about 25% of the capacity. When fully charged, all Indicator lights will light up.

背面

3.Note: Fully charge the power bank before using the power bank for the first time. Recharge the power bank once every three months when not in use or seldom used.

2. Charging device

A.Wired charging
Press the power button, indicator lights are on. One end of charging cable should be inserted in the USB or type c port,and the other end should be inserted in the charging port of your device which needs to be charged. When charging device, The indicator lights are on.
B.Wireless charging
Press the power button, LED1 light flashes and then goes out. Put your smartphone on top of the power bank, exactly in the center of the wireless charging area. LED1 light is always on, which means wireless charging is in progress.
Note: Make sure your smartphone is fit for Qi standard receiving equipment.

Troubleshooting

1.Press the power button, If LED2 indicator light is flashing, battery is running out soon, please recharge.
2.This power bank can automatically identify equipment that need to charge, If there is no equipment on it, the power bank will be turned off after 30 seconds，Normal version of power bank is off after 3S.
3.For wireless charging, your mobile device must be equipped with a Qi wireless receiver. The device can automatically identify a Qi–compatible device placed on it.If the center point of the receiving terminal is deflected over 10mm from the center point of transmitting terminal, the power bank will be turned off automatically.
4.If wired charging is not working properly, please try a different charging cable, since the connector may become loose due to wearing.
5.During charging, the device may become warm due to high currents and resistance, especially during wireless charging. To reduce temperature, avoid running intensive applications or using GPS on your mobile device when charging.

Cautions:

Read all the instructions and warnings carefully prior to using this product.
•The power bank will generate heat when charging. Always charge in a well–ventilated and open–air area. Do not charge under pillows, blankets, clothing or on flammable surfaces.
Keep the power bank away from heat sources, direct sunlight, combustible gas, humidity, water or other liquids.
•Do not disassemble, open, microwave, incinerate, paint or insert foreign objects into the power bank.
•Do not subject the power bank to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy objects on the power bank.
•Do not short–circuit the power bank or store it in a receptacle where it may be short–circuited by other metallic or conductive objects.
•Do not operate the power bank if it has been wet or otherwise damaged, to prevent against electric shock, explosion and/or injury. Contact the dealer or authorized agent.

Warning:

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
– Reorient or relocate the receiving antenna.
– Increase the separation between the equipment and receiver.
– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
– Consult the dealer or an experienced radio/TV technician for help.
the transmitter may not be co - located with any other transmitter or antenna.