

Car Sentinel Camera

User Guide

The user guide is for reference only. Screenshots displayed in this user's guide of the UBooPro app may appear differently than those currently featured in your app as frequent updates and improvements.

DOWNLOAD AND INSTALL AP

1.Scan the QR code below and click Install or search "UBooPro" or Apptstore to download and install.

APP REGISTRATION

Click "Register Now!"(when, (For better user experience, please allow all permissions to avoid not receiving notifications)



2.Please enter your email phone number, click on User Agreement,click next to get the verification code.



3.Enter the verification code received and click next. (If you are registering by email and did not find the verification code, you can check if you received the code in your spam mailbox)



4.Set your login password and Click Register. (For the security of your password, the password should be more than 8 letters and numbers.)



5.Enter your registered cell phone number or email address, then enter your password and click login in.

3.CAMERA PAIRING (Turn on the device before use.)



CONNECTION

Click "Device" of the device, check whether the blue indicator light is always on, go back to the APP interface, click "Add Device", when the blue indicator light of the device is always on, click "Next".



3.When APP pops up to allow "UBooPro" to search for devices, click "Allow" to search for devices, click on the device to be connected, when the device is found, the first 4 digits of the device are displayed, "1234" is used as an hotspot.



5.The device is automatically located in the address, the name can be changed to the name you want (generally the "Home" address), the camera will prompt after a successful prompt. Click - "OK" - congratulations, the device is added successfully.



SCANNING CONNECTION METHOD

Click "Device" of the device, check whether the blue indicator light is always on, go back to the APP interface, click "Add Device", when the blue indicator light is always on, click "Next".



2.Click "Scan QR Code", wait for the blue indicator light to be always on, then scan the QR code on your device and go to the next step.



4.After the blue light is always on, click "Next", the device is automatically located in the address, the name can be changed to the name you need, after the change press "Next".



6.Enter the configuration page, click "OK" after the prompt of adding success, congratulations, the device is added successfully.



DEVICE INDICATOR STATUS DESCRIPTION

1.Blue indicator Light.	The device is connected to the network.
2.The red and blue lights keep blinking rapidly.	Machine can't access the network, weak signal or abnormal traffic card.
3.Red and blue lights flash slowly alternately.	Unpaid or deactivated traffic card.
4.Red and blue lights flash alternately and rapidly.	No traffic card detected.
5.Red indicator light	Traffic card not installed.

3.The product installation instructions

(1) Install the electrostatic sticker to the front glass of the car.



(2) Locate the mounting bracket to adjust it to the proper monitoring angle.



(3) Remove the double-sided sticker from the bracket.



(4) Where the device is affixed to the bracket.



Installation Notes: If there are metal objects covering the device, it will affect the radar detection distance, GPS function of the device.

About the power supply for monitoring.

The power supply of the device can be connected to the USB port and cigarette lighter of the car. If you need to use the parking monitoring function, you need to connect to the hard wire parking, you need to buy the monitoring cable (no the cable needs to be purchased separately) to connect to the device.



Car fuse box drop wire schematic

Each brand of car fuse box location is different, connecting the car buck cable need professional operation, please do not operate the connection by yourself!



The yellow cable indicates the position of the ON/ constant for some models. Red cable indicates the location of the ACC cable fuse box socket.

Description of camera operating modes

Parking monitoring mode

The device is powered by the car's ACC signal (powered by the OBD hush cable or fuse line hush cable disassembly, the device will enter the low power parking monitoring mode, the device will enter the sleep state after 10 minutes, 2.0GSS device will trigger the video recording function when there is an impact/collision, and the video will be saved in the event folder. If the SD card is not in storage or is jammed in the phone, in this mode, the phone can open the APP to view the front and rear camera scenes at any time.

Car Logger Mode

(1) Then when the body vibration detected by the collision sensor exceeds the set threshold, it will be stored in the TF card and playback the HD video through the APP. (2) When the car is in the flameout state, the car is bumped or moved detected by the mode exceeds the set threshold.The vibration mode video will be stored in the TF card and the HD video can be played back through the APP in real time, and then in this mode, the phone can open the APP to view the front and rear camera scenes at any time.

4.HOME PAGE DESCRIPTION





(1) Add Location
(2) On Quick Search Devices
(3) Add Device by Scanning The QR Code, Wi-Fi Hotspot Mode
(4) Quick AP, Cloud Storage Recharge, Device Sharing
(5) Enter The Monitoring Screen
(6) Device Name
(7) Turn On/Off Message Notifications
(8) Enter Cloud Video
(9) Enter Device Settings
(10) Enter Equipment
(11) Add Device
(12) Enter The Quick List
(13) View Video Of The Event
(14) Enter Customer Service
(15) Access Accessory And Value-Added Services

(1) Changing Cloud Service Enablement Status and Enabling Cloud Services
(2) Enter The Device Sharing Application and Quick Application Prompts
(3) Enter The APP Function Brief Introduction
(4) Enter Common Device Network Status
(5) Add a Voice Control Device Permissions And View FAQ/FUQ
(6) Find Device Location
(7) Solutions To Common Problems When Using Devices
(8) Change Password And Cancel Account
(9) Set Voice Protection And System Privilege Settings
(10) Setting Functions Such As Clarity And Device Time
(11) Check The Status Of APP Version Information

5. Camera function introduction

1.) radar detection

If there are metal objects blocking the front and rear radar, it will affect the detection distance, and the detection distance will be 0.5m-3m when the vehicle is parked in the distance outside the front window will be 1.5m~3m, outside the front window will be 0.5m~1.5m, and outside the rear window will be 0.5m~1.5m.



0.5m~3m outside front windows

Within 0.5m outside the rear window



About the Radar Detection feature tip:



"The radar detection sensitivity can be set in the device settings, and the default is the most sensitive gear, which is recommended to turn down the device sensitivity to the appropriate gear according to the actual parking lot to avoid frequent false alarms."

When radar detection/motion detection is turned on, the device will immediately turn on and record the video and send the information to the phone after an object/motion occurs within the radar sensing range.



2.) Camera Mode

In driving mode, there is red preview from the APP, press the APP button below the screen, the APP will switch to photo mode, press the shutter button, a photo is taken, and the photo will be triggered.



3.) Privacy Mode

Long press "PM" on the bottom of the device, the privacy indicator lights up and the device enters privacy mode, and the device will not record the video, but the rest of the camera video function and device recording function, and at the same time turn off the remote viewing of the unit's camera impact and listening functions.



4.) TF Card Video Export

Insert the TF card into the card slot of the device, enter the monitor preview interface and click " " icon to query TF video, (If you need to export HD video, you need to use a card reader to query it on your computer using HCL player)



5.) Cloud Services

Click on the purchase of APP and click the button to open "Cloud Storage". Each device's "cloud service" is free to try for 30 days, click the free trial to experience the cloud service. (After the expiration of the trial period, you can purchase the cloud service according to your own needs.)



② When the cloud storage service is opened successfully, the following will appear in the cloud storage service video, open the video, click on the "Cloud Storage Playback" icon, and the video of the cloud service, when the cloud service expires can not be queried)



6.) GPS positioning function

APP into the preview screen, click the " " icon, the preview screen below the pop-up window will appear longitude and latitude, speed.



7.) Crash-sensitive video

When a collision occurs when the device is parked/standing, the machine will automatically record the video and send the information to the phone in real time. (Please set the sensitivity of the collision sensing, if the collision sensitivity is lower than 50, the collision sensing of the device will be slow)



FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user ' s authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co - located for operating in conjunction with any other antenna or transmitter.