蓝牙耳机系列
使用说明书

包装清单

耳机X2　充电仓X1　说明书&保修卡　Type-C充电线X1

产品示意图

温馨提示

1、切勿使用具有腐蚀性的清洁剂清理本产品。
2、切勿让本产品加热或靠近火源。
3、切勿让本产品长时间置于阳光下直接照射。
4、切勿让本产品异置于火中，避免发生爆炸。
5、切勿为尝试拆开本产品存在任何修改。
6、切勿在雨中使用本产品。
7、如果长时期内不使用本产品，请您将它储存在干燥的环境中，并每月至少给耳机充电一次以延长寿命，避免极端的温度和灰尘。

产品规格

蓝牙版本：V5.3
传输距离：>10米
音乐时间：10小时
喇叭尺寸：φ16.2mm
充电时间：<2.5小时
电池容量：110mAh
额定输入：5V ⎓ 80mA
待机时间：100小时

充电仓规格

电池容量：300mAh
充电时间：<2小时
额定输入：5V ⎓ 500mA
(所有技术信息以实际性能为准)

给充电仓充电用
Type-C充电线连接充电仓到5V电源适配器。
(温馨提示：耳机电池电量低于3.5V,低电量提示每隔1分钟提示一次，低电量指示灯快闪。
声音提示：主 耳 低 电 ,主 耳 提 示 我battery low,副耳低电,副耳提示音 Battery low)

额定输入：5V ⎓ 80mA（耳机）　额定输入：5V ⎓ 500mA（充电仓）

产品操作说明

LED指示状态

开机	蓝灯闪烁 5 次
关机	红灯常亮 1 秒后灭
蓝牙配对	1、配对模式: 左/右耳机红蓝灯交替闪烁 2、左右配对成功,主耳红蓝灯交替闪烁，副耳灯灭 3、耳机与设备连接完毕后 LED 灯灭
建立回连	1、主耳红蓝灯交替闪烁，副耳灯灭，5 分钟内无连接自动关机，红灯常亮 1 秒后灭 2、回连成功 LED 灯灭
耳机入仓	1、耳机入仓，充电中电量>15%，白灯闪烁一次 熄灭白灯闪烁一次 2、耳机入仓，充电中电量<15%，红灯闪烁一次 熄灭红灯闪烁一次
耳机入仓充电	充电红灯长亮，充满红灯熄灭
低电提醒	低电量指示红灯快闪
充电仓	1、充电中，红灯闪烁 2、充满，红灯常亮
恢复出厂设置	红灯亮 1 秒后灭

产品操作说明

①开机
方法一：打开充电盒盖，取出耳机自动开机。
方法二：单个耳机在充电盒外，长按"触摸键"5 秒开机。
(开机提示音："power on")

②关机
方法一：耳机放入充电盒内，自动关机并充电。
方法二：与设备断无连接，5 分钟后自动关机。
方法三：耳机未连接状态，长按任意一边耳机触摸按键 5 秒，左右耳同时关机。
(关机提示音："power off")

③蓝牙配对
步骤一：打开充电仓取出耳机，TWS 耳机自动进入手机配对模式（已配过耳机进入回连状态）
步骤二：手机搜索设备名连接。
步骤三：目前大部分手机不需要密码，如需密码请输入（0000），连接成功后语音声提示，此时耳机可以通话，听歌！

触摸操作

■ 常规模式

Siri：长按左边 Touch 键 2S
音量加：单击右边 Touch 键
音量减：单击左边 Touch 键

■ 音乐播放模式

播放/暂停：双击左/右边 Touch 键
上一曲：三击左边 Touch 键
下一曲：三击右边 Touch 键

■ 通话模式

接听来电：来电时双击 Touch 键一下可接听来电
挂断通话：通话时，双击 Touch 键可结束通话
拒接电话：来电时长按 Touch 键 2 秒,拒绝对方来电

■ 游戏/音乐模式切换

音乐模式：长按右边 Touch 键2S
(提示音："music mode")
游戏模式：长按右边 Touch 键2S
(提示音："game mode")

恢复出厂设置

蓝牙开机未连接状态，5 击（左右均可）完成清除与设备配对信息并自动关机

产品中有害物质名称及含量

部件名称	有害物质					
	铅 (Pb)	汞(Hg)	镉(Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷电路组件	○	○	○	○	○	○
外壳等小结构件	○	○	○	○	○	○

本表格依据SJ/T11364的规定编制
O:表示该有害物质在该部件所有均质材料中的含量均在
GB/T26572规定限量要求以下。
X:表示该有害物质至少在该部件的某一均质材料中的含量超出
GB26572规定的限量要求。
表单标记"×"的部件,首改支球技术发展水平限制而无法实现有害物质的替代。

本表格依据SJ/T11364的规定编制
印刷电路板组件:包括印刷电路板及其零部件,电子元器件等。
根据产品型号不同,印刷电路板组件品可能不会含有以上所有部件

在中华人民共和国境内销售的电子电气产品必须标识此标志,标志内的数字代表在正常的使用状态下的产品的环保使用期限。

保修声明

免责声明
本使用手册没有任何形式的担保，立场表达或其他暗示，本使用手册所提到的产品，规格及信息仅供参考，内容会随时更新于网页，恕不另行通知。

保修声明：
就本文件提供的产品做如下保证：如产品在您购买日起十二（12）个月("保修期")内，在正常使用情况下因质量瑕疵发生损坏，能修理的，免费修理；坏厂家确认无法修理的，免费更换；修理或更换后的产品，在剩余保修期（最短不少于30天）内继续享有保修。购买日以销售发票日期为准，如无法确定购买日，则保修期自产品生产日期起按十三（13）个月计算。
如申请保修，请先取电产品服务热线，并按照们指示的方式执行。申请保修时，您需要提供发票，完整和清晰填写的有效销售发票，以上保证不适用于下列情况:
1.超过三包有效期的;
2.滥改保修卡，产品编码与产品本体不符;
3.因误用、滥用或不适当的运输、使用、维护或保管而导致的故障或损坏;
4.因不可抗力（如地震、战争、火灾等）或意外导致的故障或损坏;
5.拉链、锁扣因受力过大而损坏;
6.因承载过重造成的耳线或音腔;
7.任何因义购物渠道造成的损坏;
8.有害物质或水浸造成的产品;
9.因擅自改装造成的损坏;
10.产品正常使用过程中发生的老化、脱色、磨损、破裂和其他损耗。
11.如产品原有标识标签被更改或损毁，本保证将失效。
产品及随附物料的齐备和外观完好不属于保证范围，您应在接收产品时当场检验并对任何不符提出异议。

以上保证是我们就产品做出的全部保证，且仅在中国大陆地区境内适用。本文件的任何内容均不影响根据法律规定不能排除或限制的消费者权利。

Packing list



Headset X2　Charging CaseX1　Instructions Warranty card　Type-C Charging CableX1

Product diagram

Tips

1、Except for the operation methods specifically marked in the manual,please do not try to disassemble or replace any parts in the earbuds.
2、Don't put the earbuds in the water or any others liquid.The earbuds are not waterproof.
3、If any liquid enters the product by accidentally,please disconnect and remove the connection immediately.
4、Please make sure that there is no water on your hands when Installing or uninstalling the product to avoid electricshock.
5、Do not make any modifications to this product in order to attempt to disassemble it.
6、Do not put the product in the environment with strong electromagnetic force, otherwise it will cause product malfunction.

BLUETOOTH HEADSET SERIES INSTRUCTIONS

Product specifications

Bluetooth version: V5.3
Transmission distance: 10M
Music time: 10 hours
Horn size: φ16.2mm
Charging time: <2.5 hours
Battery capacity: 110mAh
Rated input: 5V ⎓ 80mA
Standby time: 100 hours

Charging case specifications

Battery capacity: 300mAh
Charging time: <2 hours
Rated input: 5V ⎓ 500mA
(All technical information is subject to actual performance)

To charge the charging box
The Type-C charging cable connects the charging case to the 5V power adapter.

(Reminder: The battery power of the headset is lower than 3.5V, the low battery reminder will be prompted once every 1 minute, and the low battery indicator red light will flash quickly.
Sound prompts: low battery in the main ear, battery low for the main ear; low battery for the secondary ear, battery low for the secondary ear)

Rated input: 5V ⎓ 80mA (headset)　Rated input: 5V ⎓ 500mA (charging case)

Product Operation Instructions

LED Indicator Status

Power On	Blue light flashes 3 times
Power Off	The red light stays on for 1 second and then goes off
Bluetooth Pairing	1. pairing mode:The red and blue lights of the left/right earphones flash alternately. 2. Pairing is succeeded,The red and blue lights of the main ear flash alternately. The secondary ear light is off. 3. LED off when connection is complete
Create A Connection	1. The red and blue lights of the main ear flash alternately and the lights of the auxiliary ear go out. No connection for 5 minutes. Connected to automatic shutdown, the red light is always on for 1 second and then off. 2. The LED light is off when the connection is successful.
Headphones Into Warehouse	1. Put the earphones into the warehouse, the power of the charging chamber is >15%, and the white light flashes once.Take out the white light flashes once 2. When the earphones are put into the warehouse, the power of the charging warehouse is <15%, and the red light flashes once. Take out the red light flashes once
Charge The Earphones In The Warehouse	The charging red light is always on, and the full red light is off
Low Battery Reminder	flashing red light
Charging Case	1. Charging, the red light is flashing 2. Fully charged, the red light is always on
Reset	The red light is on for 1 second and then off

Product Operation Instructions

① power on
Method 1: Open the cover of the charging box, take out the headset and turn it on automatically.
Method 2: With a single earphone outside the charging box, press and hold the "touch button" for 5 seconds to turn it on.
(Power on prompt tone: "power on")

② power off
Method 1: Put the headset into the charging box, automatically shut down and charge.
Method 2: If there is no connection with the device, it will automatically shut down after 5 minutes.
Method 3: When the earphone is not connected, press and hold the touch button of either earphone for 5 seconds, and the left and right earphones will be turned off at the same time.
(Shutdown tone: "power off")

③bluetooth pairing
Step 1: Open the charging compartment and take out the earphones, the TWS earphones will automatically enter the mobile phone pairing mode (enter theconnection status)
Step 2: Search the device name on the mobile phone to connect.
Step 3: At present, most mobile phones do not need a password. If you need a password, please enter (0000). After the connection is successful, the voice Sound prompts, at this time the headset can talk and listen to music!

Touch operation

■ General mode



Siri: Hold down the left Touchbutton for 2S
Volume Plus: Click the Touch key on the right
Volume reduction: Click the Touch key on the left

■ Music playback mode

Play/Pause: Double click the left/right Touch button
Last song: Hit the left Touch three times
Next song: Strike three on the right Touch

■ Call mode

Answer incoming calls: Double click Touch to answer incoming calls.
End Call: During a call, double-tap the Touch button to end the call
Reject a call: Hold down the Touch button for 2 seconds to reject an incoming call

■ Game/ Music mode switch

Music mode: Long press the right Touch button for 2S
(Sound: "music mode")
Game mode:Long press the right Touch button for 2S
(Sound: "game mode")

Factory Reset

When the Bluetooth is turned on and not connected, 5 clicks (both left and right) to clear the pairing information with the device and automatically shut down

The name and content of harmful substances in the earbuds

Part Names	Harmful Substances					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
Printed circuit assembly	○	○	○	○	○	○
Small structural parts such as shell	○	○	○	○	○	○

This form is compiled in accordance with SJ/T 11364.
○Indicates that the content of the hazardous substance in all homogeneous materials of the part is in below the limit required by GB/T 26572.
XIndicates that the hazardous substance at least in a certain homogeneous material of the part exceeds The limit requirements specified in GB/T 26572.
The parts marked with "X" on the form are all harmful due to the limitations of global technological development. Substitution of substances.

Printed circuit board components
Including printed circuit boards and their parts,electronic components, etc.and depending on the product model,the earbuds you purchased may not contain all the above components.

Electronic and electrical products sold in the People' s Republic of China must mark this LOGO,the number in the logo represents the product under normal use Environmental protection use period.

Warranty statement

Disclaimer
This user manual does not have any form of guarantee,position expression or other implication.The mentioned products,specifications and information are for reference only,and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:
The product attached to this document is guaranteed as follows:If the product is twelve (12) months from the date of purchase("Warranty Period")under normal conditions of use due to quality defects damaged,can be repaired,free maintenance;If it is a manufacturer's unrepairable or unrepairable, repaired or replaced product.Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days).Purchased by sale the ticket date shall prevail;If the purchase date cannot be determined,the warranty period shall be 13 (13) months.
If you apply for a warranty,please call the product service hotline first and execute it in the manner instructed by us.When applying for warranty,you need to provide an accurate,complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1.Exceeding the validity period of the three parts;
2.Altering the warranty card and product code does not match the product body;
3.Causes caused by misuse,abuse or improper transportation,use,maintenance or storage obstacles or damage;
4.Failure or damage caused by force majeure (such as earthquake,war,disaster,etc.) or accident bad;
5.The zipper and tower buckle are damaged due to excessive force;
6.Disconnection or tearing caused by excessive load;
7.Any damage caused by sharp objects;
8.Products with signs of burning of flooding;
9.Unauthorized modification or unauthorized disassembly;
10.Aging,discoloration,abrasion,rupture and other losses that occur during the normal use of the product.
11.If the original identification label of the product is changed or damaged,this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are only applicable in mainland China;Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.

Warranty statement

Disclaimer
This user manual does not have any form of guarantee,position expression or other implication.The mentioned products,specifications and information are for reference only,and the content will also be updated on the web at any time without additional separate notice.

Warranty statement:
The product attached to this document is guaranteed as follows:If the product is twelve (12) months from the date of purchase("Warranty Period")under normal conditions of use due to quality defects damaged,can be repaired,free maintenance;If it is a manufacturer's unrepairable or unrepairable, repaired or replaced product.Continue to enjoy the warranty during the remaining warranty period (the shortest not less than 30 days).Purchased by sale the ticket date shall prevail;If the purchase date cannot be determined,the warranty period shall be 13 (13) months.
If you apply for a warranty,please call the product service hotline first and execute it in the manner instructed by us.When applying for warranty,you need to provide an accurate,complete and clearly filled out valid sales invoice.

The above guarantee does not apply to the following situations:
1.Exceeding the validity period of the three parts;
2.Altering the warranty card and product code does not match the product body;
3.Causes caused by misuse,abuse or improper transportation,use,maintenance or storage obstacles or damage;
4.Failure or damage caused by force majeure (such as earthquake,war,disaster,etc.) or accident bad;
5.The zipper and tower buckle are damaged due to excessive force;
6.Disconnection or tearing caused by excessive load;
7.Any damage caused by sharp objects;
8.Products with signs of burning of flooding;
9.Unauthorized modification or unauthorized disassembly;
10.Aging,discoloration,abrasion,rupture and other losses that occur during the normal use of the product.
11.If the original identification label of the product is changed or damaged,this guarantee will become invalid.

The completeness and appearance of the product and accompanying materials are only applicable in mainland China;Nothing in this document affects consumer rights that cannot be excluded or restricted under the law profit.

FCC Warnning:

This equipment has been tested and found to comply with the limits for a Class B digital device,pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonableprotection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there
is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipmentoff and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:
Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.• Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.
Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This equipment complies with FCC radiation exposure limits set forth for an uncontrolled
environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.