Iprintit Portable Wirless Phone Printer

Operating Manual

Model: AW-68

Warm Prompt: Specifications and parameters may be changed depending on the configuration of the model. Please refer to the actual product.

Brief Introduction

Thank you for using the intelligent digital products produced by our company. We have randomly equipped with detailed instructions, from which you can obtain instructions on the use of the products. Please read the instructions carefully before you start using this machine,so as to facilitate you to use this product accurately. When the contents involved are changed, no notice willbe given.

This product is aunique sheape, exquisite design,easy to operate Portable mini printer,designed for children's digital products,so that children in use to learn more imagination play, experience the fun of nature.

Maintenance and maintenance

This product should not be placed in wet environment for a long time,please wipe the surface stains with dry cloth.Wires,plug shells and other components must be regularly checked for damage,and damage should be stopped immediately until repaired.in order to reduce battery aging and swelling; If it is not used for a long time,it needs to be charged once every three months or so

Key/interface specification



Indicator status

Green light flash:Normal use status.
Red light on:Out of paper/Overheat/Cover opened.
Red/Green light flash:low power

Product specification

Battery capacity:800mAh	Sharpness：200dpi
Printing method: inkless printing	Paper size:57*26MM*6M
Display method:Black and white	Bluetooth：5.3
Product Size:85X85X45MM	Input power:Type-C

Use the wizard

1. First use please charge first , long press the power key 3 seconds to boot .

2. Apple store or Google search:Tiny Print insalled APP to use.

Tiny Print



3. After bluetooth is enabled,use the app downloaded from the mobile phone to connect to the Bluetooth printer in the TAB bar of "My device", After successful connection, the note can be printed.

Paper replacement course

1.

Manual according to the direction indicated by the arrow. Press inward on both sides and up at the same time. Open the lid of the paper bin.

2.

Take out the old paper roll, put the paper straight, don't. Put it askew. (note: new thermal paper is required. Expose the 2CM length of the paper bin for casual wear. The machine can absorb paper automatically when the carton is in a carton.

3.

Cover the paper bin,the machine can automatically absorb paper after normal use

4.

After the above steps are correct , the machine can print normally.

Battery Warning Note

1 . Please use 5V charger to charge according to the specification to avoid damage to the machine

2 . Disassembly , impact , extrusion or fire are prohibited ;

3 . If severe bulging occurs , do not continue to use ,

4 . Do not put in high temperature environment , battery after immersion is prohibited to use;

5 . Replacement with the wrong type of battery can be explosive , be sure to follow the instructions to dispose of used batteries .

Matters needing

1 . when charging . please gently insert or pull out the charging line to prevent excessive force damage to the port;

2 . After charging , please unplug the charging line in time

3 . In order to avoid danger , do not use or charge in high temperature ,high humidity , excessive smoke and dust environment . such as: bathroom , steam room , open fire , etc ;

4 . Improper charging may lead to print head damage ;

5 . Do not touch the print head to prevent overheating and scalding ;

6 . Tear paper blade sharp , be careful not to touch;

7.Contains small parts, not suitable for children under three years of age to use

8.The Guardian should be in custody while the child is playing.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
•Consult the dealer or an experienced radio/TV technician for help.
Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:
(1) This device may not cause interference.
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée sur deux conditions suivantes :
(1) L'appareil ne doit pas produire de brouillage,
(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.