Mini PC

Product Manual

1.Disclaimer

- This product manual makes no guarantee, express or implied, regarding the accuracy, completeness, or reliability of any information or statements provided herein. To the maximum extent permitted by applicable law, we shall not be liable for incidental, special, or consequential damages arising out of the use or inability to use this manual or the products described herein.
- Please read and use the original power adapter provided with the product. The company shall not be liable for any losses or malfunctions caused by third-party power adapters.
- Users may utilize third-party-provided music, videos, images, and software ("Third-Party Content"). We do not assume any responsibility for copyright issues or software malfunctions.
- In case of product malfunction, we will strictly adhere to the warranty terms. However, we are not liable for any property damage or economic loss incurred during use.
- The software pre-installed in the product at the time of manufacture is intended solely for the operation of this device. We do not provide technical support, debugging, testing or for any other reasons will not affect the product, and it does not constitute a product quality issue.
- All product specifications and information provided in this manual are for reference only, including both hardware and software content.
- The company reserves the right to improve the product. Changes to product specifications, software, or this manual may be made at any time (the latest content will be updated accordingly). Please refer to the actual product for details.
- The company reserves the right to interpret and modify the product manual.


2.Precautions

- Power purchase and use memory and hard drives from reputable brands.
- Do not operate the device in extreme heat sources or in damp areas such as bathrooms, kitchens, basements, or pools.
- Ensure the device is placed on a stable surface; dropping it may cause personal injury or damage the device.
- Store and use the equipment in a cool, dry, and well-ventilated area, away from radiation sources and heat sources.
- Do not cover or block the ventilation holes on the casing. Do not place it on beds, sofas, or other soft surfaces.
- The voltage range for operating the device is indicated on the rear shell label. If unsure about the supplied voltage, consult the dealer or local power company.
- When the device is not in use for an extended period, disconnect the power to prevent damage from lightning strikes or voltage surges. Use a stable power source to avoid voltages. Use a reliable grounded socket and avoid overloading it, as it may cause fires or electric shocks.
- Do not insert foreign objects into the device, as it may cause fires or electric shocks.
- Do not disassemble or repair the product yourself to avoid the risk of electric shock. If there is a malfunction, contact the after-sales service personnel directly.
- Do not expose the device to rain or moisture.
- If the adapter power cord is damaged, it must be replaced with a specialized component purchased from its manufacturer or repair department.
- To prevent electromagnetic interference, keep away from wireless devices, and peripherals that meet standards and shielded cables between system components.
- Product storage temperature: -15°C to 45°C
- Do not use damaged, deformed, or leaking power. Replacing with the wrong battery model may compromise safety measures, leading to risks such as explosions or fires.
- Do not expose the battery to extremely high temperatures, such as sunlight, fire, microwaves, or ovens, as it may cause explosions or leakage of flammable liquids or gases.
- Do not disassemble, crush, squeeze, or cut the battery, as it may cause explosions.
- Do not expose the battery to extremely low pressure, as it may cause the battery to explode or leak flammable liquids or gases.

- If the battery becomes severely swollen, discontinue use immediately.
- Do not swallow the battery, as it may pose a risk of asphyxiation or chemical burns. If swallowed, seek medical attention immediately. If battery fluid comes into contact with the skin or eyes, rinse with clean water and seek medical attention immediately.
- Dispose of batteries in accordance with local laws, comply with national regulations for the safe disposal of used batteries.
- The product contains button batteries. Ingesting button batteries can cause severe internal burns and may lead to death.

Plastic Packaging Bag Safety Warning:
Keep plastic packaging bags out of reach of infants and children.


3.Product Introduction



- Power Indicator
- Power button
- DC power interface
- USB-A 2.0 port
- USB-A 3.0 port
- USB-C port
- HDMI port
- reset button
- Headset jack
- USB-C port
- RJ45 port

Note: The functions and interfaces mentioned in this article are marked. Any minor variations due to the upgrade of the product are not covered. Please refer to the actual product.

4. Packing list



MiniPC Adapter HDMI Cable

Product Manual VESA Wall Mount Screw kit

5.Basic parameters

Product Name	MiniPC
Product Size	112 x 112 x 39 mm
Product Weight	420g
Rated Input	12VDA, DC 5%
Rated Power	65W
LED	LED Status Light
Interface Type	Front: 1 x Power button 1 x 3.5mm Headset jack 2 x USB-A 3.0 Back: 2 x HDMI Port 1 x RJ45 Port 1 x 3.5mm DC Charging port 2 x USB-C Port 2 x USB-A 2.0 Indoor: 1 x reset button
LAN	1000Mbps
Wireless	Wi-Fi 6
Operating Temperature	0~40℃
Working Humidity	20%~75°C in non-condensing state

BIOS Setting

When the motherboard is powered on and the system is restarted,Press Delete to go to the BIOS Setup.



Press F7 to Enter the Boot menu. You can use the left and right buttons to move the selection box to the Boot option, and then use the up and down buttons to select options. Press F10 to Hot key and <Y>or to exit. See the table below for details.



Control Key	Function Description
↑ or ←	Move the left and right arrows to select the menu.
↓ or →	Move the up and down arrows to select the menu.
+ or -	Increase/decrease the value or change the option.
<Enter>	Select the option to access the submenu.
<Esc>	Return to the main screen, or exit the CMOS SETUP and restart the computer.
<F1>	The general help menu for the Setup Navigation.
<F5>	Load previous values from CMOS.
<F6>	Load optimized Settings (BIOS setup values).
<F9>	Save the changed CMOS Settings and restart.

7. Troubleshooting

Fault phenomenon	Possible Causes	Solution
Unable to power on	No power	Check connections to power and ensure proper seating.
Can not boot	Improper operation or faulty operating system	Try to clear the cmos and restart. If all else fails, contact the dealer or customer service.
The indicator light is on, but there is no picture when connected to the monitor	Not using standard cables	Use standard cables to connect the monitor video interface.
Screen does not display	Improper connection or disconnection	Reconnect.
After being properly connected and turned on, the screen displays garbled characters or applies signals	Disturbed	Keep away from objects that cause electromagnetic interference.electrical appliances
Unable to wake the system when booting	System damage	Restore or reinstall the system.
Running slowly	Too many files scattered	Run hard drive defragmentation tool to defragment files or uninstall or programs on your hard drive.
No sound when connected to audio interface	Sound card driver damaged	Reinstall the sound card driver.
Wi-Fi weak signal	External interference or loose antenna interface	Clean the metal shielding around the host to check for external interference

The fan is noisy	The fan has been loud since the first time it was turned on, and it is a condition-dependent condition.	Please ensure that the air vents on both sides are not blocked, and that the fan is not damaged. If the above conditions are normal, please contact the dealer or customer service for repair.
There are some unknown processes running in the background, causing the system to operate slowly.	The memory module is not properly inserted or is damaged.	Reinsert the memory module or replace it with a new one.
When installing the system, it shows that there is no hard disk.	The solid-state drive protocol is incompatible or unrecognizable	Check the product and ensure all the solid state drive I'm protocol supports the M.2 NVME Supporting interface
System is unresponsive	The application is incompatible with the system, causing a conflict or malfunction.	Please shut down the power button 5 to enter the please to pc 3 second but may cause data loss. Please back up your data regularly.
Unable to shut down	The application is incompatible with the system, causing a conflict or malfunction. Insufficient resources hinder opportunities	Please simultaneously hold down the Ctrl, Alt, and Del keys, then press the power button.Then select Restart or Shut Down. If more than 10 seconds, power cord to force power disconnect.

Mainland China ROHS

According to the "Measures and Measures for the Restriction of Hazardous Substances in Electronic and Electrical Products" of China Mainland, the following table lists the names and contents of hazardous substances that may be contained in this product.

Component Name	Hazardous Substances or Elements				
	(Pb)	(Hg)	(Cd)	(Cr(VI))	(PBB) (PBDE)
Circuit Board	○	○	×	○	○
Metal Parts	○	○	○	○	○
Cables	○	○	○	○	○
Plastic Covering	○	○	○	○	○
Fasteners	○	○	○	×	○
Power Supply	○	○	○	○	○
Optical Drive (Optional)	○	○	○	○	○
Hardware	○	○	○	○	○
Cables	×	○	○	○	○
Accessories	○	○	○	○	○

*This table is prepared in accordance with the provisions of SJ/T11365.

○: Indicates that the content of the hazardous substance in all homogeneous materials of the component is below the limit requirements specified in GB/T26572.

×: Indicates that the content of the hazardous substance exceeds the limit requirements specified in SJ/T11363-2006 in at least one homogeneous material of the component.

The environmental protection use period refers to the period during which hazardous substances or elements contained in microcomputers (including batteries) and their accessories will not leak or mutate under normal use conditions, causing the use of the product by users of electronic information products will not cause serious pollution to the environment or cause serious damage to their personal or property.

Product recycling and harmless treatment period: This information indicates that the product can be disposed of in accordance with the relevant laws and will not leak and cause environmental pollution or serious harm to personal or property for a period of 10 years.

This product is only suitable for use below 2000m.

This product is only suitable for use in non-tropical regions and is classified as Grade 2. In living environments, this product may cause radio interference. In such cases, users may need to take feasible measures to address the interference.

The Management Measures for the Restriction of Hazardous Substances in Electronic Information Products (China RoHS) is mandatory in China. This electronic product contains certain hazardous substances, which can be safely used during the environmental protection use period. After the environmental protection use period expires, it should be recycled through the recycling system

Indicative Rules on the "Regulations on the Management of Recycling and Disposal of Waste Electrical and Electronic Products":

In order to better care for and protect the earth, when users do not need this product or the product life has expired, please abide by the relevant national laws and regulations and hand over the waste electrical and electronic products to the waste recycling station or to a manufacturer with nationally recognized qualifications at that time for recycling. Improper use or disposal can have an impact on the environment and human health.

2. Time-Limited Protection Labeling Product Advisory Instructions:

1. Please ensure that the product is not damaged by any external force or any other use connected to any external power source.
2. Ensure that replacement parts are provided within 3 years after the product is sold (only applicable to models certified by the Chinese environmental labeling).

China RoHS Conformity Assessment System Identification

GB 4943.1-2022 Warning Requirements

For Class I equipment, use power plugs and grid connections with protective grounding. When installing in buildings, ensure that the distribution system can provide a circuit breaker with a rated voltage of 120/240V and a maximum of 20A.

Attention!

Only applicable to products with batteries.

Replacing with the wrong type of battery pack may result in loss of safety protection. Placing battery packs in fire or ovens, or mechanically squeezing or cutting battery packs can cause explosions.

Placing battery packs in extremely high-temperature environments may cause them to explode or leak flammable liquids or gases.

Battery packs subjected to extremely low air pressure may explode or leak flammable liquids and gases.

There is a risk of fire or explosion if the wrong type of battery pack is used for replacement.

Only applicable to products with button batteries.

Do not swallow button batteries.

This product (the remote control device provided with this product) contains button batteries. If a button battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

Keep new and used batteries away from children.

If the battery compartment does not close securely, stop using the product and keep it away from children.

If you think a battery may have been swallowed or lodged in any part of the body, seek medical attention immediately.

This voucher is an important basis for product warranty.

Please keep it safe!

User Information	User Name
	Mobile/Zip Code
	E-mail
Product Information	Model Name
	Phone Number
	Distributor Name
Sales Information	Mobile/Zip Code
	Phone Number
	Sell date

Maintenance Record Form

Repair Date	Fault Description	Fault Handling	Handler Sign	Customer's Signature

Dealer's Seal

FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.