THE FOURTH SPACE
CREATOR AIR CONDITIONER

USER MANUAL

Please read this manual carefully before use

User Manual

Please read the user manual of the product carefully before use to ensure proper use. If the product is used for the first time, please read the safety tips and the precautions at the end of the manual. Keep the manual for future reference. Our company reserves the right to modify the product and the manual.

We are constantly improving and upgrading our products, which may change specifications or content of this manual. For the latest product information, please contact our customer service and staff directly or **Like The Fourth Space** on Facebook to obtain the latest version of the manual.

Thank you for your understanding and support.

1.Product Specifications

Product Information:
Product Name: **Air Conditioner**
Product Model: **CP-12**
Product Height: 27.5cm
Product Weight: 2.5kg
Product Dimensions: 20cm*20cm*27.5cm

DC Adapter specifications:
Adapter Input voltage/frequency: 100-240V ~ 50/60Hz
Adapter Output voltage: 12V ⎓ 5A

Refrigeration specifications:
Refrigerant Type: R600a, Isobutane
Refrigerant Weight: 45g±5g, R290 75g
Refrigerant Pressure: 0.6MPa-1.2MPa
Cooling Area: 10-15㎡
Cooling Capacity: 1000-1500 BTU
Front and rear ventilation air volume: 180CBM/H
Noise: 45dB-55dB
Operation Tips: 15L

2.Precautions

Please read the following safety precautions carefully before using the product. Improper use of air conditioners can cause personal injury or property damage, such as electrical shock, fire, or other hazards. Please ensure you understand and follow these safety guidelines.

- Do not place the air conditioner near flammable substances and combustible materials, such as gasoline, kerosene, or other flammable gas, to prevent fire or explosion.
- Do not place the air conditioner near heat sources or in environments with high temperatures, such as near stoves or heaters, to avoid overheating and damage.
- Do not place the air conditioner in a location where the air flow might be obstructed or covered, such as in a closed cabinet or a corner, to ensure proper ventilation and prevent overheating.
- Do not place the air conditioner near water or in a wet environment to prevent electrical hazards and ensure the safe operation of the device.
- Do not place the air conditioner directly in front of an air conditioner or other cooling equipment.
- Do not place the air conditioner in a location where it may cause damage or injury if it falls or tips over

FCC Requirement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

– Reorient or relocate the receiving antenna.

– Increase the separation between the equipment and receiver.

– Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

– Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator & your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.