OUTSIDE

L-R = 7.1 cm

L-R = 7.1 cm

T-B = 10.5 cm

Disney Vacation Club
MEMBER CRUISE

BLUETOOTH SPEAKER MANUAL

©Disney ©Disney/PIXAR

MaCher

Made in China
FAC-085864
RN127453

LEFT

RIGHT

INSIDE

L-R = 7.1 cm

L-R = 7.1 cm

T-B = 10.5 cm

BLUETOOTH SPEAKER MANUAL

Instructions

1. Press and hold for power on and off. Press and release for pause/play/answer call/hang up.
2. Press and release + to raise volume.
3. Press and hold + to skip to the next song.
4. Press and release – to lower volume.
5. Press and hold – to change to the previous song.
6. Play two speakers at the same time: Power on both speakers. Press and release twice on either speaker to enter speakers into pairing mode. After pairing successfully, the main speaker will have a voice pairing prompt. To end pairing, press and release twice on either speaker.

* Switch off your Bluetooth connection before pairing speakers to each other. After speakers are paired, switch on Bluetooth connection and search for the twin speaker name in Bluetooth setup.

7. Insert microSD card and the speaker will automatically play from the microSD card.
8. RESET: When the speaker is on and not working properly, use a pin to insert into the hole to reset, and the speaker will reboot.

Basic Features

- Bluetooth play
- Support hands-free call
- Support music from microSD card
- Support twin speaker playing
- Waterproof

Troubleshooting

- If the speaker will not power on, check if the battery has power.
- Cannot connect with Bluetooth devices: Check if the speaker is connected to a different Bluetooth device, if yes, disconnect it first. If still cannot connect, reset the speaker and try again.

Charging via USB Cable

- USB cable is for charging use only, not for data transferring or playing music.

Specifications

- Built-in Li-ion Battery: 2500mAh
- USB charging Voltage: 5V
- Speaker: 4 ohm 5W*2
- Frequency Range: 100 Hz-18KHz
- Distortion ≤ 1%

Interfaces

- USB Port: Power charging.
- MicroSD Card Slot: Insert microSD card into slot to play music from card.

LED Indicator

- Blue light: Power on.
- Red light: Charging status (red light turns off when fully charged).

Caution

- Keep out of reach of children.
- Never drop the speaker.
- Keep it away from fire, high and low temperature.
- Never block speakers nets.
- Never open the speaker.
- Do not charge speaker longer than 5 hours at a time.

FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.