8581 overseas instruction manual

Foreword: We are very pleased that you have chosen this car navigation audio-visual product. This manual will systematically introduce the basic functions, use skills and precautions of the car. Let new users quickly get to know, please read carefully before using, thanks!

directory

1、Basic knowledge.....2nd
1.1 Basic operation gesture recognition.....2nd
1.2 Main interface and application interface.....2nd
1.3 Wallpaper replacement.....3rd
1.4 Main interface-add application shortcuts.....3rd
1.5 Main interface-delete application icon.....3rd
1.6 Boot LOGO settings.....4th
2、Main functions of the main interface.....4th
2.1 Navigation function.....5th
2.2 Bluetooth function.....5th
2.3 Application interface.....8th
2.4 Radio function.....8th
2.5 Set interface.....10th
3、Introduction to common app functions.....10th
3.1 Equalizer.....10th
3.2 Steering wheel learning.....11th
3.3 File management.....12th
3.4 Touchscreen assistant.....12th
3.5 music player.....13th
3.6 Video playback.....13th
3.7 Picture Preview.....14th
4、 Introduction to settings.....16th
4.1 WiFi.....16th
4.2 Device settings.....17th
4.3 General settings.....17th
4.4 Factory setting.....18th
4.5 User.....19th
4.6 System settings.....19th

1、 Basic knowledge

1.1 Basic operation gesture recognition

The gestures that the machine can recognize are mainly divided into short-press, long-press, drag, and slide types. The results of the same function under different gestures are different, and the user operates the machine by touching the display screen.



1.2 Main interface and application interface

1. After the machine is started, it will jump to the main menu page by default. This page mainly displays the shortcuts of some commonly used functions. The user can also adjust the layout of the page according to personal preferences. This device has multiple screens. You can swipe left or right to switch between interfaces. When it is not the main interface, tap the icon on the screen to return to the main interface.

2. Tap the icon on the main interface to enter the application interface.





1.3 Wallpaper replacement

There are two ways to set the wallpaper:

1. In the main interface, long press the blank space to pop up the wallpaper and live wallpaper setting buttons.
2. Settings→Devices→Display→Wallpaper，Choose wallpaper according to personal hobbies.





1.4 Main interface-add application shortcuts

Find the application icon that needs to be dragged in the application interface, and long press the icon for a few seconds, it will enter the draggable state. At this time, the car machine automatically switches from the application interface to the main menu, and the user can move the dragging icon to the place where the main menu can be arranged.





1.5 Main interface-delete application icon

When you press and hold an application icon or widget in the main menu, a delete button will pop up on the interface. If the user moves the long-pressed icon or widget to the delete button, it will enter the red deleteable state. At this time, let go of the icon or widget's shortcut.





1.6 Boot LOGO settings

1.Setting→Factory Setting→Car Logo Setting, the user can choose the car logo pattern he wants to specify.
2.Customize the boot logo: First, the resolution of the picture to be set needs to be greater than or equal to 1024x600, create a new mycar folder under the root directory of the SD card or U disk, put the picture into the folder, insert the SD card or U disk into the machine, and click the car Icon setting, slide to the last page to display it.



2、 Main functions of the main interface

The main interface is as follows:



2.1 Navigation function

Tap the navigation icon on the main interface to enter the map interface, Tap the search destination to use the navigation function.

2.2 Bluetooth function

Click the Bluetooth icon on the main interface to enter the Bluetooth interface.

1. Bluetooth phone



Click to enter the Bluetooth phone interface. The phone Bluetooth needs to be connected to the car machine to use the Bluetooth phone function.

1) Turn on the Bluetooth function of the mobile phone and the car equipment respectively, and set the mobile phone as "visible to everyone".

2) Search for the Bluetooth device in the mobile phone and select it to connect after finding it. At this time, it shows that the pairing password should be input, which is generally: 0000. After inputting the pairing, it shows that the connection is successful.

3) After the connection is successful, the Bluetooth phone function can be used.

2.Bluetooth music

Click the icon to enter the Bluetooth music interface. When the Bluetooth connection between the car and the mobile phone is normal, the music in the mobile phone can be played through the Bluetooth of the car, and the switch between upper and lower songs can be controlled.



3.Bluetooth sync phone address book



Click the icon to enter the synchronization phone address book interface. The car and the phone are synchronized with the phone address book. First of all, ensure that the Bluetooth of the phone and the phone are connected normally. The following is the synchronization method:

1） Click the download icon to download the phone book, and a prompt box will pop up on the phone to choose whether to allow the car to access the phone address book.

2) Wait for the car to pop up the download complete prompt box, and then click the save button.

3) Click Search to find the contacts in the downloaded phone book.

4) Click the delete button to delete the contact in the phone book.

4.Bluetooth call log



Click the icon to enter the call log interface. All call records during the Bluetooth connection between the car and the mobile phone will be displayed on this page. You can view the incoming call, outgoing, and hang-up records. Incoming call, You can also delete records.

5.Bluetooth device search interface



1.Click the icon to enter the device search interface, and then click the search button, Bluetooth will search for all nearby Bluetooth devices and display them in the list. Find and select the Bluetooth device you want to connect in the list.

2. Click the connect button, it will send a connection request to the selected Bluetooth device, enter the matching password in the selected Bluetooth device, the unconnected device is a disconnected icon, if the connected icon appears, it means the connection is successful.

3. Click Disconnect to disconnect the connected device.

4. Click Clear Device to clear the device.

6. Bluetooth setting interface

The Bluetooth setting page displays the name of the car's Bluetooth and the pairing password, and the user can manually change these information. The function of automatic answering is that when a call comes in, the car will answer it automatically. When the Bluetooth reset button is pressed, all Bluetooth information set by the user will be restored to the factory settings.



2.3 Application interface

Tap the icon on the main interface to enter the application interface



2.4 Radio function

Click the icon on the main interface to enter the radio interface, and users can

set the following function points according to their needs.



1. Click the icon to switch the band, the radio band will switch between FM1, FM2, FM3 cyclically, and the station information on the 6 save information buttons of the current band will also change accordingly. Due to the inconsistency of broadcast bands in various regions, users can switch manually according to local conditions.

2.Click the icon to switch stereo.

3.Click the icon to search for radio stations. After this button is pressed, the radio will search for radio stations in all bands.

4.Click the icon to switch between long and short range

5.Click the icon to save the radio station. The radio is divided into 5 bands, and each band can save 6 radio stations. The user only needs to press and hold any button in p1-p6 to save the current band frequency under this button. At the same time, you can also click the save button, first click the address that needs to be saved, then adjust the frequency, and click the save button after the frequency is completed.

6.Click the icon edit button, the edit box pops up, click the cursor to edit the station information (Note: this item cannot be empty), press the keyboard finish button after editing, if you want to change the frequency of the station, you can use the left and right FM buttons, and click save after finishing Button.

7.Click the icon to enter the radio setting interface. In the radio setting interface, there is FM sensitivity adjustment. Of course, the premise is that the automatic stop sensitivity is turned on. After setting the FM sensitivity or RDS switch on the radio setting interface, or changing the area, it feels very messy, which is not conducive to us to adjust the radio. We can click the one-key default button to restore to the default setting.

2.5 Set interface

Click the setting icon on the main interface to enter the setting interface



3、Introduction to common app functions

3.1 Equalizer

1.Enter the equalizer interface, the user can enter the sound adjustment mode through EQ, sound field settings, surround sound, stereo enhancement, bass enhancement, and sound filtering. The user can set the preset sound effects or manually adjust the setting values to set the sound effects.



3.2 Steering wheel learning

1.steering wheel button learning

For cars with buttons on the steering wheel, if the buttons support learning, you can customize the function through the steering wheel. The steps are as follows:

The first step is to press and hold the button to be learned on the steering wheel.



The second step is to select the function button to be learned on the machine and press it. Only when a valid number appears below the button (the number indicates the resistance value of the button) can you let go.

The third step is to learn other keys in sequence according to the previous two steps, and click the save button after learning (the same key can only learn one function)

1. Steering wheel-steering wheel button function

Power switch function

Mode key

Navigation function

Volume increase function

Volume down function

Mute function

Previous song function

Next song function

Rewind function

Fast forward function

Answer call function

Hang up function

Save function

Clear function

3.3 File management

File manager interface



You can view and operate all files in the machine in the file manager, and there are file directories that allow selection on the left side of the page. If you need to copy or move a file, just select the file you want to operate, a row of operation buttons will appear at the bottom, select the file directory that needs to be stored, and click the corresponding operation button.

3.4 Touchscreen assistant

1.Show button

The floating button in the touch screen assistant is provided with many shortcuts for operations, through which you can easily perform function jumps. If the user needs to display the floating button, click on the touch screen assistant to enter the page and set the display button options.

2.boot

After setting the floating button to display, by setting the boot options, the floating button will be automatically displayed every time you turn on the device, and you do not need to enter the touch screen assistant to set it every time. For the video interface, navigation and other interfaces need to hide the floating button, you can set the hidden function when using car-related applications.

3.Button size adjustment

In the process of using the touch screen assistant, you can set the button size adjustment to change the size of the floating button, and the user can set it according to personal usage habits .

3.5 music player

1.Music playlist

Enter the main interface of the music player through the application icon on the main interface or the application interface. If there is no playback record, it will jump to the list interface by default.

Song list button, click this button to display all the songs in the car's internal storage and external storage devices.

Folder list button, click this button to display all the folder information containing songs in the internal storage of the car and the external storage device.

Singer list button, click this button to sort and display the songs in the car with the singer information.

Album list button, click this button to sort and display the songs in the car with album information.



2.Introduction to Play Interface Function

Select the song you want to play in the list interface, and click to jump to the play interface. This interface will display some basic information of the currently playing song and commonly used control buttons. The user can achieve the corresponding effect by setting the corresponding button, and at the same time can drag the progress bar of the song to realize the fast forward and fast rewind function.

3.6 Video playback

1. Video playback

The video player can identify all video resources from the machine's internal storage and external storage, and supports playing 3gp, mp4, m4v, flv, f4v, mkv, webm, avi and other common video formats. Unique and simple operation interface,powerful decoding ability and support for high-definition video playback.

2. Video list

In the video list interface, the user can view the corresponding video list by selecting the storage device type on the left. (Note: As shown below, the left picture is the list of videos in the current storage device, and the right picture is the list of video folders in the current storage device)

3.Video playback interface and picture-in-picture

Select the video to be played through the video list interface and jump to the video playback interface. The interface will display the title of the video and the playback progress, etc. You can drag the progress bar to realize the fast forward and rewind function. Touch the screen and the operation interface will automatically hide and emerge, making it easy to watch the video.

Click the picture-in-picture function button, and the video playback interface will be reduced as a whole and then superimposed on other application interfaces. And click the zoom in and full screen button in the upper right corner of the picture-in-picture to select the video size. The picture-in-picture function helps users to watch videos while operating navigation and other applications.



3.7 Picture Preview

1.Picture browsing interface

The picture browsing function can browse all format pictures in the internal

storage and external storage on the car, and can customize the wallpaper.



2.Picture manipulation

Click any picture to enter the browse mode, as shown in the figure below, the picture can be zoomed in and out in this mode, and the function buttons can be hidden and displayed by long pressing the screen. At the same time, it supports the function of moving the picture with the finger and cutting the picture with gestures.



Wallpaper function key: set the currently displayed picture as wallpaper

Previous picture: switch to the previous picture

Play/pause function key: let the picture automatically switch to play

Next picture: switch to the next picture

Rotation function key: rotate the picture

4、Introduction to settings

4.1 WiFi



1. WiFi：Click the main interface settings or application interface settings → WiFi → wifi interface, or you can pull down the menu and long press the wifi button to enter the wifi interface, open wifi, the available wifi resources found nearby will be displayed, select the available wifi name Click Connect.
2. data usage： You can check the data usage, you can also turn on and off the data saving program.
3. SIM info： You can view the SIM card information inserted into the car
4. more： There are mobile network, network sharing portable hotspot, flight mode, VPN function. Users can connect to or set up wifi hotspots through this page.

4.2 Device settings



1. Display: In the display options, the user can set the screen brightness, wallpaper, and automatically enter the black screen function.
2. Sound: In the sound interface, you can set the sound output effect of the machine through touch screen sound, LOUD, power amplifier switch, power, bass, and equalizer options, and users can experience the effect according to actual operation.
3. GPS: GPS information displays the basic information of machine positioning, and supports dual-module display of Beidou and GPS. The automatic synchronization switch can control whether the time of the machine is synchronized with the time of the positioning satellite when the vehicle is positioned.
4. Storage: You can check the usage of the car's memory and external storage space.
5. Apps: In the application options, the user can view the usage of the internal storage space of the application. The user needs to uninstall or stop the installed external program, just find and click the program icon in the downloaded list, and then click the function button that needs to be operated after the interface pops up.
6. USB video output setting: access to the USB cable can output video.

4.3 General settings

General settings can set some basic attributes of the machine, and users can configure functions according to personal habits.



The function is introduced as follows：

1.Press any key to start: click any key on the touch screen to turn on

2.brake wire for video in motion: the video display is controlled by the handbrake status

3.Auto-start navigation: automatically enter the navigation function after booting

4.OSD time : the time can be displayed on the image screen after opening

5.mirror view on reverse image: reversing image is displayed in mirror mode

6.mute audio when reversing: shield other sound output when reversing

7.sound reduction when reversing: Control the sound level of reversing background

8.Backlight control： There are two ways of time control and small light control

9.default volume switch ： Control the power-on default volume setting

10.Power-on default volume: set the default volume value at power-on

11.GPS Mix: control the background sound output when the navigation report

12.Sound Mixing Scale: control the background sound when navigation sound

13.lantern settings： Control the color of the button light on the screen

14.Steering wheel setting: can enter the steering wheel learning interface

15.Navigation application settings: set the called navigation map

16.map data copy:Copy the map data package and install it at the target location

4.4 Factory setting

The factory settings can be configured for the machine functions. Enter the correct pairing password. In order to ensure the normal operation of the machine, it is not recommended that the user change the settings.

4.5 User



1. Location: in the right to use location information option, you can set GPS satellite positioning to obtain your current location information. The GPS satellite positioning function needs to be kept on to ensure the normal use of the navigation function.
2. Security: You can view the device management application, the opening and closing of the fixed screen and other functions.
3. Language and input : You can switch languages and add languages.
4. Backup and reset: You can restore the factory settings, etc. To ensure the normal operation of the machine, it is not recommended that users change the settings.
5. ACC off and delayed power off: You can set the power-off delay time

4.6 System settings



1. Date and time: Set the system time, and generally provide a time mode for automatically acquiring the network.

2. About device: Mainly display basic information of applications, systems and other software in the machine
3. Device Info： You can check the IMEI number of the SIM card slot, etc.

Help--FAQ

1. The Bluetooth of the mobile phone and the Bluetooth of the car cannot be paired and connected?

If the Bluetooth connection fails, you can turn off the phone's Bluetooth, turn it on and search again, and then connect again. If it doesn't work, you can click the reset of the Bluetooth settings. After a few seconds, you can pair and connect.

2.There is no sound from Bluetooth music?

Make sure that the paired mobile phone has volume output.

3. There is no response when you click to download the phone book?

After Bluetooth connection, after clicking download on the phone book, the mobile phone will receive a request to download the contact, confirm and allow the download request to download.

4.The Bluetooth name is not updated after setting?

After the Bluetooth name is set, if it is not updated immediately, please disconnect the Bluetooth and click the pairing connection.

5. No data update at the first time when I plug in SD card or USB in the music player?

After the user plugs in the storage device, the music player will detect and scan the data. If the stored data is relatively large, it may take a while to update (a few seconds to 1 minute). If it is still not updated, please make sure that the storage device is hung up. Upload (check the file browser to see if there is a corresponding storage directory, if there is no directory, please re-plug the card or check the hardware).

6. Song file name shows garbled code?

The song name is not the file name name of the file. If the coding method of the song itself is neither a common format nor a coding method in accordance with the local language, there will be an error in coding display.

FCC warning statements:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.
This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.