14+ AGES

TENSPEED
ITEM NO.9522-4

PROFESSIONAL REMOTE CONTROL HIGH SPEED CARS


INSTRUCTIONS



Dear Customer,
Thank you for your purchase! As long as you contact us by email, there are many promotions to share with you and help you solve the problems. Wishing you good luck every day!

+1 (855) 422-2777


usa@wiaorchi.com (USA) eu@wiaorchi.com (EU)
ca@wiaorchi.com (CA) jp@wiaorchi.com (JP)



4.Charge and Install Rechargeable Battery Pack

(1)a) Insert the USB charger into the outlet (figure 4)
note the power light turns red .
b)Connect the battery pack to the USB charger
(figure 5) note the green light flashs.
c)When charging is completed , green light turns solid.

(Figure 4)



(Figure 5)


7.4V

(2)Loosen the latch of the battery cover on the chassis then remove it (Figure 6).



(Figure6)


(3).Place your fully charged battery in the battery slot. connect the battery connector. Don't force it,it only goes one way (Figure 7)



Power Switch

(Figure7)

(4).Replace the battery cover , tighten the latch (Figure 8)




(Figure8)

5.USB Charger Precautions

⚠ CAUTION


(1).The USB charger does not apply the input current bigger than 2.4A

(2).When input current is bigger than 2.4A, the USB charger will start-up protection mode ,all the lights will turn off.




7.4V

6.Transmitter instructions



A. Power switch and Throttle trim (Push from OFF to 70%, remote control power on, push from 70% to 100%, remote control car from low speed to high speed)
B. Headlight switch
C. Steering trim


1.Forward
2.Brake
3.Left
4.Right
5.Backward



⚠ Notice

- Please note the battery polarities when installing or replacing batteries
- Non- rechargeable batteries can not be charged
- Remove rechargeable battery pack from car before charging
- Do not mix new and old batteries in the transmitter
- Do not mix new and old batteries, or batteries of different types
- Remove batteries from car once they are exhausted
- Keep the car away from water and moisture
- Touching the transmitter antenna while operating the car can affect the remote control distance, broken antennas should be handled by an adult.
- Do not run the car when the battery is low. When moving at high speed, please do not try to break abruptly due to inertia.
- when the car move slowly, it indicates power is low. Please recharge following instructions.
- When charging, please ensure power sockets are connected properly.
- While not used for a long time, please remove batteries from the car and the transmitter.
- Do not charge for more than 8 hours.
- Keep this manual for future reference.





OPERATION

1. ALWAYS turn on your transmitter before you turn on the receiver in the vehicle. Always power off the receiver before turning your transmitter off.






2. ALWAYS operate your vehicle in a wide open area. Operating the vehicle on slippery floor or indoors may crash because of the high speed.

3. WARNING: WATERPROOF FEATURE EXPLAIN
please be cautious that the water should not be over than the body shell. If immersed in water, please take out the body of the truck and cause damage or other related problems. We will not be responsible for such damages. We will not be responsible for any replacements and additional accessories if needed.



4. ALWAYS start with low speed, or the vehicle may slip or turn on curves, (as shown on Pic 1) NEVER operate your vehicle in max speed. Operating the vehicle in highest speed may hurt yourself and damage your vehicle.





MOTOR CARE

- Seat the motor brushes by driving smoothly on a flat surface during use of the first battery charge. Failing to do so can greatly reduce motor performance and functional life.
- Prolong motor life by preventing overheating conditions. Undue motor wear results from frequent turns, stops and starts, pushing objects, driving in deep water and tall grass, and driving continuously up hill.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Short run time	• Battery damaged/not charged • Motor dirty or brushes worn	• Check/change battery • Check/clean/replace
Sluggish action	• Motor dirty or brushes worn • Bind in drivetrain • Vehicle battery is not charged	• Check/clean/replace • Clean/lubricate • Replace/recharge
Do not operate	• Transmitter batteries low • Receiver batteries low • Vehicle battery is not charged	• Replace/recharge • Replace • Replace/recharge
Poor range	• Low transmitter batteries • Receiver antenna damaged	• Replace/recharge • Check/repair/replace
The system will not Connect	• Transmitter and receiver too near each other • Transmitter and receiver too near large metal objects (vehicles, etc.) • Receiver accidentally put in bind mode so receiver is no longer bound	• Move transmitter 6–12 feet (2.4–3.6m) away from receiver • Move away from large metal objects (vehicles, etc.) • Rebind transmitter and receiver
The receiver quits responding During operation	• Low battery voltage	• Completely recharge battery
Receiver loses its bind	• Transmitter accidentally put in bind mode, ending bond to receiver	• Bind transmitter to receiver



CE compliance for Users in the European Union
WEEE Compliance:

Please help the environment by disposing of your product responsibly at the end of its life. The Waste of Electrical and Electronic Equipment(WEEE) Directive (2002/96/EC) requires that the best available recycling techniques be employed to minimize the impact on the environment. Recycling electronics helps by keeping harmful chemicals out of the environment, and also saves money by reusing precious metals. Remove any batteries and dispose of them and the product at your local authority's recycling facility. For more information about where you can drop off your waste equipment for recycling, please contact your local city office, your household waste disposal service or the location where you purchased this product.

Declaration of Conformity for RED Directive
In accordance with IEC 17050-1

This is to certify that the following products conform to the requirements of the RED Directive 2014/53/EU and that all essential test suites have been carried out.

FC CAUTION: FCC PART 15 B Notice

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions,may cause harmful interference to radio communications. However,there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
•Reorient or relocate the receiving antenna.
•Increase the separation between the equipment and receiver.
•Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
•Consult the dealer or experienced radio/TV technician for help.
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and
(2)this device must accept any interference received, including interference that may cause undesired operation.

