G890A_.book Page 1 Thursday, April 30, 2015 10:59 AM

SAMSUNG

M O B I L E P H O N E

Health and Safety and Warranty Guide

Please read this manual before operating your device and keep it for future reference.

Warning! This product contains chemicals known to the State of California to cause cancer and reproductive toxicity. For more information, please call 1-800-SAMSUNG (726-7864).

Intellectual Property

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG Phone, including but not limited to, accessories, parts, or software relating thereto (the "Phone System"), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

Open Source Software

Some software components of this product incorporate source code covered under GNU General Public License (GPL), GNU Lesser General Public License (LGPL), OpenSSL License, BSD License and other open source licenses. To obtain the source code covered under the open source licenses, please visit:

http://opensource.samsung.com.

Disclaimer of Warranties; Exclusion of Liability

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT "AS IS", AND SAMSUNG MAKES NO EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

Modification of Software

SAMSUNG IS NOT LIABLE FOR PERFORMANCE ISSUES OR INCOMPATIBILITIES CAUSED BY YOUR EDITING OF REGISTRY SETTINGS, OR YOUR MODIFICATION OF OPERATING SYSTEM SOFTWARE.

USING CUSTOM OPERATING SYSTEM SOFTWARE MAY CAUSE YOUR DEVICE AND APPLICATIONS TO WORK IMPROPERLY. YOUR CARRIER MAY NOT PERMIT USERS TO DOWNLOAD CERTAIN SOFTWARE, SUCH AS CUSTOM OS.

IF YOUR CARRIER PROHIBITS THIS, IF YOU ATTEMPT TO DOWNLOAD SOFTWARE ONTO THE DEVICE WITHOUT AUTHORIZATION, YOU WILL BE NOTIFIED ON THE SCREEN THAT UNAUTHORIZED SOFTWARE HAS BEEN DETECTED. YOU SHOULD THEN POWER DOWN THE DEVICE AND CONTACT YOUR CARRIER TO RESTORE THE DEVICE TO THE CARRIER AUTHORIZED SETTINGS.

Diagnostic Software

This device is equipped with diagnostic software reporting usage and performance information used solely to deliver improved network quality and overall device experience to AT&T customers. Please refer to your AT&T Wireless Customer Agreement and/or the AT&T Privacy Policy (www.att.com/privacy) for more information.

Samsung KNOX™

Samsung Knox™ is Samsung's security platform and is a mark for a Samsung device tested for security with enterprise use in mind. Additional licensing fee may be required. For more information about Knox, please refer to: www.samsung.com/us/knox. [030115]

Samsung Electronics America (SEA), Inc

Address:
85 Challenger Road
Ridgefield Park,
New Jersey 07660

Phone:
1-800-SAMSUNG (726-7864)

Internet Address:
www.samsung.com

©2015 Samsung Electronics America, Inc. Samsung is a registered trademark of Samsung Electronics Co., Ltd.

Do you have questions about your Samsung Mobile Device?
For 24 hour information and assistance, we offer a new FAQ/ARS System (Automated Response System) at:
www.samsung.com/us/support

Legal Information

Important legal information can be accessed in writing on the mobile device or on samsung.com.
Read this information before using your mobile device.

Samsung Limited Warranty - This product is covered under the applicable Samsung Limited Warranty.
Full written terms and detailed information about the warranty and obtaining service are available on the device at: Settings ➔ About device ➔ Legal Information ➔ Samsung legal or at samsung.com.

The online version of the Health/Safety and Warranty guide for your device can be found at:

English:
www.samsung.com/us/Legal/Phone-HSGuide

Spanish:
www.samsung.com/us/Legal/Phone-HSGuide-SP

Location of Legal Information on the device:

Health and Safety Information

- Settings ➔ About device ➔ Legal information ➔ Samsung legal ➔ Health and Safety

Warranty

- Settings ➔ About device ➔ Legal information ➔ Samsung legal ➔ Warranty

EULA

- Settings ➔ About device ➔ Legal information ➔ Samsung legal ➔ End User License Agreement

Table of Contents

Section 1: Health and Safety Information 2

Specific Absorption Rate (SAR) Certification Information 2
FCC Part 15 Information to User 4
Commercial Mobile Alerting System (CMAS) . . 5
Battery Use and Safety 5
Samsung Mobile Products and Recycling 7
UL Certified Travel Charger 9
GPS & AGPS 10
Emergency Calls 11
FCC Hearing Aid Compatibility (HAC) Regulations for Wireless Devices 12
Restricting Children's Access to Your Mobile Device 15

Section 2: Online Legal Information 16

End User License Agreement for Software . . . 16
Health/Safety and Warranty Guide 16

Section 3: Samsung Product Registration 17

Index 18

Section 1: Health and Safety Information

This section outlines the safety precautions associated with using your phone. The terms “mobile device” or “cell phone” are used in this section to refer to your phone. **Read this information before using your mobile device**.

Note: Water-resistant and dustproof based on IP68 rating, which tests submersion up to 1.5 meters for up to 30 minutes.

This device is capable of operating in Wi-Fi™ mode in the 2.4 and 5 GHz bands. The FCC requires that devices operating within 5.15-5.25 GHz may only be used indoors, not outside, in order to avoid interference with Mobile Satellite Services (MSS). Therefore, this device is restricted from being used outdoors when operating in frequencies between 5.15-5.25 GHz.

Specific Absorption Rate (SAR) Certification Information

Your wireless device is a radio transmitter and receiver. It is designed and manufactured not to exceed the exposure limits for Radio Frequency (RF) energy set by the Federal Communications Commission (FCC) of the U.S. Government.

These FCC RF exposure limits are derived from the recommendations of two expert organizations: the National Council on Radiation Protection and Measurement (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

The RF exposure limit set by the FCC for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate (SAR). The SAR is a measure of the rate of absorption of RF energy by the human body expressed in units of watts per kilogram (W/kg). The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg).

The FCC SAR limit incorporates a substantial margin of safety to give additional protection to the public and to account for any variations in measurements.

SAR tests are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum reported value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output of the device.

Before a new device is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the SAR limit established by the FCC. Tests for each model phone are performed in positions and locations (e.g. at the ear and worn on the body) as required by the FCC. For body-worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the mobile device a minimum of 1.5 cm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. The FCC has granted an Equipment Authorization for this mobile device with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines.

This device has a FCC ID number: A3LSMG890A [Model Number: SM-G890A] and the specific SAR levels for this device can be found at the following FCC website:www.fcc.gov/oet/ea/.

The SAR information for this device can also be found on Samsung's website: www.samsung.com/sar.

SAR information on this and other model devices can be accessed online on the FCC's website through http://transition.fcc.gov/oet/rfsafety/sar.html. To find information that pertains to a particular model, this site uses the device FCC ID number which is usually printed somewhere on the case of the device. Sometimes it may be necessary to remove the battery pack to find the number. Once you have the FCC ID number for a particular device, follow the instructions on the website and it should provide values for typical or maximum SAR for a particular phone. Additional SAR information can also be obtained at www.fcc.gov/encyclopedia/specific-absorption-rate-sar-cellular-telephones.

FCC Part 15 Information to User

Pursuant to part 15.21 of the FCC Rules, you are cautioned that changes or modifications not expressly approved by Samsung could void your authority to operate the device.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Commercial Mobile Alerting System (CMAS)

This device is designed to receive wireless emergency alerts from the Commercial Mobile Alerting System ("CMAS"; which may also be known as the Personal Localized Alerting Network ("PLAN")). If your wireless provider has chosen to participate in CMAS/PLAN, alerts are available while in the provider's coverage area. If you travel outside your provider's coverage area, wireless emergency alerts may not be available. For more information, please contact your wireless provider.

Battery Use and Safety

The battery in your device is not intended to be replaced by the consumer. If you believe the battery is damaged or needs to be replaced, take the device to a service center for inspection and replacement.

- **Do not let the device or battery come in contact with liquids**. Liquids can get into the device's circuits, leading to corrosion. Even when the device appears to be dry and appears to operate normally, the circuitry could slowly corrode and pose a safety hazard. If the device and/or battery get wet, have them checked by your service provider or contact Samsung, even if they appear to be working properly.
- **Do not place your battery in or near a heat source**. Excessive heating can damage the device or the battery and could cause the device or the battery to explode. Do not dry a wet or damp battery with an appliance or heat source such as a microwave oven, hair dryer, iron, or radiator. Avoid leaving your device in your car in high temperatures.
- **Caution: Some applications or prolonged usage may increase device temperature.** Prolonged skin contact with a device that is hot to the touch may produce skin discomfort or redness, or low-temperature burns. If the device feels hot to the touch, discontinue use and close all applications or turn off the device until it cools. Always ensure that the device has adequate ventilation and air flow. Covering the device with bedding, your body, thick clothing or any other materials that significantly affect air flow may affect the performance of the device and poses a possible risk of fire or explosion, which could lead to serious bodily injuries or damage to property.
- **Do not dispose of the device or the battery in a fire**. The device or the battery may explode when overheated.
- **Avoid dropping the device**. Dropping the device, especially on a hard surface, can potentially cause damage to the device. If you suspect damage to the device or battery, take it to a service center for inspection.
- **Never use any charger or battery that is damaged in any way**.

Important! Use only Samsung-approved batteries, and recharge your battery only with Samsung-approved chargers which are specifically designed for your device.

WARNING!

Use of a non-Samsung-approved battery or charger may present a risk of fire, explosion, leakage, or other hazard. Samsung's warranty does not cover damage to the device caused by non-Samsung-approved batteries and/or chargers.

- **Do not use incompatible batteries and chargers**. Some websites and second-hand dealers not associated with reputable manufacturers and carriers, might be selling incompatible or even counterfeit batteries and chargers. Consumers should purchase manufacturer or carrier-recommended products and accessories. If unsure about whether a replacement battery or charger is compatible, contact the manufacturer of the battery or charger.
- **Misuse or use of incompatible batteries and charging devices could result in damage to the equipment and a possible risk of fire, explosion, or leakage, leading to serious injuries, damages to your device, or other serious hazard**.

Samsung Mobile Products and Recycling

Samsung cares for the environment and encourages its customers to recycle Samsung mobile devices and genuine Samsung accessories.

Proper disposal of your mobile device and its battery is not only important for safety, it benefits the environment.

Batteries must be recycled or disposed of properly.

Note: Dispose of unwanted electronics through an approved recycler.

We've made it easy for you to recycle your old Samsung mobile device by working with respected take-back companies in every state in the country.

Drop It Off

You can drop off your Samsung-branded mobile device and batteries for recycling at one of our numerous Samsung Recycling Direct (SM) locations.

To find the nearest recycling location, go to: www.samsung.com/recyclingdirect or call 1-877-278-0799.

Samsung-branded devices and batteries will be accepted at these locations for no fee.

Mail It In

The Samsung Mobile Take-Back Program will provide Samsung customers with a free recycling mailing label.

For more information about recycling your device, go to: https://pages.samsung.com/recycling/index.jsp or call 1-800-822-8837 and follow the instructions to print out a free pre-paid postage label and then send your old mobile device or battery to the address listed, via U.S. Mail, for recycling.

Consumers may also recycle their used mobile device or batteries at many retail or carrier-provided locations where mobile devices and batteries are sold. Additional information regarding specific locations may be found at: www.epa.gov/epawaste/conserve/materials/ecycling/donate.htm or at www.call2recycle.org/.

Follow local regulations regarding disposal of mobile devices and batteries

Dispose of your mobile device and batteries in accordance with local regulations. In some areas, the disposal of these items in household or business trash may be prohibited. Help us protect the environment - recycle!

Warning! Never dispose of batteries in a fire because they may explode.

UL Certified Travel Charger

The Travel Charger for this mobile device has met applicable UL safety requirements. Please adhere to the following safety instructions per UL guidelines:

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE.

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS.

DANGER - TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, CAREFULLY FOLLOW THESE INSTRUCTIONS.

FOR CONNECTION TO A SUPPLY NOT IN NORTH AMERICA, USE AN ATTACHMENT PLUG ADAPTOR OF THE PROPER CONFIGURATION FOR THE POWER OUTLET. THIS POWER UNIT IS INTENDED TO BE CORRECTLY ORIENTED IN A VERTICAL OR HORIZONTAL OR FLOOR MOUNT POSITION.

GPS & AGPS

Certain Samsung mobile devices can use a Global Positioning System (GPS) signal for location-based applications. A GPS uses satellites controlled by the U.S. Government that are subject to changes implemented in accordance with the Department of Defense policy and the 2008 Federal Radio navigation Plan (FRP). Changes may affect the performance of location-based technology on your mobile device.

Certain Samsung mobile devices can also use an Assisted Global Positioning System (AGPS), which obtains information from the cellular network to improve GPS performance. AGPS uses your wireless service provider's network and therefore airtime, data charges, and/or additional charges may apply in accordance with your service plan. Contact your wireless service provider for details.

Your Location

Location-based information includes information that can be used to determine the approximate location of a mobile device. Mobile devices which are connected to a wireless network transmit location-based information. Additionally, if you use applications that require location-based information (e.g. driving directions), such applications transmit location-based information. The location-based information may be shared with third-parties, including your wireless service provider, applications providers, Samsung, and other third-parties providing services.

Use of AGPS in Emergency Calls

When you make an emergency call, the cellular network may activate AGPS technology in your mobile device to tell the emergency responders your approximate location.

AGPS has limitations and **might not work in your area**. Therefore:

- Always tell the emergency responder your location to the best of your ability; and
- Remain on the mobile device for as long as the emergency responder instructs you.

Navigation

Maps, directions, and other navigation-data, including data relating to your current location, may contain inaccurate or incomplete data, and circumstances can and do change over time. In some areas, complete information may not be available. **Therefore, you should always visually confirm that the navigational instructions are consistent with what you see before following them. All users should pay attention to road conditions, closures, traffic, and all other factors that may impact safe driving or walking. Always obey posted road signs**.

Emergency Calls

This mobile device, like any wireless mobile device, operates using radio signals, wireless and landline networks, as well as user-programmed functions, which cannot guarantee connection in all conditions, areas, or circumstances.

Therefore, you should never rely solely on any wireless mobile device for essential communications (medical emergencies, for example). Before traveling in remote or underdeveloped areas, plan an alternate method of contacting emergency services personnel. Remember, to make or receive any calls, the mobile device must be switched on and in a service area with adequate signal strength.

Emergency calls may not be possible on all wireless mobile device networks or when certain network services and/or mobile device features are in use. Check with local service providers. If certain features are in use (call blocking, for example), you may first need to deactivate those features before you can make an emergency call. Consult your User Manual and your local cellular service provider. When making an emergency

call, remember to give all the necessary information as accurately as possible. Remember that your mobile device may be the only means of communication at the scene of an accident; do not cut off the call until given permission to do so.

To make an emergency call:

1. If the mobile device is not on, switch it on.
2. Open your phone dialer.
3. Enter the emergency number for your present location (for example, 911 or other official emergency number), then tap Call/Send. Emergency numbers vary by location.

FCC Hearing Aid Compatibility (HAC) Regulations for Wireless Devices

The U.S. Federal Communications Commission (FCC) has established requirements for digital wireless mobile devices to be compatible with hearing aids and other assistive hearing devices.

When individuals employing some assistive hearing devices (hearing aids and cochlear implants) use wireless mobile devices, they may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and mobile devices also vary in the amount of interference they generate.

The wireless telephone industry has developed a rating system for wireless mobile devices to assist hearing device users find mobile devices that may be compatible with their hearing devices. Not all mobile devices have been rated. Mobile devices that are rated have the rating on their box or a label located on the box.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated mobile

device successfully. Trying out the mobile device with your hearing device is the best way to evaluate it for your personal needs.

M-Ratings: Wireless mobile devices rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than mobile devices that are not labeled. M4 is the better/higher of the two ratings. M-ratings refer to enabling acoustic coupling with hearing aids that do not operate in telecoil mode.

T-Ratings: Mobile devices rated T3 or T4 meet FCC requirements and are likely to generate less interference to hearing devices than mobile devices that are not labeled. T4 is the better/higher of the two ratings. T-ratings refer to enabling inductive coupling with hearing aids operating in telecoil mode.

Hearing devices may also be rated. Your hearing aid manufacturer or hearing health professional may help you find this rating. Higher ratings mean that the hearing device is relatively immune to interference noise.

Under the current industry standard, American National Standards Institute (ANSI) C63.19, the hearing aid and wireless mobile device rating values are added together to indicate how usable they are together. For example, if a hearing aid meets the M2 level rating and the wireless mobile device meets the M3 level rating, the sum of the two values equals M5.

Under the standard, this should provide the hearing aid user with normal use while using the hearing aid with the particular wireless mobile device. A sum of 6 or more would indicate excellent performance.

However, these are not guarantees that all users will be satisfied. T ratings work similarly.



The HAC rating and measurement procedure are described in the American National Standards Institute (ANSI) C63.19 standard.

HAC for Newer Technologies

This phone has been tested and rated for use with hearing aids for some of the wireless technologies that it uses. However, there may be some newer wireless technologies used in this phone that have not been tested yet for use with hearing aids.

It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Consult your service provider or the manufacturer of this phone for information on hearing aid compatibility. If you have questions about return or exchange policies, consult your service provider or phone retailer.

Caution! Some applications or prolonged usage may increase device temperature. Prolonged skin contact with a device that is hot to the touch may produce skin discomfort or redness, or low-temperature burns. If the device feels hot to the touch, discontinue use and close all applications or turn off the device until it cools. Always ensure that the device has adequate ventilation and air flow. Covering the device with bedding, your body, thick clothing or any other materials that significantly affect air flow may affect the performance of the device and poses a possible risk of fire or explosion, which could lead to serious bodily injuries or damage to property.

Restricting Children's Access to Your Mobile Device

Your mobile device is not a toy. Do not allow children to play with it because they could hurt themselves and others, damage the mobile device, or make calls that increase your mobile device bill.

Keep the mobile device and all its parts and accessories out of the reach of small children.

Section 2: Online Legal Information

SAMSUNG ELECTRONICS AMERICA, INC. (“SAMSUNG”) warrants that SAMSUNG’s devices and accessories (“Products”) are free from defects in material and workmanship under normal use and service.

Samsung Electronics America, Inc.

85 Challenger Road

Ridgefield Park, New Jersey 07660

Phone: 1-800-SAMSUNG (726-7864)

End User License Agreement for Software

The EULA for this device can be found:

- Online at: www.samsung.com/us/Legal/SamsungLegal-EULA4.

Health/Safety and Warranty Guide

The online version of the Health/Safety and Warranty guide for your device can be found at:

English: www.samsung.com/us/Legal/Phone-HSGuide.

Spanish: www.samsung.com/us/Legal/Phone-HSGuide-SP.

G890A_.book Page 17 Thursday, April 30, 2015 10:59 AM

Sign Up Now

Customize your Samsung device experience

- Activate product warranty
- Access to a personalized My Samsung Mobile account
- No monthly fees

Get More

- Latest info on promotions, events and special offers on related products
- Review Samsung products and share your opinion
- Great deals on downloads

Register now at
www.samsung.com/register

Scan this code to go
directly to the registration page.

SAMSUNG
mobile

Index

B

Battery Use & Safety 5

C

Commercial Mobile Alerting System (CMAS) 5

E

Emergency Calls 11

F

FCC Hearing Aid Compatibility (HAC) Regulations for Wireless Devices 12

G

GPS & AGPS 10

H

Health and Safety Information 2

O

Online Legal Information 16

P

Personal Localized Alerting Network (PLAN) 5

R

Restricting Children's Access to Your Mobile device 15

S

Samsung Mobile Products and Recycling 7

Specific Absorption Rate (SAR) Certification Information 2

U

UL Certified Travel Charger 9

This document is watermarked because certain important information in the document has not yet been verified.
This document has been sent to you as a draft and for informational purposes only.
The document should only be used for internal purposes and may not be distributed outside of the company.
Distributing the document outside of the company could result in legal exposure to the company if the preliminary, unverified information in the draft turns out to be inaccurate.

SAMSUNG

Galaxy S6® active™

SMARTPHONE

User Manual

Please read this manual before operating your device
and keep it for future reference.

DRAFT
FOR INTERNAL USE O

SAMSUNG

Legal Notices

Warning: This product contains chemicals known to the State of California to cause cancer and reproductive toxicity. For more information, please call 1-800-SAMSUNG (726-7864).

Intellectual Property

All Intellectual Property, as defined below, owned by or which is otherwise the property of Samsung or its respective suppliers relating to the SAMSUNG Phone, including but not limited to, accessories, parts, or software relating there to (the "Phone System"), is proprietary to Samsung and protected under federal laws, state laws, and international treaty provisions. Intellectual Property includes, but is not limited to, inventions (patentable or unpatentable), patents, trade secrets, copyrights, software, computer programs, and related documentation and other works of authorship. You may not infringe or otherwise violate the rights secured by the Intellectual Property. Moreover, you agree that you will not (and will not attempt to) modify, prepare derivative works of, reverse engineer, decompile, disassemble, or otherwise attempt to create source code from the software. No title to or ownership in the Intellectual Property is transferred to you. All applicable rights of the Intellectual Property shall remain with SAMSUNG and its suppliers.

Open Source Software

Some software components of this product incorporate source code covered under GNU General Public License (GPL), GNU Lesser General Public License (LGPL), OpenSSL License, BSD License and other open source licenses. To obtain the source code covered under the open source licenses, please visit: http://opensource.samsung.com.

Disclaimer of Warranties; Exclusion of Liability

EXCEPT AS SET FORTH IN THE EXPRESS WARRANTY CONTAINED ON THE WARRANTY PAGE ENCLOSED WITH THE PRODUCT, THE PURCHASER TAKES THE PRODUCT "AS IS", AND SAMSUNG MAKES NO EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT, INCLUDING BUT NOT LIMITED TO THE MERCHANTABILITY OF THE PRODUCT OR ITS FITNESS FOR ANY PARTICULAR PURPOSE OR USE; THE DESIGN, CONDITION OR QUALITY OF THE PRODUCT; THE PERFORMANCE OF THE PRODUCT; THE WORKMANSHIP OF THE PRODUCT OR THE COMPONENTS CONTAINED THEREIN; OR COMPLIANCE OF THE PRODUCT WITH THE REQUIREMENTS OF ANY LAW, RULE, SPECIFICATION OR CONTRACT PERTAINING THERETO. NOTHING CONTAINED IN THE INSTRUCTION MANUAL SHALL BE CONSTRUED TO CREATE AN EXPRESS OR IMPLIED WARRANTY OF ANY KIND WHATSOEVER WITH RESPECT TO THE PRODUCT. IN ADDITION, SAMSUNG SHALL NOT BE LIABLE FOR ANY DAMAGES OF ANY KIND RESULTING FROM THE PURCHASE OR USE OF THE PRODUCT OR ARISING FROM THE BREACH OF THE EXPRESS WARRANTY, INCLUDING INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES, OR LOSS OF ANTICIPATED PROFITS OR BENEFITS.

Modification of Software

SAMSUNG IS NOT LIABLE FOR PERFORMANCE ISSUES OR INCOMPATIBILITIES CAUSED BY YOUR EDITING OF REGISTRY SETTINGS, OR YOUR MODIFICATION OF OPERATING SYSTEM SOFTWARE.

USING CUSTOM OPERATING SYSTEM SOFTWARE MAY CAUSE YOUR DEVICE AND APPLICATIONS TO WORK IMPROPERLY. YOUR CARRIER MAY NOT PERMIT USERS TO DOWNLOAD CERTAIN SOFTWARE, SUCH AS CUSTOM OS.

DRAFT
FOR INTERNAL USE ONLY

IF YOUR CARRIER PROHIBITS THIS, IF YOU ATTEMPT TO DOWNLOAD SOFTWARE ONTO THE DEVICE WITHOUT AUTHORIZATION, YOU WILL BE NOTIFIED ON THE SCREEN THAT UNAUTHORIZED SOFTWARE HAS BEEN DETECTED. YOU SHOULD THEN POWER DOWN THE DEVICE AND CONTACT YOUR CARRIER TO RESTORE THE DEVICE TO THE CARRIER AUTHORIZED SETTINGS.

Samsung KNOX™

Samsung Knox is Samsung's security platform and is a mark for a Samsung device tested for security with enterprise use in mind. Additional licensing fee may be required. For more information about Knox, please refer to: www.samsung.com/us/knox. [030115]

Samsung Electronics America (SEA), Inc.

Address:

85 Challenger Road
Ridgefield Park,
New Jersey 07660

Phone:
1-800-SAMSUNG (726-7864)

Internet Address:
www.samsung.com

©2015 Samsung Electronics America, Inc.
Samsung, Galaxy, Multi window, and S Health are registered trademarks of Samsung Electronics Co., Ltd.

Do you have questions about your Samsung Mobile Device?

For 24 hour information and assistance, we offer a new FAQ/ARS System (Automated Response System) at: www.samsung.com/us/support

The actual available capacity of the internal memory is less than the specified capacity because the operating system and default applications occupy part of the memory. The available capacity may change when you upgrade the device.

Nuance®, VSuite™, T9® Text Input, and the Nuance logo are trademarks or registered trademarks of Nuance Communications, Inc., or its affiliates in the United States and/or other countries.

The Bluetooth® word mark, figure mark (stylized "B Design"), and combination mark (Bluetooth word mark and "B Design") are registered trademarks and are wholly owned by the Bluetooth SIG.

Google, the Google logo, Android, the Android logo, Google Play, Gmail, Google Maps, Google Music, Google Hangouts, Picasa, Play Newsstand, YouTube, and other marks are trademarks of Google Inc.

Wi-Fi is a registered trademark of the Wireless Fidelity Alliance, Inc.

LTE is a trademark of ETSI.

Swype and the Swype logos are trademarks of Swype, Inc.

Devices purchased for use on AT&T's system are designed for use exclusively on AT&T's system. You agree that you won't make any modifications to the Equipment or programming to enable the Equipment to operate on any other system. A voice plan is required on all voice-capable devices, unless specifically noted otherwise in the terms governing your agreement. Some devices or plans may require you to subscribe to a data plan.

Your phone is designed to make it easy for you to access a wide variety of content. For your protection, AT&T wants you to be aware that some applications that you enable may involve the location of your phone being shared. For applications available through AT&T, AT&T offers privacy controls that let you decide how an application may use the location of your phone and other phones on your account. However, AT&T's privacy tools do not apply to applications available outside of AT&T. Please review the terms and conditions and the associated privacy policy for each location-based service to learn how location information will be used and protected.

DRAFT
FOR INTERNAL USE ONLY

Your phone may be used to access the Internet and to download, and/or purchase goods, applications, and services from AT&T or elsewhere from third parties. AT&T provides tools for you to control access to the Internet and certain Internet content. These controls may not be available for certain devices which bypass AT&T controls.

AT&T may collect certain types of information from your device when you use AT&T services to provide customer support and to improve its services. For more information on AT&T's Privacy Policy, visit www.att.com/privacy.

Online Legal Information

The online version of the Health/Safety and Warranty guide for your device can be found at:

English
www.samsung.com/us/Legal/Phone-HSGuide

Spanish
www.samsung.com/us/Legal/Phone-HSGuide-SP

The online version of the **End User Licensing Agreement** for your device can be found online at: www.samsung.com/us/Legal/SamsungLegal-EULA4.

DRAFT
FOR INTERNAL USE ONLY

Table of Contents

Getting Started 1
- Front View 2
- Back View 3
- Assemble Your Device 4
- Set Up Your Device 6
- Set Up Accounts on Your Device 7

Know Your Device 8
- Home Screen 9
- Status Bar 12
- Navigation, Motions, and Gestures 13
- Notification Panel 14
- Multi Window 15
- Enter Text 17

Calling 19
- Make and Answer Calls 20

Applications 24
- Apps Screen 25
- Google Applications 27
- AT&T Applications 29
- Other Applications 31
- Activity Zone 33
- Calculator 34
- Calendar 35
- Camera and Video 37
- Clock 40
- Contacts 41
- Email 44
- Galaxy Apps 45
- Gallery 46
- Internet 48
- Memo 50
- Messages 51
- Music Player 53
- My Files 54
- S Health 56
- S Voice 57
- Video Player 58
- Voice Recorder 59

Settings 60
- How to Use Settings 61
- Wi-Fi Settings 62
- Bluetooth 64
- Airplane Mode 66
- Mobile Hotspot and Tethering 67
- Data Usage 69
- Mobile Networks 70
- NFC and Payment 71
- More Connection Settings 72
- Sounds and Notifications 74
- Display Settings 77
- Motions and Gestures 79
- Applications Settings 80
- Wallpaper Settings 82
- Themes 83
- Lock Screen and Security 84
- Privacy and Safety 88
- Easy Mode 90
- Accessibility 91
- Accounts 93
- Backup and Reset 94
- Language and Input Settings 95

DRAFT
FOR INTERNAL USE ONLY

Battery 97
Storage 98
Date and Time Settings 99
Help 100
About Your Device 101

DRAFT
FOR INTERNAL USE ONLY

Getting Started

Learn about your mobile device hardware, assembly procedures, and how to get started using your new device.

DRAFT
FOR INTERNAL USE ONLY

Front View

- **Back**: Tap to return to the previous screen, or to close a dialog box, menu, or keyboard.
- **Earpiece**: Listen to a call.
- **Front camera**: Take self-portraits and record videos of yourself.
- **Home key**: Tap to return to the Home screen.
- **Proximity and gesture sensors**: Detects the presence of objects near the device.
- **Recent apps**: Tap to display recent apps or touch and hold for home screen options.
- **Power/Lock key**: Press and hold to turn the device on or off. Press to lock or wake up the screen. Press and hold to turn the device off or restart it, or for quick access to Airplane Mode and Emergency Mode.
- **Status light**: Displays red when charging or the battery is low, blue when a notification has arrived or you are voice recording, and green when fully charged.
- **Volume keys**: Press to adjust the volume of your device's sounds and audio.

DRAFT
FOR INTERNAL USE ONLY

Back View

- **Back camera**: Take pictures and record videos.
- **Flash**: Illuminate subjects in low-light environments when taking a photo or recording video.
- **Headset jack**: Connect an optional headset (not included).
- **Heart rate sensor**: When using the S Health app, this sensor measures your heart rate via your fingertip.
- **Infrared transmitter**: Controls external devices using infrared light.
- **Microphone**: Records audio and detects voice commands.
- **SIM tray**: The tray that holds the SIM card. For more information, see Install the SIM Card.
- **Speaker**: Plays music and other sounds.
- **USB charger/Accessory port**: Connect the Charger/USB cable (included), and other optional accessories (not included).

DRAFT
FOR INTERNAL USE ONLY

Assemble Your Device

This section helps you to assemble your device.

Install the SIM Card

When you subscribe to a cellular network, you are provided with a plug-in SIM card. During activation, your SIM card will be loaded with your subscription details, such as your PIN, available optional services, and other features.

Warning: Please be careful when handling the SIM card to avoid damaging it. Keep all SIM cards out of reach of small children.

1. Carefully pull the SIM card tray out of the slot.
2. Place the SIM card on the tray, and slide the tray back into the slot.

   Make sure that the card's gold contacts face down into the device and that the card is positioned as shown.

Caution: If the card is not inserted correctly, the device will not detect the SIM card. Re-orient the card and place it back into the slot if the SIM is not detected.

Charge the Battery

Note: For fastest charging times, use the Adaptive Fast Charging charger that came with your phone. This charger provides faster charging only when connected to devices that support Adaptive Fast Charging.

Caution: Use only Samsung-approved charging devices. Samsung accessories are designed to maximize battery life. Using other accessories may invalidate your warranty and may cause damage.

1. Insert the USB 2.0 cable into the port.

2. Connect the USB cable to the charging head, and then plug the charging head into a standard outlet.
3. When charging is complete, unplug the charging head from the outlet and remove the USB cable from the device.

DRAFT
FOR INTERNAL USE ONLY

When to Charge the Battery

When the battery is weak and only a few minutes of operation remain, the device sounds a warning tone at regular intervals.

In this condition, your device conserves its remaining battery power by dimming the screen.

When the battery level becomes too low, the device automatically turns off.

► For a quick check of your battery level, view the battery charge indicator located in the upper-right corner of your device's display. A solid color ( ) indicates a full charge.

You can also choose to display a percentage value. Viewing a percentage value can provide a better idea of the remaining charge on the battery. For more information, see Battery.

DRAFT
FOR INTERNAL USE ONLY

Set Up Your Device

Turn Your Device On or Off

Turn the Device On

► Press and hold the **Power/Lock** key until the device vibrates and starts up.

Turn the Device Off

1. Press and hold the **Power/Lock** key until the device vibrates and the Device options menu displays.
2. Tap **Power off**.
3. On the window that appears, tap **POWER OFF**.

Configure Your Phone

When you first turn on your phone, you will need to set up a few things.

1. As each screen is displayed, follow the instructions on each screen to set up that particular feature.
2. Tap **NEXT**, **SKIP**, or **LATER** to progress to the next screen.

Secure Your Device

Use your device's screen lock features to secure your device.

Lock the Device

By default, the device locks automatically when the screen times out.

► To lock the device, press the **Power/Lock** key.

Unlock the Device

The default Screen lock on your device is Swipe.

► To unlock your device, press the **Power/Lock** key or **Home** key, and then touch and drag your finger across the screen.

Set Up a Secure Screen Lock

The default Screen lock is Swipe, which offers no security. To choose a more secure screen lock, see Set a Screen Lock.

DRAFT
FOR INTERNAL USE ONLY

Set Up Accounts on Your Device

Google Account

Your new device uses your Google Account to fully utilize its Android features, including Gmail, Google Hangouts, and the Google Play store.

When you turn on your device for the first time, set up your existing Google Account, or create a new Google Account.

– or –

To create a new Google Account or set up your Google Account on your device at any time, use Accounts settings. For more information, see Accounts.

► From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab > **Accounts** > **Add account** > **Google**.

Samsung Account

Create a Samsung account for access to Samsung content and apps on your device. When you turn on your device for the first time, set up your existing Samsung account, or create a new Samsung account.

– or –

To create a new Samsung account or set up your Samsung account on your device at any time, use Accounts settings. For more information, see Accounts.

► From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab > **Accounts** > **Add account** > **Samsung account**.

DRAFT
FOR INTERNAL USE ONLY

Know Your Device

Learn some of the key features of your mobile device, including the screens and icons, as well as how to navigate the device and enter text using the keyboard.

Warning: Please note that a touch screen responds best to a light touch from the pad of your finger or a non-metallic stylus. Using excessive force or a metallic object when pressing on the touch screen may damage the tempered glass surface and void the warranty.

DRAFT
FOR INTERNAL USE ONLY

Home Screen



- **Apps folder**: For your convenience, there are several applications that are grouped into a folder on the main Home screen.
- **Apps screen**: Allows quick access to all of your applications.
- **App shortcuts**: Shortcuts to your favorite applications.
- **Home screen indicator**: Indicates which Home screen is presently displayed. Swipe across the screen to the right to open My Magazine.
- **Notification icons**: Display new messages and emails, notifications, available software updates, and so on.
- **Status Bar**: Displays device status icons (right) and notification icons (left).
- **Status icons**: Display information about the device, such as the network signal strength, battery level, the time, and so on.
- **Widget**: Self-contained application that run on the Home screen (not shortcuts).

DRAFT
FOR INTERNAL USE ONLY

The Home screen is the starting point for using your device.

Customize your Home screen by adding application shortcuts, widgets, folders, and using wallpapers.

Manage Home Screens

Your device comes with multiple Home screens to hold apps and widgets. You can rearrange the Home screens in a different order.

1. From a Home screen, pinch the screen.

   – or –

   Touch and hold an empty space on the screen.

2. Use these options to manage screens:

   - **Add a screen**: Scroll to the end of the screens, and then tap **Add**.
   - **Remove a screen**: Touch and hold on a screen, and then drag it to **Remove**.
   - **Set a screen as the main Home screen**: Tap **Main Home screen** at the top of a screen. This screen displays when you press the Home Key.
   - **Change the order of screens**: Touch and hold on a screen, and then drag to a new position.
   - **Flipboard Briefing**: Scroll to the left of the screens to find the Flipboard Briefing screen. To activate this feature, tap the checkbox at the top center of the screen.

Wallpapers

Change the look of the Home and Lock screens with wallpaper. You can display a favorite picture or choose from preloaded wallpapers.

1. From a Home screen, pinch the screen.

   – or –

   Touch and hold an empty space on the screen.

2. Tap **Wallpapers**.

For details on viewing and changing wallpapers, see Wallpaper Settings.

To access Wallpaper settings:

► From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab > **Wallpaper**.

Widgets

Widgets are self-contained apps that run on a Home screen. There are all kinds of widgets, including links to a specific contact, Internet bookmarks, Gmail and email accounts, and many others.

Add a Widget to a Home Screen

1. From a Home screen, pinch the screen.

   – or –

   Touch and hold an empty space on the screen.

2. Tap **Widgets**.

3. Touch and hold a widget, drag it to a Home screen, and then release it.

Remove a Widget

1. From a Home screen, touch and hold a widget to release it.

2. Drag the widget to **Remove** and release it.

Note: Removing a widget does not delete the widget, it just removes the widget from the Home screen.

DRAFT
FOR INTERNAL USE ONLY

Themes

Set visual themes for all system screens and icons on your phone.

1. From a Home screen, pinch the screen.

   – or –

   Touch and hold an empty space on the screen.

2. Tap **Themes**.

For details on viewing and changing themes, see Themes.

To access Theme settings:

► From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab > **Themes**.

Screen Grid

Change the number of icons that can be placed on each Home screen by changing the Screen grid dimensions.

1. From a Home screen, pinch the screen.

   – or –

   Touch and hold an empty space on the screen.

2. Tap **Screen grid**.
3. Tap a dimension option to preview its appearance. The numbers indicate how many icons can be placed horizontally by how many icons can be placed vertically.
4. Tap **APPLY** to apply the selected dimensions.

App Shortcuts

You can use app shortcuts to launch an app from any Home screen.

Add a Shortcut to a Home Screen

1. From a Home screen, tap **Apps**.
2. Touch and hold an app shortcut, drag it to a Home screen, and then release it.

Remove a Shortcut

1. Touch and hold an app shortcut to release it.
2. Drag the app shortcut to **Remove** and release it.

Note: Removing a shortcut does not delete the app, it just removes the shortcut from the Home screen.

Folders

Place folders on a Home screen to organize items.

Create a Folder

You can create app folder on a Home screen.

1. Touch and hold an app icon and drag it on top of another app until a highlighted box appears.
2. Release the app icon to create the folder.
3. Tap **Enter folder name** to enter a name for the folder.
4. Tap the **Palette** icon to change the color (if desired).
5. Tap anywhere outside of the folder to close it.
6. To add more apps, touch an hold an app icon and drag it to the folder.

Remove a Folder from a Home Screen

1. Touch and hold the folder until it detaches.
2. Drag the folder to **Remove** and release it.

DRAFT
FOR INTERNAL USE ONLY

Status Bar

The Status Bar at the top of the Home screen provides device information (such as network status, battery charge, and time) on the right side and notification alerts on the left.

Status Icons	
	Battery is fully charged.
	Battery is low.
	Battery is charging.
	Vibrate mode is enabled.
	Mute mode is enabled.
4G LTE	The device is connected to a 4G LTE wireless network.
	Signal strength.
	Wi-Fi is active.
	No wireless network is available.
	NFC (Near-Field Communication) is enabled.

Notification Icons	
	Missed call.
	Call in progress.
	Call is on hold.
	Call is using speakerphone.
	New email has arrived.
	New Gmail has arrived.
	New voicemail message has been received.
	New text or multimedia message has arrived.
	Download of a file or app is in progress.
	File is being uploaded or sent.
	Location service (GPS) is active.
	App updates are available from the Google Play store.
	App updates are complete.
	Keyboard is in use.

DRAFT
FOR INTERNAL USE ONLY

Navigation, Motions, and Gestures

Touchscreen Navigation

Tap

Lightly tap items to select or launch them.

- Tap the on screen keyboard to enter characters or text.
- Tap an item to select it.
- Tap an app icon to launch the application.

Touch and Hold

Activate onscreen items by a touch and hold gesture.

- Touch and hold a widget on the Home screen to move it.
- Touch and hold a field to display a pop-up menu of options.

Swipe or Slide

To swipe, lightly drag your finger vertically or horizontally across the screen.

- Swipe the screen to unlock the device.
- Swipe the screen to scroll through the Home screens or menu options.

Drag

To drag, touch and hold on an item, and then move it to a new location.

- Drag an app shortcut to add it to a Home screen.
- Drag a widget to place it in a new location on a Home screen.

Pinch and Spread

Pinch the screen using your thumb and forefinger or spread by moving your fingers apart.

- Pinch or spread the screen to zoom in or out while viewing a picture or a web page.
- Pinch or spread the screen to zoom in or out while taking a picture.

Motions and Gestures

Control your device by making specific gestures with your hand above the device's screen. For details, see Motions and Gestures.

To access the Motions and Gestures settings:

► From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Motions and Gestures**.

DRAFT
FOR INTERNAL USE ONLY

Notification Panel



Notification icons on the Status Bar display calendar events, device status, and more. For details, open the Notification Panel.

View the Notification Panel

1. Swipe down on the Status Bar to display the Notification Panel.
2. Scroll down the list to see notification details.
   - Tap an item to open it.
   - To clear a single notification, drag the notification left or right. Tap **Clear** to clear all notifications.
3. To close the Notification Panel, swipe upward from the bottom of the screen or tap **Back**.

Quick Settings

In addition to notifications, the Notification Panel also provides quick access to device functions such as Wi-Fi, allowing you to quickly turn them on or off.

To view additional Quick settings:

► On the Notification Panel, swipe left or right across the visible icons.

To customize the Quick settings that appear:

► On the Notification Panel, tap **EDIT**.

DRAFT
FOR INTERNAL USE ONLY

Multi Window



Multitask by using multiple applications at the same time.

Activate Multi Window

Apps that support Multi window display together on a split screen. You can switch between the apps, adjust the size of their display on the screen, and copy information from one app to the other.

Note: Multi window is not available for all apps.

1. From any screen, touch and hold **Recent apps**.
2. If you are currently using an app that supports Multi window, tap an app to add in split screen, or tap two new apps to open in split view.

You can also launch recently used apps directly into Multi window view:

1. Tap the **Recent apps** key.
2. Recently used apps that support Multi window have a **Multi window** icon in the title bar. Tap the Multi window icon in the title bar to launch the application in Multi window view.
3. Other recently used apps that support Multi window appear below the launched app. Tap the app icon to add it to the Multi window view.

Note: Only applications that support Multi window have the Multi window icon.

DRAFT
FOR INTERNAL USE ONLY

Window Controls

Select an application window and tap the **Border button** in the middle of the window border.

Control Buttons	
	Switch windows: Switch locations between Multi window applications.
	Drag and drop content: Move items between the application windows. Drag an item to share from one window to another. Some applications may not support this feature.
	Minimize window: Minimize the selected app window. This turns the app into a circular, movable icon that can be opened by tapping on it.
	Maximize window: Open the selected window in full screen view.
	Close app: Close the selected application.

DRAFT
FOR INTERNAL USE ONLY

Enter Text

Use the Samsung Keyboard

Type your text input using a QWERTY keyboard.



Special Keys	
Sym	Tap to insert numbers and symbols.

Touch and hold the **Options** key to:

	Use Google Voice Typing.
	Access the clipboard.
	Insert emoticons.
	Change the layout of the keyboard.
	Access keyboard settings.

Predictive Text

Predictive text suggest words matching your text entries, and, optionally, completes common words automatically. Predictive text can learn your personal writing style from your contacts, messages, email, and social networking sites—improving its accuracy of predicting your text entries.

Configure the Samsung Keyboard

To customize the Samsung Keyboard:

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab > **Language and input**.
2. Tap **Samsung keyboard** for options.

Using Google Voice Typing

Instead of typing, speak your text input.



1. On the Samsung Keyboard, tap **Google voice typing**. You may need to touch and hold the **Options** key (left of the **Space** key) to find it.
2. Speak your text.

Configure Google Voice Typing

To customize Google Voice Typing:

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab > **Language and input**.
2. Tap **Google voice typing** for options.

DRAFT
FOR INTERNAL USE ONLY

Use Swype

Swype is a text input method that makes it possible to enter a word by sliding your finger or stylus from letter to letter, lifting your finger between words.



Enable and Configure Swype

To enable the Swype keyboard while entering text:

1. Touch the top of the screen and swipe downward to display the Notification Panel.
2. Tap **Select keyboard**.
3. Tap **Swype**.

Configure Swype

To customize Swype:

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab > **Language and input**.
2. Tap **Swype** for options.

DRAFT
FOR INTERNAL USE ONLY

Calling

Make telephone calls using a variety of calling features and services.

DRAFT
FOR INTERNAL USE ONLY

Make and Answer Calls

Learn how to make or answer a call. Explore features and functionality associated with making or answering a call.

Make a Call

1. From a Home screen, tap **Phone**.
2. Enter a number on the keypad and tap **Dial**.

Note: If the keypad does not appear, tap the **Keypad** icon.

Quickly Dial a Number from Your Contact List

1. From a Home screen, tap **Apps** > **Contacts**.

   – or –

   From a Home screen, tap **Phone** > **CONTACTS** tab.
2. While viewing your contact list, swipe your finger across a contact to the right call the contact.

Dial a Recent Number

All incoming, outgoing, and missed calls are recorded in the Call log. If the number or caller is listed in your contacts list, the associated name is also displayed.

1. From a Home screen, tap **Phone**.
2. Tap **LOG**. A list of recent calls is displayed.
3. Tap an entry, and then tap **Call**.

End a Call

► When you are ready to end your call, tap **End**.

Answer a Call

When a call is received the phone rings and displays the caller's phone number, or name if stored in the contacts list.

► At the incoming call screen:

- Touch and drag **Answer** to the right to answer the call.
- Touch and drag **Reject** to the left to reject the call and send it to your voicemail.
- Touch and drag **REJECT CALL WITH MESSAGE** upward, and select a message.

If you are using an app, a popup screen appears for the incoming call.

► On the incoming call popup screen:

- Tap **Answer** to answer the call.
- Tap **Reject** to reject the call and send it to your voicemail.
- Tap **REJECT CALL WITH MESSAGE** and select a message.
- Tap **Expand** to exit the app and view the main incoming call screen.

DRAFT
FOR INTERNAL USE ONLY

Multitask While On a Call

If you exit the call screen and return to a Home screen, your active call is indicated by **Active call** on the Status Bar.

This lets you continue with your current call and do something else, such as access the contacts list, view a recent email, locate a picture, and so on.

To return to the call screen:

► Swipe the Status Bar downward to reveal the Notification Panel, and then tap the Call notification.

To end a call from any application:

► Swipe the Status Bar downward to reveal the Notification Panel, and then tap **End call**.

Options During a Call

Your phone provides a number of functions that you can use during a call.

Adjust the Call Volume

► Press the **Volume Key** to increase or decrease the volume.

– or –

Quickly add more volume to the incoming audio by tapping **Extra volume**.

Listen with the Speaker or Bluetooth Headset

Listen to the call using the speaker or through a Bluetooth headset (not included).

► Tap **Speaker** to hear the caller using the speaker.

– or –

Tap **Bluetooth** to use a Bluetooth headset (not included).

Place a New Call While On a Call

If your service plan supports this feature, you can make another call while a call is in progress.

1. From the active call, tap **Add call** to dial the second call.
2. Dial the new number and tap **Dial**. When the call is answered:
   - Tap **Swap** to switch between the two calls.
   - Tap **Merge** to hear both callers at once (multi conferencing).

Call Waiting

If your service plan supports this feature, you can answer an incoming call while you have a call in progress. You are notified of an incoming call by a call waiting tone.

To answer a new call while you have a call in progress:

1. Slide **Answer** in any direction to answer the new call.
2. Tap an option:
   - **Put [caller] on hold** to place the previous caller on hold while you answer the new incoming call.
   - **Merge with [caller]** to add the new caller to the current call.
   - **End call with [caller]** to end the previous call and answer the new call.
3. Tap the previous **On hold number entry** and select **Swap** to switch between the two calls. This places the new caller on hold and activates the previous call.

DRAFT
FOR INTERNAL USE ONLY

Call Log

The numbers of the calls you have dialed, received, or missed are stored in the Call log.

1. From a Home screen, tap **Phone**.
2. Tap **LOG**. A list of recent calls is displayed. If the caller is in your contacts list, the caller's name is displayed.

Save a Recent Call to Your Contacts List

1. From a Home screen, tap **Phone** > **LOG**.
2. Tap the call that contains the information that you want to save to your contacts list.
3. Tap **CREATE CONTACT**.

   – or –

   If you want to replace the number for an existing contact, tap **UPDATE EXISTING**.

Delete a Call from the Call Log

1. From a Home screen, tap **Phone** > **LOG**.
2. Touch and hold the call you want to delete from the Call log.
3. Tap **DELETE**.

Add a Call to the Reject List

By adding a caller to your Reject list, future calls from this number will be sent directly to your voicemail.

1. From a Home screen, tap **Phone** > **LOG**.
2. Tap the caller you want to add to the Reject list.
3. Tap **MORE** > **Add to Auto reject list**.

Use Speed Dial to Make a Call

You can assign a shortcut number to a contact for speed dialing their default number.

To make a call using Speed Dial:

1. From a Home screen, tap **Phone** > **Keypad**.
2. Touch and hold the Speed dial number.

   If the Speed dial number is more than 1 digit long, enter the first digits, then hold the last digit.

Create a Speed Dial

1. From a Home screen, tap **Apps** > **Phone** > **CONTACTS**.
2. Tap **MORE** > **Speed dial**. The Speed dial screen displays showing the numbers 1 through 100. Number 1 is reserved for voicemail.
3. Tap an unused number (**Add contact**).
4. Tap a contact to assign to the number.
   The selected contact displays in the Speed dial number box.

To remove a Speed Dial number assignment:

1. From a Home screen, tap **Apps** > **Phone** > **CONTACTS**.
2. Tap **MORE** > **Speed dial**.
3. Find the contact to remove from Speed dial and tap **Remove**.

DRAFT
FOR INTERNAL USE ONLY

Make an Emergency Call

The Emergency calling mode makes redialing an emergency number a one-tap process.

Note: This mode can drain your battery power more rapidly than normal calling mode.

Make an Emergency Call without a SIM Card

Without a SIM card, you can only make an emergency call with the phone; normal cell phone service is not available.

1. From a secured Lock screen, tap **EMERGENCY CALL**.
2. Enter **911** and tap **Dial**.
3. Complete your call. During this type of call, you will have access to the Speaker mode, Keypad, and End Call features.

Make an Emergency Call with a SIM Card

1. From a Home screen, tap **Phone**.
2. Enter the emergency number (such as 911), then tap **Dial**.

Call Settings

To access the Call settings menu:

► From a Home screen, tap **Phone** > **MORE** > **Settings**.

– or –

From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Applications** > **Phone**.

DRAFT
FOR INTERNAL USE ONLY

Applications

The Apps screen displays all applications installed on your device, both preloaded apps and apps you download and install yourself.

Learn how to change the way apps appear, organize apps into folders, and uninstall or disable apps.

DRAFT
FOR INTERNAL USE ONLY

Apps Screen

The Apps screen shows all preloaded apps and apps that you downloaded. You can uninstall, disable, or hide apps from view.

Shortcuts to apps can be placed on any of the Home screens. For more information, see Add a Shortcut to a Home Screen.

Access Applications

1. From a Home screen, tap **Apps**.
2. Tap an application's icon to launch it.
3. To return to the main Home screen, press the **Home** key.

Download and Install New Apps

Find new apps to download and install on your device:

- **Play Store**: Download new apps from the Google Play store. Visit play.google.com/store/apps to learn more.
- **Galaxy Apps**: View and download Samsung apps that are optimized for use with Galaxy devices. Visit apps.samsung.com to learn more.

Uninstall or Disable Apps

You can uninstall or disable apps you download and install.

- Preloaded apps cannot be uninstalled.
- Apps that are disabled are turned off and hidden from view.

1. From a Home screen, tap **Apps**.
2. Tap **EDIT**. Apps that can be uninstalled or disabled show **Remove** on their icon.
3. Tap **Remove** and follow the prompts to either uninstall or disable the app.
4. When you are finished, tap **DONE**.

Organize Your Apps

The Apps icons can be organized into folders and rearranged in your own custom order.

Change the Order Apps Are Listed

1. From a Home screen, tap **Apps**.
2. Tap **EDIT**.
3. Touch and hold an app icon or folder and drag it to the location you want.
4. Tap **DONE** when finished.

To arrange apps in alphabetical order:

► From a Home screen, tap **Apps** > **A-Z**.

DRAFT
FOR INTERNAL USE ONLY

Use Folders to Organize Apps

1. From a Home screen, tap **Apps** > **EDIT**.
2. Touch and hold an app icon and drag it on top of another app until a highlighted box appears.
3. Release the app icon to create the folder.
   - Tap **Enter folder name** to name the folder.
   - Tap the **Palette** icon to change the color (if desired).
4. Tap anywhere outside of the folder to close it.
   - To add more apps, touch an hold an app icon and drag it to the folder.
5. Tap **DONE** when you are finished.

DRAFT
FOR INTERNAL USE ONLY

Google Applications

Enjoy these applications from Google.

Note: Certain applications require a Google account. Visit google.com to learn more.

Chrome

Use Google Chrome to browse the Internet and bring your open tabs, bookmarks, and address bar data from your computer to your mobile device.

Drive

Open, view, rename, and share your Google Docs and files.

Gmail

Send and receive email with Gmail, Google's web-based email service.

Google

Search not only the Internet, but also the apps and contents of your device.

Google Now

Google Now works in the background to collect information you regularly look up and organize it into convenient cards that appear when you need them.

► Press and hold the **Home** key.

Note: When Google Now is enabled, you can also access it by touching .

Google Settings

Quickly and easily change Google app settings to suit your preferences.

Note: You must be signed in to the application you want to configure. For example, sign in to Google+ to configure Google+ settings.

Google+

Stay connected and share with Google+. Chat with friends and family, post photos, and see what others are sharing.

Hangouts

Hangouts is an online place to meet friends and family, share photos, and host video calls. Conversation logs are automatically saved to a Chats area in your Gmail account.

Maps

Use Google Maps to find your current location, get directions, and other location-based information.

Note: You must enable location services to use Maps. See Location.

Photos

This application automatically backs up your photos and videos to your Google+ account.

Play Books

With Google Play Books, you can find millions of free e-books and hundreds of thousands more to buy in the eBookstore.

DRAFT
FOR INTERNAL USE ONLY

Play Games

Discover hundreds of games for download and purchase through the Google Play store.

Play Movies & TV

Watch movies and TV shows purchased from Google Play. You can stream them instantly, or download them for viewing when you are not connected to the Internet. You can also view videos saved on your device.

Play Music

With Google Play Music, you can play music and audio files on your device.

Play Newsstand

Subscribe to your favorite magazines to read on your device at your leisure.

Play Store

Find new apps, movies and TV shows, music, books, magazines, and games in Google Play store.

Voice Search

Use voice commands to search the web with Google.

YouTube

View and upload YouTube videos right from your device.

DRAFT
FOR INTERNAL USE ONLY

AT&T Applications

Enjoy these applications from AT&T.

Note: Certain applications require a data plan or paid subscription. Visit att.com to learn more, or contact your service provider for additional information.

AT&T FamilyMap

AT&T FamilyMap provides peace of mind by being able to conveniently locate a family member from your wireless device or PC and know that your family's location information is secure and private.

FamilyMap requires a paid subscription. Visit att.com/familymap for more information or contact your AT&T Customer Service Representative.

AT&T Live

Access *AT&T Live/Yahoo!* on the Internet.

AT&T Locker

AT&T Locker allows you to store, share, and sync all of your photos, videos, and documents in one safe, convenient place: the AT&T cloud.

AT&T Mail

Instantly get your mail anytime, anywhere. Read, respond to, and organize your messages quickly, whether you are at home or on the go.

AT&T Mobile Locate

With the AT&T Mobile Locate app you can access the Mobile Protection Pack and with a paid subscription, replace your phone if it is lost or damaged, locate your phone if it is lost, and receive backup and phone support.

In order to take advantage of the AT&T Mobile Locate application, you must purchase the Mobile Protection Pack within 30 days of purchase/activation of a new device. For more information, see att.com/mpp.

AT&T Navigator

AT&T Navigator provides you with access to real-time GPS-driven applications. These programs not only allow you to achieve turn-by-turn navigation, but also access local searches.

Note: You must have a data plan to use this feature. These services require the purchase of a subscription.

AT&T Ready2Go

AT&T Ready2Go allows you to quickly and easily setup your device by using the web browser on your PC. You can set-up email accounts, import contacts, set wallpaper, configure Wi-Fi and many more features.

AT&T Smart Wi-Fi

With AT&T Smart Wi-Fi, you can maximize your battery performance, simplify access to AT&T Hot Spots and Wi-Fi networks, automate your Wi-Fi connections, and track your data use.

DRAFT
FOR INTERNAL USE ONLY

Caller Name ID

Subscribe to Caller Name ID to identify unknown callers by name, picture, city, and state.

Caller Name ID requires a subscription.

Device Help

Device Help provides online information to help with your device questions.

Digital Life

Help protect and manage your home from your phone.

DriveMode

With the AT&T DriveMode application, you can set your phone to auto reply when you are driving and do not want to answer the phone. You can auto reply to messages, emails, and phone calls. You can also allow up to five of your contacts to contact you while using DriveMode.

Mobile TV

Mobile TV is a subscription service that allows you to watch your favorite TV shows using your handset.

myAT&T

The myAT&T application allows you to manage your AT&T account. You can review and pay your bill, check minutes and data usage, upgrade to a new device, or change your plan.

Smart Limits

Smart Limits is a family smartphone manager that helps you set limits on purchases and texts, block data and phone numbers, and view phone activity.

Usage Manager

This is a shortcut to your Data usage settings for managing your mobile data usage.

For more information, see Data Usage.

Visual Voicemail

Use Visual Voicemail to review and manage your voicemail messages directly from your phone without dialing into voicemail. You can also see a list of your messages on your phone and select which ones you want to play, call back, share, delete, or save.

DRAFT
FOR INTERNAL USE ONLY

Other Applications

Amazon

Shop at Amazon.com from your device.

Games

Play full version games for free. Use Wild Coins to rent or buy games and in-game items. Enjoy new games every week.

Hancom Office 2014

Opens and manages Hancom Office Hanword (*.hwp) and Hanshow (*.show) documents.

Keeper

Keeper is a secure password manager for your device and work seamlessly across your mobile phones, tablets, computers, and web browsers.

Lookout

Lookout Mobile Security provides key security options, such as anti-virus and anti-malware technology, a lost and stolen device locater service, an application privacy adviser, and a backup service.

Milk

Exclusive to Galaxy owners, Milk Music is a radio service that gives you more of the music you love, curated by top DJs and industry pros and all for free.

Milk Video

Exclusive to Galaxy owners, Milk Video helps you discover and share the most talked about videos.

OneNote

You can stay organized using text, pictures, or audio notes. Create Quick Notes or review and edit shared OneNote notebooks using OneDrive.

Skype

Use free Skype to hold video and voice calls, as well as send instant messages to anyone around the world. Just open the app and start using it.

Smart Remote

Smart Remote lets you control select Wi-Fi-enabled Samsung TV models using your Samsung Galaxy device. Now you can control all of your TV's settings, such as ON/OFF function, channel navigation, and volume control from the same Samsung device you already know.

DRAFT
FOR INTERNAL USE ONLY

Uber

An entirely new and modern way to travel is at your fingertips. Uber is your private driver in more than 130 cities and 30 countries.

YP

The Yellow Pages Mobile application provides quick and ready access to businesses, map locations, and storage of your favorite searches. Use YP to touch into local businesses, locations, and events, and connect to your search in real-time.

DRAFT
FOR INTERNAL USE ONLY

Activity Zone

Enjoy the outdoors even when you only have one hand free.

With a compass, a stopwatch, and more, Activity Zone makes being outside easier.

To launch all your outdoor activity-related features, all on one application screen:

1. Press the **Active** key on the side of your device.

   – or –

   From a Home screen, tap **Apps** > **Activity Zone**.

   The Activity Zone screen is displayed.

2. Follow the onscreen instructions to use each feature. The following features are available:

   - **Weather**: View weather conditions for you current location or a selected location.
   - **Barometer**: Displays your elevation and atmospheric pressure
   - **Compass**: Displays the compass heading that your device is pointing to and also your latitude and longitude.
   - **Flashlight**: Allows you to use your device as a flash light. You can also set it to blink and adjust the brightness.
   - **Stopwatch**: Allows you to use your device as a stopwatch. You can also set multiple lap times.

3. Tap **MORE** for more options.

DRAFT
FOR INTERNAL USE ONLY

Calculator

The Calculator provides basic and advanced arithmetic functions.

Basic Operation

1. From a Home screen, tap **Apps** > **Calculator**.
2. Enter the first number using the numeric keys.
3. Tap the appropriate arithmetic function key.
4. Enter the next number.
5. To view the result, tap the **Equals** key.

Additional Functions

To clear the results:

► Tap **Clear**.

To clear the calculator history:

► Tap **HISTORY** > **CLEAR HISTORY**.

Tip: Tap **KEYPAD** to return to the calculator keys.

To copy all or part of the calculation to the clipboard:

► Touch and hold an entry in the display field.

Scientific Calculator

Turn the device landscape to use advanced arithmetic functions, such as *sin*, *cos*, and *tan*.

DRAFT
FOR INTERNAL USE ONLY

Calendar

Manage your calendar events and tasks.

Create an Event

1. From a Home screen, tap **Apps** > **Calendar**.
2. Tap **Add** to add an event.
3. Enter details for the event, and then tap **SAVE**.

Delete an Event

1. From a Home screen, tap **Apps** > **Calendar**.
2. Tap an event to view it, and then tap **DELETE**, and then confirm by tapping **DELETE**.

   – or –

   Touch and hold an event, tap **Delete**, and then confirm by tapping **DELETE**.

Share an Event

1. From a Home screen, tap **Apps** > **Calendar**.
2. Tap an event to view it.
3. Tap **SHARE** and tap a sharing format.
4. In the **Share as** window, tap a sharing method and follow the prompts.

Create a Task

Tasks are items you add to the calendar to be accomplished on a certain day. A task appears as a checklist item and is removed once you mark the task as complete.

1. From a Home screen, tap **Apps** > **Calendar**.
2. Tap the drop down menu in the top left corner (by default, the Month and Year are shown) and tap **Tasks**.
3. Tap the **Enter new task** field to enter a new task.
4. You can choose to set the task for **TODAY**, **TOMORROW**, or tap the **Expand** icon to view and set the following options:
   - **Due date**: Tap the **ON/OFF** switch to select a date on the calendar for the task.
   - **Reminder**: Tap to set a reminder alert.
   - **Notes**: Tap to save a note with your task.
   - **Priority**: Tap to assign a priority to the task.
5. Tap **SAVE** to save the task.

Delete a Task

1. From a Home screen, tap **Apps** > **Calendar**.
2. Tap a day on the calendar to view the tasks for the day, or select **Tasks** from the drop down menu.
3. Tap the checkbox by the task to mark it as complete and remove it from the calendar.
4. To delete the task permanently, tap the task to open it, and then tap **DELETE**.

DRAFT
FOR INTERNAL USE ONLY

Calendar Settings

These settings allow you to modify settings associated with using the Calendar.

1. From a Home screen, tap **Apps** > **Calendar**.
2. Tap **MORE** > **Settings**.
3. Tap an option and follow the prompts.

DRAFT
FOR INTERNAL USE ONLY

Camera and Video



Take Pictures

Take pictures with your device's front or back camera, or combine shots with Dual mode.

1. From a Home screen, tap **Apps** > **Camera**.

Note: You can also press the **Home** key twice from any screen to access the Camera if Quick Launch is enabled.

2. Using the display screen as a viewfinder, compose your shot by aiming the camera at the subject. While composing your picture, use the onscreen options or these gestures:
   - Touch the screen with two fingers and pinch or spread them on the screen to zoom in and out.
   - Tap the screen to focus on the area you touched.
3. If desired, before taking the photo, you can touch onscreen icons to access various camera options and settings. You can also touch the screen to move the focus field to the area you touch.
4. Tap to take the picture.

Note: You can also press the **Volume** key up or down to take a picture. This is the default action of the Volume key. You can also set the Volume key to act as the video record key or as a zoom key.

DRAFT
FOR INTERNAL USE ONLY

Shooting Mode

Several visual effects are available. Modes differ by which camera is active (front or rear facing).

1. From a Home screen, tap **Apps** > **Camera**.
2. Tap **MODE** to view the following options. Each section indicates which camera (front or rear) the modes are available for.

Rear camera

- **Auto**: Allow the camera to evaluate the surroundings and determine the ideal mode for the picture.
- **Pro**: Manually adjust the ISO sensitivity, exposure value, white balance, and color tone while taking pictures.
- **Selective focus**: Change the focus of pictures after they have been taken. You can focus on subjects near to the camera, far away from the camera, or both.
- **Panorama**: Create a linear image by taking pictures in either a horizontal or vertical direction.
- **Slow motion**: Record videos at a high frame rate for viewing in slow motion. You can play a specific section of each video in slow motion after recording it.
- **Fast motion**: Record videos for viewing in fast motion. You can play a specific section of each video in fast motion after recording it.
- **Sports**: Take clearer pictures of fast moving subjects.
- **Aqua**: Take pictures underwater.
- **Tag shot**: Provide environment information of picture.

Front camera

- **Selfie**: Take selfie shots and apply various effects, such as an airbrushed effect.
- **Wide selfie**: Take wide-angle selfie shots to fit more people into your pictures.
- **Interval shot**: Select the best pictures from a series of continuous shots taken at set intervals.

Both cameras

- **Virtual shot**: Create multi-directional views of objects.
- **Download**: Download additional shooting modes from the Galaxy Apps store.

Camera Settings

1. From a Home screen, tap **Apps** > **Camera**.
2. Quick settings are listed across one side of the camera view finder. Available options vary depending on the camera or recording mode used. Default settings include:
   - **Flash**: Activate or deactivate the flash (back camera only).
   - **Beauty**: Take a picture with lightened faces for gentler images (front camera only).
   - **Timer**: Take time-delayed pictures or videos.
   - **HDR (rich tone)**: Save the picture in HDR (rich tone) only.
   - **Effects**: Add special graphical effects.
3. Tap **Settings** to configure settings for Camera. Available options vary depending on the camera/recording mode used.

Rear camera

- **Tracking AF**: Focus on and track a subject selected on the preview screen.

Front camera

- **Gesture control**: Detect palm and automatically take a picture two seconds later.
- **Save as horizontally flipped**: Save the self-portrait or self-recording as a reversed (or 'mirrored') image.

Both cameras

- **Picture size**: Select a resolution. Use higher resolution for higher quality. Higher resolution pictures take up more memory.
- **Video size**: Select a resolution. Use higher resolution for higher quality. Higher resolution videos take up more memory.

DRAFT
FOR INTERNAL USE ONLY

- **Video stabilization**: Activate anti-shake. Anti-shake helps to keep the focus steady when the camera is moving.
- **Grid lines**: Display viewfinder grid lines to help composition when selecting subjects.
- **Location tags**: Attach a GPS location tag to the picture.
- **Review pictures**: Set to show pictures after taking them.
- **Quick launch**: Open camera by pressing the Home key twice in quick succession.
- **Voice control**: To take pictures say smile, cheese, capture, or shoot. To record videos, say Record video.
- **Volume keys function**: Use the Volume key as the camera key, the record key, or as a zoom key.
- **Shutter sound**: Enable or disable a shutter sound when pictures are taken.
- **Reset settings**: Reset the camera settings.
- **Help**: View information on using the camera.

DRAFT
FOR INTERNAL USE ONLY

Clock

The Clock app offers features for keeping track of time and setting alarms.

1. From a Home screen, tap **Apps** > **Clock**.
2. Tap a tab to use a feature:
   - **Alarm**: This feature allows you to set an alarm to ring at a specific time.
   - **World Clock**: View the time of day or night in other parts of the world. World Clock displays time in hundreds of different cities, within all 24 time zones around the world.
   - **Stopwatch**: You can use this option to measure intervals of time.
   - **Timer**: You can use this option to set a countdown timer. Use a timer to count down to an event based on a preset time length (hours, minutes, and seconds).

Create an Alarm

Create an alarm event. You can set one-time or recurring alarms, and choose options for how to be notified.

1. From a Home screen, tap **Apps** > **Clock**.
2. Tap the following items to configure an alarm:
   - **Date**: Choose the day for this alarm.
   - **Time**: Set a time for the alarm.
   - **Repeat**: Choose when to repeat the alarm, if so desired.
   - **OPTIONS**: Tap to view and set the following options:
     - **Alarm type**: Choose whether the alarm will use sound, vibration, or vibration and sound to alert you.
     - **Volume**: If you have chosen an alarm type that includes sound, drag the slider to set the volume of the alarm.
     - **Alarm tone**: If you have chosen an alarm type that includes sound, choose a sound to play for the alarm.
     - **Snooze**: Allow snoozing, and set interval and repeat values for the alarm while snoozing.
     - **Increasing volume**: When on, the alarm will start playing a tone at a low volume at an interval before the alarm time, and slowly increase in volume. Available when you have chosen an alarm type that includes sound.
     - **Alarm name**: Enter a name for the alarm.
3. Tap **SAVE** to save the alarm.

Delete an Alarm

1. From a Home screen, tap **Apps** > **Clock**.
2. Find the alarm in the alarm list (under the **Alarm** tab), and then tap **Delete** in the upper right corner of the alarm entry.

DRAFT
FOR INTERNAL USE ONLY

Contacts

Store and manage your contacts with the Contacts app, which can be synchronized with a variety of your existing personal accounts, including Google, Email, Facebook, and your Samsung account.

For more information on connecting with and managing your accounts through your device, see Accounts.

Note: The Contacts app is different from the CONTACTS tab in the Phone app. Although both list the contacts in your phone and accounts, the available options and functions are different.

Manage Contacts

Access your list of contacts by using the Contacts app. To access your Contacts list:

► From a Home screen, tap **Apps** > **Contacts**.

Find a Contact

You can search for a contact, or scroll the list to find one by name.

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap the **Search** field, and then enter characters to find contacts that match.

   – or –

   Tap a letter on the side of the list to jump directly to that letter in the alphabetical list. You can also press and slide across the alphabetical list to select a letter with better precision.

Add a Contact

Use the following procedure to add a new contact.

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap **Add**, and then tap contact fields to enter information.
   - Choose a storage account for the contact. You can store the contact on the device, your SIM card, or sync it with an account.
   - Tap **Contact photo** to assign a picture to the new contact.
   - Enter a name, phone number, email address, assign the contact to a group, and assign a ringtone. Tap **ADD ANOTHER FIELD** to add additional contact information.
     - Tap **Add** to enter additional entries.
     - Tap **Remove** to remove an entry.
     - Tap **Expand** for additional fields.
     - Tap the label to the right of an entry to choose a label for the field (for example, **Home** or **Work**).
3. Tap **SAVE**.

Edit a Contact

When editing a contact, you can tap a field and change or delete the information, or you can add additional fields to the contact's list of information.

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap the contact to display it, and then tap **EDIT**.
3. Tap any of the fields to add, change, or delete information.
4. Tap **SAVE**.

DRAFT
FOR INTERNAL USE ONLY

Share a Name Card

When you share a name card, the contact's information is sent as a vCard file (.vcf). You can share a vCard via Bluetooth or Wi-Fi Direct, attach it to a message, or save it to a storage location.

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap a contact to display it, and then tap **MORE** > **Share name card**.
3. Choose a sharing method and follow the prompts.

Link Contacts

When you have contacts from various sources (Gmail, Facebook, and so on), you may have multiple similar entries for a single contact. Contacts lets you link multiple entries into a single contact.

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap the contact to display it, and then tap **Link**.
3. Tap **LINK ANOTHER CONTACT**, and then select contact(s) to link to the original contact.
4. Tap **LINK**.

Unlink Contacts

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap the contact to display it, and then tap **Link**.
3. Tap **Remove** beside contacts to unlink them from the main contact.

Delete Contacts

You can delete a single contact, or choose multiple contacts to delete.

1. From a Home screen, tap **Apps** > **Contacts**.
2. Touch and hold a contact to select it. You can also tap other contacts, or tap the checkbox at the top of the screen to select all.
3. Tap **DELETE**.

Favorites

When you mark contacts as favorites, they are easily accessible from other apps. Favorites display together on the Favorites tab in Contacts.

Mark Contacts as Favorites

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap a contact to display it, and then tap **Favorite** (the star turns gold).

Remove Contacts from Favorites

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap a contact to display it, and then tap **Favorite** (the star loses the gold color).

Groups

You can use groups to organize your contacts. Your device comes with preloaded groups, and you can create your own. You might create a group for your family, for coworkers, or a team. Groups make it easy to find contacts, and you can send messages to the members of a group.

Create a Group

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap **GROUPS**, and then tap **ADD**.
3. Tap fields to enter information about the group:
   - Tap **Create group in [location]** to choose where to save the group. You can save it to a specific account, to the device memory, or to all accounts. Tap the entries to select or deselect them.
   - Tap **Group name** to enter a name for the new group.
   - Tap **Add member** and select contact(s) to add to the new group, and then tap **DONE**.
   - Tap **Group ringtone** to assign a ringtone to members of the group.
4. Tap **SAVE**.

DRAFT
FOR INTERNAL USE ONLY

Rename a Group

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap **GROUPS**, and then tap a group.
3. Tap **MORE** > **Edit group** and enter a new name.
4. Tap **SAVE**.

Add Contacts to a Group

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap **GROUPS**, and then tap a group.
3. Tap **ADD**, and then tap the contacts you want to add.
4. Tap **DONE**.

Send a Message or an Email to a Group

You can send a text message or an email to members of a group.

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap **GROUPS**, and then tap a group.
3. Tap **MORE** > **Send message or email**.
4. Tap either **Message** or **Email**.
5. Tap contacts to select them, or tap the **selected** checkbox at the top of the screen to select all, and then tap **DONE**. You will only see group members that have the appropriate contact information (a phone number or an email address) in their records.
6. For email, choose an account and follow the prompts.

Delete a Group

Preset groups, such as Family, cannot be deleted.

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap **GROUPS**.
3. Tap **DELETE**.
4. Tap the group category to open.
5. Tap the groups to select them or tap the **Select group** checkbox at the top of the screen to select all
6. Tap **DELETE**.

Contact Settings

These settings allow you to modify settings associated with using the Contacts app.

1. From a Home screen, tap **Apps** > **Contacts**.
2. Tap **MORE** > **Settings**.
3. Tap an option and follow the onscreen instructions.

DRAFT
FOR INTERNAL USE ONLY

Email

Use the Email app to view and manage all your email accounts in one application.

To access Email:

► From a Home screen, tap **Apps** > **Email**.

Configure Email Accounts

You can configure Email for most accounts in just a few steps.

1. From a Home screen, tap **Apps** > **Email**.
2. Follow the onscreen instructions to set up your email account.

   – or –

   For additional accounts, tap **MORE** > **Settings** > **Add account**.

The device communicates with the appropriate server to set up your account and synchronize your email. When complete, your email appears in the Inbox for the account.

Note: To configure email account settings at any time, tap **MORE** > **Settings**. Tap the email account to manage to display its settings.

Manage Your Email Accounts

You can view email you receive for all accounts on the **Combined view** screen or you can view email accounts individually.

1. From a Home screen, tap **Apps** > **Email**.
2. Tap the drop down menu at the top left of the screen to view the current account mailbox.
3. Tap on the account name to view:
   - **Combined view**: View all email in a combined inbox.
   - [**Account Name**]: View email for only one email account.

Delete Email Accounts

To delete an Email account:

1. From a Home screen, tap **Apps** > **Email**.
2. Tap **MORE** > **Settings**.
3. Tap the account you want to remove.
4. Tap **REMOVE**. Confirm by tapping **REMOVE** on the prompt.

Email Settings

These settings allow you to modify settings associated with using the Email app.

1. From a Home screen, tap **Apps** > **Email**.
2. Tap **MORE** > **Settings**.
3. Tap an option and follow the onscreen instructions.

DRAFT
FOR INTERNAL USE ONLY

Galaxy Apps

Samsung Galaxy Apps is a free storefront that provides a quick and easy way to find and download apps that are compatible with your Galaxy device.

Galaxy Essentials is a collection of specially chosen applications available through Samsung Apps.

From Galaxy Essentials, you can access and download a collection of premium content, free of charge.

To access the Samsung Galaxy Apps website:

► From a Home screen, tap **Apps** > **Galaxy Apps**.

To access Galaxy Essentials:

1. Swipe across the Galaxy Apps screen and then tap **Galaxy Essentials**.

   – or –

   Swipe across the Home screens and locate and tap the Galaxy Essentials widget.

2. Follow the onscreen instructions to download Galaxy Essentials apps specially chosen from Samsung Apps.

Note: A Samsung account is required to purchase and download apps.

DRAFT
FOR INTERNAL USE ONLY

Gallery

View, edit, and manage pictures and videos.

Note: Some functions described in this section are only available if there are images or videos in the Gallery.

View Images and Videos

Launching Gallery displays available folders. When another application, such as Email, saves an image, a Download folder is automatically created to contain the image. Likewise, capturing a screenshot automatically creates a Screenshots folder.

1. From a Home screen, tap **Apps** > **Gallery**.
2. Tap the drop down menu in the upper left corner, and then tap an option to choose the way items display.
   - In Album view, you can create albums to organize your images. On the drop down menu, tap **Album**, and then tap **MORE** > **Create album**.
3. Depending on the view mode selected, either tap an image or video to view it, or first tap an album or folder and then tap an image or video.
4. When viewing an image or video, you can scroll left or right to view the next or previous image or video.

Zoom In and Out

Use one of the following methods to zoom in or out on an image:

- Double-tap anywhere on the screen to zoom in or zoom out.
- Spread two fingers apart on any place to zoom in. Pinch the screen to zoom out.

Play Videos

1. From a Home screen, tap **Apps** > **Gallery**.
2. Tap a folder or category to open it.
3. Tap a video to view it.
4. Tap the Play icon to play the video.

Trim Segments of a Video

1. Select a video, and then tap the screen once to see the video options.
2. Tap **Editor**, and then tap **Trim**.
3. Use the sliders at the bottom of the screen to trim the video. Move the start bracket to the desired starting point, move the end bracket to the desired ending point.
4. Tap **EXPORT** to save the video. Modify the File name or Resolution, and then tap **EXPORT** to confirm the changes.

Edit Images

1. While viewing an image, tap the screen once to see the image options.
2. Tap **Edit** to view and use the editing tools.

Delete Images

1. From a Home screen, tap **Apps** > **Gallery**.
2. Tap a folder or category to open it.
3. Tap **MORE** > **Edit**.
4. Tap images to select them.
5. Tap **DELETE**.

DRAFT
FOR INTERNAL USE ONLY

Share Images

Use one of the following methods:

1. From a Home screen, tap **Apps** > **Gallery**.
2. Tap a folder or category to open it.
3. Tap **MORE** > **Share**.
4. Tap images to select them, and then tap **SHARE**.
5. Tap a sharing service and follow the prompts to send the image or images.

DRAFT
FOR INTERNAL USE ONLY

Internet

Access the Internet with a fully featured web browser.

Access the Internet

► From a Home screen, tap **Apps** > **Internet**.

Command Keys

The following command keys are available on the browser window:

- **Back** or **Back** key to return to the previous page.
- **Forward** to go forward to a recent page.
- **Home** to display your Internet Home screen.
- **Bookmarks** to manage bookmarked pages, saved pages, and history.
- **Tabs** to manage open tabs. The number on the icon indicates the number of tabs that are currently open.
- **Refresh** to refresh or reload the current Web page.

View a Web Site

To view a web site:

► Tap the address field, enter the web address, and then tap **Go** on the keyboard.

To zoom in or out:

► Tap the screen twice or pinch the screen to zoom out and stretch the screen to zoom in.

Browser Tabs

Use tabs to view multiple web pages at the same time.

To open a new tab:

► Tap **Tabs** > **NEW TAB**.

To close a tab:

► Tap **Tab manager** and then tap **Close tab**.

Bookmarks

To bookmark the current web page:

1. Tap **Bookmarks** > **ADD**.
2. Type a title for the bookmark and tap **SAVE**.

To open a bookmarked web page:

► Tap **Bookmarks**, then tap a folder, and an entry.

DRAFT
FOR INTERNAL USE ONLY

History

To view a list of recently visited web pages:

► Tap **Bookmarks** > **HISTORY**.

Saved Pages

To save a web page:

► Tap **MORE** > **Save web page**.

To view a list of saved web pages:

► Tap **Bookmarks** > **SAVED PAGES**.

Share Pages

To share a web page address with others:

► Tap **MORE** > **Share** and follow the prompts.

Secret Mode

Pages viewed in secret mode do not appear within your browser history or search history, and leave no traces (such as cookies) on your device. Secret tabs are a darker shade than the normal tab windows.

Note: Any downloaded files will remain on your device after you close a secret tab.

To open a new secret tab:

► Tap **Tabs** > **MORE** > **New secret tab**.

Internet Settings

These settings allow you to modify settings associated with using the Internet app.

1. From a Home screen, tap **Apps** > **Internet**.
2. Tap **MORE** > **Settings**.
3. Tap an option and follow the onscreen instructions.

DRAFT
FOR INTERNAL USE ONLY

Memo

Use the Memo app to write and save notes on your device.

Compose a Memo

1. Tap **Apps** > **Samsung** folder > **Memo**.
2. Tap **Create memo** and type a memo.
   - To change the category, tap **Category**.
   - To insert an image into the memo, tap **Image**.
   - To use your voice to insert text into the memo, tap **Voice**.
   - To add tasks, tap **Tasks**.
3. When finished creating your memo, tap **SAVE**.

Manage Memos

1. Tap **Apps** > **Samsung** folder > **Memo**.
2. Tap a memo entry to open it.
3. To edit a memo, tap the content of the memo.
4. To delete memos, tap **MORE** > **Edit**, select memos, and tap **DELETE**.
5. To send a memo to others, tap **MORE** > **Share**, select a memo, and then select a method to share the memo.

Browse Memos

1. Tap **Apps** > **Samsung** folder > **Memo**.
2. Browse memo entries by scrolling up or down.
3. To search for a memo, tap **SEARCH**.

Memo Options

► While browsing memos, tap **MORE** for the following options:

- **Edit**: Select notes to delete or move.
- **Share**: Share memos.
- **Manage categories**: Create and manage categories to organize your memos.

DRAFT
FOR INTERNAL USE ONLY

Messages

Learn how to send and receive different messages using the default messaging app on your phone.

Types of Messages

Your default Messaging app provides the following message types:

- Text Messages (SMS)
- Multimedia Messages (MMS)

The Short Message Service (SMS) lets you send and receive text messages to and from other mobile phones or email addresses. To use this feature, you may need to subscribe to your service provider's message service.

The Multimedia Messaging Service (MMS) lets you send and receive multimedia messages (such as picture, video, and audio messages) to and from other mobile phones or email addresses. To use this feature, you may need to subscribe to your service provider's multimedia message service.

Messaging icons are displayed at the top of the screen and indicate when messages are received and their type.

Create and Send Messages

This section describes how to create a send a message using the Messages app.

1. From a Home screen, tap **Messages** > **Compose**.
2. Tap the **Enter recipients** field to manually enter a recipient or tap **Add Recipient** to select a recipient from your Contacts or Groups.
   - If manually entering recipients, enter additional recipients by separating each entry with a semicolon (;). More recipients can be added at any time before the message is sent.
   - If adding a recipient from your Contacts, tap the contact to place a check mark then tap **DONE**. The contact will be placed in the recipients field.
   - For the Group option, if the number of recipients is less than 10, all members in the group can be added by placing a check mark by the contacts and then tap **DONE**.
3. Tap the **Enter message** field and use the onscreen keypad to enter a message.
   - Tap **Add emoticons** to choose an available emoticon from an onscreen list and then add it into your message (at the cursor location) if desired.
4. Review your message and tap SEND **SEND**.

Note: If you exit a message before you send it, the message is automatically saved as a draft.

DRAFT
FOR INTERNAL USE ONLY

View New Messages

When you receive a new message, a new message icon appears on the Status Bar.

To view the message:

► Open the Notification Panel and select the message. For more information, please see Notification Panel.

– or –

From a Home screen, tap **Messages**, and then tap the new message to view it.

- To play a multimedia message (audio or video), tap **Play**.
- To scroll through the list of messages, tap the screen and scroll up or down the page.

Delete Messages

To delete messages, follow these steps:

1. From a Home screen, tap **Messages**.
2. Tap **MORE** > **Edit**.
3. Tap each message you want to delete or tap the checkbox **All**.
4. Tap **DELETE**.

Message Search

You can search through your messages by using the Message Search feature.

1. From a Home screen, tap **Messages**.
2. Tap **SEARCH**.
3. Enter a word or phrase to search for, and then tap **Search** on the keyboard.

Messaging Settings

Configure the settings for text messages, multimedia messages, push messages, and so on.

► From a Home screen, tap **Apps** > **Messages** > **MORE** > **Settings**.

Emergency Alerts

This device is designed to receive wireless emergency alerts from the Commercial Mobile Alerting System (CMAS) which may also be known as the Personal Localized Alerting Network (PLAN). For more information, please contact your wireless provider.

Emergency Alerts allows customers to receive geographically-targeted messages. Alert messages are provided by the US Department of Homeland Security and will alert customers of imminent threats to their safety within their area. There is no charge for receiving an Emergency Alert message.

There are three types of Emergency Alerts:

- Alerts issued by the President
- Alerts involving imminent threats to safety of life (Extreme and Severe)
- AMBER Alerts (missing child alert)

Users may choose not to receive Imminent Threats (Extreme and Severe) and AMBER Alerts. Alerts issued by the President cannot be disabled.

To disable Imminent Threats and AMBER Alerts, follow the instructions below:

1. From a Home screen, tap **Messages**.
2. Tap **MORE** > **Settings** > **Emergency alerts** > **Emergency alerts**.
3. All alerts are enabled by default. Tap an alert option to disable it. You cannot disable Presidential alerts.

DRAFT
FOR INTERNAL USE ONLY

Music Player



Listen to your favorite songs with the Music player. Navigate through your music library, play songs, and create customized playlists.

Listen to Music

1. From a Home screen, tap **Apps** > **Music.**
2. Tap a category at the top left of the screen to view your music files.
3. Scroll through the list of songs and tap a song to begin playback.

DRAFT
FOR INTERNAL USE ONLY

My Files

Access files stored on your device, including images, videos, songs, and sound clips.

View Files

Files stored in the device are organized into the following groups:

- **Recent files**: View recently accessed files.
- **Category**: Files are grouped into the following categories:
  - **Images**: View image files.
  - **Videos**: View video files.
  - **Audio**: View audio files.
  - **Documents**: View document files.
  - **Download history**: View all apps and files that have been downloaded to the device.
- **Local storage**: View folders and files in their storage locations.
  - **Device storage**: View folders and files located on the device.
- **Cloud storage**: Contains shortcuts to FTP servers or other cloud storage locations that you have added.
  - **Google Drive**: Sign in to view folders and files located in your Google Drive account.

To view files in My Files:

1. From a Home screen, tap **Apps** > **Samsung** folder > **My Files**.
2. Tap a category to view the relevant files or folders.
3. Tap a file or folder to open it.

My Files Options

On the main My Files screen, the following options are available:

- **SEARCH**: Search for a file or folder.
- **MORE**: Tap for the following options:
  - **Edit**: Edit files shown in Recent files.
  - **Clear recent file history**: Clear the Recent files category.
  - **Show/Conceal hidden files**: Show or conceal hidden files.
- **STORAGE USAGE**: Tap to view memory information for your device.

Category Options

After tapping on a category, the following options are available:

- **HOME**: Return to the main My Files screen.
- **SEARCH**: Search for a file in the selected category.
- **MORE**: Tap for the following options:
  - **Edit**: Select files or folders.
  - **Share**: Select files to share.
  - **View as**: Change the appearance of the files or folders.
  - **Sort by**: Change the sort order of the files.
  - **Show/Conceal hidden files**: Show or conceal hidden files.

DRAFT
FOR INTERNAL USE ONLY

Options for Selected Files and Folders

► Tap **MORE** > **Edit**, select a file or folder, and then use one of these functions:

- **DELETE**: Delete files or folders.
- **MORE**: Select one of the following options:
  - **Move**: Move files or folders to another folder.
  - **Copy**: Copy files or folders to another folder
  - **Rename**: Rename a file or folder. This option only appears when just one file or folder is selected.
  - **Add shortcut on Home screen**: Add a shortcut the Home screen.
  - **Compress**: Create a zip folder containing the selected files. This option only appears in Local Storage categories. A selected zip folder has the additional options of **Extract** and **Extract to current folder**.
  - **Details**: View details of the selected file(s) or folder(s).

DRAFT
FOR INTERNAL USE ONLY

S Health

Use S Health to plan, track, and manage your health goals and activities, including exercise, sleep, and meals.

Note: This device and related software are not intended for use in the diagnosis of disease or other conditions, or in the cure, mitigation, treatment or prevention of disease.

1. From Home, tap **Apps** > **S Health**.
2. Read and accept the terms and conditions.
3. Set up your health profile and goals.

Before You Start Exercising

This app can be used to monitor your exercise. While moderate physical activity, such as brisk walking, is safe for most people, health experts suggest that you talk with your doctor before you start an exercise program, particularly if you have any of the following conditions:

- Heart disease;
- Asthma or lung disease;
- Diabetes, or liver or kidney disease;
- Arthritis.

You should also check with your doctor if you have symptoms suggestive of heart, lung, or other serious disease, such as:

- Pain or discomfort in your chest, neck, jaw, or arms during physical activity;
- Dizziness or loss of consciousness;
- Shortness of breath with mild exertion or at rest, or when lying down or going to bed;
- Ankle swelling, especially at night;
- A heart murmur or a rapid or pronounced heartbeat;
- Muscle pain when walking upstairs or up a hill that goes away when you rest.

Finally, the American College of Sports Medicine recommends that you see your doctor before engaging in vigorous exercise if two or more of the following apply:

- You are a man older than age 45 or a woman older than age 55;
- You have a family history of heart disease before age 55;
- You smoke or quit smoking in the past six months;
- You have not exercised for three months or more;
- You are overweight or obese;
- You have high blood pressure or high cholesterol;
- You have impaired glucose tolerance, also called prediabetes.

When in Doubt — Check It Out

If you are unsure of your health status, have several health problems, or are pregnant, you should speak with your doctor before starting a new exercise program. Working with your doctor ahead of time is a good way to plan an exercise program that is right and safe for you. Consider it the first step on your path to physical fitness.

DRAFT
FOR INTERNAL USE ONLY

S Voice

Speak commands to perform operations on your device, and to speak criteria for searches and other operations.

Use S Voice to find everything from directions to trivia answers to the current weather forecast.

1. From a Home screen, tap **Apps** > **S Voice**.
2. Speak a command.
3. Tap the microphone icon, if the device does not hear you, or to give it another command.

Tip: Tap **Help** for example commands and to view a tutorial.

S Voice Settings

These settings allow you to modify settings associated with using the Internet app.

1. From a Home screen, tap **Apps** > **S Voice**.
2. Tap **Settings**.
3. Tap an option and follow the onscreen instructions.

DRAFT
FOR INTERNAL USE ONLY

Video Player

Play and manage videos stored on your device.

To access video:

1. From a Home screen, tap **Apps** > **Video**.
2. Scroll through the videos stored on your device. After a few seconds, each video thumbnail begins playing a preview of the clip.
3. Tap a video to view it.

Use Pop-Up Play

Multi task with Pop-Up Play—transform your video player into a pop-up window. The video will continue to play, and the pop-up window can be resized or moved anywhere on the screen.

1. From a Home screen, tap **Apps** > **Video**.
2. Tap a video to view it.
3. Tap to continue playing the video in a floating window.
   - Drag the window to any location on the screen.
   - Use two fingers to pinch or spread to resize the floating window.

DRAFT
FOR INTERNAL USE ONLY

Voice Recorder

Record voice memos and notes.

Create a Voice Recording

► From a Home screen, tap **Apps** > **Samsung** folder > **Voice Recorder**.

- Tap the drop down menu in the upper left corner to choose the appropriate recording mode:
  - **Standard**: This recording mode picks up any sounds detected by the microphones.
  - **Interview**: The top and bottom microphones are used for two-directional recording. The top and bottom of the device pick up equal amounts of sound. Microphones can be muted during playback.
  - **Voice memo**: Voice input is converted to text on screen. The maximum recording time is five minutes.
- Tap **Record** to record an audio file.
- Tap **Stop** to stop recording. The file is automatically saved.
- Tap **Pause** to pause the recording of an audio file.
- Tap **Bookmark** to bookmark a position in the recording for later reference.
- While recording, tap **MORE** > **Turn on Call rejection** to reject incoming calls during a recording.

Manage Recordings

To display a list of recordings:

1. From a Home screen, tap **Apps** > **Samsung** folder > **Voice Recorder**.
2. Tap **Recordings**.
3. Tap a recording to play it back.
4. Tap **MORE** for additional options:
   - **Edit**: Tap to select recordings. Once selected, the following options are available:
     - **DELETE**: Delete the recording.
     - **MORE**: Tap to either **Rename** the file or **Write to Voice Label** (which writes the recording to an NFC voice label).
   - **Share**: Tap to select recording files, and then tap **SHARE** to select a sharing method.
   - **Search**: Tap to search for a recording.

DRAFT
FOR INTERNAL USE ONLY

Settings

Configure your device's connections and settings, add accounts, and customize the home screen, apps, and features.

- Some options use an **ON/OFF** button to turn the option on (ON) or off (OFF).
- For some options, you must tap a field, such as **Email address**, to display and set options.
- Some options are enabled or disabled by tapping a ☑ checkbox. When enabled, a check mark displays. Tap the check mark to remove it and disable the option.

DRAFT
FOR INTERNAL USE ONLY

How to Use Settings

Access Settings

► From a Home screen, tap **Apps** > **Settings**.

– or –

From a Home screen, drag down from the Status Bar to display the Notification panel, and then tap **Settings**.

Search for Settings

If you are not sure exactly where to find a certain setting, you can use the Search feature.

1. From a Home screen, tap **Apps** > **Settings**.
2. Tap **SEARCH**.
   - Enter a word or words in the Search box. As you type, settings that match will appear on the screen.
   - Tap an entry to go to that setting.

Customize the Quick Settings Menu

Quick settings are the settings that you are most likely to frequently use. When you first access the Settings menu, the Quick settings are set to a default list of settings.

To find the Quick settings menu:

► From a Home screen, tap **Apps** > **Settings** > **QUICK SETTINGS**.

Change the Quick Settings

You can change the Quick settings list to include your most frequently used settings.

1. From a Home screen, tap **Apps** > **Settings**.
2. Tap **MORE** > **Edit quick settings**.
   - Select additional settings to appear in your Quick settings menu. Settings that are already in the Quick settings menu are checked. Up to nine settings can be selected.
   - Uncheck a setting to remove it from the Quick settings list.
3. Tap **Back arrow** to save your new Quick settings menu.

DRAFT
FOR INTERNAL USE ONLY

Wi-Fi Settings

Wi-Fi is a term used for certain types of Wireless Local Area Networks (WLAN). Wi-Fi communication requires access to a Wireless Access Point (WAP).

Wi-Fi Direct creates a direct connection between two or more devices using Wi-Fi.

Turn Wi-Fi On or Off

Turning Wi-Fi on makes your device able to discover and connect to compatible in-range WAPs.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab.
2. Tap **Wi-Fi**, and then tap **ON/OFF** to turn Wi-Fi on or off.

Scan and Connect to a Wi-Fi Network

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab.
2. Tap **Wi-Fi**, and then tap **ON/OFF** to turn Wi-Fi on. When Wi-Fi is turned on, your device will automatically scan for available networks and display them.
3. Tap the network you want to connect to. When you select an open network, you are automatically connected to the network. Otherwise, enter a password to connect.

Manually Connect to a Wi-Fi Network

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab.
2. Tap **Wi-Fi**, and then tap **ON/OFF** to turn Wi-Fi on.
3. Tap **MORE** > **Add network**.
4. Enter information about the Wi-Fi network:
   - Tap **Enter network name** to enter the name of the Wi-Fi network.
   - Tap the **Security** field and select a security option and enter your password.
   - Tap **Show advanced options** if you need to add advanced options such as IP settings and Proxy settings.
5. Tap **CONNECT** to store the new information and connect to your target WAP.

DRAFT
FOR INTERNAL USE ONLY

Wi-Fi Options

The Wi-Fi settings menu allows you to set up many of your device's advanced Wi-Fi services.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab.
2. Tap **Wi-Fi**, and then tap **ON/OFF** to turn Wi-Fi on.
3. Tap **MORE** for options:
   - **Add network**: Manually add a Wi-Fi network.
   - **WPS push button**: Set up a connection to a WPS (Wi-Fi Protected Setup) router or other equipment.
   - **WPS PIN entry**: View the PIN used by your device to set up a PIN-secured connection to a Wi-Fi router or other equipment (not configurable).
   - **Smart network switch**: Tap to enable this feature, which automatically switches to a mobile network if the Wi-Fi connection becomes unstable.
   - **Advanced**:
     - **Network notification**: Receive a notification when new Wireless Access Points (WAPs) are available.
     - **Passpoint**: Connect to passpoint-enabled Wi-Fi Access Points automatically.
     - **Keep Wi-Fi on during sleep**: Specify when to disconnect from Wi-Fi.
     - **Always allow scanning**: Allow Google location service and other apps to scan for networks, even when Wi-Fi is turned off.
     - **Auto connect**: Automatically connect to an AT&T Wi-Fi Hotspot as soon as your phone detects it.
     - **Install network certificates**: Install authentication certificates.
     - **MAC address**: View your device's MAC address, which is required when connecting to some secured networks (not configurable).
     - **IP address**: View your device's IP address (not configurable).
   - **Help**: Learn about setting up and using Wi-Fi networks, and other settings.

Wi-Fi Status Indicators

Status Bar icons show your current Wi-Fi connection status:

- When Wi-Fi is connected, active, and communicating with a Wireless Access Point (WAP), displays.
- If a Wi-Fi access point is available, but your device is not connected to it, displays. It may also display if there is a communication issue with the target Wireless Access Point (WAP).

Wi-Fi Direct

Wi-Fi Direct allows direct device-to-device connections via Wi-Fi, without having to connect to a Wi-Fi network.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab.
2. Tap **Wi-Fi**, and then tap **ON/OFF** to turn Wi-Fi on. Wi-Fi must be on to configure settings.
3. Tap **Wi-Fi Direct**. Your device automatically scans for nearby Wi-Fi Direct devices.
4. After scanning for devices, select a device, and then follow the prompts to complete the connection.

Wi-Fi Direct Status Indicator

When your device is connected to another device using Wi-Fi Direct, displays in the Status Bar.

DRAFT
FOR INTERNAL USE ONLY

Bluetooth

Bluetooth is a short-range communications technology that allows you to connect wirelessly to a number of Bluetooth devices, such as headsets and hands-free car Bluetooth systems, and Bluetooth-enabled computers, printers, and wireless devices.

Note: The Bluetooth communication range is approximately 30 feet.

Turn Bluetooth On or Off

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab.
2. Tap **Bluetooth**, and then tap **ON/OFF** to turn Bluetooth on or off.

Bluetooth Status Indicator

When Bluetooth is turned on, displays in the Status Bar.

Scan for Bluetooth Devices

When you want to pair with another Bluetooth device, you can scan for nearby devices that are visible.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab.
2. Tap **Bluetooth**, and then tap **ON/OFF** to turn on Bluetooth.
3. When Bluetooth is first turned on, it scans for nearby Bluetooth devices and displays them.
   - Tap **REFRESH** to manually perform a new scan.

Pair Bluetooth Devices

The Bluetooth pairing process allows you to establish trusted connections between your device and another Bluetooth device.

Pairing between two Bluetooth devices is a one-time process. Once a pairing is created, the devices will continue to recognize their partnership and exchange information without having to re-enter a passcode.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab.
2. Tap **Bluetooth**, and then tap **ON/OFF** to turn on Bluetooth.
3. Make sure that the target device is discoverable, so that your device can find it. Refer to the instructions that came with the device to find out how to set it to discoverable mode.
4. Tap **REFRESH**. Your device will start to scan for Bluetooth devices within range.
5. When you see the name of the target device displayed in the Bluetooth devices section, tap the name. Your device then automatically tries to pair with the target device. If automatic pairing fails, enter the passcode supplied with the target device.

DRAFT
FOR INTERNAL USE ONLY

Note: Due to different specifications and features of other Bluetooth-compatible devices, display and operations may be different, and functions such as transfer or exchange may not be possible with all Bluetooth compatible devices.

Delete a Paired Device (Unpairing)

When you unpair from a Bluetooth device, the two devices will no longer recognize each other. To connect again, you'd need to pair the devices.

1. Verify your Bluetooth is active.
2. From the Bluetooth settings page, tap ⚙ next to the previously paired device, and then tap **Unpair** to delete the paired device.

DRAFT
FOR INTERNAL USE ONLY

Airplane Mode

Airplane mode disconnects your device from all networks and turns off connectivity features, such as phone calls and Wi-Fi.

While in airplane mode, you can use other features, such as playing music, watching videos, and other online applications.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab.
2. Tap **Airplane mode**, and then tap **ON/OFF** to enable or disable the option.

Note: You can also control Airplane mode from the Device options menu. Press and hold the **Power/Lock** key, and then tap **Airplane mode**.

DRAFT
FOR INTERNAL USE ONLY

Mobile Hotspot and Tethering

Use Mobile Hotspot to share your device's Internet connection with other devices using your device as a portable Wi-Fi hotspot.

Share your device's Internet connection with a computer that connects to your device using a USB cable.

Use Your Device as a Portable Wi-Fi Hotspot

Note: You must have a tethering plan on your service account in order to use the Mobile Hotspot.

Warning: Mobile Hotspot consumes battery power and uses data service.

Turn Mobile Hotspot On or Off

Activate your device's Mobile Hotspot application to allow other devices to use your device's Internet connection.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **Mobile Hotspot and Tethering** > **Mobile Hotspot**.
2. Tap **ON/OFF** to turn Mobile Hotspot on or off.

Warning: By default, your device's Mobile Hotspot has no security applied, and any device can connect. For more information, see Configure Mobile Hotspot Settings.

Connect a Device to Your Mobile Hotspot

Use the other device's Wi-Fi control to connect to your device's Mobile Hotspot.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **Mobile Hotspot and Tethering** > **Mobile Hotspot**.
2. Tap **ON/OFF** to turn on Mobile Hotspot.
3. Activate Wi-Fi on the target device.
4. Scan for Wi-Fi hotspots and select the target device from the list.
5. On the target device, enter your device's Mobile Hotspot password.

Allowed Device List

Control whether devices connect to your Portable Wi-Fi hotspot with the Allowed device list. After you add devices to the list, they can scan for your device and connect using your device's Mobile Hotspot name and password.

Note: Using your device as a Mobile Hotspot consumes battery power and uses data service. While Mobile Hotspot is active, your device's applications will use the Mobile Hotspot data service. Roaming while using your device as a Mobile Hotspot will incur extra data charges.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **Mobile Hotspot and Tethering** > **Mobile Hotspot**.
2. Tap **ON/OFF** to turn on Mobile Hotspot.
3. Tap **MORE** > **Allowed devices**, and then tap **ADD** to enter the other device's Device name and MAC address.
4. Tap **OK** to add the device.

DRAFT
FOR INTERNAL USE ONLY

Change the Mobile Hotspot Password

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **Mobile Hotspot and Tethering** > **Mobile Hotspot**.
2. Tap **ON/OFF** to turn on Mobile Hotspot.
3. Tap **MORE** > **Configure Mobile Hotspot**.
4. Tap the **Security** field and select **WPA2 PSK**.
5. Scroll down and enter a new password in the **Password** field.

Configure Mobile Hotspot Settings

Manage your Mobile Hotspot security and connecting settings.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **Mobile Hotspot and Tethering** > **Mobile Hotspot**.
2. Tap **MORE** > **Configure Mobile Hotspot**:
   - **Network name**: View and change the name of your Mobile Hotspot.
   - **Hide my device**: Make your Mobile Hotspot invisible to other Wi-Fi devices during a scan. Other devices can still connect to your Mobile Hotspot, but will have to set up the connection manually with your Network SSID and Password.
   - **Security**: Choose the security level for your Mobile Hotspot.

Note: Scroll down to view all options.

   - **Password**: If you choose a security level that uses a password, enter the password. By default, the password is your device's phone number.
   - **Show password**: Display your password instead of masking it.
   - **Show advanced options**: Access advanced options, including Broadcast channel, and to specify the channel your device uses for Mobile Hotspot.

Turn Off Mobile Hotspot Automatically

Set your device to automatically turn off Mobile Hotspot if there are no connected device.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **Mobile Hotspot and Tethering** > **Mobile Hotspot**.
2. Tap **ON/OFF** to turn on Mobile Hotspot.
3. Tap **MORE** > **Timeout settings** and select an amount of time.

Use Tethering to Connect Your Device to a Computer

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **Mobile Hotspot and Tethering**.
2. Connect the computer to the device using the USB cable, and then tap **USB tethering** to turn tethering on.

DRAFT
FOR INTERNAL USE ONLY

Data Usage

Monitor your mobile data usage.

Note: Your service provider may account for data usage differently.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **Data usage** for options:
   - **Mobile data**: Enable mobile data. You can also control Mobile Data at the Notification panel.
   - **International Data Roaming**: Customize options for when roaming outside the U.S., Puerto Rico and USVI. International roaming data charges may apply.
   - **Set mobile data limit**: Your mobile data connection will be turned off when the specified limit is reached.
   - **Data usage cycle**: Tap the drop-down menu, and then choose a time period for data usage. Data usage for the period displays on the graph, along with usage by application below.
   - **By application**: View data usage by application.
2. Tap **MORE** for the following options:
   - **Restrict background data**: Restrict some apps and services from working unless you are connected to a Wi-Fi network.
   - **Show Wi-Fi usage**: Display a Wi-Fi tab that shows Wi-Fi usage.
   - **Restrict networks**: Select Wi-Fi networks that are mobile hotspots. You can restrict apps from using these networks, and you can configure apps to warn you before using these networks for large downloads.

DRAFT
FOR INTERNAL USE ONLY

Mobile Networks

Control your device's access to networks and mobile data service.

► From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **Mobile networks** for options:

- **Mobile data**: Allow your device to connect to a mobile data network.
- **International Data Roaming**: Allow your device to connect to data services while roaming outside of the U.S., Puerto Rico, and USVI. Significantly higher charges may result.
- **Access Point Names**: Choose or add APNs.
- **Network operators**: Choose a preferred network mode.

DRAFT
FOR INTERNAL USE ONLY

NFC and Payment

NFC (Near Field Communication) allows data exchange when you touch your device with another compatible device. This is used for features like Android Beam.

To activate NFC*:*

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **NFC and payment**.
2. Tap **NFC**, and tap **ON/OFF** to turn NFC on.

Android Beam

When Android Beam is activated, you can beam app content to another NFC-capable device by holding the devices close together. You can beam browser pages, YouTube videos, contacts, and more.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **NFC and payment**.
2. Tap **NFC**, and tap **ON/OFF** to turn NFC on.
3. Tap **Android Beam**, and tap **ON/OFF** to turn Android Beam on.
4. Touch the back of your device with another NFC-capable device and the content is transferred.

Tap and Pay

Tap and pay allows you to select the default payment application you want to use for making purchases on your phone.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **NFC and payment**.
2. Tap **Tap and pay**.
3. Select the payment app that you want as your default.

DRAFT
FOR INTERNAL USE ONLY

More Connection Settings

This option displays additional connectivity information.

Printing

Print images and documents to Samsung printers and other compatible printers (not included).

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **More connection settings** > **Printing**.
2. Tap a print service and follow the prompts.

Note: Tap **Download plug-in** to install additional print service drivers.

MirrorLink

Mirror your device's display on your car's entertainment and information screen using a USB connection. To use this feature, your car system must support MirrorLink.

To turn on MirrorLink:

1. Connect your device to your car's system using the USB cable.
2. On your device's Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **More connection settings** > **MirrorLink**.
3. Tap **Connect to vehicle via USB**.

Virtual Private Networks (VPN)

Set up and manage your Virtual Private Networks (VPNs).

Note: You must set a screen lock PIN or password before setting up a VPN. For more information, see Lock Screen and Security.

Add a VPN

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **More connection settings** > **VPN**.
2. Tap **Basic VPN** or **Advanced IPSec VPN**.
3. Tap **ADD VPN** and follow the prompts to set up your VPN.

Connect to a VPN

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **More connection settings** > **VPN**.
2. Tap **Basic VPN** or **Advanced IPSec VPN**.
3. Tap the VPN, enter your log in information, and tap **CONNECT**.

Edit or Delete a VPN

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **More connection settings** > **VPN**.
2. Tap **Basic VPN** or **Advanced IPSec VPN**.
3. Touch and hold the VPN that you want to edit or delete.

DRAFT
FOR INTERNAL USE ONLY

Default Messaging App

If you have multiple messaging apps installed, you can select which app should be your default messaging app.

1. From a Home screen, tap **Apps** > **Settings** > **CONNECTIONS** tab > **More connection settings**.
2. Tap **Default messaging app** to select a default.

DRAFT
FOR INTERNAL USE ONLY

Sounds and Notifications

Configure the sounds and vibrations used to indicate notifications, screen touches, and other activities.

Change the Sound Mode

You can switch between sound modes, while preserving the individual sound settings you have made.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notifications** > **Sound mode**, and then choose a mode:
   - **Sound**: Your device uses the sounds, vibrations, and volume levels you have chosen in Sound settings for notifications and alerts.
   - **Vibrate**: Your device vibrates for notifications and alerts. This uses the Vibration intensity you choose in Sound settings.
   - **Mute**: Your device mutes all sounds and notifications.

Adjust the Volume

Set the system volume level, and set default volume for call ringtones, notifications, and other audio.

Tip: You can also set System volume from the home screen by pressing the **Volume** key.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notifications** > **Volume**.
3. Drag the sliders to set the default volume for:
   - Ringtone
   - Media
   - Notifications
   - System

Ringtones and Sound

Select a Default Ringtone

Choose from preset ringtones or add your own.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notifications** > **Ringtones and sounds** > **Ringtone**
3. Tap a ringtone to hear a preview and select it.

   – or –

   Tap **Add ringtone** to use an audio file as a ringtone.

DRAFT
FOR INTERNAL USE ONLY

Change the Notification Sound

Choose a sound for notifications, such as for new messages and event reminders.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notifications** > **Ringtones and sounds** > **Default notification sound**.
3. Tap a sound to hear a preview and select it.

Set Notification Sounds for Samsung Applications

Choose notification alerts for new messages, calendar events, and email.

1. From a Home screen, tap **Apps** > **Settings**.
2. Tap **Sounds and notification** > **Ringtones and sounds**, and tap to configure each option:
   - **Messages**: Configure message notifications and alerts.
   - **Calendar**: Configure event notifications.
   - **Email**: Configure email account notifications.

System Sounds

Set various other system sound options.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notification** > **Ringtones and sounds**, and tap to enable each option:
   - **Touch sounds**: Play tones when you touch or tap the screen to make selections.
   - **Dialing keypad tone**: Play tone when the dialing keypad is tapped.
   - **Screen lock sounds**: Play a sound when you unlock the screen.
   - **Keyboard sound**: Play a sound when the Samsung keyboard is tapped.

Vibrations

Set the amount of vibration for incoming calls, notifications, and haptic feedback.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notification** > **Vibrations**.
   - Tap **Vibration intensity** and move the sliders to change the amount.
   - Tap **Vibration pattern** to choose a pattern.
   - Tap **ON/OFF** for each option to enable.
     - Vibrate when ringing
     - Vibration feedback
     - Keyboard vibration

Sound Quality and Effects

Choose from advanced sound options to customize your audio experience.

Sound Quality

Find the best sound setting for your preferences

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notification** > **Sound quality and effects**.
3. Tap **Adapt Sound** and follow the prompts to customize your sound settings.

Sound Effects

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sound and notification** > **Sound quality and effects**.
3. Tap **ON/OFF** to enable each option:
   - **SoundAlive+**: Recreate the effects of rich surround sound.
   - **Tube Amp**: Simulate the soft timbre of a tube amplifier.

DRAFT
FOR INTERNAL USE ONLY

Do Not Disturb

This setting allows you to block all notifications and alerts. The options below determine what notifications can make sounds, and during what time periods you want to enter this mode.

To activate Do Not Disturb mode:

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notifications** > **Do not disturb**.
3. Tap **ON/OFF** to enable this option.

Allow Exceptions

This option lets you customize what notifications are allowed while your phone is in Do not disturb mode.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notifications** > **Do not disturb**.
3. Tap **Allow exceptions**, and tap **ON/OFF** to enable the exceptions you want to allow.

Scheduling

This option allows you to turn Do not disturb mode on and off automatically at scheduled times.

Note: Scheduling is not available if Do not disturb mode has been turned on manually.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notifications** > **Do not disturb**.
3. Tap **Set schedule**, and set the Days, Start time, and End time.

Notifications on Lock Screen

Choose what notifications can display while the device is locked.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notifications** > **Notifications on lock screen**, and choose an option.

App Notifications

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notifications** > **App notifications**, and choose an app to enable or disable notifications.

LED Indicator

Light up the LED indicator when charging, voice recording, or receiving notifications.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab.
2. Tap **Sounds and notifications** > **LED indicator** to enable this feature.

DRAFT
FOR INTERNAL USE ONLY

Display Settings

Adjust the Screen Brightness

Adjust the screen brightness to suit your surroundings or personal preference. You may also want to adjust screen brightness to conserve battery power.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Display**.
2. Tap **Brightness** for options:
   - Tap **Auto** to allow the device to adjust brightness automatically.
   - To set a custom brightness level, clear the Automatic brightness check mark and drag the **Brightness** slider.

Note: You can also control Brightness from the Notification panel. Drag down the Status Bar at the top of the screen to find the Brightness options.

Change the Font Style and Size

You can set the font style and size for all text that displays on the screen.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Display**.
2. Tap **Font** to choose a font style and font size.
   - Drag the slider to adjust the font size.
   - Tap a font style to select a font, or tap **Download fonts** to find new fonts from Galaxy Apps.
3. Tap **DONE** to set the font size and style.

Set the Screen Timeout Delay

Choose how long the display screen remains lit after you tap the screen or press any key.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Display**.
2. Tap **Screen timeout**, and then choose a time period.

Smart Stay

Using the front camera to detect your face, the screen will not time out as long as you are facing the screen.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Display**.
2. Tap **Smart stay** to turn the feature on.

Select a Screen Mode

Choose a screen mode to match your type of viewing. You can choose to have the device automatically adapt the display depending on the type of image being displayed, and other criteria such as battery level.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Display**.
2. Tap **Screen mode**, and then choose a screen mode.
   - To have your device automatically optimize the display to match the type of image being displayed and other criteria, such as battery level, tap **Adaptive display**.

     – or –

     Choose a specific type of screen mode based on what your are viewing.

DRAFT
FOR INTERNAL USE ONLY

Daydream (Screen Saver)

The Daydream setting controls what the screen displays when the device is docked (dock not included), or while charging. You can choose to display colors, or display photos stored on your device.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Display**.
2. Tap **Daydream**. Tap **ON/OFF** to turn Daydream on. Configure options:
   - **Colors**: Tap the selector to display a changing screen of colors.
   - **Google Photos**: Display pictures from your Google+ account. (Only available if you are signed in to your Google account.) Tap **Settings** for options.
   - **Photo Frame**: Display pictures in a photo frame. Tap **Settings** for options.
   - **Photo Table**: Display pictures in a photo table. Tap **Settings** for options.
3. Tap **MORE** > **Preview** to see a demonstration of Daydream.
4. Tap **MORE** > **Select when to daydream** to chose an option.

DRAFT
FOR INTERNAL USE ONLY

Motions and Gestures

Control certain device actions by touching the screen with the palm of your hand.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Motions and gestures**.
2. Tap **ON/OFF** to enable each of the following:
   - **Direct call**: Call the contact whose call log, message, or contact details are currently on the screen by bringing the device close to your ear.
   - **Smart alert**: Set the device to vibrate when you pick it up to notify you about missed calls and messages.
   - **Mute**: Mute sounds and video by covering the screen or turning over the device.
   - **Palm swipe to capture**: Capture an image of the screen when you sweep your hand left or right across the screen.

DRAFT
FOR INTERNAL USE ONLY

Applications Settings

Manage settings for applications on your phone.

Application Manager

You can download and install new applications on your device. Use Application manager settings to manage your downloaded and preloaded applications.

Warning: Because this device can be configured with system software not provided by or supported by Google or any other company, end-users operate these devices at their own risk.

Memory Usage

See how memory is being used by Downloaded or Running applications.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Applications** > **Application manager**.
2. Swipe across the screen to display DOWNLOADED, RUNNING, or ALL to display memory usage for that category of applications.

   The graph on the DOWNLOADED tab shows used and free device memory. The graph on the RUNNING tab shows used and free RAM.

Downloaded

Displays apps you have downloaded onto your device.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Applications** > **Application manager**.
2. Tap **DOWNLOADED** to view a list of all the downloaded applications on your device.
   - To switch the order of the DOWNLOADED list, tap **MORE** > **Sort by size** or **Sort by name**.
   - To reset all of your application preferences, tap **MORE** > **Reset app preferences**.
   - Tap an application to view and update information about the application, including memory usage, default settings, and permissions. The following options are displayed:
     - **FORCE STOP**: Stop an app that is misbehaving. Restart your device if stopping an app, process, or service causes your device to stop working correctly.
     - **UNINSTALL UPDATES**: Delete the application from the device or uninstall updates made to apps that cannot be deleted.
     - **DISABLE**: Disable apps that cannot be deleted.
     - **CLEAR DATA**: Clear application data from memory.
     - **CLEAR CACHE**: Clear an application's temporary memory storage.
     - **CLEAR DEFAULTS**: Clear an application's customization.
     - **Permissions**: View information about the application's access to your device and data.

DRAFT
FOR INTERNAL USE ONLY

Running Services

View and control services running on your device.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Applications** > **Application manager**.
2. Tap **RUNNING** to view a list of running services.

   All the applications that are currently running on the device display.
3. Tap **MORE** > **Show cached processes** to display all the cached processes that are running. Tap **MORE** > **Show services in use** to switch back.
4. Tap one of the applications to view application information.
   - **STOP**: Stops the application from running on the device. This is usually done prior to uninstalling the application. (Not all services can be stopped. Stopping services may have undesirable consequences on the application or Android System.)
   - **REPORT**: Report failure and other application information.

Note: Options vary by application.

Default Applications

If you have multiple applications of the same type, such as email apps, you can select one app to be the default.

You can also use a simpler Home screen which provides an easier user experience for first-time smartphone users.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Applications** > **Default Applications**.
2. Tap **Home** and select a Home screen mode:
   - **TouchWiz easy home**: Provides an easier user experience for the first-time smartphone users.
   - **TouchWiz home**: The Home screen that originally displays on your phone.
3. Tap **Messages** and select a default messaging app.
4. To clear defaults you have set up, tap **CLEAR**.

Application Settings

Shortcuts to the settings for various apps are available in one convenient location.

1. From a Home screen, tap **Apps** > **Settings** > **DEVICE** tab > **Applications**.
2. Tap one of the following to display the settings for the selected app:
   - Calendar
   - Camera
   - Contacts
   - Email
   - Internet
   - Messages
   - Music
   - Phone
   - S Voice
   - Weather

DRAFT
FOR INTERNAL USE ONLY

Wallpaper Settings

Change the look of the home and lock screens with wallpaper.

You can display a favorite picture or choose from preloaded wallpapers.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab > **Wallpaper**.
2. Tap **Home screen**, **Lock screen**, or **Home and lock screen**.
3. Tap a image to preview it, and then tap **SET AS WALLPAPER**.
   - Tap **From Gallery** for additional wallpapers.

DRAFT
FOR INTERNAL USE ONLY

Themes

Set the theme to be applied to your home and lock screens, wallpapers, and app icons.

Apply Themes

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab > **Themes**.
   - Tap a theme to view a preview of various screens.
   - Tap **STORE** to download additional themes from the Theme Store with your Samsung account.
   - Tap **MORE** for help using this feature.
2. Tap **APPLY** to apply the selected theme.

DRAFT
FOR INTERNAL USE ONLY

Lock Screen and Security

Secure your device and protect your data with Lock Screen and Security settings.

Set a Screen Lock

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Screen lock type** to select a screen lock and level of security:
   - **Swipe**: Swipe the screen to unlock it. This option provides no security.
   - **Pattern**: A screen unlock pattern is a tap gesture you create and use to unlock your device. This option provides medium security.
   - **PIN**: Select a PIN to use for unlocking the screen. This option provides medium to high security.
   - **Password**: Create a password for unlocking the screen. This option provides high security.
   - **None**: Never use a Lock screen.
3. If choosing a secured lock screen option, select your notification settings:
   - **Show content**: Content which may include personal information will be shown on the lock screen.
   - **Hide content**: Only notifications will be shown on the lock screen.
   - **Do not show notifications**: No content or notifications will be shown on the lock screen.
4. Choose a screen lock option:
   - **Show information**: Show the dual clock, or information such as the weather information, on the lock screen.
   - **Unlock effect**: Set the visual effect used when unlocking the screen. (This option is available with Swipe only.)
   - **Secure lock settings**: Set your secure lock functions such as Secured lock time, and Smart lock.

Note: Options vary based on the screen lock type.

Device Security

Configure security for your phone.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Device security**.
3. Tap the **ON/OFF** switch to activate KNOX active protection on your phone.

DRAFT
FOR INTERNAL USE ONLY

Find My Mobile

Protect your device from loss or theft allowing your device to be locked, tracked, and for your data to be deleted remotely.

► To access your device remotely, visit findmymobile.samsung.com.

Note: You must sign up for a Samsung account and enable Google location service to use Find My Mobile.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Find My Mobile.**
3. Enter your Samsung account password, or if you are not logged in to your Samsung account, tap **Add account** and follow the prompts.
4. The following options are available:
   - **Remote controls**: Tap to activate or deactivate Remote controls, which allows you to access your device remotely.
   - **Google location service**: Tap to activate or deactivate Google location service. This service must be on in order to find your phone.
   - **SIM change alert**: Prevent unauthorized changes to your SIM card by being alerted whenever an app or service attempts to change data on your SIM card.
   - **Reactivation lock**: Use your Samsung account to stop anyone from reactivating you device without your permission.

Unknown Sources

Enable installation of non-Google Play applications.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Unknown sources** to enable this option.

Warning: Enabling installation of third-party applications can cause your device and personal data to be more vulnerable to attacks by unknown sources.

Other Security Settings

Encrypt Your Data

Require a numeric PIN or password to decrypt your device each time you power it on.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Other security settings** > **Encrypt device,** and follow the prompts to encrypt all data on your device.

Set Up or Change Your Factory Data Password

Protect your device from being reset accidentally by requiring a special password before it can be reset to its factory defaults.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Other security settings** > **Set up/change password** and follow the prompts.

DRAFT
FOR INTERNAL USE ONLY

Set Up SIM Card Lock

Require both your SIM card PIN and your ordinary screen lock type when unlocking the device.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Other security settings** > **Set up SIM card lock** and follow the prompts.
   - To change your SIM card PIN, tap **Change SIM card PIN**.

View Passwords

Display password characters briefly as you type them.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Other security settings** > **Make passwords visible** to turn the feature on.

Security Update Service

Automatically receive security updates.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Other security settings** for the following Security update service options:
   - **Security policy updates**: Automatically or manually check for security policy updates.
   - **Send security reports**: Send security reports to Samsung via Wi-Fi for threat analysis.

Device Administration

Manage your device administrators and application installation privileges.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Other security settings** > **Device administrators**.
3. Tap **Android Device Manager** to allow it to lock or erase a lost device.

Credential Storage

Manage your security certificates. If a certificate authority (CA) certificate gets compromised or for some other reason you do not trust it, you can disable or remove it.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Other security settings** for the following Credential storage options:
   - **Storage type**: Select a storage location for credential contents.
   - **View security certificates**: Display certificates in your device's ROM and other certificates you have installed.
   - **Install from phone storage**: Install a new certificate from storage.
   - **Clear credentials**: Erase the credential contents from the device and reset the password.

DRAFT
FOR INTERNAL USE ONLY

Advanced Security Settings

Use these options to configure advanced security settings.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Lock screen and security** > **Other security settings** for the following Advanced options:
   - **Trust agents**: View or disable trusted agents.
   - **Pin windows**: Pin an app on your device screen, preventing access to other features of you phone.
   - **Usage data access**: View the applications that can access your device's usage history.
   - **Notification access**: View the applications that can access notifications you receive on your phone.

Note: To view Trust agents, set up a screen lock (pin, password, or pattern). For more information, see Set a Screen Lock.

DRAFT
FOR INTERNAL USE ONLY

Privacy and Safety

Choose from various modes designed to hide personal content from being accessed by anyone else using your device, or to aid you in an emergency.

Note: A secure screen lock (Pattern, PIN, Fingerprint, or Password) is required to use Private Mode.

Location

Some apps, such as Google maps, may require one or more location services be turned on for full functionality.

Locating Method

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab > **Privacy and safety** > **Location**.
2. Tap **ON/OFF** to turn on Location services.
3. Tap **Locating method** to select how your location is determined:
   - **GPS, Wi-Fi, and mobile networks**: Use GPS, Wi-Fi, and mobile networks.
   - **Wi-Fi and mobile networks**: Use Wi-Fi and mobile networks (no GPS).
   - **GPS only**: Use GPS only.

Recent Location Requests

Apps that have requested your location are listed under Recent location requests.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab > **Privacy and safety** > **Location**.
2. Tap **ON/OFF** to turn on Location services.
3. Tap an entry under **Recent location requests** to view the app's settings.

Location Reporting

Google uses Location Reporting to store and use your device's most recent location data. Google apps, such as Google Maps, can use this data to improve your search results based on places that you have visited.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab > **Privacy and safety** > **Location**.
2. Tap **ON/OFF** to turn on Location services.
3. Tap **Google Location Reporting** for options:
   - **Location Reporting**: Allow Google apps to use your device's most recent location data.
   - **Location History**: Allow Google to store a history of your location data. Tap **DELETE LOCATION HISTORY** to permanently delete your location history.

Private Mode

Hide personal content from being accessed by anyone else using your device. Private mode is only available for certain applications.

Note: A secure screen lock (Pattern, PIN, Password, or Fingerprint) is required to use Private Mode.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Privacy and safety** > **Private mode**.
3. Follow the prompts to learn about and set up Private mode.

DRAFT
FOR INTERNAL USE ONLY

Report Diagnostic Info

This feature sends diagnostic information about your phone when you are having technical problems.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Privacy and safety**, and then tap the **ON/OFF** switch for **Report diagnostic info** to either enable or disable this feature.

Send SOS Messages

Send a quick alert to your primary contacts when you are in an emergency situation.

To enable this feature:

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Privacy and safety** > **Send SOS messages**.
3. Tap **ON/OFF** to turn the feature on and configure the following options:
   - **Send messages to**: Add recipients by creating new contacts or selecting from Contacts.
   - **Attach pictures**: Send photos taken with the front and back cameras to your emergency contacts.
   - **Attach audio recording**: Send a short audio message to your emergency contacts.

To send a help message:

► Press the **Power/Lock** key quickly three times.

DRAFT
FOR INTERNAL USE ONLY

Easy Mode

Switch between the default screen layout and a simpler layout. The Easy Mode layout has larger text and icons, making for a more straightforward visual experience.

To enable Easy Mode:

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab > **Easy mode**.
2. Tap **Easy mode** to enable this feature. When Easy mode is enabled, you can scroll down the page and select which apps you want to appear on the Home screens.
3. Tap the checkbox next to the apps you want to add or remove.
4. When finished, tap **DONE**.

DRAFT
FOR INTERNAL USE ONLY

Accessibility

Accessibility services are special features that make using the device easier for those with certain physical disabilities.

Note: You can download additional accessibility applications from the Google Play store.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Accessibility** for options:

Vision

- **Voice Assistant**: Speak feedback aloud to help blind and low-vision users.
  - Voice Assistant can collect all of the text you enter, except passwords, including personal data and credit card numbers. It may also log your user interface interactions with the device.
- **Voice Assistant help**: Tap for help on using Galaxy TalkBack.
- **Dark screen**: Keep the screen turned off at all times for privacy.
- **Rapid key input**: Release your finger to enter selection instead of double tapping.
- **Speak passwords**: Read the characters aloud as you enter your passwords.
- **Voice Label**: Write voice recordings to NFC tags to provide information about nearby objects.
- **Font size**: Set the font size.
- **Magnification gestures**: Use exaggerated gestures such as triple-tapping, double pinching, and dragging two fingers across the screen.
- **Magnifier window**: Magnify content shown on the screen.
- **Grayscale**: Change all colors to gray.
- **Negative colors**: Reverse the display of onscreen colors from White text on a Black background to Black text on a White background.
- **Color adjustment**: Adjust the color of the screen if you are color blind or have difficulty reading the display because of the screen color. Tap **Color adjustment** for options.
- **Accessibility shortcut**: Quickly enable accessibility features in two quick steps. Tap **ON/OFF** to turn the feature on.
- **Text-to-speech options**: Set your preferred TTS engine and options.

Hearing

- **Sound detectors**: Alert when baby crying or the doorbell is detected.
- **Flash notification**: Set your camera light to blink whenever you receive a notification.
- **Turn off all sounds**: For privacy, turn off all notifications and audio.
- **Hearing aids**: Improve the sound quality for use with hearing aids.
- **Samsung subtitles (CC)**: Use Samsung subtitles with multimedia files when available Tap Samsung subtitles (CC) for options.
- **Google subtitles (CC)**: Use Google subtitles with multimedia files when available. Tap Google subtitles (CC) for options.
- **Left/right sound balance**: Use the slider to set the Left and Right balance when using a stereo device.
- **Mono audio**: Switch audio from stereo to mono for use with one earphone.

DRAFT
FOR INTERNAL USE ONLY

- **Auto haptic**: The device will vibrate in time to the sound when listening to music, watching videos, or playing games. It will also vibrate when buttons are tapped in supported apps. This may consume battery power, and not all applications will support this feature.

Dexterity and Interaction

- **Universal switch**: Control your phone with your customized switches.
- **Assistant menu**: Improve the device accessibility for users with reduced dexterity.
- **Gesture wake up**: Wake up your device by waving your hand over the sensor.
- **Press and hold delay**: Select a time interval for this tap gesture.
- **Interaction control**: Block areas of the screen from touch interaction. Disable Auto rotate screen and hard key functions. Only show application notifications in the Notification Panel and the Status Bar.

More Settings

- **Direction lock**: Unlock the screen by swiping in a series of four to eight directions.
- **Direct access**: Open your accessibility settings by pressing the Home Key three times in quick succession.
- **Notification reminder**: Beep at set intervals to remind you of any unread notifications.
- **Answering and ending calls**: Select shortcuts for answering and ending calls.
- **Single tap mode**: Tap to stop/snooze alarms and calendar events.
- **Manage accessibility**: Export your accessibility settings and share them with another device.

Services

- **Keeper FastFill**: Enable this feature to securely and quickly auto-fill your login credentials on your websites and mobile apps. Simply tap the FastFill lock icon when logging in to a website or app.
- Additional accessibility apps may be downloaded from the Google Play store. Certain accessibility services you install may be configured here.

DRAFT
FOR INTERNAL USE ONLY

Accounts

Set up and manage accounts, including your Google Account, Samsung account, email, and social networking accounts.

Depending on the account, you can choose to synchronize your calendar, contacts, and other types of content.

Add an Account

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Accounts** > **Add account**.
3. Tap one of the account types.
4. Follow the prompts to enter your credentials and set up the account.

Synchronize Accounts

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Accounts** > **[Account type]**.
3. Tap an account to view the sync settings for that account.
4. Tap individual data items to sync.
5. Tap **MORE** > **Sync all** or **Sync now** to synchronize the account.

Note: Sync options and the location of the sync command differ depending on the account type.

Account Settings

Each account has its own set of settings. In addition, you can configure common settings for all accounts of the same type.

Note: Account settings and available features vary between account types and service providers. Contact your service provider for more information on your account's settings.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Accounts** > **[Account type]**.
   - Tap an account to configure that account's sync settings.
   - Tap other available options for the account.

Delete an Account

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Accounts** > **[Account type]**.
3. Tap the account and then tap **MORE** > **Remove account**.

DRAFT
FOR INTERNAL USE ONLY

Backup and Reset

Back up your data to Google servers. You can also reset your device to its factory defaults.

Backup and Restore

Enable backup of your information to Google servers.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Backup and reset** for options:
   - **Backup account**: Select a Google account to be used as your backup account.
   - **Back up my data**: Enable back up of application data, Wi-Fi passwords, and other settings to Google servers.
   - **Automatic restore**: Enable automatic restoration of settings from Google servers. When enabled, backed-up settings are restored when you reinstall an application.

Factory Data Reset

Return your device to its factory defaults.

Warning: This action permanently erases ALL data from the device, including Google or other account settings, system and application data and settings, downloaded applications, as well as your music, photos, videos, and other files.

1. From a Home screen, tap **Apps** > **Settings** > **PERSONAL** tab.
2. Tap **Backup and reset** > **Factory data reset**.
3. Tap **RESET DEVICE** and follow the prompts to perform the reset.

DRAFT
FOR INTERNAL USE ONLY

Language and Input Settings

Configure your device's language and input settings.

Set Your Default Language

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Language and input** > **Language**.
3. Select a language from the list.

Select Your Default Keyboard or Input Method

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Language and input** > **Default keyboard**.
3. Select a keyboard.

Note: Additional keyboards can be downloaded from the Google Play store.

Samsung Keyboard Settings

Configure options for using the Samsung keyboard.

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Language and input** > **Samsung keyboard** for options:
   - **English(US)**: Set the keyboard type: Qwerty keyboard or 3x4 keyboard.
   - **Select input languages**: Choose which languages are available on the keyboard. To switch between languages, slide the space bar sideways.
   - **Predictive text**: Allow Predictive text to suggest words matching your text entries, and, optionally, complete common words automatically. Predictive text can learn your personal writing style from your contacts, messages, Gmail, and social networking sites—improving its accuracy of predicting your text entries.
   - Additional keyboard settings provide assistance with capitalization, punctuation, and much more.

Swype Keyboard Settings

Configure options for using the Swype keyboard.

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Language and input** > **Swype** for options:
   - **Settings**: Configure basic options.
   - **Themes**: Change the keyboard layout.
   - **My Words**: Manage your personal dictionary, new word updates, as well as how Swype can learn from your writing style in various apps.
   - **Languages**: Set the current language. Additional languages can be downloaded.
   - **Gestures**: Learn about using Swype gestures.
   - **Help**: View information on using Swype.

DRAFT
FOR INTERNAL USE ONLY

Google Voice Typing Settings

Speak rather than type your text entries using Google Voice Typing.

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Language and input**.
3. Tap **Google voice typing** for options:
   - **Choose input languages**: Select languages for Google voice typing.
   - **Block offensive words**: Hide words many people find offensive are in results of Google voice searches. Offensive words are replaced in results with a placeholder (####).
   - **Offline speech recognition**: Manage downloaded languages.

Voice Input

Use Google voice recognition to perform Google searches using spoken commands.

To perform a voice search, tap in the Google search bar or widget. Or say "Ok Google" to launch a Google search (if the hotword detection option is enabled).

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Language and input** > **Voice input** for options.
3. Tap **Enhanced Google services** for full voice interaction or **Basic Google recognition** for simple voice recognition.
4. Tap **Settings** next to the selected option to configure its options.

Text-To-Speech Options

Configure your Text-To-Speech (TTS) options. TTS is used for various accessibility features, such as TalkBack. For more information, see Accessibility.

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Language and input** > **Text-to-speech options** for options:
   - Tap **Settings** next to the Samsung text-to speech engine for options.
   - **Speech rate**: Set the speed at which the text is spoken.
   - **Default language status**: Display the default language in use.

Mouse/Trackpad Settings

Configure settings for using an optional mouse or trackpad (not included).

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Language and input** > **Pointer speed**.
3. Drag the slider to the right to go faster or to the left to go slower.
4. Tap **OK** to save your setting.

DRAFT
FOR INTERNAL USE ONLY

Battery

View how battery power is used for device activities.

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Battery** for options:
   - **Power saving mode**: Tap **ON/OFF** to turn the feature on, and customize options.
   - **Ultra power saving mode**: Tap **ON/OFF** to turn the feature on.
   - **Display battery percentage**: Display the battery charge percentage next to the battery icon on the Status Bar.
   - **Battery Chart**: The battery level displays as a percentage. The amount of time the battery has been used also displays.
   - Tap **REFRESH** to update the listing.

Apps and System Usage

Battery usage displays in percentages per application and system process.

1. Tap an option to see how they are affecting battery use.
2. Tap **REFRESH** to update the listing.

Note: Other applications may be running that affect battery use.

DRAFT
FOR INTERNAL USE ONLY

Storage

View the device memory and usage.

Device Memory

View and manage the memory used by the device.

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Storage**.
   - The Device memory displays Total space.
   - The amounts of memory used are further divided into System memory, Used space, Cached data, Miscellaneous files, and Available space.

To increase available memory:

1. Tap **Cached data** to clear cached data for all apps. Tap **DELETE** to confirm.
2. Tap **Miscellaneous files**, select unnecessary files individually, or tap **SELECT ALL**, and then tap **DELETE**.

DRAFT
FOR INTERNAL USE ONLY

Date and Time Settings

By default, your device receives date and time information from the wireless network.

When you are outside network coverage, you may want to set date and time information manually using the date and time settings.

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Date and time**.
3. Set the date, time, time zone, time format, and date format.

DRAFT
FOR INTERNAL USE ONLY

Help

View tips and guidelines for using your device.

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **Help** for information about new features, applications, settings, and so on.

DRAFT
FOR INTERNAL USE ONLY

About Your Device

View information about your device, including status, legal information, hardware and software versions, and a tutorial.

1. From a Home screen, tap **Apps** > **Settings** > **SYSTEM** tab.
2. Tap **About device**, and then tap items for more details:
   - **Software update**: Check for and install available software updates.
   - **Status**: View the status of the battery, network, and other information about your device.
   - **Legal information**: View legal notices and other legal information.
   - **Device name**: View and change your device's name.
   - Additional device information includes the Model number, Android version, Build number, and more.

Software Updates

Use Software update to update your device's software.

1. From a Home screen, tap **Apps** > **Settings**.
2. Tap **About DEVICE** tab > **Software update**.
3. Follow the prompts to check for available software updates to download and install.

DRAFT
FOR INTERNAL USE ONLY